



## Firgelli\_LAC\_LabVIEW.vi

Interactive program that allows control and display of linear actuator parameters. Portions of this example can be copied and pasted into your application following this example.

Written by: Complete Automated Solutions  
www.CompleteAutomatedSolutions.com

April 18, 2011

Firgelli  
LAC  
Example



Firgelli  
Position  
Read

## readPositionFirgelli.vi

C:\Documents and Settings\Matt\My Documents\CAScontracts\_11\Firgelli\code\LAC\LAC\_SampleCode\_LabVIEW\support\VI\read PositionFirgelli.vi

**writeLimitsFirgelli.vi**

C:\Documents and Settings\Matt\My Documents\CAScontracts\_11\Firgelli\code\LAC\LAC\_SampleCode\_LabVIEW\supportVIs\writeLimitsFirgelli.vi

**writeAccuracyFirgelli.vi**

C:\Documents and Settings\Matt\My Documents\CAScontracts\_11\Firgelli\code\LAC\LAC\_SampleCode\_LabVIEW\supportVIs\writeAccuracyFirgelli.vi

**writeVelocityFirgelli.vi**

C:\Documents and Settings\Matt\My Documents\CAScontracts\_11\Firgelli\code\LAC\LAC\_SampleCode\_LabVIEW\supportVIs\writeVelocityFirgelli.vi

**MPUSBRead.vi**

C:\Documents and Settings\Matt\My Documents\CAScontracts\_11\Firgelli\code\LAC\LAC\_SampleCode\_LabVIEW\USB\_VIs\MPUSBRead.vi

**writePositionFirgelli.vi**

C:\Documents and Settings\Matt\My Documents\CAScontracts\_11\Firgelli\code\LAC\LAC\_SampleCode\_LabVIEW\supportVIs\writePositionFirgelli.vi

**actuatorSelect.vi**

C:\Documents and Settings\Matt\My Documents\CAScontracts\_11\Firgelli\code\LAC\LAC\_SampleCode\_LabVIEW\supportVIs\actuatorSelect.vi

**MPUSBClose.vi**

C:\Documents and Settings\Matt\My Documents\CAScontracts\_11\Firgelli\code\LAC\LAC\_SampleCode\_LabVIEW\USB\_VIs\MPUSBClose.vi

**MPUSBOpen.vi**

C:\Documents and Settings\Matt\My Documents\CAScontracts\_11\Firgelli\code\LAC\LAC\_SampleCode\_LabVIEW\USB\_VIs\MPUSBOpen.vi

**MPUSBGetDLLVersion.vi**

C:\Documents and Settings\Matt\My Documents\CAScontracts\_11\Firgelli\code\LAC\LAC\_SampleCode\_LabVIEW\USB\_VIs\MPUSBGetDLLVersion.vi

**General Error Handler.vi**

C:\Program Files\National Instruments\LabVIEW 2010\vi.lib\Utility\error.lib\General Error Handler.vi

**MPUSBGetDeviceCount.vi**


C:\Documents and Settings\Matt\My Documents\CAScontracts\_11\Firgelli\code\LAC\LAC\_SampleCode\_LabVIEW\USB\_VIs\MPUSBGetDeviceCount.vi

**controlValues.cti**

C:\Documents and Settings\Matt\My

"Firgelli\_LAC\_LabVIEW.vi History"  
Current Revision: 13  
rev. 0 Mon, Apr 18, 2011 8:25:52 AM Matt  
Written by: Complete Automated Solutions  
www.CompleteAutomatedSolutions.com

### convertReadResponse.vi



**U8** **rawDataIn** Points to the buffer that receives the data read from the pipe.

**U8**

**TF** **error in (no error)** **error in** can accept error information wired from VIs previously called. Use this information to decide if any functionality should be bypassed in the event of errors from other VIs.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**TF** **status status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **code code** is the error or warning code.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **source source** describes the origin of the error or warning.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **rawDataOut** Points to the buffer that receives the data read from the pipe.



 **cmd** The LAC command

 **setValue** The LAC set point for position

 **error out error out** passes error or warning information out of a VI to be used by other VIs.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **status status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.


 **code code** is the error or warning code.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **source source** string describes the origin of the error or warning.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

Convert the pData read response to an actual position



error in (no error)



error out



"convertReadResponse.vi History"

Current Revision: 1

rev. 0 Mon, Apr 18, 2011 8:31:32 AM Matt

Written by: Complete Automated Solutions


www.CompleteAutomatedSolutions.com

### MPUSBGetDeviceCount.vi

Returns count of devices found

Written by: Complete Automated Solutions

www.CompleteAutomatedSolutions.com



**pVID\_PID** A string containing the PID&VID value of the target device. The format is "vid\_xxxx&pid\_yyyy". Where xxxx is the VID value in hex and yyyy is the PID value in hex.

Example: If a device has the VID value of 0x04d8 and PID value of 0x000b, then the input string should be: "vid\_04d8&pid\_000b"



**error in (no error) error in** can accept error information wired from VIs previously called. Use this information to decide if any functionality should be bypassed in the event of errors from other VIs.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.



**status status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate

a warning or that no error occurred.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **code code** is the error or warning code.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **source source** describes the origin of the error or warning.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **return\_value**

 **error out error in** can accept error information wired from VIs previously called. Use this information to decide if any functionality should be bypassed in the event of errors from other VIs.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **status status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.


Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **code code** is the error or warning code.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **source source** describes the origin of the error or warning.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.



"MPUSBGetDeviceCount.vi History"  
Current Revision: 1  
rev. 0 Mon, Apr 18, 2011 8:28:21 AM Matt  
Written by: Complete Automated Solutions  
www.CompleteAutomatedSolutions.com

### MPUSBRead.vi


```
// Note that "input" and "output" refer to the parameter designations in calls  
// to this function, which are the opposite of common sense from the  
// perspective of an application making the calls.  
//
```

```

DWORD MPUSBRead(HANDLE handle,      // Input
                PVOID pData,        // Output
                DWORD dwLen,        // Input
                PDWORD pLength,     // Output
                DWORD dwMilliseconds); // Input

```

Written by: Complete Automated Solutions  
[www.CompleteAutomatedSolutions.com](http://www.CompleteAutomatedSolutions.com)



- U32** **handleIn** Identifies the endpoint pipe to be read. The pipe handle must have been created with MP\_READ access attribute.
- U32** **dwLen** Specifies the number of bytes to be read from the pipe.
- U32** **dwMilliseconds** Specifies the time-out interval, in milliseconds. The function returns if the interval elapses, even if the operation is incomplete. If dwMilliseconds is zero, the function tests the data pipe and returns immediately. If dwMilliseconds is INFINITE, the function's time-out interval never elapses.
- U32** **pLength** Points to the number of bytes written by this function call. MPUSBWrite sets this value to zero before doing any work or error checking.
- Err** **error in (no error) error in** can accept error information wired from VIs previously called.

Use this information to decide if any functionality should be bypassed in the event of errors from other VIs.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **status status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **code code** is the error or warning code.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **source source** describes the origin of the error or warning.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **maxLength** The maximum length of the actuator

 **return type**

 **pDataOut** Points to the buffer that receives the data read from the pipe.



 **handleOut** Identifies the endpoint pipe to be read. The pipe handle must have been created with MP\_READ access attribute.

 **error out error out** passes error or warning information out of a VI to be used by other VIs.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **status status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **code code** is the error or warning code.


Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **source source** string describes the origin of the error or warning.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **cmd**

**setValue** The register set value (0-1023)



**convertPositionResponse.vi**

C:\Documents and Settings\Matt\My Documents\CAScontracts\_11\Firgelli\code\LAC\LAC\_SampleCode\_LabVIEW\supportVIs\convertPositionResponse.vi

"MPUSBRead.vi History"


Current Revision: 1  
 rev. 0 Mon, Apr 18, 2011 8:26:46 AM Matt  
 Written by: Complete Automated Solutions  
 www.CompleteAutomatedSolutions.com

**writeLimitsFirgelli.vi**

0x02 SET\_RETRACT\_LIMIT and 0x03 SET\_EXTEND\_LIMIT

These are the values that are set with the Limits Potentiometers. Setting the Extend\_Limit to 1023 and the Retract\_Limit to zero will allow movement over the full range. However, it is recommended to offset these values to ensure the actuator is never driven into the physical end stops. This increases cycle life considerably. To set the desired limits take the distance (mm) from the physical stop you wish to limit the actuator to, and plug it into the following equation.

Written by: Complete Automated Solutions  
 www.CompleteAutomatedSolutions.com





**PT** **error in (no error)** **error in** can accept error information wired from VIs previously called. Use this information to decide if any functionality should be bypassed in the event of errors from other VIs.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**TF** **status** **status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**I32** **code** **code** is the error or warning code.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**abc** **source** **source** describes the origin of the error or warning.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**U32** **handleIn** Identifies the endpoint pipe to be read. The pipe handle must have been created with MP\_READ access attribute.

**limit** The value to set the limit

**select** Select Retract or Extend

**maxLength** The value to set the limit

**error out** **error out** passes error or warning information out of a VI to be used by other VIs.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**status** **status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**code** **code** is the error or warning code.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**source** **source** string describes the origin of the error or warning.


Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**handleOut** Identifies the endpoint pipe to be read. The pipe handle must have been created with MP\_READ access attribute.

**pDataOut** Points to the buffer that receives the data read from the pipe.

**U8**

**regSetting** The current register LAC setting





### MPUSBWrite.vi

C:\Documents and Settings\Matt\My Documents\CAScontracts\_11\Firgelli\code\LAC\LAC\_SampleCode\_LabVIEW\USB\_VIs\MPUSBWrite.vi

"writeLimitsFirgelli.vi History"

Current Revision: 2

rev. 0 Mon, Apr 18, 2011 8:30:43 AM Matt

Written by: Complete Automated Solutions

www.CompleteAutomatedSolutions.com



### readPositionFirgelli.vi

(Distance / Stroke) × 1023

For example, to half way extend(25mm) a 50mm actuator, send 512. (The calculated value is rounded to a whole number).

Written by: Complete Automated Solutions

www.CompleteAutomatedSolutions.com



**error in (no error)** error in can accept error information wired from VIs previously called. Use this information to decide if any functionality should be bypassed in the event of errors from other VIs.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.



**status status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.



**code code** is the error or warning code.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.



**source source** describes the origin of the error or warning.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.



**handleIn** Identifies the endpoint pipe to be read. The pipe handle must have been created with MP\_READ access attribute.



**error out error out** passes error or warning information out of a VI to be used by other VIs.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.



**status status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.



**code code** is the error or warning code.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.



**source source** string describes the origin of the error or warning.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.




**handleOut** Identifies the endpoint pipe to be read. The pipe handle must have been created with MP\_READ access attribute.



**pDataOut** Points to the buffer that receives the data read from the pipe.







**U32** Devices

**E** **error in (no error) error in** can accept error information wired from VIs previously called. Use this information to decide if any functionality should be bypassed in the event of errors from other VIs.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**TF** **status status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**I32** **code code** is the error or warning code.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**abc** **source source** describes the origin of the error or warning.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **Selected**

 **error out error in** can accept error information wired from VIs previously called. Use this information to decide if any functionality should be bypassed in the event of errors from other VIs.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **status status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.


Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **code code** is the error or warning code.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **source source** describes the origin of the error or warning.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.




"actuatorSelect.vi History"  
Current Revision: 1  
rev. 0 Mon, Apr 18, 2011 8:32:11 AM Matt  
Written by: Complete Automated Solutions  
www.CompleteAutomatedSolutions.com

### writeAccuracyFirgelli.vi

0x01 SET\_ACCURACY:

This is the value controlled by the Accuracy Potentiometer. A value between 0-1023 is accepted. When the feedback position is plus or minus this value, the actuator will stop moving. Reducing this too far will result in the actuator continuously moving back and forth, never reaching the set point. The default value is four. To find the equivalent distance, use the formula:

Written by: Complete Automated Solutions  
www.CompleteAutomatedSolutions.com



**Set** **error in (no error)** **error in** can accept error information wired from VIs previously called. Use this information to decide if any functionality should be bypassed in the event of errors from other VIs.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**TF** **status status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**I32** **code code** is the error or warning code.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**abc** **source source** describes the origin of the error or warning.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**U32** **handleIn** Identifies the endpoint pipe to be read. The pipe handle must have been created with MP\_READ access attribute.

 **accuracy** The accuracy LAC setting

 **maxLength**

 **error out error out** passes error or warning information out of a VI to be used by other VIs.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **status status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **code code** is the error or warning code.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **source source** string describes the origin of the error or warning.


Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **handleOut** Identifies the endpoint pipe to be read. The pipe handle must have been created with MP\_READ access attribute.

 **pDataOut** Points to the buffer that receives the data read from the pipe.



 **regSetting** The current LAC register value



(accuracy / stroke) \* 1024 = register setting



**MPUSBWrite.vi**

C:\Documents and Settings\Matt\My Documents\CAScontracts\_11\Firgelli\code\LAC\LAC\_SampleCode\_LabVIEW\USB\_VIs\MPUSBWrite.vi

"writeAccuracyFirgelli.vi History"

Current Revision: 3  
 rev. 0 Mon, Apr 18, 2011 8:30:57 AM Matt  
 Written by: Complete Automated Solutions  
 www.CompleteAutomatedSolutions.com


**MPUSBWrite.vi**

// Note that "input" and "output" refer to the parameter designations in calls  
 // to this function, which are the opposite of common sense from the  
 // perspective of an application making the calls.  
 //

```

DWORD MPUSBWrite(HANDLE handle,      // Input
                 PVOID pData,        // Input
                 DWORD dwLen,        // Input
                 PDWORD pLength,     // Output
                 DWORD dwMilliseconds); // Input
  
```

Written by: Complete Automated Solutions  
 www.CompleteAutomatedSolutions.com



The screenshot shows a LabVIEW front panel control for a pipe read operation. It features several input fields and status indicators:

- pLength (out)**: A numeric control set to 0.
- handleIn**: A numeric control set to 0.
- dwLen**: A numeric control set to 0.
- pDataIn**: A numeric control set to 0.
- error in (no error)**: A status code control set to 0 with a green checkmark icon, and a source dropdown menu.
- handleOut**: A numeric control set to 0.
- return type**: A numeric control set to 0.
- pDataOut**: A numeric control set to 0.
- error out**: A status code control set to 0 with a green checkmark icon, and a source dropdown menu.
- dwMilliseconds**: A numeric control set to 1000.

**[U32]** **handleIn** Identifies the endpoint pipe to be read. The pipe handle must have been created with MP\_READ access attribute.

**[U32]** **dwLen** Specifies the number of bytes to be read from the pipe.

**[U32]** **dwMilliseconds** Specifies the time-out interval, in milliseconds. The function returns if the interval elapses, even if the operation is incomplete. If dwMilliseconds is zero, the function tests the data pipe and returns immediately. If dwMilliseconds is INFINITE, the function's time-out interval never elapses.

**[U8]** **pDataIn** Points to the buffer that receives the data read from the pipe.

**[U8]**

**[TF]** **error in (no error)** **error in** can accept error information wired from VIs previously called. Use this information to decide if any functionality should be bypassed in the event of errors from other VIs.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**[TF]** **status** **status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**[I32]** **code** **code** is the error or warning code.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **source source** describes the origin of the error or warning.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **return type**

 **pLength (out)** Points to the number of bytes written by this function call. MPUSBWrite sets this value to zero before doing any work or error checking.

 **pDataOut** Points to the buffer that receives the data read from the pipe.



 **error out error out** passes error or warning information out of a VI to be used by other VIs.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **status status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.


 **code code** is the error or warning code.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **source source** string describes the origin of the error or warning.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **handleOut** Identifies the endpoint pipe to be read. The pipe handle must have been created with MP\_READ access attribute.



**"MPUSBWrite.vi History"**


Current Revision: 1  
 rev. 0 Mon, Apr 18, 2011 8:29:03 AM Matt  
 Written by: Complete Automated Solutions  
 www.CompleteAutomatedSolutions.com


**writeVelocityFirgelli.vi**

0x0A SET\_MAX\_PWM\_VALUE

This is the value that is manually controlled by the speed potentiometer. This is the speed that the actuator runs at when outside the PWM\_THRESHOLD. Setting this to 1023 will allow the actuator to achieve full speed. The actuator may exceed this value while attempting to overcome a stall condition.

Written by: Complete Automated Solutions  
 www.CompleteAutomatedSolutions.com





**DBL** **Velocity** Sets the current velocity to the LAC

**ERR** **error in (no error)** **error in** can accept error information wired from VIs previously called. Use this information to decide if any functionality should be bypassed in the event of errors from other VIs.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**TF** **status** **status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**I32** **code** **code** is the error or warning code.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**abc** **source** **source** describes the origin of the error or warning.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**U32** **handleIn** Identifies the endpoint pipe to be read. The pipe handle must have been created with MP\_READ access attribute.

**ERR** **error out** **error out** passes error or warning information out of a VI to be used by other

Vis.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **status status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **code code** is the error or warning code.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **source source** string describes the origin of the error or warning.


Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **handleOut** Identifies the endpoint pipe to be read. The pipe handle must have been created with MP\_READ access attribute.

 **pDataOut** Points to the buffer that receives the data read from the pipe.



 **regSetting** The current LAC register setting




 **MPUSBWrite.vi**  
C:\Documents and Settings\Matt\My Documents\CAScontracts\_11\Firgelli\code\LAC\LAC\_SampleCode\_LabVIEW\USB\_VIs\MPUSBWrite.vi

"writeVelocityFirgelli.vi History"  
Current Revision: 1  
rev. 0 Mon, Apr 18, 2011 8:32:36 AM Matt  
Written by: Complete Automated Solutions  
www.CompleteAutomatedSolutions.com

**MPUSBClose.vi**

```
// MPUSBClose : closes a given handle.
//
// Note that "input" and "output" refer to the parameter designations in calls
// to this function, which are the opposite of common sense from the
// perspective of an application making the calls.
```

Written by: Complete Automated Solutions  
www.CompleteAutomatedSolutions.com



**U32** **handle** Identifies the endpoint pipe to be read. The pipe handle must have been created with MP\_READ access attribute.

**Err** **error in (no error)** **error in** can accept error information wired from VIs previously called. Use this information to decide if any functionality should be bypassed in the event of errors from other VIs.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**TF** **status** **status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**I32** **code** **code** is the error or warning code.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**abc** **source** **source** describes the origin of the error or warning.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**I32** **return type**



**error out** passes error or warning information out of a VI to be used by other VIs.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.



**status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.




**code** is the error or warning code.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.



**source** string describes the origin of the error or warning.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.



"MPUSBClose.vi History"

Current Revision: 1

rev. 0 Mon, Apr 18, 2011 8:28:52 AM Matt

Written by: Complete Automated Solutions

www.CompleteAutomatedSolutions.com

### MPUSBOpen.vi

// MPUSBOpen : Returns the handle to the endpoint pipe with matching VID & PID

//

// All pipes are opened with the FILE\_FLAG\_OVERLAPPED attribute.


// This allows MPUSBRead,MPUSBWrite, and MPUSBReadInt to have a time-out value.

//

// Note: Time-out value has no meaning for Isochronous pipes.

Written by: Complete Automated Solutions

www.CompleteAutomatedSolutions.com



The screenshot shows a configuration window with the following fields and values:

- instance:** 0
- pVID\_PID:** vid\_04d8&pid\_0
- pEP:** \\MCHP\_EP1
- dwDir:** Write
- instanceOut:** 0
- error in (no error) status code:** 0
- error in (no error) source:** no error
- error out status code:** 0
- error out source:** no error
- dwReserved:** 0

**U32** **instance** An instance number of the device to open.  
 Typical usage is to call MPUSBGetDeviceCount first to find out how many instances there are. It is important to understand that the driver is shared among different devices. The number of devices returned by MPUSBGetDeviceCount could be equal to or less than the number of all the devices that are currently connected & using the generic driver.

**abc** **pVID\_PID** A string containing the PID&VID value of the target device. The format is "vid\_xxxx&pid\_yyyy". Where xxxx is the VID value in hex and yyyy is the PID value in hex.  
 Example: If a device has the VID value of 0x04d8 and PID value of 0x000b, then the input string should be: "vid\_04d8&pid\_000b"

**abc** **pEP** A string of the endpoint number on the target endpoint to open. The format is "\\MCHP\_EPz". Where z is the endpoint number in decimal.  
 Example: "\\MCHP\_EP1"  
 This argument can be NULL. A NULL value should be used to create a handles for non-specific endpoint functions.  
 MPUSBRead, MPUSBWrite, MPUSBReadInt are endpoint specific functions. All others are not. Non-specific endpoint functions will become available in the next release of the DLL.

**dir** **dwDir** Specifies the direction of the endpoint.  
 Use MP\_READ for MPUSBRead, MPSUBReadInt  
 Use MP\_WRITE for MPUSBWrite

**U32** **dwReserved** Specifies the direction of the endpoint.  
 Use MP\_READ for MPUSBRead, MPSUBReadInt  
 Use MP\_WRITE for MPUSBWrite

**err** **error in (no error) error out** can accept error information wired from VIs previously called.  
 Use this information to decide if any functionality should be bypassed in the event of

errors from other VIs.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.



**status status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.



**code code** is the error or warning code.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.



**source source** describes the origin of the error or warning.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.



**HANDLE** Identifies the endpoint pipe to be read. The pipe handle must have been created with MP\_READ access attribute.



**error out error in** can accept error information wired from VIs previously called. Use this information to decide if any functionality should be bypassed in the event of errors from other VIs.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.



**status status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.



**code code** is the error or warning code.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.




**source source** describes the origin of the error or warning.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.



**instanceOut** An instance number of the device to open.

Typical usage is to call MPUSBGetDeviceCount first to find out how many instances there are. It is important to understand that the driver is shared among different devices. The number of devices returned by MPUSBGetDeviceCount could be equal to or less than the number of all the devices that are currently connected & using the generic driver.



"MPUSBOpen.vi History"

Current Revision: 0

rev. 0 Mon, Apr 18, 2011 8:27:21 AM Matt

Written by: Complete Automated Solutions

www.CompleteAutomatedSolutions.com

### writePositionFirgelli.vi


0x20 SET\_POSITION


This command allows USB control and disables RC, I, and V inputs until the system is rebooted. The data sent with this command determines what position the actuator moves too.

For example, to half way extend(25mm) a 50mm actuator, send 512. (The calculated value is rounded to a whole number).

Written by: Complete Automated Solutions

www.CompleteAutomatedSolutions.com





**Err** **error in (no error)** error in can accept error information wired from VIs previously called. Use this information to decide if any functionality should be bypassed in the event of errors from other VIs.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**TF** **status** status is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**I32** **code** code is the error or warning code.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**abc** **source** source describes the origin of the error or warning.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**U32** **handleIn** Identifies the endpoint pipe to be read. The pipe handle must have been created with MP\_READ access attribute.

**DBL** **lengthMax** The maximum length of the actuator

**DBL** **Position (mm)** Position to set the actuator



**error out** passes error or warning information out of a VI to be used by other VIs.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.



**status status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.



**code code** is the error or warning code.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.



**source source** string describes the origin of the error or warning.


Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.



**handleOut** Identifies the endpoint pipe to be read. The pipe handle must have been created with MP\_READ access attribute.



**regSetting** The current LAC register setting



### MPUSBWrite.vi

C:\Documents and Settings\Matt\My Documents\CAScontracts\_11\Firgelli\code\LAC\LAC\_SampleCode\_LabVIEW\USB\_VIs\MPUSBWrite.vi

### "writePositionFirgelli.vi History"

Current Revision: 2  
 rev. 0 Mon, Apr 18, 2011 8:30:12 AM Matt  
 Written by: Complete Automated Solutions  
 www.CompleteAutomatedSolutions.com


### convertPositionResponse.vi

Scale actuator value to millimeters

(Distance / Stroke) × 1023

Format: 3-byte packet  
 Control, Data Low, Data High  
 Buffer[0]=Control  
 Buffer[1]=Data Low  
 Buffer[2]=Data High

Written by: Complete Automated Solutions  
[www.CompleteAutomatedSolutions.com](http://www.CompleteAutomatedSolutions.com)



**DBL** **maxLength** Teh actuators maximum length

**U8** **pData** Points to the buffer that receives the data read from the pipe.

**U8**

**Err** **error in (no error) error in** can accept error information wired from VIs previously called. Use this information to decide if any functionality should be bypassed in the event of errors from other VIs.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**TF**

**status status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**I32**

**code code** is the error or warning code.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **source source** describes the origin of the error or warning.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **position** The position of the actuator

 **rawDataOut** Points to the buffer that receives the data read from the pipe.



 **cmd** Teh current LAC command

 **error out error out** passes error or warning information out of a VI to be used by other VIs.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **status status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.


 **code code** is the error or warning code.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

 **source source** string describes the origin of the error or warning.

Right-click the **error out** indicator on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

Convert the pData read response to an actual position



Scale actuator value to millimeters



**convertReadResponse.vi**

C:\Documents and Settings\Matt\My

Documents\CAScontracts\_11\Firgelli\code\LAC\LAC\_SampleCode\_LabVIEW\supportVIs


\convertReadResponse.vi

"convertPositionResponse.vi History"  
Current Revision: 1  
rev. 0 Mon, Apr 18, 2011 8:31:59 AM Matt  
Written by: Complete Automated Solutions  
www.CompleteAutomatedSolutions.com

### MPUSBGetDLLVersion.vi

```
// MPUSBGetDLLVersion : get mpusbapi.dll revision level
//
// Input:
//     None
// Output:
//     32-bit revision level MMmmdii
//     MM - Major release
//     mm - Minor release
//     dd - dot release or minor fix
//     ii - test release revisions
```

Written by: Complete Automated Solutions  
www.CompleteAutomatedSolutions.com



**ETI** **error in (no error) error in** can accept error information wired from VIs previously called. Use this information to decide if any functionality should be bypassed in the event of errors from other VIs.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**TF** **status status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**I32** **code code** is the error or warning code.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**abc** **source source** describes the origin of the error or warning.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**U32** **return type**

**error out error in** can accept error information wired from VIs previously called. Use this information to decide if any functionality should be bypassed in the event of errors from other VIs.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**TF** **status status** is TRUE (X) if an error occurred or FALSE (checkmark) to indicate a warning or that no error occurred.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.


**I32** **code code** is the error or warning code.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**abc** **source source** describes the origin of the error or warning.

Right-click the **error in** control on the front panel and select **Explain Error** or **Explain Warning** from the shortcut menu for more information about the error.

**abc** **DLLver**



"MPUSBGetDLLVersion.vi History"

Current Revision: 1

rev. 0 Mon, Apr 18, 2011 8:27:33 AM Matt

Written by: Complete Automated Solutions

www.CompleteAutomatedSolutions.com

**controlValues.ctl**

Written by: Complete Automated Solutions  
www.CompleteAutomatedSolutions.com



Control Values	
<b>Position</b>	<b>Retract Limit</b>
<input type="text" value="0"/>	<input type="text" value="0"/>
<b>Velocity</b>	<b>Extend Limit</b>
<input type="text" value="0"/>	<input type="text" value="0"/>
<b>Accuracy</b>	
<input type="text" value="0"/>	

"controlValues.ctl History"

Current Revision: 2  
rev. 0 Mon, Apr 18, 2011 8:29:46 AM Matt  
Written by: Complete Automated Solutions  
www.CompleteAutomatedSolutions.com