



## Instructions for **BEHRINGER BCR2000 & PROPELLERHEAD® REASON Dr. Rex**

### BEHRINGER BCR2000 REASON Dr. Rex

This document will give you a quick overview about the BEHRINGER BCR2000 'REASON DR. REX' PRESET and how to install it.

Please consider this preset merely as a starting point and as inspiration for your own imagination.

#### Installation:

##### 1. Open and extract the ZIP file.

The following files are included:

- This INSTRUCTION text document (.pdf)
- SINGLE PRESET file (.syx)

##### 2. How to get the **B-CONTROL PRESET** from your computer into your hardware:

- **Connect the B-CONTROL to your computer** via USB or MIDI port (Computer MIDI OUT to B-Control MIDI IN)
- **Select the correct USB or stand alone operating mode** on the hardware (please refer to the manual for details)
- **Open the B-CONTROL preset file of your choice with a MIDI dump program** like "MIDI-OX" or "Send-SX" on your computer or use the B-CONTROL EDIT software editor, which is available free of charge at our homepage [www.behringer.com](http://www.behringer.com)
- Don't forget to **select the correct MIDI ports** in the dump software!


## Dumping a single preset

1. **Select the desired preset** (e.g. 'bcr\_Reason\_Dr\_Rex.syx') on your MIDI dump program
2. **Send the preset** to the B-CONTROL and wait until completion
3. **Push the STORE** button on the hardware
4. **Select the desired destination** preset number
5. **Push the STORE** button again
6. **The preset is now saved** on your hardware
7. Now you can dump the next preset (repeat the steps 1 thru 5 again)

**Hint:** If you do not want to overwrite one of your presets in the B-CONTROL hardware, select a free destination number at step 4 (e.g. preset 'P-32').

## Detailed Documentation

#	Name	Type	Description/Application
07	'bcr_Reason_Dr_Rex'	Single Preset	Basic Setup for controlling Propellerhead®'s REASON 'Dr. Rex' * [loop player]



- E1 – Encoder Group 1 (Mod. Wheel + Velocity)
- E2 – Encoder Group 2 (-)
- E3 – Encoder Group 3 (-)
- E4 – Encoder Group 4 (-)
- UB – Upper Button Line (-)
- LB – Lower Button Line (LFO- + Filter-Switches)
- UE – Upper Encoder Line (Osc. Pitch)
- ME – Middle Encoder Line (Filter + Filter Env.)
- LE – Lower Encoder Line (LFO + Amp Env.)

\* Software depicted is **not** included and all rights therein belong to its respective owners. Screenshots used with owner's kind permission. PROPELLERHEAD® Reason and its respective logos are registered trademarks of their respective owners. Their use neither constitutes a claim of the trademarks by BEHRINGER® nor affiliation of the trademark owners with BEHRINGER®.

© 2004 BEHRINGER Spezielle Studiotechnik GmbH