

electribe sampler Ver 2.02 Release Note

Changes in Ver 2.02 from Ver 1.16

Added Functions

- Added a Chain function that plays multiple patterns in succession.

The pattern parameters "CHAIN TO" and "CHAIN REPEAT" and the global parameter "CHAIN MODE" have been added.

For details, refer to the latest version of the "electribe sampler Parameter Guide."

Immediately after the software update, the settings will be as follows.

Pattern parameters		Global parameters	
CHAIN TO	"Off"	CHAIN MODE	"Off"
CHAIN REPEAT	"1"		

- Added an UNDO function.

We have added an UNDO function that cancels the previous operation, such as parameter edit, sequence recording, or Erase.

To execute UNDO, hold down the shift button and press the < button.

- Added an "Original Value" function that indicates the saved value of the parameters.
- Reduced the time required to load samples when the memory card contains an exported "e2sSample.all" file at startup.
- Reduced the time required to export all samples when using the DATA UTILITY "EXPORT ALL SAMPLE" function.
- A few minor bugs have been fixed.

Updating the software

- ⚠ If you are using electribe version 1.15 software or earlier, update to version 1.16, and then update to 2.02.

What you will need

- Memory card supported by electribe
- Computer with memory card adapter
- AC adapter KA350 or six AA batteries



- ⚠ Make sure the batteries are brand new if using alkaline or fully charged if using NiMH batteries.

Updating the software

1. Prepare a memory card that has been formatted by electribe sampler.
2. Insert the memory card into your card reader, and connect it to your computer.
3. Copy "SYSTEM.VSB" into the [System] folder under the [KORG][electribe sampler] folder on the memory card.
4. Insert the memory card containing the new system file into your electribe sampler, and turn on the power.

- ⚠ Do not insert or remove a memory card while the power is still on. Doing so may cause the update to fail.

5. Select "SOFTWARE UPDATE" from the DATA UTILITY menu.



6. Press Menu/Enter. Current version and new version will appear. Press Menu/Enter button.



7. A confirmation message will appear. Press Menu/Enter button to begin the update operation.



- ⚠ Do not turn off electribe sampler while update is in progress.

8. electribe sampler will display the following screen when update is complete.



9. Long push the power button. electribe sampler will now turn off. The system has been updated.

KORG INC.

4015-2 Yanokuchi, Inagi-City, Tokyo 206-0812 JAPAN

©2016 KORG INC.

www.korg.com