



# Voice Name List

## Table of Contents

<b>Combination</b> .....	<b>2</b>	<b>GM Drum Kit</b> .....	<b>76</b>
Bank A. ....	2	48 (GM): STANDARD .....	76
Bank B. ....	3	49 (GM): ROOM .....	77
Bank C. ....	4	50 (GM): POWER. ....	78
<b>Program</b> .....	<b>6</b>	51 (GM): ELECTRONIC .....	79
Bank A. ....	6	52 (GM): ANALOG .....	80
Bank B. ....	7	53 (GM): JAZZ .....	81
Bank C. ....	8	54 (GM): BRUSH .....	82
Bank D .....	9	55 (GM): ORCHESTRA .....	83
Bank E. ....	10	56 (GM): SFX .....	84
Bank G / g(1)...g(9) / g(d). ....	11	<b>Drum Track Patterns/Preset Patterns.</b> .....	<b>86</b>
<b>Drum Kit</b> .....	<b>14</b>	<b>Template song</b> .....	<b>88</b>
00 (INT): Studio Standard Kit. ....	14	<b>Preset Arpeggio Patterns/User Arpeggio Patterns</b> ..	<b>90</b>
01 (INT): Funk Kit .....	16	<b>Multisample.</b> .....	<b>94</b>
02 (INT): Jazz/Brush Kit .....	18	ROM mono .....	94
03 (INT): B.Real Rap Kit .....	20	ROM stereo .....	97
04 (INT): Acoustic Pop Kit. ....	22	<b>Drumsample</b> .....	<b>98</b>
05 (INT): Wild Rock Kit. ....	24	ROM mono .....	98
06 (INT): New Processed Kit. ....	26	ROM stereo .....	103
07 (INT): Electro Rock Kit .....	28	<b>Demo Song</b> .....	<b>104</b>
08 (INT): Insane FX Kit .....	30	S000 .....	104
09 (INT): Nu Style Kit .....	32	S001 .....	104
10 (INT): Hip Hop Kit .....	34	S002 .....	104
11 (INT): Tricki kit. ....	36	S003 .....	104
12 (INT): Mashed Kit. ....	38	Cue List .....	104
13 (INT): Drum'n'Bass Kit .....	40		
14 (INT): House Kit .....	42		
15 (INT): Trance Kit .....	44		
16 (INT): Hard House Kit .....	46		
17 (INT): Psycho-Chill Kit .....	48		
18 (INT): Down Low Rap Kit. ....	50		
19 (INT): Orch.-Ethnic Kit .....	52		
20 (INT): Original Perc .....	54		
21 (INT): Brazilian Perc. ....	56		
22 (INT): Cuban Perc .....	58		
23 (INT): Conga Variation Kit. ....	60		
24 (INT): Misc. Perc .....	62		
25 (INT): Vinyl Loop Kit .....	64		
26 (INT): DJ-BeatBox Kit .....	66		
27 (INT): Rap-Gospel Kit .....	67		
28 (INT): Industry-Vocal Kit .....	68		
29 (INT): BD-SD Catalog Kit .....	70		
30 (INT): BD-SD Catalog Kit 2 .....	72		
31 (INT): Cymbal Catalog Kit. ....	74		

## Combination

### Bank A

#	Name	Category
A000	Dreaming without Sleeping	Keyboard
A001	Driving Miles SW1,2	Bass/Splits
A002	No Mo' Money Rap	Bass/Splits
A003	Large Analog String Pad	Strings
A004	The Fellowship of Saturn	MotionSynth
A005	Trumpets&Brass Open Tone	Brass/Reed
A006	The Orchestra	Orchestral
A007	Prog Rock Festival	Organ
A008	The Future of Funk	LeadSplits
A009	European Holiday	LeadSplits
A010	Flight Of The Eagle	Pads/Vocal
A011	Wizard Dust	Bell/Mallet/Perc
A012	Powerful Intro	Synth
A013	Tribal Dance	World
A014	Fireside	Guitar/Plucked
A015	Elec & Ac Guitar (Hold)	Guitar/Plucked
A016	Towards The Sun	Keyboard
A017	Winter Walk	Keyboard
A018	Worship	Keyboard
A019	Piano & Natural Voices	Keyboard
A020	Across The Milky Way	Keyboard
A021	Tirtian Piano	Keyboard
A022	The Ballade Piano	Keyboard
A023	Eternal Visionary	Keyboard
A024	Piano & Strings	Keyboard
A025	Piano Tech Pad	Keyboard
A026	Melancholy Piano Pad	Keyboard
A027	Poetic Flute Ensemble	Keyboard
A028	Stranded	Keyboard
A029	Lake of Two Mountains	Keyboard
A030	WS Layer Keys	Keyboard
A031	Stereo E.Piano	Keyboard
A032	Electric Piano Pad	Keyboard
A033	Tingly Breath E.Piano	Keyboard
A034	Electus Grandus SW2 JS-Y	Keyboard
A035	Princess Hannah's Piano	Keyboard
A036	Future Tine	Keyboard
A037	Reed Piano Pad	Keyboard
A038	Sparkling Beauty	Keyboard
A039	Indulge EP SW1	Keyboard
A040	Blend Piano	Keyboard
A041	Electric Bell EP	Keyboard
A042	Tone Adjusted EP	Keyboard
A043	Pianophonix	Keyboard
A044	The Crawl	Keyboard
A045	Safe from the Storm	Keyboard
A046	Street Market	Keyboard
A047	Vintage Tremolo EP	Keyboard
A048	NuBreed E.Piano 1	Keyboard
A049	NuBreed E.Piano 2	Keyboard
A050	Garage Night SW2	Keyboard
A051	Krazy Clav	Keyboard
A052	Over Ground Wah	Keyboard
A053	Stereo Buddies	Keyboard
A054	Clavanator	Keyboard
A055	Clav Clone	Keyboard
A056	Buzzy Finga Clav	Keyboard
A057	Chasing Vector	Keyboard
A058	The Recital	Keyboard
A059	A Baroque Moment	Keyboard
A060	Distorted Full Organ	Organ
A061	Vintage Organ	Organ
A062	Old Jazz "B"	Organ
A063	BX-3 Key Click Organ	Organ

#	Name	Category
A064	Wah Organ Velo SW	Organ
A065	Funky Dual Manual Organ	Organ
A066	Jazzy Organ Split	Organ
A067	Jazz Organ & Pedals	Organ
A068	Master Rock Solo Organ	Organ
A069	Pipes & Strings & Brass	Organ
A070	Hymn for Him	Organ
A071	Pipe Organ & Choir	Organ
A072	Magic Pipe Organ	Organ
A073	Cathedral Organ	Organ
A074	Pipe Organ 1 (Use Knobs)	Organ
A075	Pipe Organ 2 (Use Knobs)	Organ
A076	Reflective Tone	Bell/Mallet/Perc
A077	Siberian Bells	Bell/Mallet/Perc
A078	Ice On The Pond	Bell/Mallet/Perc
A079	Welcoming	Bell/Mallet/Perc
A080	Gamelan Dance	Bell/Mallet/Perc
A081	Echoscapes Bell	Bell/Mallet/Perc
A082	A Bell and a Wish	Bell/Mallet/Perc
A083	Balinese Joy	Bell/Mallet/Perc
A084	Cute Music Box	Bell/Mallet/Perc
A085	Bouncing With Benny SW1	Bell/Mallet/Perc
A086	Rainbow Bridge	Bell/Mallet/Perc
A087	Mallet Kalimba	Bell/Mallet/Perc
A088	Breathing Bells JS-Y	Bell/Mallet/Perc
A089	Camera Strings Control	Strings
A090	Delicato Strings	Strings
A091	String Menu SW1,2	Strings
A092	Vibrato Strings/Arco	Strings
A093	Xpressive Strings	Strings
A094	Mixed Strings	Strings
A095	DynaOctave Strings	Strings
A096	Natural Strings	Strings
A097	Natural String/Arco	Strings
A098	Tremolo Strings JS-Y	Strings
A099	Pizzicato/Strings SW1	Strings
A100	Velvet Pad Strings	Strings
A101	Red Velvet Strings	Strings
A102	Arco String Section	Strings
A103	Octave Legato Strings	Strings
A104	String->Tremolo Xfade	Strings
A105	Slow Pad String XL	Strings
A106	Pro Strings	Strings
A107	Grand Legato Strings	Strings
A108	Arco Grand Strings	Strings
A109	Dynamic Quantity Strings	Strings
A110	Slow Grand Strings	Strings
A111	Dyna Trombones Stereo	Brass/Reed
A112	Slow Brass 2 SW1 Oct	Brass/Reed
A113	Orchestral Horns	Brass/Reed
A114	Sforzando Brass	Brass/Reed
A115	CupMute Brass Ensemble	Brass/Reed
A116	Muted Brass	Brass/Reed
A117	Bright Brass SW1 Oct	Brass/Reed
A118	Slow Brass 1 SW1 Oct	Brass/Reed
A119	FrenchHorns & Bones	Brass/Reed
A120	3 Soft Trumpets SW1	Brass/Reed
A121	Trumpets & Bones	Brass/Reed
A122	Brass & Mutes	Brass/Reed
A123	Super Sax Section	Brass/Reed
A124	All Saxophones	Brass/Reed
A125	Saxophone Solo's Family	Brass/Reed
A126	Silver Flutes SW1 Oct	Brass/Reed
A127	All Flutes	Brass/Reed

## Bank B

#	Name	Category
B000	All Clarinets	Brass/Reed
B001	All Doublereeds	Brass/Reed
B002	Cuban Breeze	Brass/Reed
B003	Brass & Sax Section	Brass/Reed
B004	Alto & Brass Section	Brass/Reed
B005	Flute & Bassoon	Brass/Reed
B006	Sugar Dreams	Orchestral
B007	Concert in the Castle	Orchestral
B008	Strings & Woodwinds	Orchestral
B009	Ceremony for a King	Orchestral
B010	Orchestral Passages	Orchestral
B011	Renaissance Ensemble	Orchestral
B012	Orchestra Mezzopiano	Orchestral
B013	Orchestral Woodwinds	Orchestral
B014	Flutes & Orchestra	Orchestral
B015	Orch Menu SW1,2	Orchestral
B016	Brass&Strings Orchestra	Orchestral
B017	Chick Flick Orchestra	Orchestral
B018	Piccolo&Xylophone Split	Orchestral
B019	Reed/Str/Brass/Orch.	Orchestral
B020	Woodwind & Strings	Orchestral
B021	Baroquesque	Orchestral
B022	The Love Scene SW2	Orchestral
B023	Dynamic Score Sketcher	Orchestral
B024	Flute In The Movie	Orchestral
B025	M50 Orchestra	Orchestral
B026	Harpsichord & Orchestra	Orchestral
B027	Matinee Hero Orch	Orchestral
B028	Velo Dynamic Orch	Orchestral
B029	Symphonic Music	Orchestral
B030	Movie Landscapes	Orchestral
B031	Ethno Geo	World
B032	Mayan Temple	World
B033	Asian Mystery	World
B034	Safari King	World
B035	Dance for Rain	World
B036	New World Beat SW1	World
B037	Celtic Tale	World
B038	Going Home to Eire	World
B039	Son of Nature	World
B040	Asian DJ	World
B041	Dingo Dance	World
B042	The Battle at Karnack	World
B043	Tiger by the Tail	World
B044	Kilimanjaro	World
B045	Chinese Flavours SW1,2	World
B046	Hakone & Fuji-san	World
B047	Irish Flavors Split	World
B048	Pipes! SW1,2 Recording	World
B049	Mandolin Orchestra	World
B050	When Daddy Gets Home	Guitar/Plucked
B051	Nylon Guitars	Guitar/Plucked
B052	Soundtrack Guitar	Guitar/Plucked
B053	Acoustic Gtr Vocoder	Guitar/Plucked
B054	...and keeps on picking!	Guitar/Plucked
B055	Guitar&Heavenly Pad SW1	Guitar/Plucked
B056	Gentle Guitar SW2	Guitar/Plucked
B057	Tranquil Guitar Pad	Guitar/Plucked
B058	Acoustic Duet	Guitar/Plucked
B059	Son Of The Musical Fox	Guitar/Plucked
B060	12 String Guitar	Guitar/Plucked
B061	Hot + Cold Guitar	Guitar/Plucked
B062	Constant Sorrow	Guitar/Plucked
B063	Tines 'n' Frets	Guitar/Plucked

#	Name	Category
B064	Monster Metal Axe	Guitar/Plucked
B065	Atmospheric Hybrid Bass	Guitar/Plucked
B066	Mandolin Concert	Guitar/Plucked
B067	New Age Harp & Strings	Guitar/Plucked
B068	As The Dust Rises	Pads/Vocal
B069	Velocity Trembles	Pads/Vocal
B070	Nimbus Bells	Pads/Vocal
B071	The Final Scene	Pads/Vocal
B072	For Magical Moments	Pads/Vocal
B073	A Formant Moment	Pads/Vocal
B074	High Above Hills	Pads/Vocal
B075	Lost at Sea	Pads/Vocal
B076	Matrix Recursive	Pads/Vocal
B077	New Orchestral	Pads/Vocal
B078	CrossWave Pad.Wait..	Pads/Vocal
B079	The Dawn of Life	Pads/Vocal
B080	Endless Strings	Pads/Vocal
B081	Silver Slumbers	Pads/Vocal
B082	New Copland	Pads/Vocal
B083	Warm Wind Pad	Pads/Vocal
B084	Chanters	Pads/Vocal
B085	Android Dream	Pads/Vocal
B086	Paddy Cool	Pads/Vocal
B087	A Secret Garden	Pads/Vocal
B088	Berimbau A Minor Prayer	Pads/Vocal
B089	Deep Thinking Machines	Pads/Vocal
B090	A Subtle Remark	Pads/Vocal
B091	Ripplator Pad	Pads/Vocal
B092	Super Stereo Choir	Pads/Vocal
B093	Vintage Prog Voices	Pads/Vocal
B094	Endless Choir	Pads/Vocal
B095	Jazzy Singers	Pads/Vocal
B096	Our Hero's Last Battle	Pads/Vocal
B097	Vocalraiser	Pads/Vocal
B098	Those Rainy Dayz	Pads/Vocal
B099	The Calling	Pads/Vocal
B100	Deep Vocal Pad	MotionSynth
B101	Winter Morning	MotionSynth
B102	Spectracolor Pad	MotionSynth
B103	Galactic Journey	MotionSynth
B104	Shifting Cells	MotionSynth
B105	Kaleidoscopic	MotionSynth
B106	Please...just hold me	MotionSynth
B107	Dust Storm on Mars	MotionSynth
B108	Motivation	MotionSynth
B109	Mafia Hit Man	MotionSynth
B110	Always Watching You...	MotionSynth
B111	Watching the Virus Grow	MotionSynth
B112	AstroBabe a Dancin'	MotionSynth
B113	M Station	MotionSynth
B114	The Secret Adventure	MotionSynth
B115	Advanced JS-Y Mix	MotionSynth
B116	Wandering Waves	MotionSynth
B117	City of the Pad	MotionSynth
B118	Sprinkle Town	MotionSynth
B119	Desert Moonrise	MotionSynth
B120	Silver Swirlings	MotionSynth
B121	Fading Planes	MotionSynth
B122	Collective Motion	MotionSynth
B123	Love for Trance	Synth
B124	Castaway	Synth
B125	Power Monster Synth	Synth
B126	Moreish Polysynth	Synth
B127	Aerofreak	Synth

## Bank C

#	Name	Category
C000	Air Freshener Pad	Synth
C001	Dancing Perky Vokal Pad	Synth
C002	EuroPop Supa'Starr	Synth
C003	Electronica	Synth
C004	Paisley Groove	Synth
C005	Trivector	Synth
C006	The Driven Synth	Synth
C007	Digital Obesity	Synth
C008	SupaDupa Zinth	Synth
C009	Dark Element SW2	Synth
C010	Freshly Squeezed Air	Synth
C011	Return To Cyberville	LeadSplits
C012	JPop Cover Girl	LeadSplits
C013	And Rest..	LeadSplits
C014	Can't Stop The Groove	LeadSplits
C015	Skippy Wants to Dance!	LeadSplits
C016	The Gates of Mordor SW1	LeadSplits
C017	Homie's Coming Home	LeadSplits
C018	Motion Pad&Bell Syn Lead	LeadSplits
C019	Smooth Pad & Soft Lead	LeadSplits
C020	Cozumel Beach Romance	LeadSplits
C021	Morning Mist	LeadSplits
C022	Oboe & Orchestra Split	LeadSplits
C023	Voices/EthnicFlute Split	LeadSplits
C024	The Spirit Lives	LeadSplits
C025	..and she started crying	LeadSplits
C026	LFO Pad & Alto Sax	LeadSplits
C027	Electric Piano & Sax	LeadSplits
C028	Guitar Stories	LeadSplits
C029	Heavy Metal Split	LeadSplits
C030	Rock Guitar Solo Split	LeadSplits
C031	Beatbox	LeadSplits
C032	CyberJazz Cafe	LeadSplits
C033	A Jazzy Night	LeadSplits
C034	Late Night Jam	LeadSplits
C035	The Winds of Venice	LeadSplits
C036	Old West Theme	LeadSplits
C037	Pedaling to Nashville	LeadSplits
C038	Heavy Dirigible Blues	LeadSplits
C039	Rock Tool Kit	LeadSplits
C040	Fab Split Baby!	LeadSplits
C041	Alligator Swamp...	LeadSplits
C042	Bluegrass Waltz	LeadSplits
C043	SoftBrass&Clarinet Split	LeadSplits
C044	Love Theme Split	LeadSplits
C045	A.Bass & Piano SW1	BassSplits
C046	Jazz Bass Split SW&Kn2	BassSplits
C047	Acid Funk Shadow Dance	BassSplits
C048	Celebration Church SW1	BassSplits
C049	The House Club Band	BassSplits
C050	Dreamin' and a Jahmmin'	BassSplits
C051	E.Bass & Old EP	BassSplits
C052	Brazilian Tribal Chill	BassSplits
C053	Gentle Rosey Split	BassSplits
C054	Smooth Jazzmitazz	BassSplits
C055	Trickapalooza	BassSplits
C056	Cool Street Split	BassSplits
C057	She Walks into ...	BassSplits
C058	Stealth Lovers	BassSplits
C059	Roller Boogie	BassSplits
C060	Mod Bass & Elec. Piano	BassSplits
C061	Jaw Harp Groove JS-Y Mix	BassSplits
C062	French Hop	BassSplits
C063	Udu Hop JS-Y Mix	BassSplits

#	Name	Category
C064	Follow the Leader	BassSplits
C065	Cool Mute & A.Bass Split	BassSplits
C066	Tech Out My House SW2	BassSplits
C067	Anthem Of Summer	BassSplits
C068	Neon Lovers	BassSplits
C069	Quiet Storm Split	BassSplits
C070	Rough Riders	BassSplits
C071	Pearly Gates Split	BassSplits
C072	Drum 'n' Bass Split	BassSplits
C073	Hook Me Up SW1,2 JS-Y	BassSplits
C074	Taped Orch Hop	BassSplits
C075	Tricki Flash Wah	BassSplits
C076	No Sleep! SW2	BassSplits
C077	Koochie Groovy	BassSplits
C078	Groove All Night	BassSplits
C079	Thrill Dome	BassSplits
C080	PCM Pirates	BassSplits
C081	Never Surrender!	BassSplits
C082	Gettin' My Groove On	BassSplits
C083	BellHop Ballad	BassSplits
C084	New Ride Jam	BassSplits
C085	Rad M50 Breakbeat Jam !	BassSplits
C086	Dark Revolutions	BassSplits
C087	DnB Black Mass	BassSplits
C088	You're Too Late	BassSplits
C089	Hip 3-way Split	BassSplits
C090	Lucid Dreamin' Rap Star	BassSplits
C091	Guitar Synth Split	BassSplits
C092	The Power & the Glory	BassSplits
C093	A Space Odyssey	BassSplits
C094	Prehistoric Predators	Complex&SFX
C095	Beyond the Cosmos	Complex&SFX
C096	Planetary Explosion	Complex&SFX
C097	Amazon Exploration	Complex&SFX
C098	Multiple Agents	Complex&SFX
C099	Loop Y'Self SW1	Complex&SFX
C100	Pod Doors are Opening...	Complex&SFX
C101	Miracle at Stormy Cove	Complex&SFX
C102	World Of Horror	Complex&SFX
C103	The Lost Continent	Complex&SFX
C104	Super Mega Fragalistix	Complex&SFX
C105	Mutant Patrol	Complex&SFX
C106	Relaxed Tracks	Complex&SFX
C107	Quantize Play	BPM Sync
C108	Tryin' Not to Lose it...	BPM Sync
C109	Transmission Wires	BPM Sync
C110	Butterfly Jam	BPM Sync
C111	Such a Rush	BPM Sync
C112	Distort 'n' Grind	BPM Sync
C113	Pure Attitude	BPM Sync
C114	Restless Natives	BPM Sync
C115	Re Mix Party SW1,2	BPM Sync
C116	Whacktronix JS+Y	BPM Sync
C117	Club Fantasy SW1,2	BPM Sync
C118	Futura	BPM Sync
C119	'Splain It to Me SW2	Drums/Hits
C120	Vocoder Remix Hits	Drums/Hits
C121	R&B Overture	Drums/Hits
C122	Loop 'n' Hits	Drums/Hits
C123	Drumz & Hitz	Drums/Hits
C124	Samba Drum Festival	Drums/Hits
C125	Revenge Rock Kit	Drums/Hits
C126	Jam on da M50! JS-Y	Drums/Hits
C127	Hitsville M50	Drums/Hits



## Program

### Bank A

#		Name	Category
A000	D	M50 Grand Piano	Keyboard
A001	D	M3 Mono Piano & Damper	Keyboard
A002	S	Pan Suit EP 1 SW2,Knob1	Keyboard
A003	D	Rich Tea E.Piano	Keyboard
A004	S	Pure Wurlly E.Piano	Keyboard
A005	D	Clav Register AC	Keyboard
A006	D	Rock Perc.Organ	Organ
A007	D	Intimate Strings	Strings
A008	D	Sharp Brass & Sax Octave	Brass
A009	S	New Vib Flute	Woodwind/Reed
A010	D	Stereo Voice Pad	Vocal/Airy
A011	@	Funk Kit	Drums
A012	@	B.Real Rap Kit	Drums
A013	D	Nylon Guitar 2	Guitar/Plucked
A014	D	Bright Acoustic Bass	Bass/Synth Bass
A015	D	2 the Point	Bass/Synth Bass
A016	D	Deep Soul Lead	LeadSynth
A017	D	Super Analog Pad	SlowSynth
A018	D	Time Machines	MotionSynth
A019	D	S&H Sync Shot	Short Decay/Hit
A020	S	Stereo Grand 3-Way	Keyboard
A021	D	Stereo Grand 2-Way SW1	Keyboard
A022	D	Stereo Concert Piano	Keyboard
A023	D	Classic Piano+Damper	Keyboard
A024	D	Stereo Piano+Damper	Keyboard
A025	S	New Harmonic Grand Piano	Keyboard
A026	S	SG-1D New Piano	Keyboard
A027	D	Stereo MIDI Grand w/Pad	Keyboard
A028	D	Daydream Piano	Keyboard
A029	D	Romance Piano Bell Knob1	Keyboard
A030	D	Sparkling Piano	Keyboard
A031	S	CP Electric Grand	Keyboard
A032	S	M1 Piano	Keyboard
A033	D	Mild Suitcase E.Piano	Keyboard
A034	S	Suitcase E.Piano 3-Way	Keyboard
A035	D	Attack Stage Piano	Keyboard
A036	D	Custom E.Piano	Keyboard
A037	S	Open E.Piano	Keyboard
A038	S	Real Suit E.Piano	Keyboard
A039	S	Direct E.Piano 1	Keyboard
A040	S	Direct E.Piano 2	Keyboard
A041	D	Master Rho.Piano	Keyboard
A042	S	Phunky Drive E.Piano	Keyboard
A043	D	Stage E.P. Amp Type 1	Keyboard
A044	S	Pan Suit EP 2 SW2,Knob1	Keyboard
A045	D	Stereo Suitcase	Keyboard
A046	S	Wah Panning E.Piano	Keyboard
A047	S	Bi-Phase E.Piano	Keyboard
A048	S	Deep Phaser E.Piano	Keyboard
A049	D	Stereo Dyno E.Piano	Keyboard
A050	S	Dyna-My Electric Piano	Keyboard
A051	D	Master Dyno E.Piano	Keyboard
A052	S	Reed E.Piano	Keyboard
A053	D	Wurlly E.Piano	Keyboard
A054	S	Dist Black Wurlly	Keyboard
A055	D	Master Wurlly E.Piano	Keyboard
A056	D	Piano Power Pad	Keyboard
A057	S	Ballade E.Piano	Keyboard
A058	D	Digi E.Piano 4-Way	Keyboard
A059	D	Breathy EP Pad	Keyboard
A060	D	SynPianoxy	Keyboard
A061	D	Dark RnB Piano	Keyboard
A062	D	Tiny Tine E.Piano	Keyboard
A063	D	VS Wave Piano	Keyboard

#		Name	Category
A064	D	Smooth Operators	Keyboard
A065	D	Digi E.Piano 3-Way	Keyboard
A066	D	Dynamic E.Piano	Keyboard
A067	D	Funky Tine E.Piano	Keyboard
A068	S	VPM E.Piano	Keyboard
A069	D	Clav 1/Mute SW1	Keyboard
A070	D	Clav 2/Mute SW1	Keyboard
A071	D	Velo Clav Mutes	Keyboard
A072	D	Buzzy Clav	Keyboard
A073	D	Sticky Finga Clav	Keyboard
A074	D	Spike Rez Clav	Keyboard
A075	S	V.Switch WS Clav	Keyboard
A076	D	Crunch Clav	Keyboard
A077	D	Clav Keyoff 1 SW1	Keyboard
A078	D	Clav Keyoff 2 SW1	Keyboard
A079	D	Clav Keyoff 3 SW1	Keyboard
A080	D	Clav Register AD	Keyboard
A081	D	Clav Register BC	Keyboard
A082	D	Clav Register BD	Keyboard
A083	S	Velo Clav "BD"	Keyboard
A084	D	Master Clav	Keyboard
A085	S	Touch Wah Clav	Keyboard
A086	D	Phase Clav Keyoff	Keyboard
A087	D	Mute Clav Keyoff	Keyboard
A088	D	8' Harpsichord + Key Off	Keyboard
A089	D	16'+8' Harpsichord+Pluk	Keyboard
A090	D	JazzPerc Organ (3rd/2nd)	Organ
A091	D	Perc 1/3rd Organ	Organ
A092	D	Jazz Organ Dist.Perc	Organ
A093	D	Perc 3rd Dist/Organ	Organ
A094	D	Perc Blues OD.Organ SW	Organ
A095	D	Dist.Organ Perc	Organ
A096	D	Distortion Organ	Organ
A097	D	Rock-Organ Overdrive	Organ
A098	D	Master Perc Rock Organ	Organ
A099	D	Perc Organ	Organ
A100	D	Master Full Organ	Organ
A101	D	Screamin' CX-3 SW1,2	Organ
A102	D	Master Rock Organ	Organ
A103	D	M1/Perc1 Organ	Organ
A104	D	Smoke House Organ	Organ
A105	D	Jazz Perc Organ	Organ
A106	D	Percussive Organ	Organ
A107	D	Gospel BX3	Organ
A108	D	Jazzy Med. Organ	Organ
A109	D	Ballade Organ	Organ
A110	D	Drawbars adds Highs	Organ
A111	D	Drawbars soft<->full	Organ
A112	D	Full Power BX3	Organ
A113	D	Full Organ	Organ
A114	D	DWGS Mix Organ	Organ
A115	D	CX-3 Organ	Organ
A116	D	DWGS Soft Organ	Organ
A117	D	Ballade Organ SW1,2	Organ
A118	D	Jazzy Dark Organ SW,Knob	Organ
A119	D	Techno Organ Leader	Organ
A120	D	Vox Organ SW2 Tabs	Organ
A121	S	Vox E.Organ	Organ
A122	D	UK Rock Organ	Organ
A123	D	Positive Organ	Organ
A124	D	Church Positive/Full	Organ
A125	D	Pipe Organ Mixture	Organ
A126	D	Pipe Full Organ	Organ
A127	D	VS Bells Twinkle Dust	Bell/Mallet

## Bank B

#		Name	Category
B000	D	Air Bells	Bell/Mallet
B001	D	Morning Bells	Bell/Mallet
B002	D	Happy Kids Bells	Bell/Mallet
B003	D	Pure Satin Bells	Bell/Mallet
B004	D	Silver Solar Bells	Bell/Mallet
B005	D	VPM Pluck Bells	Bell/Mallet
B006	D	Glass Pluck Bells	Bell/Mallet
B007	D	VS Bells 1	Bell/Mallet
B008	D	VS Bells 2	Bell/Mallet
B009	D	VS Bells 3	Bell/Mallet
B010	D	VPM Tubular Bells	Bell/Mallet
B011	D	Finger Cymbal Bells	Bell/Mallet
B012	D	DigiMetal Bell	Bell/Mallet
B013	D	Little Fuzz Bell	Bell/Mallet
B014	D	Analog Bell/Harp	Bell/Mallet
B015	D	Calm Bell Synth	Bell/Mallet
B016	S	Glass Bell	Bell/Mallet
B017	S	Music Box	Bell/Mallet
B018	D	Orchestral Celesta	Bell/Mallet
B019	D	Glockenspiel Soft	Bell/Mallet
B020	D	Glockenspiel Hard	Bell/Mallet
B021	S	Tubular Bells Rack	Bell/Mallet
B022	D	Vibraphone Soft	Bell/Mallet
B023	D	Vibraphone Hard	Bell/Mallet
B024	D	Bali Gamelan	Bell/Mallet
B025	D	Birds in the Kalimba SW1	Bell/Mallet
B026	D	African Kalimba	Bell/Mallet
B027	D	The Kalimba	Bell/Mallet
B028	S	Marimba Hard Mallet	Bell/Mallet
B029	S	Xylophone Dynamic Xfade	Bell/Mallet
B030	D	Balaphone	Bell/Mallet
B031	D	The Log Drum	Bell/Mallet
B032	D	Steel Drums SW1	Bell/Mallet
B033	D	Santur Dynamic Xfade	Bell/Mallet
B034	D	Stereo Strings Legato	Strings
B035	D	Stereo Oct Strings SW1	Strings
B036	D	Symphony Strings	Strings
B037	D	Arco Stereo Strings	Strings
B038	D	Symphonic Bows	Strings
B039	D	Hollywood Strings	Strings
B040	D	Legato Strings	Strings
B041	D	Platinum Strings	Strings
B042	D	Few Bows Stereo	Strings
B043	D	Beautiful Strings	Strings
B044	D	Tremolo Strings Knob1	Strings
B045	D	Analog Strings Stereo	Strings
B046	D	Analog Strings	Strings
B047	D	String Pad 1	Strings
B048	D	String Pad 2	Strings
B049	D	Vintage Analog Strings	Strings
B050	D	Analog Strings Pad	Strings
B051	D	Analog Strings Ens	Strings
B052	S	Progressive Ana Strings	Strings
B053	D	Krimson Strings SW2	Strings
B054	D	Pizz Ensemble/Solo 1 SW2	Strings
B055	D	Pizz Ensemble/Solo 2 SW2	Strings
B056	D	String Quartet/Pizz SW1	Strings
B057	D	Vib StrQuartet/Pizz SW1	Strings
B058	D	Violin Solo/Pizz SW1	Strings
B059	D	Vib Violin Solo/Pizz SW1	Strings
B060	D	Viola Solo/Pizz SW1	Strings
B061	D	Cello Solo/Pizz SW1	Strings
B062	D	Erhu SW1	Strings
B063	D	Scat Voices	Vocal/Airy

↑ S: single program, D: double program,  
 @: drums program

#		Name	Category
B064	D	Male Scat Voices	Vocal/Airy
B065	D	Female Scat Voices	Vocal/Airy
B066	D	Classical Choir	Vocal/Airy
B067	D	Classic Choir	Vocal/Airy
B068	D	Aaah Stereo Voices	Vocal/Airy
B069	D	Ah Voices	Vocal/Airy
B070	D	Ooh Voices L&R	Vocal/Airy
B071	D	Oooh Stereo Voices	Vocal/Airy
B072	D	Uh-Wooh M&F Voices	Vocal/Airy
B073	D	Tron Choir	Vocal/Airy
B074	D	VoxFormant AAH/OOH=SW1	Vocal/Airy
B075	D	Sing-2-Me Kn1=Ah,Ha,Lah	Vocal/Airy
B076	D	Mountain Voices	Vocal/Airy
B077	D	New Day Voices	Vocal/Airy
B078	D	Alpine Voice Pad	Vocal/Airy
B079	D	Dream Voices	Vocal/Airy
B080	D	Arctic Voices	Vocal/Airy
B081	D	Light Voices L&R	Vocal/Airy
B082	D	Air Voices	Vocal/Airy
B083	D	Dreaming of Blue	Vocal/Airy
B084	D	Stereo Open Brass	Brass
B085	D	Session Brass	Brass
B086	D	Big Stereo Brass	Brass
B087	D	Thin Stereo Brass	Brass
B088	D	Trumpets Xfade	Brass
B089	D	Warm Brass	Brass
B090	D	Full Brass Section	Brass
B091	D	Mono Brass	Brass
B092	D	SFZ Brass	Brass
B093	D	Brass Vel. Fall 3-Way	Brass
B094	S	Sharp Brass	Brass
B095	D	Trumpets Velocity	Brass
B096	D	Trombone Duo	Brass
B097	D	2 Trumpets Oct-Velo Fall	Brass
B098	D	T.O.P Section	Brass
B099	D	Trombones 4-Way	Brass
B100	D	Trombones Xfade	Brass
B101	D	Brass & Saxophones	Brass
B102	D	Stereo Brass & Tubas	Brass
B103	D	French Horn Ensemble	Brass
B104	D	French Horn Duo	Brass
B105	D	Nu French Horn Ensemble	Brass
B106	D	Brass doit/fall Hit !	Brass
B107	D	Mute Tp/Tb Ensemble	Brass
B108	D	Sharp Mute Tp/Tb Octave	Brass
B109	S	Sensitive Trumpet	Brass
B110	S	Trumpet Overblown	Brass
B111	S	Trumpet Open Tone	Brass
B112	S	Tongue Trumpet Xfade	Brass
B113	S	Trumpet Vibrato	Brass
B114	S	Mute Trumpet	Brass
B115	S	Piccolo Trumpet	Brass
B116	S	Flugelhorn	Brass
B117	S	Solo Trombone 4-Way	Brass
B118	S	Trombone Vibrato	Brass
B119	D	Mute Trombone	Brass
B120	S	Solo French Horn	Brass
B121	D	Tuba Dynamic Xfade	Brass
B122	D	Silver Flute	Woodwind/Reed
B123	D	Vibrato Flute	Woodwind/Reed
B124	D	Flute Dynamic	Woodwind/Reed
B125	D	Magical Flute	Woodwind/Reed
B126	D	Jazz Flute Solo Perf.	Woodwind/Reed
B127	D	Piccolo Flute	Woodwind/Reed

↑ S: single program, D: double program,  
 @: drums program

**Bank C**

#		Name	Category
C000	D	Strawberry Flutes SW1	Woodwind/Reed
C001	D	Recorder	Woodwind/Reed
C002	D	Nay	Woodwind/Reed
C003	D	Ocarina Classic Tone	Woodwind/Reed
C004	D	PanFlute + Overtones	Woodwind/Reed
C005	D	Tin Whistle	Woodwind/Reed
C006	D	Shakuhachi Xfade	Woodwind/Reed
C007	D	Soprano Sax JS-Y Growl	Woodwind/Reed
C008	D	Vibrato Saxes JS-Y Growl	Woodwind/Reed
C009	D	Alto Sax Soft -Y Breath	Woodwind/Reed
C010	D	Alto Sax Hard JS-Y Growl	Woodwind/Reed
C011	D	Tenor & Alto Saxes Forte	Woodwind/Reed
C012	D	Tenor Sax Hard -Y Growl	Woodwind/Reed
C013	D	Baritone Sax JS-Y Growl	Woodwind/Reed
C014	D	Doublereed Family	Woodwind/Reed
C015	S	Oboe	Woodwind/Reed
C016	S	English Horn SW1	Woodwind/Reed
C017	D	Clarinets	Woodwind/Reed
C018	D	Clarinet	Woodwind/Reed
C019	D	Bass Clarinet SW1 Duo	Woodwind/Reed
C020	S	Bassoon	Woodwind/Reed
C021	D	Musette + Principal	Woodwind/Reed
C022	D	Musette + 4'	Woodwind/Reed
C023	D	Astor's Bandoneon	Woodwind/Reed
C024	S	Harmonica SW1 Distortion	Woodwind/Reed
C025	D	Uilleann Pipe VeloSwitch	Woodwind/Reed
C026	D	Nylon Guitar 1	Guitar/Plucked
C027	D	12 String Guitar	Guitar/Plucked
C028	D	A.Guitar Dynamic Pick	Guitar/Plucked
C029	D	Steel Ac Guitar	Guitar/Plucked
C030	D	Metal Res Guitar	Guitar/Plucked
C031	D	Glassy Strat	Guitar/Plucked
C032	D	Xfade E.Guitar	Guitar/Plucked
C033	D	E.Guitar Dynamic Pick	Guitar/Plucked
C034	S	Hybrid Guitar	Guitar/Plucked
C035	S	Fly Studio Guitar	Guitar/Plucked
C036	D	Telly E.Guitar Comp	Guitar/Plucked
C037	S	Twin Telly E.Guitar	Guitar/Plucked
C038	S	Muted Pick Guitar 1	Guitar/Plucked
C039	S	Muted Pick Guitar 2	Guitar/Plucked
C040	D	Funkaholic Mute E.Guitar	Guitar/Plucked
C041	S	Elec Guitar + Twin	Guitar/Plucked
C042	S	Dirty Guitar + AC30	Guitar/Plucked
C043	S	SemiDist. Guitar	Guitar/Plucked
C044	D	Overdrive Guitar SW1,2	Guitar/Plucked
C045	S	Cool AutoWah Gtr	Guitar/Plucked
C046	D	Whack-a-Wah SW1	Guitar/Plucked
C047	S	Vintage Tremolo Guitar	Guitar/Plucked
C048	D	Rotary Guitar	Guitar/Plucked
C049	D	Tremolo-matic	Guitar/Plucked
C050	S	Brit Guitar	Guitar/Plucked
C051	D	Boutique Lead Guitar	Guitar/Plucked
C052	S	New Fuzz Guitar Velo	Guitar/Plucked
C053	D	Distorted Guitar Lead	Guitar/Plucked
C054	D	Wah Lead Gtr JS+-Y	Guitar/Plucked
C055	D	Screaming Tube Guitar	Guitar/Plucked
C056	D	Dist.Guit JS-Y Mute	Guitar/Plucked
C057	D	Mega Mute Guitar	Guitar/Plucked
C058	D	Power Guitar FX	Guitar/Plucked
C059	D	Gtr Power Chords & FX	Guitar/Plucked
C060	D	JazzGuitar & AmpCabinet	Guitar/Plucked
C061	S	Pedal Steel PreBend Gtr	Guitar/Plucked
C062	D	Bouzuki Octave Strings	Guitar/Plucked
C063	D	Dyna Banjo	Guitar/Plucked
C064	S	Harp 'Nails'	Guitar/Plucked

S: single program, D: double program,  
@: drums program

#		Name	Category
C065	D	Mandolin Pick	Guitar/Plucked
C066	D	Mandolin Trem & Str	Guitar/Plucked
C067	D	Sitar & Tambura	Guitar/Plucked
C068	D	Sitar SW2	Guitar/Plucked
C069	D	Shamisen SW1 Double	Guitar/Plucked
C070	D	Koto SW1	Guitar/Plucked
C071	D	Oud Dynamic Xfade	Guitar/Plucked
C072	D	Dark Floor Bass	Bass/Synth Bass
C073	D	2 Deep Bass	Bass/Synth Bass
C074	D	Dark Point Bass	Bass/Synth Bass
C075	S	Woody Syn Bass	Bass/Synth Bass
C076	S	Props Bass	Bass/Synth Bass
C077	D	DistortionHead	Bass/Synth Bass
C078	D	Elephant Sub Bass	Bass/Synth Bass
C079	S	Dark Round Wound	Bass/Synth Bass
C080	S	Syn Reso Bass SW1,2	Bass/Synth Bass
C081	S	Hevy O	Bass/Synth Bass
C082	S	Deep in the Growler	Bass/Synth Bass
C083	S	Funkylicious Bass	Bass/Synth Bass
C084	S	Rezziz Bazz Knob3	Bass/Synth Bass
C085	D	Blue Acid Bass	Bass/Synth Bass
C086	D	PowerBar Bass	Bass/Synth Bass
C087	D	Memento Mori Bass	Bass/Synth Bass
C088	D	Trauma Bass	Bass/Synth Bass
C089	S	Raunchy Bass	Bass/Synth Bass
C090	D	Evil Eye Bass	Bass/Synth Bass
C091	S	VPM Syn Bass	Bass/Synth Bass
C092	D	Take Me Home Bass	Bass/Synth Bass
C093	D	Phone Home Bass	Bass/Synth Bass
C094	D	Vulcan Ear Bass	Bass/Synth Bass
C095	D	RnB Bass/Lead	Bass/Synth Bass
C096	D	Harmonic Bass	Bass/Synth Bass
C097	S	HipHop Shop	Bass/Synth Bass
C098	D	Mud Bass	Bass/Synth Bass
C099	D	Ragin' Bass	Bass/Synth Bass
C100	D	Father of Disco Bass	Bass/Synth Bass
C101	D	Electro Big Bass	Bass/Synth Bass
C102	D	MG Funk Bass	Bass/Synth Bass
C103	D	JungleHead	Bass/Synth Bass
C104	D	Hard Sync Bass	Bass/Synth Bass
C105	D	Kryptonik Bass	Bass/Synth Bass
C106	D	House Organ Bass	Bass/Synth Bass
C107	D	Strong/Baddd Bass	Bass/Synth Bass
C108	D	A'Kustik Bass	Bass/Synth Bass
C109	D	Acoustic Bass 1 SW1	Bass/Synth Bass
C110	D	Acoustic Bass 2 SW1	Bass/Synth Bass
C111	S	Finger Bass 1	Bass/Synth Bass
C112	S	Finger Bass 2	Bass/Synth Bass
C113	D	Finger Bass 3	Bass/Synth Bass
C114	D	Finger Bass 4	Bass/Synth Bass
C115	D	Finger Bass 5	Bass/Synth Bass
C116	D	Finger Bass 6	Bass/Synth Bass
C117	S	Finger Bass 7	Bass/Synth Bass
C118	D	Velocity Bend Bass	Bass/Synth Bass
C119	S	Stinger Bass	Bass/Synth Bass
C120	S	Picked Precision Bass	Bass/Synth Bass
C121	D	Picked Bass 1	Bass/Synth Bass
C122	D	Picked Bass 2 SW1	Bass/Synth Bass
C123	D	Picked Velocity Mute	Bass/Synth Bass
C124	S	HB Fretless Bass	Bass/Synth Bass
C125	D	Pro Fretless Bass SW1	Bass/Synth Bass
C126	D	Dark Fretless	Bass/Synth Bass
C127	D	Slap Bass Sting SW1 Noiz	Bass/Synth Bass

S: single program, D: double program,  
@: drums program



## Bank D

#		Name	Category
D000	D	Thumb Bass 1	Bass/Synth Bass
D001	D	Thumb Bass 2 SW1	Bass/Synth Bass
D002	D	Mono Dyna Slap Bass	Bass/Synth Bass
D003	D	Hybrid String Pad	SlowSynth
D004	D	Ana-2-Real Strings	SlowSynth
D005	D	Tranquil Pad	SlowSynth
D006	D	Paddylicious	SlowSynth
D007	D	MassBrassPad	SlowSynth
D008	D	Breeze Pad	SlowSynth
D009	D	Airy Tails	SlowSynth
D010	D	Evoxativity Pad	SlowSynth
D011	D	Spectral Voices Knob2	SlowSynth
D012	D	Whale's World SW1	SlowSynth
D013	D	Angel World	SlowSynth
D014	D	Late Night Pad	SlowSynth
D015	D	Givin' Out Vibes	SlowSynth
D016	D	Pad Hissing Pad	SlowSynth
D017	S	Slow Metal Pad	SlowSynth
D018	D	Reed Pad	SlowSynth
D019	D	Filter Bank	SlowSynth
D020	D	Slow Flange Pad	SlowSynth
D021	D	Synth Brass Pad	SlowSynth
D022	D	Slow Sine Pad	SlowSynth
D023	D	Cloud City	SlowSynth
D024	D	Deepest Vox Pad	SlowSynth
D025	D	The 5th Vector	SlowSynth
D026	D	Beautiful Longings	SlowSynth
D027	D	Ripplator	SlowSynth
D028	D	Gentle Syn Strings	SlowSynth
D029	D	Warm & Slow Pad	SlowSynth
D030	D	{{(Meditate)}}	SlowSynth
D031	D	Splash From The Past	SlowSynth
D032	D	Freedom Pad	SlowSynth
D033	D	Simple Rez Sweep Pad	SlowSynth
D034	D	Notchstradamus	SlowSynth
D035	D	High Octane HPF Sweep	SlowSynth
D036	D	Cross Sweeper	SlowSynth
D037	D	Debussian Pad	SlowSynth
D038	D	Pad-O-Rama	SlowSynth
D039	D	Ghost Motions	SlowSynth
D040	D	Oddy-say Pad	SlowSynth
D041	D	Rapper's D'light	FastSynth
D042	D	Syn Brass The Sailor	FastSynth
D043	D	Leader of Trance	FastSynth
D044	D	Spiky Analog	FastSynth
D045	D	VeloFilter Stabs SW1	FastSynth
D046	D	Pure Power 5th	FastSynth
D047	D	Rat Chords controls!	FastSynth
D048	D	Warm Analog	FastSynth
D049	S	DoubleSynth SW1	FastSynth
D050	D	Brite Rezy Synth SW1	FastSynth
D051	D	Flute Pad	FastSynth
D052	D	Padme & Leadme	FastSynth
D053	D	Gliding Squares	FastSynth
D054	D	Sine Synth	FastSynth
D055	D	Synth Mallet	FastSynth
D056	D	Syn. Mallet 5ths	FastSynth
D057	D	Beauty Keys	FastSynth
D058	D	Pulse Morph Comp	FastSynth
D059	D	Fun Comp Synth	FastSynth
D060	D	Storm Chaser	FastSynth
D061	D	Dist Satellite	FastSynth
D062	D	Brite Bold Saws	FastSynth
D063	D	Powerful Euphoria	FastSynth
D064	D	Attacking Synth	FastSynth

↑ S: single program, D: double program,  
@: drums program

#		Name	Category
D065	D	Power Synth	FastSynth
D066	D	Cosmic Furnace	FastSynth
D067	D	Perky Vox Synth	FastSynth
D068	D	Pop Synth Pad	FastSynth
D069	D	Fresh Air	FastSynth
D070	D	Happy Air Synth	FastSynth
D071	D	Soft Rezz Synth	FastSynth
D072	D	Bright Square Lead	LeadSynth
D073	D	TeknoSink Lead	LeadSynth
D074	D	Wikid Lead	LeadSynth
D075	D	Mega Lead	LeadSynth
D076	D	Bright Saw Lead	LeadSynth
D077	D	Classic Unison Lead	LeadSynth
D078	D	Fear Not	LeadSynth
D079	D	Amsterdam Momma	LeadSynth
D080	D	Lead With a Vengeance	LeadSynth
D081	D	Pulse Morph Lead	LeadSynth
D082	D	Squeekish Lead	LeadSynth
D083	D	Stealth Sync Lead	LeadSynth
D084	D	Syncified Lead	LeadSynth
D085	D	Mega Sync Lead	LeadSynth
D086	D	Tranceferrance Lead	LeadSynth
D087	D	ResRes One Mono Lead	LeadSynth
D088	D	Vintage SciFi Lead	LeadSynth
D089	D	Huggy lead	LeadSynth
D090	D	Trance Form Lead	LeadSynth
D091	S	Diss (LH controllers!)	LeadSynth
D092	D	Mass Destruction	LeadSynth
D093	D	Surfin PWM Lead	LeadSynth
D094	D	Screaming Mini	LeadSynth
D095	D	Vintage Lead	LeadSynth
D096	D	Espress Lead	LeadSynth
D097	D	Singing Lead	LeadSynth
D098	D	Lead Ting	LeadSynth
D099	S	Pro Synth Lead	LeadSynth
D100	D	Round Poppy Lead	LeadSynth
D101	S	Leading Sines	LeadSynth
D102	S	Vox Lead SW1	LeadSynth
D103	D	Syn Pipes	LeadSynth
D104	S	Vintage Sine Lead	LeadSynth
D105	D	Evolving	MotionSynth
D106	D	Aqua Phonics	MotionSynth
D107	D	Liquid Evolution	MotionSynth
D108	S	Dark Revolution	MotionSynth
D109	D	Morphing Cloud Pad	MotionSynth
D110	D	Eternity	MotionSynth
D111	D	Butterflies	MotionSynth
D112	D	The Good Fairy's Pad	MotionSynth
D113	D	Lost & Falling	MotionSynth
D114	D	Pods In The Pad	MotionSynth
D115	D	Flying Machines	MotionSynth
D116	D	Windy Atmosphere	MotionSynth
D117	D	Transformation	MotionSynth
D118	D	Swirl Pad	MotionSynth
D119	D	Flutter Pad	MotionSynth
D120	D	Dream Catcher	MotionSynth
D121	D	Spirals & Steps	MotionSynth
D122	D	Sea Glass	MotionSynth
D123	D	VS Waves Mirror*rorriM	MotionSynth
D124	D	Flutterz	MotionSynth
D125	D	Shimmer Sparkle Pad	MotionSynth
D126	D	Scatter Synth	MotionSynth
D127	D	Apollo Pad	MotionSynth

↑ S: single program, D: double program,  
@: drums program

**Bank E**

#		Name	Category
E000	D	BPM Gating Voice Pad	MotionSynth
E001	D	Whispering	MotionSynth
E002	D	BPM Flashlight Pad	MotionSynth
E003	D	BPM Gatepad	MotionSynth
E004	D	Sea Creature	MotionSynth
E005	D	BPM Pulse	MotionSynth
E006	S	BPM Orbit Blip	MotionSynth
E007	D	Ready for Liftoff	MotionSynth
E008	D	BPM Motion Trance	MotionSynth
E009	D	BPM Metallic Water	MotionSynth
E010	D	BPM Dense Motionations	MotionSynth
E011	D	BPM Machine Jam	MotionSynth
E012	D	BPM Telephone Jam	MotionSynth
E013	D	BPM QuantizedFilterPlay	MotionSynth
E014	S	BPM Step Slowly	MotionSynth
E015	D	eMoTiOn	MotionSynth
E016	D	BPM Not a Care.....	MotionSynth
E017	D	Perfect Storm	SFX
E018	D	SubSonik War Drums	SFX
E019	D	Sonic Blast	SFX
E020	D	Outside Elements	SFX
E021	D	Jungle Habitat	SFX
E022	S	Meditation Tree	SFX
E023	S	Coin Thwack	SFX
E024	D	New North Wind	SFX
E025	S	Wuukkee FX	SFX
E026	D	Stereo Flange Sweep	SFX
E027	D	Cosmic Waves	SFX
E028	D	Hemispheres	SFX
E029	D	Orbiting Probes	SFX
E030	D	New Voyage	SFX
E031	D	Sweep-n-Drop	SFX
E032	D	Space Gliders	SFX
E033	D	Ask For Directions	SFX
E034	D	Steam Sweeps	SFX
E035	D	Distant Ice	SFX
E036	D	The Great Wall	SFX
E037	S	Cosmic Frisbee	SFX
E038	D	Ominous Orch Pad/Hit SW1	SFX
E039	D	Crypt-on	SFX
E040	D	Close the Blast Doors	SFX
E041	D	Short SAW Arp	Short Decay/Hit
E042	D	Short SQUARE Arp	Short Decay/Hit
E043	D	Bright Synth Hits	Short Decay/Hit
E044	S	Metal Arp	Short Decay/Hit
E045	D	Goober Uber Alles	Short Decay/Hit
E046	D	Tech-Blip	Short Decay/Hit
E047	D	Synth Chord Hit	Short Decay/Hit
E048	D	Synth Hitter	Short Decay/Hit
E049	D	Mega Synth Hit	Short Decay/Hit
E050	D	Hit The Road!	Short Decay/Hit
E051	D	Hevy LO-FI Synth Hits	Short Decay/Hit
E052	D	Tinkle Hit	Short Decay/Hit
E053	D	Dance/House Hits	Short Decay/Hit
E054	D	Sky Boy	Short Decay/Hit
E055	D	R&B Planet	Short Decay/Hit
E056	D	We All Fall Down	Short Decay/Hit
E057	D	Lo<->Hi Hit	Short Decay/Hit
E058	S	Brass Hit (Maj/HipHop)	Short Decay/Hit
E059	D	Stereo Power Hit	Short Decay/Hit
E060	D	Mega Orch Hit	Short Decay/Hit
E061	S	Multi Orch Hits	Short Decay/Hit
E062	@	Studio Standard Kit	Drums
E063	@	Jazz/Brush Kit	Drums
E064	@	Acoustic Pop Kit	Drums

↑ S: single program, D: double program,  
@: drums program

#		Name	Category
E065	@	Wild Rock Kit	Drums
E066	@	Processed Kit	Drums
E067	@	Electro Rock Kit	Drums
E068	@	Insane FX Kit	Drums
E069	@	Nu Style Kit	Drums
E070	@	Hip Hop Kit	Drums
E071	@	Tricki Kit	Drums
E072	@	Mashed Kit	Drums
E073	@	Drum'n'Bass Kit	Drums
E074	@	House Kit	Drums
E075	@	Trance Kit	Drums
E076	@	Hard House Kit	Drums
E077	@	Psycho/Chill Kit	Drums
E078	@	Down Low Rap Kit	Drums
E079	@	Low bit Kit	Drums
E080	@	Vinyl Loop Kit	Drums
E081	@	DJ/BeatBox Kit	Drums
E082	@	Rap/Gospel Kit	Drums
E083	@	Industry/Vocal Kit	Drums
E084	@	Original Perc. Kit	Drums
E085	@	Brazilian Perc. Kit	Drums
E086	@	Cuban Perc. Kit	Drums
E087	@	Conga Variation Kit	Drums
E088	@	Misc. Perc. Kit	Drums
E089	@	Orch./Ethnic Kit	Drums
E090	@	BD/SD/CymKit 1 TA Knob4	Drums
E091	@	BD/SD/CymKit 2 TA Knob4	Drums
E092	D	New Mega Drum Hit	Drums
E093	D	China Gong (Tam Tam)	Drums
E094	D	Timpani Splits SW2 Roll	Drums
E095	S	Marktree	Drums

↑ S: single program, D: double program,  
@: drums program

## Bank G / g(1)...g(9) / g(d)

#	Name	Category
GM001	S Acoustic Piano	Keyboard
g(1)001	S Acoustic Piano w	Keyboard
g(2)001	S Acoustic Piano d	Keyboard
GM002	S Bright Piano	Keyboard
g(1)002	S Bright Piano w	Keyboard
GM003	S El.Grand Piano	Keyboard
g(1)003	S El.Grand Piano w	Keyboard
GM004	D Honkey-Tonk	Keyboard
g(1)004	D Honkey-Tonk w	Keyboard
GM005	S Electric Piano 1	Keyboard
g(1)005	D Detuned E.Piano1	Keyboard
g(2)005	D ElectricPiano1 v	Keyboard
g(3)005	S 60's E.Piano	Keyboard
GM006	S Electric Piano 2	Keyboard
g(1)006	D Detuned E.Piano2	Keyboard
g(2)006	D ElectricPiano2 v	Keyboard
g(3)006	D E.Piano Legend	Keyboard
g(4)006	D E.Piano Phase	Keyboard
GM007	D Harpsichord	Keyboard
g(1)007	D Harpsi. oct-mix	Keyboard
g(2)007	S Harpsichord w	Keyboard
g(3)007	D Harpsi. key-off	Keyboard
GM008	D Clavi.	Keyboard
g(1)008	S Pulse Clavi.	Keyboard
GM009	S Celesta	Bell/Mallet
GM010	D Glockenspiel	Bell/Mallet
GM011	S Music Box	Bell/Mallet
GM012	S Vibraphone	Bell/Mallet
g(1)012	S Vibraphone w	Bell/Mallet
GM013	S Marimba	Bell/Mallet
g(1)013	S Marimba w	Bell/Mallet
GM014	S Xylophone	Bell/Mallet
GM015	S Tubular Bells	Bell/Mallet
g(1)015	D Church Bell	Bell/Mallet
g(2)015	D Carillon	Bell/Mallet
GM016	S Santur	Bell/Mallet
GM017	S Drawbar Organ 1	Organ
g(1)017	D Det.DrawbarOrgan	Organ
g(2)017	S Italian60'sOrgan	Organ
g(3)017	D Drawbar Organ 2	Organ
GM018	S PercussiveOrgan1	Organ
g(1)018	D Det.Perc-Organ	Organ
g(2)018	D PercussiveOrgan2	Organ
GM019	S Rock Organ	Organ
GM020	S Church Organ	Organ
g(1)020	D Church Org Oct.	Organ
g(2)020	D Det.Church Org	Organ
GM021	S Reed Organ	Organ
g(1)021	D Puff Organ	Organ
GM022	D Accordion 1	Woodwind/Reed
g(1)022	S Accordion 2	Woodwind/Reed
GM023	S Harmonica	Woodwind/Reed
GM024	D Bandoneon	Woodwind/Reed
GM025	S Nylon Guitar 1	Guitar/Plucked
g(1)025	S Ukulele	Guitar/Plucked
g(2)025	D NylonGtr.key-off	Guitar/Plucked
g(3)025	S Nylon Guitar 2	Guitar/Plucked
GM026	S Steel Guitar	Guitar/Plucked
g(1)026	S 12-StringsGuitar	Guitar/Plucked
g(2)026	D Mandolin	Guitar/Plucked
g(3)026	S Steel Gtr. Body	Guitar/Plucked
GM027	S Jazz Guitar	Guitar/Plucked
g(1)027	S Pedal Steel Gtr.	Guitar/Plucked
GM028	S Clean Guitar	Guitar/Plucked
g(1)028	D Detuned Clean Gt	Guitar/Plucked
g(2)028	D Mid Tone Guitar	Guitar/Plucked
GM029	S Muted Guitar	Guitar/Plucked

↑ S: single program, D: double program,  
 @: drums program

#	Name	Category
g(1)029	S Funky Guitar	Guitar/Plucked
g(2)029	D Muted Guitar v	Guitar/Plucked
g(3)029	D Jazz Man	Guitar/Plucked
GM030	S Overdrive Guitar	Guitar/Plucked
g(1)030	S Guitar Pinch	Guitar/Plucked
GM031	S DistortionGuitar	Guitar/Plucked
g(1)031	D Feedback Guitar	Guitar/Plucked
g(2)031	S Dist. Rhythm Gtr	Guitar/Plucked
GM032	S Guitar Harmonics	Guitar/Plucked
g(1)032	S Guitar Feedback	Guitar/Plucked
GM033	S Acoustic Bass	Bass/Synth Bass
GM034	S Fingered Bass	Bass/Synth Bass
g(1)034	D Finger Slap Bass	Bass/Synth Bass
GM035	S Picked Bass	Bass/Synth Bass
GM036	S Fretless Bass	Bass/Synth Bass
GM037	S Slap Bass 1	Bass/Synth Bass
GM038	S Slap Bass 2	Bass/Synth Bass
GM039	D Synth Bass 1	Bass/Synth Bass
g(1)039	D Warm Synth Bass	Bass/Synth Bass
g(2)039	D Synth Bass 3	Bass/Synth Bass
g(3)039	D Clavi Bass	Bass/Synth Bass
g(4)039	D Hammer	Bass/Synth Bass
GM040	S Synth Bass 2	Bass/Synth Bass
g(1)040	D Synth Bass 4	Bass/Synth Bass
g(2)040	D Rubber Bass	Bass/Synth Bass
g(3)040	S Attack Pulse	Bass/Synth Bass
GM041	S Violin	Strings
g(1)041	S Slow Violin	Strings
GM042	S Viola	Strings
GM043	S Cello	Strings
GM044	S Contrabass	Strings
GM045	S Tremolo Strings	Strings
GM046	S Pizzicato Str.	Strings
GM047	S Orchestral Harp	Guitar/Plucked
g(1)047	D Yang Chin	Bell/Mallet
GM048	S Timpani	Drums
GM049	S Strings	Strings
g(1)049	D Strings & Brass	Strings
g(2)049	D 60's Strings	Strings
GM050	S Slow Strings	Strings
GM051	D Synth Strings 1	Strings
g(1)051	D Synth Strings 3	Strings
GM052	S Synth Strings 2	Strings
GM053	S Choir Aahs 1	Vocal/Airy
g(1)053	S Choir Aahs 2	Vocal/Airy
GM054	S Voice Oohs	Vocal/Airy
g(1)054	D Humming	Vocal/Airy
GM055	S Synth Vox	Vocal/Airy
g(1)055	S Analog Voice	Vocal/Airy
GM056	D Orchestra Hit	Short Decay/Hit
g(1)056	D Bass Hit Plus	Short Decay/Hit
g(2)056	D 6th Hit	Short Decay/Hit
g(3)056	D Euro Hit	Short Decay/Hit
GM057	S Trumpet	Brass
g(1)057	S Soft Trumpet	Brass
GM058	S Trombone 1	Brass
g(1)058	D Trombone 2	Brass
g(2)058	S Bright Trombone	Brass
GM059	S Tuba	Brass
GM060	S Muted Trumpet 1	Brass
g(1)060	S Muted Trumpet 2	Brass
GM061	S French Horn	Brass
g(1)061	D Warm French Horn	Brass
GM062	S Brass Section 1	Brass
g(1)062	D Brass Section 2	Brass
GM063	D Synth Brass 1	FastSynth
g(1)063	D Synth Brass 3	FastSynth

↑ S: single program, D: double program,  
 @: drums program

## Voice Name List

#	Name	Category
g(2)063	D Analog Brass 1	FastSynth
g(3)063	D Jump Brass	FastSynth
GM064	S Synth Brass 2	FastSynth
g(1)064	D Synth Brass 4	FastSynth
g(2)064	D Analog Brass 2	FastSynth
GM065	S Soprano Sax	Woodwind/Reed
GM066	S Alto Sax	Woodwind/Reed
GM067	S Tenor Sax	Woodwind/Reed
GM068	S Baritone Sax	Woodwind/Reed
GM069	S Oboe	Woodwind/Reed
GM070	S English Horn	Woodwind/Reed
GM071	S Bassoon	Woodwind/Reed
GM072	S Clarinet	Woodwind/Reed
GM073	S Piccolo	Woodwind/Reed
GM074	S Flute	Woodwind/Reed
GM075	S Recorder	Woodwind/Reed
GM076	S Pan Flute	Woodwind/Reed
GM077	D Blown Bottle	Woodwind/Reed
GM078	D Shakuhachi	Woodwind/Reed
GM079	S Whistle	Woodwind/Reed
GM080	S Ocarina	Woodwind/Reed
GM081	D Detuned Square	FastSynth
g(1)081	S Simple Square	LeadSynth
g(2)081	S Simple Sine	LeadSynth
GM082	D Detuned Sawtooth	FastSynth
g(1)082	S Simple Sawtooth	LeadSynth
g(2)082	D Sawtooth + Pulse	LeadSynth
g(3)082	D D Sawtooth	LeadSynth
g(4)082	D Sequenced Analog	Short Decay/Hit
GM083	D Synth Calliope	FastSynth
GM084	D Chiff Lead	FastSynth
GM085	D Charang	LeadSynth
g(1)085	D Wire Lead	LeadSynth
GM086	D Air Voice	Vocal/Airy
GM087	D 5th Sawtooth	LeadSynth
GM088	S Bass & Lead	LeadSynth
g(1)088	D Soft Wurl	LeadSynth
GM089	D Fantasia	FastSynth
GM090	S Warm Pad	SlowSynth
g(1)090	D Sine Pad	SlowSynth
GM091	D Polyphonic Synth	FastSynth
GM092	D Space Voice	Vocal/Airy
g(1)092	D Itopia	Vocal/Airy
GM093	D Bowed Glass	SlowSynth
GM094	D Metallic Pad	SlowSynth
GM095	D Halo Pad	Vocal/Airy
GM096	S Sweep Pad	SlowSynth
GM097	D Ice Rain	FastSynth
GM098	D Sound Track	SlowSynth
GM099	D Crystal	Bell/Mallet
g(1)099	S Synth Mallet	FastSynth
GM100	D Atmosphere	FastSynth
GM101	D Brightness	FastSynth
GM102	D Goblins	MotionSynth
GM103	S Echo Drops	FastSynth
g(1)103	D Echo Bell	FastSynth
g(2)103	D Echo Pan	FastSynth
GM104	D Star Theme	FastSynth
GM105	S Sitar 1	Guitar/Plucked
g(1)105	D Sitar 2	Guitar/Plucked
GM106	S Banjo	Guitar/Plucked
GM107	S Shamisen	Guitar/Plucked
GM108	S Koto	Guitar/Plucked
g(1)108	D Taisho Koto	Guitar/Plucked
GM109	S Kalimba	Bell/Mallet
GM110	D Bagpipe	Woodwind/Reed
GM111	S Fiddle	Strings
GM112	S Shanai	Woodwind/Reed

↑ S: single program, D: double program,  
@: drums program

#	Name	Category
GM113	D Tinkle Bell	Bell/Mallet
GM114	S Agogo	Drums
GM115	D Steel Drums	Bell/Mallet
GM116	S Woodblock	Drums
g(1)116	S Castanets	Drums
GM117	S Taiko	Drums
g(1)117	S Concert BassDrum	Drums
GM118	S Melodic Tom 1	Drums
g(1)118	D Melodic Tom 2	Drums
GM119	S Synth Drum	Drums
g(1)119	S Analog Tom	Drums
g(2)119	S Electric Drum	Drums
GM120	S Reverse Cymbal	SFX
GM121	S Gtr.Fret Noise	Guitar/Plucked
g(1)121	S Gtr.CuttingNoise	Guitar/Plucked
g(2)121	S Bass String Slap	Bass/Synth Bass
GM122	S Breath Noise	Vocal/Airy
g(1)122	S Flute Key Click	SFX
GM123	D Seashore	SFX
g(1)123	D Rain	SFX
g(2)123	S Thunder	SFX
g(3)123	D Wind	SFX
g(4)123	S Stream	SFX
g(5)123	D Bubble	SFX
GM124	D Bird Tweet 1	SFX
g(1)124	S Dog	SFX
g(2)124	S Horse Gallop	SFX
g(3)124	S Bird Tweet 2	SFX
GM125	S Telephone Ring 1	SFX
g(2)125	S Door Creaking	SFX
g(3)125	S Door Slamming	SFX
g(4)125	S Scratch	SFX
g(5)125	S Wind Chime	Drums
g(1)125	S Telephone Ring 2	SFX
GM126	D Helicopter	SFX
g(1)126	D Car Engine	SFX
g(2)126	S Car Stop	SFX
g(3)126	S Car Pass	SFX
g(4)126	S Car Crash	SFX
g(5)126	D Siren	SFX
g(6)126	S Train	SFX
g(7)126	D Jetplane	SFX
g(8)126	D Starship	SFX
g(9)126	D Burst Noise	SFX
GM127	D Applause	SFX
g(1)127	S Laughing	SFX
g(2)127	S Screaming	SFX
g(3)127	S Punch	SFX
g(4)127	S Heart Beat	SFX
g(5)127	S Footsteps	SFX
GM128	S Gun Shot	SFX
g(1)128	S Machine Gun	SFX
g(2)128	D Lasergun	SFX
g(3)128	S Explosion	SFX
g(d)001	@ STANDARD Kit	Drums
g(d)009	@ ROOM Kit	Drums
g(d)017	@ POWER Kit	Drums
g(d)025	@ ELECTRONIC Kit	Drums
g(d)026	@ ANALOG Kit	Drums
g(d)033	@ JAZZ Kit	Drums
g(d)041	@ BRUSH Kit	Drums
g(d)049	@ ORCHESTRA Kit	Drums
g(d)057	@ SFX Kit	SFX

↑ S: single program, D: double program,  
@: drums program



## Drum Kit

### 00 (INT): Studio Standard Kit

key		Drumsample	Bus	Ex
E0	High	ROM Mono, 0584: Hi-Hat Dance 26	L/R	Off
	M Hi	ROM Mono, 0583: Hi-Hat Dance 25		
	M Lo	ROM Mono, 0582: Hi-Hat Dance 24		
F0	High	ROM Mono, 0585: Hi-Hat Dance 27	L/R	Off
	M Hi	ROM Mono, 0584: Hi-Hat Dance 26		
	M Lo	ROM Mono, 0584: Hi-Hat Dance 26		
F#0	High	ROM Mono, 0563: Hi-Hat Dance 05	L/R	Off
	M Hi	ROM Mono, 0560: Hi-Hat Dance 02		
G0	High	ROM Mono, 0583: Hi-Hat Dance 25	L/R	Off
	M Hi	ROM Mono, 0582: Hi-Hat Dance 24		
G#0	High	ROM Mono, 0828: Timbales Hi-Paila f	L/R	Off
	M Hi	ROM Mono, 0922: Shaker 2 d-Pull		
A0	High	ROM Mono, 0600: Hi-Hat-Crisp Open	L/R	Off
	M Hi	ROM Mono, 0595: Hi-Hat-Chili		
	M Lo	ROM Mono, 0602: Hi-Hat-Whispy		
A#0	High	ROM Mono, 0596: Hi-Hat-Vintage	L/R	Off
	M Hi	ROM Mono, 0596: Hi-Hat-Vintage		
B0	High	ROM Mono, 0543: Hi-Hat Basic 4-FootOpen	L/R	Off
	M Hi	ROM Mono, 0540: Hi-Hat Basic 4-Closed 1		
	M Lo	ROM Mono, 0542: Hi-Hat Basic 4-Foot		
C1	High	ROM Mono, 0130: BD-Dance 58	IFX2	Off
	M Hi	ROM Mono, 0277: SD-Dry		
C#1	High	ROM Mono, 0090: BD-Dance 20	IFX2	Off
D1	High	ROM Mono, 0130: BD-Dance 58	IFX2	Off
D#1	High	ROM Mono, 0135: BD-Dance 63	IFX2	Off
E1	High	ROM Mono, 0141: BD-Dance 69	IFX2	Off
F1	High	ROM Stereo, 0067: SD-Roll-Open 1 a -L	IFX1	9
	M Hi	ROM Stereo, 0067: SD-Roll-Open 1 a -L		
F#1	High	ROM Stereo, 0069: SD-Roll-Closed 1 a -L	IFX1	9
	M Hi	ROM Stereo, 0069: SD-Roll-Closed 1 a -L		
G1	High	ROM Stereo, 0068: SD-Roll-Open 2 -L	IFX1	9
	M Hi	ROM Stereo, 0068: SD-Roll-Open 2 -L		
G#1	High	ROM Stereo, 0070: SD-Roll-Closed 3 b -L	IFX1	9
	M Hi	ROM Stereo, 0070: SD-Roll-Closed 3 b -L		
A1	High	ROM Mono, 0682: Drumstick Hit	IFX1	Off
A#1	High	ROM Mono, 0640: Cymbal Reverse 2	L/R	Off
B1	High	ROM Mono, 0265: SD-22-amb mf REV	IFX1	Off
C2	High	ROM Stereo, 0001: BD-01-amb ff -L	IFX2	Off
	M Hi	ROM Stereo, 0000: BD-01-amb f -L		
	M Lo	ROM Stereo, 0000: BD-01-amb f -L		
C#2	High	ROM Stereo, 0005: BD-03-amb f -L	IFX2	Off
	M Hi	ROM Stereo, 0004: BD-03-amb mf -L		
	M Lo	ROM Stereo, 0004: BD-03-amb mf -L		
D2	High	ROM Stereo, 0009: BD-05-amb f -L	IFX2	Off
	M Hi	ROM Stereo, 0008: BD-05-amb mf -L		
D#2	High	ROM Stereo, 0013: BD-07-dry f -L	IFX2	Off
	M Hi	ROM Stereo, 0012: BD-07-dry mf -L		
	M Lo	ROM Stereo, 0012: BD-07-dry mf -L		
E2	High	ROM Stereo, 0017: BD-09-dry mf -L	IFX2	Off
	M Hi	ROM Stereo, 0017: BD-09-dry mf -L		
	M Lo	ROM Stereo, 0016: BD-09-dry mp -L		
	Low	ROM Stereo, 0016: BD-09-dry mp -L		
F2	High	ROM Stereo, 0019: SD-01-dry f -L	IFX1	Off
	M Hi	ROM Stereo, 0019: SD-01-dry f -L		
	M Lo	ROM Stereo, 0018: SD-01-dry mp -L		
F#2	High	ROM Stereo, 0027: SD-04-amb ff -L	IFX1	Off
	M Hi	ROM Stereo, 0026: SD-04-amb mf -L		
	M Lo	ROM Stereo, 0025: SD-04-amb mp -L		
	Low	ROM Stereo, 0024: SD-04-amb p -L		
G2	High	ROM Stereo, 0037: SD-10-dry ff -L	IFX1	Off
	M Hi	ROM Stereo, 0036: SD-10-dry f -L		
	M Lo	ROM Stereo, 0036: SD-10-dry f -L		
G#2	High	ROM Stereo, 0039: SD-11-dry ff -L	IFX1	Off
	M Hi	ROM Stereo, 0039: SD-11-dry ff -L		
	M Lo	ROM Stereo, 0038: SD-11-dry mf -L		
	Low	ROM Stereo, 0038: SD-11-dry mf -L		
A2	High	ROM Stereo, 0049: SD-14-dry ff -L	IFX1	Off
	M Hi	ROM Stereo, 0048: SD-14-dry f -L		
	M Lo	ROM Stereo, 0048: SD-14-dry f -L		

key		Drumsample	Bus	Ex
A#2	High	ROM Stereo, 0053: SD-16-dry ff -L	IFX1	Off
	M Hi	ROM Stereo, 0052: SD-16-dry f -L		
	M Lo	ROM Stereo, 0052: SD-16-dry f -L		
B2	High	ROM Stereo, 0003: BD-02-amb f -L	IFX2	Off
	M Hi	ROM Stereo, 0002: BD-02-amb mf -L		
	M Lo	ROM Stereo, 0002: BD-02-amb mf -L		
C3	High	ROM Stereo, 0007: BD-04-amb f -L	IFX2	Off
	M Hi	ROM Stereo, 0007: BD-04-amb f -L		
	M Lo	ROM Stereo, 0006: BD-04-amb mf -L		
C#3	High	ROM Stereo, 0071: SD-Sidestick 1 mf -L	IFX1	Off
	M Hi	ROM Stereo, 0071: SD-Sidestick 1 mf -L		
D3	High	ROM Stereo, 0045: SD-12-dry fff -L	IFX1	Off
	M Hi	ROM Stereo, 0043: SD-12-dry f -L		
	M Lo	ROM Stereo, 0040: SD-12-dry p -L		
	Low	ROM Stereo, 0041: SD-12-dry mp -L		
D#3	High	ROM Stereo, 0115: Hand Claps 2-g -L	IFX3	Off
	M Hi	ROM Stereo, 0114: Hand Claps 2-d -L		
E3	M Lo	ROM Stereo, 0113: Hand Claps 2-a -L	IFX1	Off
	High	ROM Stereo, 0045: SD-12-dry fff -L		
	M Hi	ROM Stereo, 0044: SD-12-dry ff -L		
	M Lo	ROM Stereo, 0042: SD-12-dry mf -L		
F3	High	ROM Stereo, 0041: SD-12-dry mp -L	IFX2	Off
	M Hi	ROM Stereo, 0075: Tom Basic Lo f -L		
F#3	M Lo	ROM Stereo, 0074: Tom Basic Lo mf -L	L/R	1
	High	ROM Mono, 0507: Hi-Hat Basic 1-Closed ff		
	M Hi	ROM Mono, 0506: Hi-Hat Basic 1-Closed f		
	M Lo	ROM Mono, 0505: Hi-Hat Basic 1-Closed mf		
G3	Low	ROM Mono, 0504: Hi-Hat Basic 1-Closed mp	IFX2	Off
	High	ROM Stereo, 0075: Tom Basic Lo f -L		
	M Hi	ROM Stereo, 0074: Tom Basic Lo mf -L		
G#3	M Lo	ROM Stereo, 0074: Tom Basic Lo mf -L	L/R	1
	High	ROM Mono, 0511: Hi-Hat Basic 1-Pedal ff		
	M Hi	ROM Mono, 0510: Hi-Hat Basic 1-Pedal f		
	M Lo	ROM Mono, 0509: Hi-Hat Basic 1-Pedal mf		
A3	Low	ROM Mono, 0508: Hi-Hat Basic 1-Pedal mp	IFX2	Off
	High	ROM Stereo, 0077: Tom Basic MidLo f -L		
	M Hi	ROM Stereo, 0076: Tom Basic MidLo mf -L		
A#3	M Lo	ROM Stereo, 0076: Tom Basic MidLo mf -L	L/R	1
	High	ROM Mono, 0514: Hi-Hat Basic 1-Open ff		
	M Hi	ROM Mono, 0513: Hi-Hat Basic 1-Open f		
	M Lo	ROM Mono, 0512: Hi-Hat Basic 1-Open mf		
B3	Low	ROM Mono, 0512: Hi-Hat Basic 1-Open mf	IFX2	Off
	High	ROM Stereo, 0079: Tom Basic MidHi f -L		
	M Hi	ROM Stereo, 0078: Tom Basic MidHi mf -L		
C4	M Lo	ROM Stereo, 0078: Tom Basic MidHi mf -L	IFX2	Off
	High	ROM Stereo, 0081: Tom Basic Hi mf -L		
C#4	M Hi	ROM Stereo, 0080: Tom Basic Hi mp -L	L/R	Off
	M Lo	ROM Stereo, 0080: Tom Basic Hi mp -L		
D4	High	ROM Stereo, 0101: Crash Cymbal 6 mf -L	IFX2	Off
	M Hi	ROM Stereo, 0101: Crash Cymbal 6 mf -L		
D#4	High	ROM Stereo, 0081: Tom Basic Hi mf -L	L/R	Off
	M Hi	ROM Stereo, 0080: Tom Basic Hi mp -L		
E4	High	ROM Stereo, 0106: Ride Cymbal 3 f -L	L/R	Off
	M Hi	ROM Stereo, 0105: Ride Cymbal 3 mf -L		
F4	High	ROM Stereo, 0111: China Cymbal 1 -L	L/R	Off
	M Hi	ROM Stereo, 0111: China Cymbal 1 -L		
F#4	High	ROM Stereo, 0109: Ride Cymbal 7-Cup -L	IFX3	Off
	M Hi	ROM Stereo, 0109: Ride Cymbal 7-Cup -L		
G4	M Lo	ROM Mono, 0877: Tambourine 2-Accent	L/R	Off
	High	ROM Mono, 0874: Tambourine 2-Push		
G#4	M Lo	ROM Mono, 0875: Tambourine 2-Pull a	IFX3	Off
	High	ROM Stereo, 0112: Splash Cymbal 1 ff -L		
A4	M Hi	ROM Stereo, 0112: Splash Cymbal 1 ff -L	L/R	Off
	High	ROM Mono, 0830: Cowbell 2		
A#4	M Hi	ROM Mono, 0831: Cowbell 3	IFX3	Off
	High	ROM Stereo, 0102: Crash Cymbal 7 f -L		
	M Hi	ROM Stereo, 0102: Crash Cymbal 7 f -L		
	High	ROM Mono, 0853: Vibra-Slap	IFX3	Off

key		Drumsample	Bus	Ex
B4	High	ROM Stereo,0104:Ride Cymbal 1 f-L	L/R	Off
	M Hi	ROM Stereo,0103:Ride Cymbal 1 mf -L		
	M Lo	ROM Stereo,0103:Ride Cymbal 1 mf -L		
C5	High	ROM Mono,0756:Bongo 1 Hi-Open f	IFX3	Off
	M Hi	ROM Mono,0755:Bongo 1 Hi-Open mf		
	M Lo	ROM Mono,0756:Bongo 1 Hi-Open f		
C#5	High	ROM Mono,0744:Bongo 1 Lo-Muffled f	IFX3	Off
	M Hi	ROM Mono,0743:Bongo 1 Lo-Muffled mp		
	M Lo	ROM Mono,0745:Bongo 1 Lo-Closed		
D5	High	ROM Mono,0728:Conga Hi-ClosedSlap	IFX3	Off
	M Hi	ROM Mono,0727:Conga Hi-Closed		
D#5	High	ROM Mono,0723:Conga Hi-OpenSlap	IFX3	Off
	M Hi	ROM Mono,0720:Conga Hi-Open mf		
	M Lo	ROM Mono,0721:Conga Hi-Open f		
	Low	ROM Mono,0719:Conga Hi-Open mp		
E5	High	ROM Mono,0709:Conga Lo-OpenSlap	IFX3	Off
	M Hi	ROM Mono,0707:Conga Lo-Open mf		
	M Lo	ROM Mono,0708:Conga Lo-Open f		
F5	High	ROM Mono,0823:Timbales Hi-RimShot ff	IFX3	Off
	M Hi	ROM Mono,0821:Timbales Hi-RimShot mf		
	M Lo	ROM Mono,0820:Timbales Hi-Edge		
F#5	High	ROM Mono,0811:Timbales Lo-Edge f	IFX3	Off
	M Hi	ROM Mono,0808:Timbales Lo-Open mp		
	M Lo	ROM Mono,0810:Timbales Lo-Edge mf		
G5	High	ROM Mono,0935:Agogo 2 Hi-Open	IFX3	Off
	M Hi	ROM Mono,0936:Agogo-Belltone		
G#5	High	ROM Mono,0934:Agogo 2 Lo-Open	IFX3	Off
	M Hi	ROM Mono,0936:Agogo-Belltone		
A5	High	ROM Mono,0892:Cabasa 1 L a-Up	IFX3	Off
	M Hi	ROM Mono,0891:Cabasa 1 L a-Down		
	M Lo	ROM Mono,0894:Cabasa 1 L b-Up		
A#5	High	ROM Mono,0848:Maracas 2-Pull b	IFX3	Off
	M Hi	ROM Mono,0847:Maracas 2-Pull a		
	M Lo	ROM Mono,0846:Maracas 2-Push b		
	Low	ROM Mono,0845:Maracas 2-Push a		
B5	High	ROM Mono,0969:Whistle 2	IFX3	2
	M Hi	ROM Mono,0970:Whistle 3		
C6	High	ROM Mono,0971:Whistle 4-Long	IFX3	2
	M Hi	ROM Mono,0972:Whistle 4-Short		
C#6	High	ROM Mono,0852:Guiro-Short b	IFX3	3
	M Hi	ROM Mono,0851:Guiro-Short a		
D6	High	ROM Mono,0850:Guiro-Long b	IFX3	3
	M Hi	ROM Mono,0849:Guiro-Long a		
D#6	High	ROM Mono,0840:Claves Hi b	IFX3	Off
	M Hi	ROM Mono,0839:Claves Hi a		
E6	High	ROM Mono,1053:Wood Block 4 a	IFX3	Off
	M Hi	ROM Mono,1054:Wood Block 4 b		
F6	High	ROM Mono,1051:Wood Block 3 a	IFX3	Off
	M Hi	ROM Mono,1052:Wood Block 3 b		
F#6	High	ROM Mono,0967:Cuica Hi c	IFX3	4
	M Hi	ROM Mono,0965:Cuica Hi a		
	M Lo	ROM Mono,0966:Cuica Hi b		
G6	High	ROM Mono,0962:Cuica Lo a	IFX3	4
	M Hi	ROM Mono,0962:Cuica Lo a		
G#6	High	ROM Mono,0947:Triangle 1 S-Mute a	IFX3	5
	M Hi	ROM Mono,0948:Triangle 1 S-Mute b		
A6	High	ROM Mono,0945:Triangle 1 S-Roll b	IFX3	5
	M Hi	ROM Mono,0944:Triangle 1 S-Roll a		
A#6	High	ROM Mono,0912:Shaker 1-Slow b	IFX3	Off
	M Hi	ROM Mono,0911:Shaker 1-Slow a		
B6	High	ROM Mono,1075:Marc Tree	IFX3	Off
C7	High	ROM Mono,0143:BD-Dance 71	IFX2	Off
C#7	High	ROM Mono,0603:Hi-Hat Dance 34	L/R	7
D7	High	ROM Mono,0417:SD-Dance 77	IFX1	Off
D#7	High	ROM Mono,0604:Hi-Hat Dance 35	L/R	7
E7	High	ROM Mono,0636:Crash Dance 4	L/R	Off
F7	High	ROM Mono,1186:Dance SynCowbell	IFX3	Off
F#7	High	ROM Mono,1146:Dance Claps 01	IFX3	Off
G7	High	ROM Mono,1187:Dance SynMaraca	IFX3	Off
G#7	High	ROM Mono,0315:SD-Orch.Roll	IFX1	8
A7	High	ROM Mono,0316:SD-Orchestral	IFX1	8
A#7	High	ROM Mono,1074:Bell Tree-Fast	L/R	Off
	M Hi	ROM Mono,1073:Bell Tree-Slow		

key		Drumsample	Bus	Ex
B7	High	ROM Mono,1418:Stadium	L/R	Off
C8	High	ROM Mono,1419:Applause	L/R	Off





Key		Drumsample	Bus	Ex
C#5	High	ROM Mono,0744: Bongo 1 Lo-Muffled f	L/R	Off
	M Hi	ROM Mono,0743: Bongo 1 Lo-Muffled mp		
	M Lo	ROM Mono,0745: Bongo 1 Lo-Closed		
D5	High	ROM Mono,0728: Conga Hi-ClosedSlap	L/R	Off
	M Hi	ROM Mono,0727: Conga Hi-Closed		
D#5	High	ROM Mono,0723: Conga Hi-OpenSlap	L/R	Off
	M Hi	ROM Mono,0720: Conga Hi-Open mf		
	M Lo	ROM Mono,0721: Conga Hi-Open f		
	Low	ROM Mono,0719: Conga Hi-Open mp		
E5	High	ROM Mono,0709: Conga Lo-OpenSlap	L/R	Off
	M Hi	ROM Mono,0707: Conga Lo-Open mf		
	M Lo	ROM Mono,0708: Conga Lo-Open f		
F5	High	ROM Mono,0823: Timbales Hi-RimShot ff	L/R	Off
	M Hi	ROM Mono,0821: Timbales Hi-RimShot mf		
	M Lo	ROM Mono,0820: Timbales Hi-Edge		
F#5	High	ROM Mono,0811: Timbales Lo-Edge f	L/R	Off
	M Hi	ROM Mono,0808: Timbales Lo-Open mp		
	M Lo	ROM Mono,0810: Timbales Lo-Edge mf		
G5	High	ROM Mono,0935: Agogo 2 Hi-Open	L/R	Off
	M Hi	ROM Mono,0936: Agogo-Belltone		
G#5	High	ROM Mono,0934: Agogo 2 Lo-Open	L/R	Off
	M Hi	ROM Mono,0936: Agogo-Belltone		
A5	High	ROM Mono,0892: Cabasa 1 L a-Up	L/R	Off
	M Hi	ROM Mono,0891: Cabasa 1 L a-Down		
	M Lo	ROM Mono,0894: Cabasa 1 L b-Up		
A#5	High	ROM Mono,0848: Maracas 2-Pull b	L/R	Off
	M Hi	ROM Mono,0847: Maracas 2-Pull a		
	M Lo	ROM Mono,0846: Maracas 2-Push b		
	Low	ROM Mono,0845: Maracas 2-Push a		
B5	High	ROM Mono,0969: Whistle 2	L/R	2
	M Hi	ROM Mono,0970: Whistle 3		
C6	High	ROM Mono,0971: Whistle 4-Long	L/R	2
	M Hi	ROM Mono,0972: Whistle 4-Short		
C#6	High	ROM Mono,0852: Guiro-Short b	L/R	3
	M Hi	ROM Mono,0851: Guiro-Short a		
D6	High	ROM Mono,0850: Guiro-Long b	L/R	3
	M Hi	ROM Mono,0849: Guiro-Long a		
D#6	High	ROM Mono,0840: Claves Hi b	L/R	Off
	M Hi	ROM Mono,0839: Claves Hi a		
E6	High	ROM Mono,1053: Wood Block 4 a	L/R	Off
	M Hi	ROM Mono,1054: Wood Block 4 b		
F6	High	ROM Mono,1051: Wood Block 3 a	L/R	Off
	M Hi	ROM Mono,1052: Wood Block 3 b		
F#6	High	ROM Mono,0967: Cuica Hi c	L/R	4
	M Hi	ROM Mono,0965: Cuica Hi a		
	M Lo	ROM Mono,0966: Cuica Hi b		
G6	High	ROM Mono,0962: Cuica Lo a	L/R	4
	M Hi	ROM Mono,0962: Cuica Lo a		
G#6	High	ROM Mono,0947: Triangle 1 S-Mute a	L/R	5
	M Hi	ROM Mono,0948: Triangle 1 S-Mute b		
A6	High	ROM Mono,0945: Triangle 1 S-Roll b	L/R	5
	M Hi	ROM Mono,0944: Triangle 1 S-Roll a		
A#6	High	ROM Mono,0912: Shaker 1-Slow b	L/R	Off
	M Hi	ROM Mono,0911: Shaker 1-Slow a		
B6	High	ROM Mono,1075: Marc Tree	L/R	Off
C7	High	ROM Mono,0143: BD-Dance 71	IFX2	Off
C#7	High	ROM Mono,0603: Hi-Hat Dance 34	IFX3	7
D7	High	ROM Mono,0417: SD-Dance 77	IFX1	Off
D#7	High	ROM Mono,0604: Hi-Hat Dance 35	IFX3	7
E7	High	ROM Mono,0636: Crash Dance 4	IFX3	Off
F7	High	ROM Mono,1186: Dance SynCowbell	L/R	Off
F#7	High	ROM Mono,1146: Dance Claps 01	L/R	Off
G7	High	ROM Mono,1187: Dance SynMaraca	L/R	Off
G#7	High	ROM Mono,0315: SD-Orch.Roll	IFX1	8
A7	High	ROM Mono,0316: SD-Orchestral	IFX1	8
A#7	High	ROM Mono,1074: Bell Tree-Fast	L/R	Off
	M Hi	ROM Mono,1073: Bell Tree-Slow		
B7	High	ROM Mono,1418: Stadium	L/R	Off
C8	High	ROM Mono,1419: Applause	L/R	Off



Key		Drumsample	Bus	Ex
D#5	High	ROM Mono,0723: Conga Hi-OpenSlap	IFX3	Off
	M Hi	ROM Mono,0720: Conga Hi-Open mf		
	M Lo	ROM Mono,0721: Conga Hi-Open f		
	Low	ROM Mono,0719: Conga Hi-Open mp		
E5	High	ROM Mono,0709: Conga Lo-OpenSlap	IFX3	Off
	M Hi	ROM Mono,0707: Conga Lo-Open mf		
	M Lo	ROM Mono,0708: Conga Lo-Open f		
F5	High	ROM Mono,0823: Timbales Hi-RimShot ff	IFX3	Off
	M Hi	ROM Mono,0821: Timbales Hi-RimShot mf		
	M Lo	ROM Mono,0820: Timbales Hi-Edge		
F#5	High	ROM Mono,0811: Timbales Lo-Edge f	IFX3	Off
	M Hi	ROM Mono,0808: Timbales Lo-Open mp		
	M Lo	ROM Mono,0810: Timbales Lo-Edge mf		
G5	High	ROM Mono,0935: Agogo 2 Hi-Open	IFX3	Off
	M Hi	ROM Mono,0936: Agogo-Belltone		
G#5	High	ROM Mono,0934: Agogo 2 Lo-Open	IFX3	Off
	M Hi	ROM Mono,0936: Agogo-Belltone		
A5	High	ROM Mono,0892: Cabasa 1 L a-Up	IFX3	Off
	M Hi	ROM Mono,0891: Cabasa 1 L a-Down		
	M Lo	ROM Mono,0894: Cabasa 1 L b-Up		
A#5	High	ROM Mono,0848: Maracas 2-Pull b	IFX3	Off
	M Hi	ROM Mono,0847: Maracas 2-Pull a		
	M Lo	ROM Mono,0846: Maracas 2-Push b		
	Low	ROM Mono,0845: Maracas 2-Push a		
B5	High	ROM Mono,0969: Whistle 2	IFX3	2
	M Hi	ROM Mono,0970: Whistle 3		
C6	High	ROM Mono,0971: Whistle 4-Long	IFX3	2
	M Hi	ROM Mono,0972: Whistle 4-Short		
C#6	High	ROM Mono,0852: Guiro-Short b	IFX3	3
	M Hi	ROM Mono,0851: Guiro-Short a		
D6	High	ROM Mono,0850: Guiro-Long b	IFX3	3
	M Hi	ROM Mono,0849: Guiro-Long a		
D#6	High	ROM Mono,0840: Claves Hi b	IFX3	Off
	M Hi	ROM Mono,0839: Claves Hi a		
E6	High	ROM Mono,1053: Wood Block 4 a	IFX3	Off
	M Hi	ROM Mono,1054: Wood Block 4 b		
F6	High	ROM Mono,1051: Wood Block 3 a	IFX3	Off
	M Hi	ROM Mono,1052: Wood Block 3 b		
F#6	High	ROM Mono,0967: Cuica Hi c	IFX3	4
	M Hi	ROM Mono,0965: Cuica Hi a		
	M Lo	ROM Mono,0966: Cuica Hi b		
G6	High	ROM Mono,0962: Cuica Lo a	IFX3	4
	M Hi	ROM Mono,0962: Cuica Lo a		
G#6	High	ROM Mono,0947: Triangle 1 S-Mute a	IFX3	5
	M Hi	ROM Mono,0948: Triangle 1 S-Mute b		
A6	High	ROM Mono,0945: Triangle 1 S-Roll b	IFX3	5
	M Hi	ROM Mono,0944: Triangle 1 S-Roll a		
A#6	High	ROM Mono,0912: Shaker 1-Slow b	IFX3	Off
	M Hi	ROM Mono,0911: Shaker 1-Slow a		
B6	High	ROM Mono,1075: Marc Tree	IFX3	Off
C7	High	ROM Mono,0143: BD-Dance 71	IFX2	Off
C#7	High	ROM Mono,0603: Hi-Hat Dance 34	L/R	7
D7	High	ROM Mono,0417: SD-Dance 77	IFX1	Off
D#7	High	ROM Mono,0604: Hi-Hat Dance 35	L/R	7
E7	High	ROM Mono,0636: Crash Dance 4	L/R	Off
F7	High	ROM Mono,1186: Dance SynCowbell	IFX3	Off
F#7	High	ROM Mono,1146: Dance Claps 01	IFX3	Off
G7	High	ROM Mono,1187: Dance SynMaraca	IFX3	Off
G#7	High	ROM Mono,0315: SD-Orch.Roll	IFX1	8
A7	High	ROM Mono,0316: SD-Orchestral	IFX1	8
A#7	High	ROM Mono,1074: Bell Tree-Fast	IFX3	Off
	M Hi	ROM Mono,1073: Bell Tree-Slow		
B7	High	ROM Mono,1418: Stadium	IFX3	Off
C8	High	ROM Mono,1419: Applause	IFX3	Off





04 (INT): Acoustic Pop Kit

Key		Drumsample	Bus	Ex
E0	High	ROM Mono,0584: Hi-Hat Dance 26	IFX3	Off
	M Hi	ROM Mono,0583: Hi-Hat Dance 25		
	M Lo	ROM Mono,0582: Hi-Hat Dance 24		
F0	High	ROM Mono,0585: Hi-Hat Dance 27	IFX3	Off
	M Hi	ROM Mono,0584: Hi-Hat Dance 26		
	M Lo	ROM Mono,0584: Hi-Hat Dance 26		
F#0	High	ROM Mono,0563: Hi-Hat Dance 05	IFX3	Off
	M Hi	ROM Mono,0560: Hi-Hat Dance 02		
G0	High	ROM Mono,0583: Hi-Hat Dance 25	IFX3	Off
	M Hi	ROM Mono,0582: Hi-Hat Dance 24		
G#0	High	ROM Mono,0828: Timbales Hi-Paila f	IFX3	Off
	M Hi	ROM Mono,0922: Shaker 2 d-Pull		
A0	High	ROM Mono,0600: Hi-Hat-Crisp Open	IFX3	Off
	M Hi	ROM Mono,0595: Hi-Hat-Chili		
	M Lo	ROM Mono,0602: Hi-Hat-Whispy		
A#0	High	ROM Mono,0596: Hi-Hat-Vintage	IFX3	Off
	M Hi	ROM Mono,0596: Hi-Hat-Vintage		
B0	High	ROM Mono,0543: Hi-Hat Basic 4-FootOpen	IFX3	Off
	M Hi	ROM Mono,0540: Hi-Hat Basic 4-Closed 1		
	M Lo	ROM Mono,0542: Hi-Hat Basic 4-Foot		
C1	High	ROM Mono,0130: BD-Dance 58	IFX2	Off
	M Hi	ROM Mono,0277: SD-Dry		
C#1	High	ROM Mono,0090: BD-Dance 20	IFX2	Off
	M Hi	ROM Mono,0990: Djembe L-ClosedSlap		
D1	High	ROM Mono,0130: BD-Dance 58	IFX2	Off
D#1	High	ROM Mono,0135: BD-Dance 63	IFX2	Off
E1	High	ROM Mono,0141: BD-Dance 69	IFX2	Off
F1	High	ROM Mono,0298: SD-Roll-Open 1 a -L	IFX1	9
	M Hi	ROM Mono,0298: SD-Roll-Open 1 a -L		
F#1	High	ROM Mono,0306: SD-Roll-Closed 1 a -L	IFX1	9
	M Hi	ROM Mono,0306: SD-Roll-Closed 1 a -L		
G1	High	ROM Mono,0302: SD-Roll-Open 2 -L	IFX1	9
	M Hi	ROM Mono,0302: SD-Roll-Open 2 -L		
G#1	High	ROM Mono,0311: SD-Roll-Closed 3 b -L	IFX1	9
	M Hi	ROM Mono,0311: SD-Roll-Closed 3 b -L		
A1	High	ROM Mono,0682: Drumstick Hit	IFX1	Off
A#1	High	ROM Mono,0640: Cymbal Reverse 2	IFX3	Off
B1	High	ROM Mono,0265: SD-22-amb mf REV	IFX1	Off
	M Hi	ROM Mono,0030: BD-07-dry mf -L		
C2	M Hi	ROM Mono,0048: BD-Dry	IFX2	Off
	M Lo	ROM Mono,0032: BD-07-dry f -L		
	High	ROM Mono,0043: BD-09-dry mf -L		
C#2	M Hi	ROM Mono,0100: BD-Dance 30	IFX2	Off
	M Lo	ROM Mono,0041: BD-09-dry mp -L		
	High	ROM Mono,0020: BD-05-amb f -L		
D2	M Hi	ROM Mono,0107: BD-Dance 37	IFX2	Off
	M Lo	ROM Mono,0018: BD-05-amb mf -L		
D#2	High	ROM Mono,0002: BD-01-amb ff -L	IFX2	Off
	M Hi	ROM Mono,0083: BD-Dance 13		
	M Lo	ROM Mono,0000: BD-01-amb f -L		
E2	High	ROM Mono,0043: BD-09-dry mf -L	IFX2	Off
	M Hi	ROM Mono,0128: BD-Dance 56		
	M Lo	ROM Mono,0041: BD-09-dry mp -L		
F2	High	ROM Mono,0179: SD-06-dry f -L	IFX1	Off
	M Hi	ROM Mono,0358: SD-Dance 32		
	M Lo	ROM Mono,0177: SD-06-dry mf -L		
F#2	High	ROM Mono,0167: SD-04-amb mf -L	IFX1	Off
	M Hi	ROM Mono,0277: SD-Dry		
	M Lo	ROM Mono,0165: SD-04-amb mp -L		
G2	High	ROM Mono,0196: SD-10-dry ff -L	IFX1	Off
	M Hi	ROM Mono,0277: SD-Dry		
	M Lo	ROM Mono,0194: SD-10-dry f -L		
G#2	High	ROM Mono,0220: SD-13-dry mf -L	IFX1	Off
	M Hi	ROM Mono,0277: SD-Dry		
	M Lo	ROM Mono,0220: SD-13-dry mf -L		
A2	High	ROM Mono,0267: SD-23-dry mf	IFX1	Off
	M Hi	ROM Mono,0395: SD-Dance 69		
	M Lo	ROM Mono,0266: SD-23-dry mp		
A#2	High	ROM Mono,0236: SD-16-dry ff -L	IFX1	Off
	M Hi	ROM Mono,0234: SD-16-dry f -L		
	M Lo	ROM Mono,0231: SD-15-dry mf		
	Low	ROM Mono,0229: SD-15-dry mp -L		
B2	High	ROM Mono,0006: BD-02-amb f -L	IFX2	Off
	M Hi	ROM Mono,0004: BD-02-amb mf -L		
	M Lo	ROM Mono,0004: BD-02-amb mf -L		

Key		Drumsample	Bus	Ex
C3	High	ROM Mono,0049: BD-Soft	IFX2	Off
	M Hi	ROM Mono,0078: BD-Dance 11		
	M Lo	ROM Mono,0049: BD-Soft		
C#3	High	ROM Mono,0317: SD-Sidestick 1 mf -L	IFX1	Off
D3	High	ROM Mono,0225: SD-14-dry f -L	IFX1	Off
	M Hi	ROM Mono,0281: SD-Atomic		
	M Lo	ROM Mono,0225: SD-14-dry f -L		
D#3	High	ROM Mono,0688: Hand Claps 2-c	IFX1	Off
	M Hi	ROM Mono,0692: Hand Claps 2-f		
	M Lo	ROM Mono,0688: Hand Claps 2-c		
E3	High	ROM Mono,0259: SD-21-dry ff -L	IFX1	Off
	M Hi	ROM Mono,0378: SD-Dance 52		
	M Lo	ROM Mono,0259: SD-21-dry ff -L		
F3	High	ROM Mono,0425: Tom Basic Lo ff	IFX2	Off
	M Hi	ROM Mono,0423: Tom Basic Lo f -L		
	M Lo	ROM Mono,0421: Tom Basic Lo mf -L		
F#3	High	ROM Mono,0507: Hi-Hat Basic 1-Closed ff	IFX3	1
	M Hi	ROM Mono,0506: Hi-Hat Basic 1-Closed f		
	M Lo	ROM Mono,0505: Hi-Hat Basic 1-Closed mf		
	Low	ROM Mono,0504: Hi-Hat Basic 1-Closed mp		
G3	High	ROM Mono,0425: Tom Basic Lo ff	IFX2	Off
	M Hi	ROM Mono,0423: Tom Basic Lo f -L		
	M Lo	ROM Mono,0421: Tom Basic Lo mf -L		
G#3	High	ROM Mono,0511: Hi-Hat Basic 1-Pedal ff	IFX3	1
	M Hi	ROM Mono,0510: Hi-Hat Basic 1-Pedal f		
	M Lo	ROM Mono,0509: Hi-Hat Basic 1-Pedal mf		
	Low	ROM Mono,0508: Hi-Hat Basic 1-Pedal mp		
A3	High	ROM Mono,0428: Tom Basic MidLo f -L	IFX2	Off
	M Hi	ROM Mono,0428: Tom Basic MidLo f -L		
	M Lo	ROM Mono,0426: Tom Basic MidLo mf -L		
A#3	High	ROM Mono,0514: Hi-Hat Basic 1-Open ff	IFX3	1
	M Hi	ROM Mono,0513: Hi-Hat Basic 1-Open f		
	M Lo	ROM Mono,0512: Hi-Hat Basic 1-Open mf		
	Low	ROM Mono,0512: Hi-Hat Basic 1-Open mf		
B3	High	ROM Mono,0435: Tom Basic MidHi ff	IFX2	Off
	M Hi	ROM Mono,0433: Tom Basic MidHi f -L		
	M Lo	ROM Mono,0430: Tom Basic MidHi mp		
C4	High	ROM Mono,0435: Tom Basic MidHi ff	IFX2	Off
	M Hi	ROM Mono,0431: Tom Basic MidHi mf -L		
	M Lo	ROM Mono,0430: Tom Basic MidHi mp		
C#4	High	ROM Mono,0625: Crash Cymbal 6 ff	IFX3	Off
	M Hi	ROM Mono,0623: Crash Cymbal 6 mf -L		
D4	High	ROM Mono,0440: Tom Basic Hi f	IFX2	Off
	M Hi	ROM Mono,0438: Tom Basic Hi mf -L		
D#4	M Lo	ROM Mono,0436: Tom Basic Hi mp -L	IFX3	Off
	High	ROM Mono,0653: Ride Cymbal 3 ff		
	M Hi	ROM Mono,0651: Ride Cymbal 3 f -L		
E4	M Lo	ROM Mono,0649: Ride Cymbal 3 mf -L	IFX3	Off
	Low	ROM Mono,0648: Ride Cymbal 3 mp		
	High	ROM Mono,0673: China Cymbal 2		
F4	M Hi	ROM Mono,0671: China Cymbal 1 -L	IFX3	Off
	High	ROM Mono,0663: Ride Cymbal 7-Cup -L		
F#4	M Hi	ROM Mono,0663: Ride Cymbal 7-Cup -L	L/R	Off
	High	ROM Mono,0877: Tambourine 2-Accent		
	M Lo	ROM Mono,0874: Tambourine 2-Push		
G4	M Lo	ROM Mono,0875: Tambourine 2-Pull a	IFX3	Off
	High	ROM Mono,0678: Splash Cymbal 1 ff -L		
	M Hi	ROM Mono,0677: Splash Cymbal 1 f		
	M Lo	ROM Mono,0676: Splash Cymbal 1 mf		
G#4	Low	ROM Mono,0675: Splash Cymbal 1 mp	L/R	Off
	High	ROM Mono,0830: Cowbell 2		
	M Hi	ROM Mono,0831: Cowbell 3		
A4	High	ROM Mono,0627: Crash Cymbal 7 f -L	IFX3	Off
	M Hi	ROM Mono,0626: Crash Cymbal 7 mf		
	M Lo	ROM Mono,0626: Crash Cymbal 7 mf		
A#4	High	ROM Mono,0853: Vibra-Slap	L/R	Off
	High	ROM Mono,0646: Ride Cymbal 1 ff		
B4	M Hi	ROM Mono,0644: Ride Cymbal 1 f -L	IFX3	Off
	M Lo	ROM Mono,0642: Ride Cymbal 1 mf -L		
	Low	ROM Mono,0641: Ride Cymbal 1 mp		
C5	High	ROM Mono,0756: Bongo 1 Hi-Open f	L/R	Off
	M Hi	ROM Mono,0755: Bongo 1 Hi-Open mf		
	M Lo	ROM Mono,0756: Bongo 1 Hi-Open f		

Key		Drumsample	Bus	Ex
C#5	High	ROM Mono,0744:Bongo 1 Lo-Muffled f	L/R	Off
	M Hi	ROM Mono,0743:Bongo 1 Lo-Muffled mp		
	M Lo	ROM Mono,0745:Bongo 1 Lo-Closed		
D5	High	ROM Mono,0728:Conga Hi-ClosedSlap	L/R	Off
	M Hi	ROM Mono,0727:Conga Hi-Closed		
D#5	High	ROM Mono,0723:Conga Hi-OpenSlap	L/R	Off
	M Hi	ROM Mono,0720:Conga Hi-Open mf		
	M Lo	ROM Mono,0721:Conga Hi-Open f		
	Low	ROM Mono,0719:Conga Hi-Open mp		
E5	High	ROM Mono,0709:Conga Lo-OpenSlap	L/R	Off
	M Hi	ROM Mono,0707:Conga Lo-Open mf		
	M Lo	ROM Mono,0708:Conga Lo-Open f		
F5	High	ROM Mono,0823:Timbales Hi-RimShot ff	L/R	Off
	M Hi	ROM Mono,0821:Timbales Hi-RimShot mf		
	M Lo	ROM Mono,0820:Timbales Hi-Edge		
F#5	High	ROM Mono,0811:Timbales Lo-Edge f	L/R	Off
	M Hi	ROM Mono,0808:Timbales Lo-Open mp		
	M Lo	ROM Mono,0810:Timbales Lo-Edge mf		
G5	High	ROM Mono,0935:Agogo 2 Hi-Open	L/R	Off
	M Hi	ROM Mono,0936:Agogo-Belltone		
G#5	High	ROM Mono,0934:Agogo 2 Lo-Open	L/R	Off
	M Hi	ROM Mono,0936:Agogo-Belltone		
A5	High	ROM Mono,0892:Cabasa 1 L a-Up	L/R	Off
	M Hi	ROM Mono,0891:Cabasa 1 L a-Down		
	M Lo	ROM Mono,0894:Cabasa 1 L b-Up		
A#5	High	ROM Mono,0848:Maracas 2-Pull b	L/R	Off
	M Hi	ROM Mono,0847:Maracas 2-Pull a		
	M Lo	ROM Mono,0846:Maracas 2-Push b		
	Low	ROM Mono,0845:Maracas 2-Push a		
B5	High	ROM Mono,0969:Whistle 2	L/R	2
	M Hi	ROM Mono,0970:Whistle 3		
C6	High	ROM Mono,0971:Whistle 4-Long	L/R	2
	M Hi	ROM Mono,0972:Whistle 4-Short		
C#6	High	ROM Mono,0852:Guiro-Short b	L/R	3
	M Hi	ROM Mono,0851:Guiro-Short a		
D6	High	ROM Mono,0850:Guiro-Long b	L/R	3
	M Hi	ROM Mono,0849:Guiro-Long a		
D#6	High	ROM Mono,0840:Claves Hi b	L/R	Off
	M Hi	ROM Mono,0839:Claves Hi a		
E6	High	ROM Mono,1053:Wood Block 4 a	L/R	Off
	M Hi	ROM Mono,1054:Wood Block 4 b		
F6	High	ROM Mono,1051:Wood Block 3 a	L/R	Off
	M Hi	ROM Mono,1052:Wood Block 3 b		
F#6	High	ROM Mono,0967:Cuica Hi c	L/R	4
	M Hi	ROM Mono,0965:Cuica Hi a		
	M Lo	ROM Mono,0966:Cuica Hi b		
G6	High	ROM Mono,0962:Cuica Lo a	L/R	4
	M Hi	ROM Mono,0962:Cuica Lo a		
G#6	High	ROM Mono,0947:Triangle 1 S-Mute a	L/R	5
	M Hi	ROM Mono,0948:Triangle 1 S-Mute b		
A6	High	ROM Mono,0945:Triangle 1 S-Roll b	L/R	5
	M Hi	ROM Mono,0944:Triangle 1 S-Roll a		
A#6	High	ROM Mono,0912:Shaker 1-Slow b	L/R	Off
	M Hi	ROM Mono,0911:Shaker 1-Slow a		
B6	High	ROM Mono,1075:Marc Tree	L/R	Off
C7	High	ROM Mono,0143:BD-Dance 71	IFX2	Off
C#7	High	ROM Mono,0603:Hi-Hat Dance 34	IFX3	7
D7	High	ROM Mono,0417:SD-Dance 77	IFX1	Off
D#7	High	ROM Mono,0604:Hi-Hat Dance 35	IFX3	7
E7	High	ROM Mono,0636:Crash Dance 4	IFX3	Off
F7	High	ROM Mono,1186:Dance SynCowbell	L/R	Off
F#7	High	ROM Mono,1146:Dance Claps 01	L/R	Off
G7	High	ROM Mono,1187:Dance SynMaraca	L/R	Off
G#7	High	ROM Mono,0315:SD-Orch.Roll	IFX1	8
A7	High	ROM Mono,0316:SD-Orchestral	IFX1	8
A#7	High	ROM Mono,1074:Bell Tree-Fast	L/R	Off
	M Hi	ROM Mono,1073:Bell Tree-Slow		
B7	High	ROM Mono,1418:Stadium	L/R	Off
C8	High	ROM Mono,1419:Applause	L/R	Off

**05 (INT): Wild Rock Kit**

Key		Drumsample	Bus	Ex
E0	High	ROM Mono,0584: Hi-Hat Dance 26	IFX3	Off
	M Hi	ROM Mono,0583: Hi-Hat Dance 25		
	M Lo	ROM Mono,0582: Hi-Hat Dance 24		
F0	High	ROM Mono,0585: Hi-Hat Dance 27	IFX3	Off
	M Hi	ROM Mono,0584: Hi-Hat Dance 26		
	M Lo	ROM Mono,0584: Hi-Hat Dance 26		
F#0	High	ROM Mono,0563: Hi-Hat Dance 05	IFX3	Off
	M Hi	ROM Mono,0560: Hi-Hat Dance 02		
G0	High	ROM Mono,0583: Hi-Hat Dance 25	IFX3	Off
	M Hi	ROM Mono,0582: Hi-Hat Dance 24		
G#0	High	ROM Mono,0828: Timbales Hi-Paila f	IFX3	Off
	M Hi	ROM Mono,0922: Shaker 2 d-Pull		
A0	High	ROM Mono,0600: Hi-Hat-Crisp Open	IFX3	Off
	M Hi	ROM Mono,0595: Hi-Hat-Chili		
	M Lo	ROM Mono,0602: Hi-Hat-Whispy		
A#0	High	ROM Mono,0596: Hi-Hat-Vintage	L/R	Off
	M Hi	ROM Mono,0596: Hi-Hat-Vintage		
B0	High	ROM Mono,0543: Hi-Hat Basic 4-FootOpen	L/R	Off
	M Hi	ROM Mono,0540: Hi-Hat Basic 4-Closed 1		
	M Lo	ROM Mono,0542: Hi-Hat Basic 4-Foot		
C1	High	ROM Mono,0314: SD-Dance 58	IFX2	Off
	M Hi	ROM Mono,0277: SD-Dry		
C#1	High	ROM Mono,0090: BD-Dance 20	IFX2	Off
D1	High	ROM Mono,0130: BD-Dance 58	IFX2	Off
D#1	High	ROM Mono,0135: BD-Dance 63	IFX2	Off
E1	High	ROM Mono,0141: BD-Dance 69	IFX2	Off
F1	High	ROM Mono,0313: SD-Roll-Closed 4	IFX1	9
	M Hi	ROM Mono,0313: SD-Roll-Closed 4		
F#1	High	ROM Mono,0311: SD-Roll-Closed 3 b -L	IFX1	9
	M Hi	ROM Mono,0311: SD-Roll-Closed 3 b -L		
G1	High	ROM Mono,0309: SD-Roll-Closed 2	IFX1	9
	M Hi	ROM Mono,0309: SD-Roll-Closed 2		
G#1	High	ROM Mono,0314: SD-Roll-Closed 5	IFX1	9
	M Hi	ROM Mono,0314: SD-Roll-Closed 5		
A1	High	ROM Mono,0682: Drumstick Hit	IFX1	Off
A#1	High	ROM Mono,0640: Cymbal Reverse 2	IFX3	Off
B1	High	ROM Mono,0265: SD-22-amb mf REV	IFX1	Off
C2	High	ROM Mono,0002: BD-01-amb ff -L	IFX2	Off
	M Hi	ROM Mono,0000: BD-01-amb f -L		
C#2	High	ROM Mono,0036: BD-08-dry f -L	IFX2	Off
	M Hi	ROM Mono,0034: BD-08-dry mf -L		
D2	High	ROM Mono,0020: BD-05-amb f -L	IFX2	Off
	M Hi	ROM Mono,0018: BD-05-amb mf -L		
D#2	High	ROM Mono,0024: BD-06-dry f -L	IFX2	Off
	M Hi	ROM Mono,0022: BD-06-dry mp -L		
E2	High	ROM Mono,0032: BD-07-dry f -L	IFX2	Off
	M Hi	ROM Mono,0030: BD-07-dry mf -L		
F2	High	ROM Mono,0263: SD-22-dry f	IFX1	Off
	M Hi	ROM Mono,0264: SD-22-amb mf		
F#2	High	ROM Mono,0179: SD-06-dry f -L	IFX1	Off
	M Hi	ROM Mono,0177: SD-06-dry mf -L		
G2	High	ROM Mono,0189: SD-09-dry ff -L	IFX1	Off
	M Hi	ROM Mono,0187: SD-09-dry f -L		
G#2	High	ROM Mono,0272: SD-24-dry ff -L	IFX1	Off
	M Hi	ROM Mono,0270: SD-24-dry f -L		
	M Lo	ROM Mono,0269: SD-24-dry mp		
	Low	ROM Mono,0268: SD-23-dry GhostRoll		
A2	High	ROM Mono,0267: SD-23-dry mf	IFX1	Off
	M Hi	ROM Mono,0266: SD-23-dry mp		
	M Lo	ROM Mono,0268: SD-23-dry GhostRoll		
A#2	High	ROM Mono,0262: SD-21-amb ff	IFX1	Off
	M Hi	ROM Mono,0261: SD-21-amb f		
B2	High	ROM Mono,0015: BD-04-amb f -L	IFX2	Off
	M Hi	ROM Mono,0013: BD-04-amb mf -L		
C3	High	ROM Mono,0043: BD-09-dry mf -L	IFX2	Off
	M Hi	ROM Mono,0041: BD-09-dry mp -L		
C#3	High	ROM Mono,0319: SD-Sidestick 1 f	IFX1	Off
	M Hi	ROM Mono,0317: SD-Sidestick 1 mf -L		
D3	High	ROM Mono,0170: SD-04-amb ff -L	IFX1	Off
	M Hi	ROM Mono,0169: SD-04-amb f		
	M Lo	ROM Mono,0167: SD-04-amb mf -L		
	Low	ROM Mono,0165: SD-04-amb mp -L		
D#3	High	ROM Mono,0693: Hand Claps 2-g -L	IFX2	Off
	M Hi	ROM Mono,0689: Hand Claps 2-d -L		
	M Lo	ROM Mono,0685: Hand Claps 2-a -L		

Key		Drumsample	Bus	Ex
E3	High	ROM Mono,0250: SD-20-dry f	IFX1	Off
	M Hi	ROM Mono,0249: SD-20-dry mp		
	M Lo	ROM Mono,0251: SD-20-dry GhostRoll		
F3	High	ROM Mono,0446: Tom Vintage Lo ff	IFX3	Off
	M Hi	ROM Mono,0445: Tom Vintage Lo f		
	M Lo	ROM Mono,0444: Tom Vintage Lo mf		
	Low	ROM Mono,0443: Tom Vintage Lo mp		
F#3	High	ROM Mono,0534: Hi-Hat Heavy 2-Closed ff	L/R	1
	M Hi	ROM Mono,0533: Hi-Hat Heavy 2-Closed f		
	M Lo	ROM Mono,0532: Hi-Hat Heavy 2-Closed mf		
	Low	ROM Mono,0531: Hi-Hat Heavy 2-Closed mp		
G3	High	ROM Mono,0451: Tom Vintage Mid ff -L	IFX3	Off
	M Hi	ROM Mono,0450: Tom Vintage Mid f		
	M Lo	ROM Mono,0448: Tom Vintage Mid mf -L		
	Low	ROM Mono,0447: Tom Vintage Mid mp		
G#3	High	ROM Mono,0539: Hi-Hat Heavy 2-FootOpen	L/R	1
	M Hi	ROM Mono,0538: Hi-Hat Heavy 2-Pedal f		
	M Lo	ROM Mono,0537: Hi-Hat Heavy 2-Pedal mf		
A3	High	ROM Mono,0457: Tom Vintage Hi ff -L	IFX3	Off
	M Hi	ROM Mono,0456: Tom Vintage Hi f		
	M Lo	ROM Mono,0454: Tom Vintage Hi mf -L		
	Low	ROM Mono,0453: Tom Vintage Hi mp		
A#3	High	ROM Mono,0536: Hi-Hat Heavy 2-Open f	L/R	1
	M Hi	ROM Mono,0535: Hi-Hat Heavy 2-Open mf		
B3	High	ROM Mono,0476: Tom Rock2-dry MidLo ff	IFX3	Off
	M Hi	ROM Mono,0475: Tom Rock2-dry MidLo mf		
C4	High	ROM Mono,0478: Tom Rock2-dry MidHi ff	IFX3	Off
	M Hi	ROM Mono,0477: Tom Rock2-dry MidHi mf		
C#4	High	ROM Mono,0619: Crash Cymbal 4 ff	L/R	Off
	M Hi	ROM Mono,0618: Crash Cymbal 4 f		
	M Lo	ROM Mono,0617: Crash Cymbal 4 mf		
	Low	ROM Mono,0616: Crash Cymbal 4 mp		
D4	High	ROM Mono,0480: Tom Rock2-dry Hi ff	IFX3	Off
	M Hi	ROM Mono,0479: Tom Rock2-dry Hi mf		
D#4	High	ROM Mono,0646: Ride Cymbal 1 ff	L/R	Off
	M Hi	ROM Mono,0644: Ride Cymbal 1 f -L		
	M Lo	ROM Mono,0642: Ride Cymbal 1 mf -L		
	Low	ROM Mono,0641: Ride Cymbal 1 mp		
E4	High	ROM Mono,0673: China Cymbal 2	L/R	Off
	M Hi	ROM Mono,0671: China Cymbal 1 -L		
F4	High	ROM Mono,0663: Ride Cymbal 7-Cup -L	L/R	Off
F#4	High	ROM Mono,0877: Tambourine 2-Accent	L/R	Off
	M Hi	ROM Mono,0874: Tambourine 2-Push		
	M Lo	ROM Mono,0875: Tambourine 2-Pull a		
G4	High	ROM Mono,0679: Splash Cymbal 1 ff -R	L/R	Off
	M Hi	ROM Mono,0677: Splash Cymbal 1 f		
	M Lo	ROM Mono,0676: Splash Cymbal 1 mf		
	Low	ROM Mono,0675: Splash Cymbal 1 mp		
G#4	High	ROM Mono,0830: Cowbell 2	L/R	Off
	M Hi	ROM Mono,0831: Cowbell 3		
A4	High	ROM Mono,0614: Crash Cymbal 2 ff	L/R	Off
	M Hi	ROM Mono,0612: Crash Cymbal 2 f -L		
A#4	High	ROM Mono,0853: Vibra-Slap	L/R	Off
B4	High	ROM Stereo,0104: Ride Cymbal 1 f -L	L/R	Off
	M Hi	ROM Stereo,0103: Ride Cymbal 1 mf -L		
	M Lo	ROM Stereo,0103: Ride Cymbal 1 mf -L		
C5	High	ROM Mono,0756: Bongo 1 Hi-Open f	L/R	Off
	M Hi	ROM Mono,0755: Bongo 1 Hi-Open mf		
	M Lo	ROM Mono,0756: Bongo 1 Hi-Open f		
C#5	High	ROM Mono,0744: Bongo 1 Lo-Muffled f	L/R	Off
	M Hi	ROM Mono,0743: Bongo 1 Lo-Muffled mp		
	M Lo	ROM Mono,0745: Bongo 1 Lo-Closed		
D5	High	ROM Mono,0728: Conga Hi-ClosedSlap	L/R	Off
	M Hi	ROM Mono,0727: Conga Hi-Closed		
D#5	High	ROM Mono,0723: Conga Hi-OpenSlap	L/R	Off
	M Hi	ROM Mono,0720: Conga Hi-Open mf		
	M Lo	ROM Mono,0721: Conga Hi-Open f		
E5	High	ROM Mono,0719: Conga Hi-Open mp	L/R	Off
	High	ROM Mono,0709: Conga Lo-OpenSlap		
	M Hi	ROM Mono,0707: Conga Lo-Open mf		
	M Lo	ROM Mono,0708: Conga Lo-Open f		
F5	High	ROM Mono,0823: Timbales Hi-RimShot ff	L/R	Off
	M Hi	ROM Mono,0821: Timbales Hi-RimShot mf		
	M Lo	ROM Mono,0820: Timbales Hi-Edge		



Key		Drumsample	Bus	Ex
F#5	High	ROM Mono,0811:Timbales Lo-Edge f	L/R	Off
	M Hi	ROM Mono,0808:Timbales Lo-Open mp		
	M Lo	ROM Mono,0810:Timbales Lo-Edge mf		
G5	High	ROM Mono,0935:Agogo 2 Hi-Open	L/R	Off
	M Hi	ROM Mono,0936:Agogo-Belltone		
G#5	High	ROM Mono,0934:Agogo 2 Lo-Open	L/R	Off
	M Hi	ROM Mono,0936:Agogo-Belltone		
A5	High	ROM Mono,0892: Cabasa 1 L a-Up	L/R	Off
	M Hi	ROM Mono,0891: Cabasa 1 L a-Down		
	M Lo	ROM Mono,0894: Cabasa 1 L b-Up		
A#5	High	ROM Mono,0848: Maracas 2-Pull b	L/R	Off
	M Hi	ROM Mono,0847: Maracas 2-Pull a		
	M Lo	ROM Mono,0846: Maracas 2-Push b		
	Low	ROM Mono,0845: Maracas 2-Push a		
B5	High	ROM Mono,0969:Whistle 2	L/R	2
	M Hi	ROM Mono,0970:Whistle 3		
C6	High	ROM Mono,0971:Whistle 4-Long	L/R	2
	M Hi	ROM Mono,0972:Whistle 4-Short		
C#6	High	ROM Mono,0852: Guiro-Short b	L/R	3
	M Hi	ROM Mono,0851: Guiro-Short a		
D6	High	ROM Mono,0850: Guiro-Long b	L/R	3
	M Hi	ROM Mono,0849: Guiro-Long a		
D#6	High	ROM Mono,0840: Claves Hi b	L/R	Off
	M Hi	ROM Mono,0839: Claves Hi a		
E6	High	ROM Mono,1053:Wood Block 4 a	L/R	Off
	M Hi	ROM Mono,1054:Wood Block 4 b		
F6	High	ROM Mono,1051:Wood Block 3 a	L/R	Off
	M Hi	ROM Mono,1052:Wood Block 3 b		
F#6	High	ROM Mono,0967: Cuica Hi c	L/R	4
	M Hi	ROM Mono,0965: Cuica Hi a		
	M Lo	ROM Mono,0966: Cuica Hi b		
G6	High	ROM Mono,0962: Cuica Lo a	L/R	4
	M Hi	ROM Mono,0962: Cuica Lo a		
G#6	High	ROM Mono,0947:Triangle 1 S-Mute a	L/R	5
	M Hi	ROM Mono,0948:Triangle 1 S-Mute b		
A6	High	ROM Mono,0945:Triangle 1 S-Roll b	L/R	5
	M Hi	ROM Mono,0944:Triangle 1 S-Roll a		
A#6	High	ROM Mono,0912:Shaker 1-Slow b	L/R	Off
	M Hi	ROM Mono,0911:Shaker 1-Slow a		
B6	High	ROM Mono,1075: Marc Tree	L/R	Off
C7	High	ROM Mono,143: BD-Dance 71	IFX2	Off
C#7	High	ROM Mono,0603: Hi-Hat Dance 34	L/R	7
D7	High	ROM Mono,0417: SD-Dance 77	IFX1	Off
D#7	High	ROM Mono,0604: Hi-Hat Dance 35	IFX3	7
E7	High	ROM Mono,0636: Crash Dance 4	IFX3	Off
F7	High	ROM Mono,1186: Dance SynCowbell	IFX3	Off
F#7	High	ROM Mono,1146: Dance Claps 01	IFX3	Off
G7	High	ROM Mono,1187: Dance SynMaraca	IFX3	Off
G#7	High	ROM Mono,0315: SD-Orch.Roll	IFX1	8
A7	High	ROM Mono,0316: SD-Orchestral	IFX1	8
A#7	High	ROM Mono,1074: Bell Tree-Fast	IFX3	Off
	M Hi	ROM Mono,1073: Bell Tree-Slow		
B7	High	ROM Mono,1418: Stadium	L/R	Off
C8	High	ROM Mono,1419: Applause	L/R	Off

## 06 (INT): New Processed Kit

Key		Drumsample	Bus	Ex
E0	High	ROM Mono,0584: Hi-Hat Dance 26	L/R	Off
	M Hi	ROM Mono,0583: Hi-Hat Dance 25		
	M Lo	ROM Mono,0582: Hi-Hat Dance 24		
F0	High	ROM Mono,0585: Hi-Hat Dance 27	L/R	Off
	M Hi	ROM Mono,0584: Hi-Hat Dance 26		
	M Lo	ROM Mono,0584: Hi-Hat Dance 26		
F#0	High	ROM Mono,0563: Hi-Hat Dance 05	L/R	Off
	M Hi	ROM Mono,0560: Hi-Hat Dance 02		
G0	High	ROM Mono,0583: Hi-Hat Dance 25	L/R	Off
	M Hi	ROM Mono,0582: Hi-Hat Dance 24		
G#0	High	ROM Mono,0828: Timbales Hi-Paila f	L/R	Off
	M Hi	ROM Mono,0922: Shaker 2 d-Pull		
A0	High	ROM Mono,0600: Hi-Hat-Crisp Open	L/R	Off
	M Hi	ROM Mono,0595: Hi-Hat-Chili		
	M Lo	ROM Mono,0602: Hi-Hat-Whispy		
A#0	High	ROM Mono,0596: Hi-Hat-Vintage	L/R	Off
	M Hi	ROM Mono,0596: Hi-Hat-Vintage		
B0	High	ROM Mono,0543: Hi-Hat Basic 4-FootOpen	L/R	Off
	M Hi	ROM Mono,0540: Hi-Hat Basic 4-Closed 1		
	M Lo	ROM Mono,0542: Hi-Hat Basic 4-Foot		
C1	High	ROM Mono,0130: BD-Dance 58	IFX2	Off
	M Hi	ROM Mono,0277: SD-Dry		
C#1	High	ROM Mono,0090: BD-Dance 20	IFX2	Off
D1	High	ROM Mono,0130: BD-Dance 58	IFX2	Off
D#1	High	ROM Mono,0135: BD-Dance 63	IFX2	Off
E1	High	ROM Mono,0141: BD-Dance 69	IFX2	Off
F1	High	ROM Mono,0313: SD-Roll-Closed 4	IFX1	9
	M Hi	ROM Mono,0313: SD-Roll-Closed 4		
F#1	High	ROM Mono,0305: SD-Roll-Open 3 b	IFX1	9
	M Hi	ROM Mono,0305: SD-Roll-Open 3 b		
G1	High	ROM Mono,0309: SD-Roll-Closed 2	IFX1	9
	M Hi	ROM Mono,0309: SD-Roll-Closed 2		
G#1	High	ROM Mono,0314: SD-Roll-Closed 5	IFX1	9
	M Hi	ROM Mono,0314: SD-Roll-Closed 5		
A1	High	ROM Mono,0682: Drumstick Hit	IFX1	Off
A#1	High	ROM Mono,0640: Cymbal Reverse 2	IFX1	Off
B1	High	ROM Mono,0265: SD-22-amb mf REV	IFX1	Off
C2	High	ROM Mono,0063: BD-Dance 02	IFX2	Off
	M Hi	ROM Mono,0038: BD-08-amb mf		
C#2	High	ROM Mono,0070: BD-Dance 06	IFX2	Off
D2	High	ROM Mono,0015: BD-04-amb f -L	IFX2	Off
	M Hi	ROM Mono,0013: BD-04-amb mf -L		
D#2	High	ROM Mono,0020: BD-05-amb f -L	IFX2	Off
	M Hi	ROM Mono,0018: BD-05-amb mf -L		
	M Lo	ROM Mono,0017: BD-05-amb mp		
E2	High	ROM Mono,0029: BD-06-amb ff	IFX2	Off
	M Hi	ROM Mono,0028: BD-06-amb f		
	M Lo	ROM Mono,0027: BD-06-amb mf		
	Low	ROM Mono,0026: BD-06-amb mp		
F2	High	ROM Mono,0179: SD-06-dry f -L	IFX1	Off
	M Hi	ROM Mono,0177: SD-06-dry mf -L		
F#2	High	ROM Mono,0182: SD-07-amb f	IFX1	Off
	M Hi	ROM Mono,0181: SD-07-amb mf		
G2	High	ROM Mono,0192: SD-09-amb ff	IFX1	Off
	M Hi	ROM Mono,0191: SD-09-amb f		
G#2	High	ROM Mono,0218: SD-12-amb fff	IFX1	Off
	M Hi	ROM Mono,0217: SD-12-amb f		
	M Lo	ROM Mono,0216: SD-12-amb mp		
A2	High	ROM Mono,0240: SD-17-dry f	IFX1	Off
	M Hi	ROM Mono,0239: SD-17-dry mf		
	M Lo	ROM Mono,0238: SD-17-dry mp		
	Low	ROM Mono,0242: SD-17-dry GhostRoll f		
A#2	High	ROM Mono,0253: SD-20-amb f	IFX1	Off
	M Hi	ROM Mono,0252: SD-20-amb mp		
B2	High	ROM Mono,0039: BD-08-amb f	IFX2	Off
	M Hi	ROM Mono,0038: BD-08-amb mf		
C3	High	ROM Mono,0064: BD-Dance 03	IFX2	Off
C#3	High	ROM Mono,0320: SD-Sidestick 2 mf	IFX1	Off
D3	High	ROM Mono,0247: SD-19-amb f	IFX1	Off
	M Hi	ROM Mono,0246: SD-19-amb mf		
	M Lo	ROM Mono,0245: SD-19-amb mp		
	Low	ROM Mono,0248: SD-19-amb GhostRoll		

Key		Drumsample	Bus	Ex
D#3	High	ROM Mono,0693: Hand Claps 2-g -L	IFX1	Off
	M Hi	ROM Mono,0689: Hand Claps 2-d -L		
	M Lo	ROM Mono,0685: Hand Claps 2-a -L		
E3	High	ROM Mono,0244: SD-18-amb ff	IFX1	Off
	M Hi	ROM Mono,0243: SD-18-amb f		
F3	High	ROM Mono,0484: Tom Rock2-amb Low	L/R	Off
F#3	High	ROM Mono,0528: Hi-Hat Heavy 1-Closed f	L/R	1
	M Hi	ROM Mono,0527: Hi-Hat Heavy 1-Closed mf		
	M Lo	ROM Mono,0526: Hi-Hat Heavy 1-Closed mp		
G3	High	ROM Mono,0485: Tom Rock2-amb MidLo	L/R	Off
	High	ROM Mono,0539: Hi-Hat Heavy 2-FootOpen		
G#3	M Hi	ROM Mono,0538: Hi-Hat Heavy 2-Pedal f	L/R	1
	M Lo	ROM Mono,0537: Hi-Hat Heavy 2-Pedal mf		
A3	High	ROM Mono,0481: Tom Rock1-amb Low	L/R	Off
A#3	High	ROM Mono,0536: Hi-Hat Heavy 2-Open f	L/R	1
	M Hi	ROM Mono,0535: Hi-Hat Heavy 2-Open mf		
B3	High	ROM Mono,0482: Tom Rock1-amb Mid	L/R	Off
C4	High	ROM Mono,0483: Tom Rock1-amb Hi	L/R	Off
C#4	High	ROM Mono,0625: Crash Cymbal 6 ff	IFX2	Off
	M Hi	ROM Mono,0623: Crash Cymbal 6 mf -L		
D4	High	ROM Mono,0483: Tom Rock1-amb Hi	L/R	Off
D#4	High	ROM Mono,0658: Ride Cymbal 5 f	IFX1	Off
	M Hi	ROM Mono,0657: Ride Cymbal 5 mf		
E4	High	ROM Mono,0673: China Cymbal 2	IFX1	Off
	M Hi	ROM Mono,0671: China Cymbal 1 -L		
F4	High	ROM Mono,0663: Ride Cymbal 7-Cup -L	IFX1	Off
F#4	High	ROM Mono,0877: Tambourine 2-Accent	IFX3	Off
	M Hi	ROM Mono,0874: Tambourine 2-Push		
	M Lo	ROM Mono,0875: Tambourine 2-Pull a		
G4	High	ROM Mono,0678: Splash Cymbal 1 ff -L	IFX1	Off
	M Hi	ROM Mono,0677: Splash Cymbal 1 f		
	M Lo	ROM Mono,0676: Splash Cymbal 1 mf		
	Low	ROM Mono,0675: Splash Cymbal 1 mp		
G#4	High	ROM Mono,0830: Cowbell 2	IFX3	Off
	M Hi	ROM Mono,0831: Cowbell 3		
A4	High	ROM Stereo,0102: Crash Cymbal 7 f -L	L/R	Off
	M Hi	ROM Stereo,0102: Crash Cymbal 7 f -L		
A#4	High	ROM Mono,0853: Vibra-Slap	IFX3	Off
B4	High	ROM Mono,0646: Ride Cymbal 1 ff	L/R	Off
	M Hi	ROM Mono,0644: Ride Cymbal 1 f -L		
	M Lo	ROM Mono,0642: Ride Cymbal 1 mf -L		
	Low	ROM Mono,0641: Ride Cymbal 1 mp		
C5	High	ROM Mono,0756: Bongo 1 Hi-Open f	IFX3	Off
	M Hi	ROM Mono,0755: Bongo 1 Hi-Open mf		
	M Lo	ROM Mono,0756: Bongo 1 Hi-Open f		
C#5	High	ROM Mono,0744: Bongo 1 Lo-Muffled f	IFX3	Off
	M Hi	ROM Mono,0743: Bongo 1 Lo-Muffled mp		
	M Lo	ROM Mono,0745: Bongo 1 Lo-Closed		
D5	High	ROM Mono,0728: Conga Hi-ClosedSlap	IFX3	Off
	M Hi	ROM Mono,0727: Conga Hi-Closed		
D#5	High	ROM Mono,0723: Conga Hi-OpenSlap	IFX3	Off
	M Hi	ROM Mono,0720: Conga Hi-Open mf		
	M Lo	ROM Mono,0721: Conga Hi-Open f		
	Low	ROM Mono,0719: Conga Hi-Open mp		
E5	High	ROM Mono,0709: Conga Lo-OpenSlap	IFX3	Off
	M Hi	ROM Mono,0707: Conga Lo-Open mf		
	M Lo	ROM Mono,0708: Conga Lo-Open f		
F5	High	ROM Mono,0823: Timbales Hi-RimShot ff	IFX3	Off
	M Hi	ROM Mono,0821: Timbales Hi-RimShot mf		
	M Lo	ROM Mono,0820: Timbales Hi-Edge		
F#5	High	ROM Mono,0811: Timbales Lo-Edge f	IFX3	Off
	M Hi	ROM Mono,0808: Timbales Lo-Open mp		
G5	M Lo	ROM Mono,0810: Timbales Lo-Edge mf	IFX3	Off
	High	ROM Mono,0935: Agogo 2 Hi-Open		
G#5	M Hi	ROM Mono,0936: Agogo-Belltone	IFX3	Off
	High	ROM Mono,0934: Agogo 2 Lo-Open		
A5	High	ROM Mono,0892: Cabasa 1 L a-Up	IFX3	Off
	M Hi	ROM Mono,0891: Cabasa 1 L a-Down		
	M Lo	ROM Mono,0894: Cabasa 1 L b-Up		
A#5	High	ROM Mono,0848: Maracas 2-Pull b	IFX3	Off
	M Hi	ROM Mono,0847: Maracas 2-Pull a		
	M Lo	ROM Mono,0846: Maracas 2-Push b		
	Low	ROM Mono,0845: Maracas 2-Push a		

Key		Drumsample	Bus	Ex
B5	High	ROM Mono,0969:Whistle 2	IFX3	2
	M Hi	ROM Mono,0970:Whistle 3		
C6	High	ROM Mono,0971:Whistle 4-Long	IFX3	2
	M Hi	ROM Mono,0972:Whistle 4-Short		
C#6	High	ROM Mono,0852:Guiro-Short b	IFX3	3
	M Hi	ROM Mono,0851:Guiro-Short a		
D6	High	ROM Mono,0850:Guiro-Long b	IFX3	3
	M Hi	ROM Mono,0849:Guiro-Long a		
D#6	High	ROM Mono,0840:Claves Hi b	IFX3	Off
	M Hi	ROM Mono,0839:Claves Hi a		
E6	High	ROM Mono,1053:Wood Block 4 a	IFX3	Off
	M Hi	ROM Mono,1054:Wood Block 4 b		
F6	High	ROM Mono,1051:Wood Block 3 a	IFX3	Off
	M Hi	ROM Mono,1052:Wood Block 3 b		
F#6	High	ROM Mono,0967:Cuica Hi c	IFX3	4
	M Hi	ROM Mono,0965:Cuica Hi a		
	M Lo	ROM Mono,0966:Cuica Hi b		
G6	High	ROM Mono,0962:Cuica Lo a	IFX3	4
	M Hi	ROM Mono,0962:Cuica Lo a		
G#6	High	ROM Mono,0947:Triangle 1 S-Mute a	IFX3	5
	M Hi	ROM Mono,0948:Triangle 1 S-Mute b		
A6	High	ROM Mono,0945:Triangle 1 S-Roll b	IFX3	5
	M Hi	ROM Mono,0944:Triangle 1 S-Roll a		
A#6	High	ROM Mono,0912:Shaker 1-Slow b	IFX3	Off
	M Hi	ROM Mono,0911:Shaker 1-Slow a		
B6	High	ROM Mono,1075:Marc Tree	IFX3	Off
C7	High	ROM Mono,0143:BD-Dance 71	IFX2	Off
C#7	High	ROM Mono,0603:Hi-Hat Dance 34	L/R	7
D7	High	ROM Mono,0417:SD-Dance 77	IFX1	Off
D#7	High	ROM Mono,0604:Hi-Hat Dance 35	L/R	7
E7	High	ROM Mono,0636:Crash Dance 4	L/R	Off
F7	High	ROM Mono,1186:Dance SynCowbell	IFX3	Off
F#7	High	ROM Mono,1146:Dance Claps 01	IFX3	Off
G7	High	ROM Mono,1187:Dance SynMaraca	IFX3	Off
G#7	High	ROM Mono,0315:SD-Orch.Roll	IFX1	8
A7	High	ROM Mono,0316:SD-Orchestral	IFX1	8
A#7	High	ROM Mono,1074: Bell Tree-Fast	IFX3	Off
	M Hi	ROM Mono,1073: Bell Tree-Slow		
B7	High	ROM Mono,1418:Stadium	IFX3	Off
C8	High	ROM Mono,1419:Applause	IFX3	Off

07 (INT): Electro Rock Kit

Key		Drumsample	Bus	Ex
C-1	High	ROM Mono, 1424: Click 1	L/R	Off
E0	High	ROM Mono, 0516: Hi-Hat Basic 2-Closed mf	L/R	Off
	M Hi	ROM Mono, 0515: Hi-Hat Basic 2-Closed mp		
F0	High	ROM Mono, 0526: Hi-Hat Heavy 1-Closed mp	L/R	13
F#0	High	ROM Mono, 0530: Hi-Hat Heavy 1-HalfOpen	L/R	13
G0	High	ROM Mono, 0541: Hi-Hat Basic 4-Closed 2	L/R	14
	M Hi	ROM Mono, 0540: Hi-Hat Basic 4-Closed 1		
G#0	High	ROM Mono, 0544: Hi-Hat Basic 4-Open 1	L/R	14
	M Hi	ROM Mono, 0545: Hi-Hat Basic 4-Open 2		
A0	High	ROM Mono, 0605: Hi-Hat Dance 36	L/R	15
A#0	High	ROM Mono, 0606: Hi-Hat Dance 37	L/R	15
B0	High	ROM Mono, 0526: Hi-Hat Heavy 1-Closed mp	L/R	Off
C1	High	ROM Mono, 1083: Jew's Harp 01	IFX2	Off
	M Hi	ROM Mono, 0985: Djembe L-Basstone a		
	M Lo	ROM Mono, 1092: Jew's Harp 10		
C#1	High	ROM Mono, 0777: Iya Boca-Open mf	IFX2	Off
	M Hi	ROM Mono, 0780: Iya Boca-Choke mf		
	M Lo	ROM Mono, 0778: Iya Boca-Open f		
D1	High	ROM Mono, 0828: Timbales Hi-Paila f	IFX2	Off
	M Hi	ROM Mono, 0074: BD-Dance 10		
	M Lo	ROM Mono, 0828: Timbales Hi-Paila f		
D#1	High	ROM Mono, 1118: WD-Brazilia 1	IFX2	Off
	M Hi	ROM Mono, 0017: BD-05-amb mp		
	M Lo	ROM Mono, 1118: WD-Brazilia 1		
E1	High	ROM Mono, 0108: BD-Dance 38	IFX2	Off
	M Hi	ROM Mono, 0108: BD-Dance 38		
F1	High	ROM Mono, 0865: Pandeiro-ClosedAcc.a	IFX1	Off
	M Hi	ROM Mono, 1037: Baya-Nail a		
F#1	High	ROM Mono, 1027: Tabla-Tele c	IFX1	Off
	M Hi	ROM Mono, 0363: SD-Dance 37		
	M Lo	ROM Mono, 1025: Tabla-Tele a		
G1	High	ROM Mono, 0390: SD-Dance 64	IFX1	Off
	M Hi	ROM Mono, 0361: SD-Dance 35		
G#1	High	ROM Mono, 0340: SD-Dance 14	IFX1	Off
	M Hi	ROM Mono, 0353: SD-Dance 27		
A1	High	ROM Mono, 0682: Drumstick Hit	IFX1	Off
A#1	High	ROM Mono, 0640: Cymbal Reverse 2	IFX3	Off
B1	High	ROM Mono, 0265: SD-22-amb mf REV	IFX1	Off
C2	High	ROM Mono, 0069: BD-Dance 05	IFX2	Off
	M Hi	ROM Mono, 0103: BD-Dance 33		
C#2	High	ROM Mono, 0139: BD-Dance 67	IFX2	Off
D2	High	ROM Mono, 0106: BD-Dance 36	IFX2	Off
	M Hi	ROM Mono, 0137: BD-Dance 65		
D#2	High	ROM Mono, 0095: BD-Dance 25	IFX2	Off
	M Hi	ROM Mono, 1425: Click 2		
E2	High	ROM Mono, 1102: WD-Native Drum 1	IFX2	Off
	M Hi	ROM Mono, 112: BD-Dance 42		
F2	High	ROM Mono, 0393: SD-Dance 67	IFX1	Off
	M Hi	ROM Mono, 0282: SD-25-dry Brush Tap mp-L		
	M Lo	ROM Mono, 0393: SD-Dance 67		
F#2	High	ROM Mono, 0365: SD-Dance 39	IFX1	Off
	M Hi	ROM Mono, 0371: SD-Dance 45		
G2	High	ROM Mono, 0362: SD-Dance 36	IFX1	Off
	M Hi	ROM Mono, 0333: SD-Dance 07		
G#2	High	ROM Mono, 0167: SD-04-amb mf -L	IFX1	Off
	M Hi	ROM Mono, 0371: SD-Dance 45		
	M Lo	ROM Mono, 0167: SD-04-amb mf -L		
A2	High	ROM Mono, 0396: SD-Dance 70	IFX1	Off
	M Hi	ROM Mono, 0359: SD-Dance 33		
	M Lo	ROM Mono, 0396: SD-Dance 70		
A#2	High	ROM Mono, 0342: SD-Dance 16	IFX1	Off
	M Hi	ROM Mono, 0284: SD-25-dry Brush Tap f-L		
B2	High	ROM Mono, 0040: BD-08-amb ff	IFX2	Off
	M Hi	ROM Mono, 0103: BD-Dance 33		
C3	High	ROM Mono, 0075: BD-Pop	IFX2	Off
	M Hi	ROM Mono, 0105: BD-Dance 35		
	M Lo	ROM Mono, 0075: BD-Pop		
C#3	High	ROM Mono, 0338: SD-Dance 12	IFX1	Off
	M Hi	ROM Mono, 0323: SD-Sidestick 4 mf -L		
D3	High	ROM Mono, 0634: Crash Dance 2	IFX1	Off
	M Hi	ROM Mono, 0192: SD-09-amb ff		
D#3	High	ROM Mono, 1150: Dance Claps 05	L/R	Off
	M Hi	ROM Mono, 0687: Hand Claps 2-b		
E3	High	ROM Mono, 0364: SD-Dance 38	IFX1	Off
	M Hi	ROM Mono, 0386: SD-Dance 60		

Key		Drumsample	Bus	Ex
F3	High	ROM Mono, 0446: Tom Vintage Lo ff	IFX3	Off
	M Hi	ROM Mono, 1143: Dance Perc 02		
	M Lo	ROM Mono, 0446: Tom Vintage Lo ff		
F#3	High	ROM Mono, 0506: Hi-Hat Basic 1-Closed f	L/R	1
	M Hi	ROM Mono, 0562: Hi-Hat Dance 04		
G3	High	ROM Mono, 0448: Tom Vintage Mid mf -L	IFX3	Off
	M Hi	ROM Mono, 1143: Dance Perc 02		
G#3	M Lo	ROM Mono, 0448: Tom Vintage Mid mf -L	L/R	Off
	High	ROM Mono, 0561: Hi-Hat Dance 03		
A3	M Hi	ROM Mono, 0571: Hi-Hat Dance 13	IFX3	Off
	M Lo	ROM Mono, 0457: Tom Vintage Hi ff -L		
A#3	High	ROM Mono, 1143: Dance Perc 02	L/R	1
	M Hi	ROM Mono, 0457: Tom Vintage Hi ff -L		
	M Lo	ROM Mono, 0588: Hi-Hat Dance 30		
B3	High	ROM Mono, 0530: Hi-Hat Heavy 1-HalfOpen	IFX3	Off
	M Hi	ROM Mono, 0486: Tom-Old R&B		
C4	High	ROM Mono, 0445: Tom Vintage Lo f	IFX3	Off
	M Hi	ROM Mono, 0486: Tom-Old R&B		
C#4	High	ROM Mono, 0448: Tom Vintage Mid mf -L	L/R	Off
	M Hi	ROM Mono, 0619: Crash Cymbal 4 ff		
	M Lo	ROM Mono, 0625: Crash Cymbal 6 ff		
D4	High	ROM Mono, 0619: Crash Cymbal 4 ff	IFX3	Off
	M Hi	ROM Mono, 0486: Tom-Old R&B		
D#4	M Hi	ROM Mono, 0454: Tom Vintage Hi mf -L	L/R	Off
	High	ROM Mono, 0651: Ride Cymbal 3 f -L		
	M Hi	ROM Mono, 0649: Ride Cymbal 3 mf -L		
E4	M Lo	ROM Mono, 0648: Ride Cymbal 3 mp	L/R	Off
	High	ROM Mono, 1167: Dance Perc 04-Open		
F4	M Hi	ROM Mono, 1165: Dance Perc 03-Open	L/R	Off
	High	ROM Mono, 0655: Ride Cymbal 4 f		
F#4	High	ROM Mono, 0878: Tri.& Tamb. a	L/R	Off
	M Hi	ROM Mono, 0888: Tri.& Tamb. k		
	M Lo	ROM Mono, 0890: Tri.& Tamb. m		
G4	High	ROM Mono, 1339: Voice 31	L/R	Off
	M Hi	ROM Mono, 0630: Crash Cymbal 9		
G#4	High	ROM Mono, 0830: Cowbell 2	L/R	Off
	M Hi	ROM Mono, 1125: WD-Ethno SD 6		
A4	High	ROM Mono, 0611: Crash Cymbal 1 ff	L/R	Off
	M Hi	ROM Mono, 0609: Crash Cymbal 1 mf		
A#4	High	ROM Mono, 1081: Bull Roar	L/R	Off
B4	High	ROM Mono, 0646: Ride Cymbal 1 ff	L/R	Off
	M Hi	ROM Mono, 0644: Ride Cymbal 1 f -L		
	M Lo	ROM Mono, 0642: Ride Cymbal 1 mf -L		
C5	Low	ROM Mono, 0641: Ride Cymbal 1 mp	L/R	Off
	High	ROM Mono, 0770: Bongo 2 Hi-Open a		
C#5	M Hi	ROM Mono, 0772: Bongo 2 Hi-Muffled	L/R	Off
	High	ROM Mono, 0767: Bongo 2 Lo-Open a		
D5	M Hi	ROM Mono, 0767: Bongo 2 Lo-Open a	L/R	8
	High	ROM Mono, 1162: Dance Conga 2 Slap a		
D#5	M Hi	ROM Mono, 1162: Dance Conga 2 Slap a	L/R	8
	High	ROM Mono, 1161: Dance Conga 2 Open b		
E5	High	ROM Mono, 1160: Dance Caoga 2 Open a	L/R	Off
F5	High	ROM Mono, 0510: Hi-Hat Basic 1-Pedal f	L/R	7
	M Hi	ROM Mono, 0511: Hi-Hat Basic 1-Pedal ff		
F#5	High	ROM Mono, 0512: Hi-Hat Basic 1-Open mf	L/R	7
	M Hi	ROM Mono, 0514: Hi-Hat Basic 1-Open ff		
G5	High	ROM Mono, 0887: Tri.& Tamb. j	L/R	Off
	M Hi	ROM Mono, 0885: Tri.& Tamb. h		
G#5	High	ROM Mono, 0887: Tri.& Tamb. j	L/R	Off
	M Lo	ROM Mono, 0885: Tri.& Tamb. h		
A5	High	ROM Mono, 0892: Cabasa 1 L a-Up	L/R	Off
	M Hi	ROM Mono, 0891: Cabasa 1 L a-Down		
	M Lo	ROM Mono, 0894: Cabasa 1 L b-Up		
A#5	High	ROM Mono, 0848: Maracas 2-Pull b	L/R	Off
	M Hi	ROM Mono, 0847: Maracas 2-Pull a		
	M Lo	ROM Mono, 0846: Maracas 2-Push b		
B5	Low	ROM Mono, 0845: Maracas 2-Push a	L/R	Off
	High	ROM Mono, 1197: Orch Hit 6		
C6	M Hi	ROM Mono, 1195: Orch Hit 4	L/R	Off
	M Lo	ROM Mono, 1193: Orch Hit 2		
C6	High	ROM Mono, 1337: Voice 29	L/R	Off
	M Hi	ROM Mono, 1335: Voice 27		
C6	M Lo	ROM Mono, 1339: Voice 31	L/R	Off

Key		Drumsample	Bus	Ex
C#6	High	ROM Mono, 1154: Dance Claps 09	L/R	Off
	M Hi	ROM Mono, 1151: Dance Claps 06		
D6	High	ROM Mono, 1391: Vocoder Voice 09	L/R	Off
	M Hi	ROM Mono, 1392: Vocoder Voice 10		
	M Lo	ROM Mono, 1396: Vocoder Voice 14		
	Low	ROM Mono, 1393: Vocoder Voice 11		
D#6	High	ROM Mono, 1383: Vocoder Voice 01	L/R	Off
	M Hi	ROM Mono, 1384: Vocoder Voice 02		
	M Lo	ROM Mono, 1386: Vocoder Voice 04		
	Low	ROM Mono, 1387: Vocoder Voice 05		
E6	High	ROM Mono, 0146: BD-Dance Revers	L/R	Off
F6	High	ROM Mono, 1437: Glass Crash	L/R	Off
F#6	High	ROM Mono, 1462: Thunder	L/R	Off
	M Hi	ROM Mono, 1461: Explosion		
G6	High	ROM Mono, 1232: DJ Vinyl Sliced 08	L/R	Off
G#6	High	ROM Mono, 0953: Triangle 2-Mute a	L/R	5
	M Hi	ROM Mono, 0954: Triangle 2-Mute b		
A6	High	ROM Mono, 0950: Triangle 2-Closed a	L/R	5
	M Hi	ROM Mono, 0954: Triangle 2-Mute b		
A#6	High	ROM Mono, 0912: Shaker 1-Slow b	L/R	Off
	M Hi	ROM Mono, 0921: Shaker 2 d-Push		
B6	High	ROM Mono, 1075: Marc Tree	L/R	Off
C7	High	ROM Mono, 0140: BD-Dance 68	IFX2	Off
C#7	High	ROM Mono, 1240: DJ Vinyl Sliced 16	L/R	2
	M Hi	ROM Mono, 1242: DJ Vinyl Sliced 18		
D7	High	ROM Mono, 0416: SD-Dance 76	IFX1	Off
D#7	High	ROM Mono, 1241: DJ Vinyl Sliced 17	L/R	2
	M Hi	ROM Mono, 1241: DJ Vinyl Sliced 17		
E7	High	ROM Mono, 1239: DJ Vinyl Sliced 15	L/R	3
	M Hi	ROM Mono, 1237: DJ Vinyl Sliced 13		
F7	High	ROM Mono, 1238: DJ Vinyl Sliced 14	L/R	3
	M Hi	ROM Mono, 1238: DJ Vinyl Sliced 14		
F#7	High	ROM Mono, 1146: Dance Claps 01	L/R	Off
G7	High	ROM Mono, 1187: Dance SynMaraca	L/R	Off
G#7	High	ROM Mono, 0315: SD-Orch.Roll	IFX1	8
A7	High	ROM Mono, 0316: SD-Orchestral	IFX1	8
A#7	High	ROM Mono, 1074: Bell Tree-Fast	L/R	Off
	M Hi	ROM Mono, 1073: Bell Tree-Slow		
B7	High	ROM Mono, 1418: Stadium	L/R	Off
C8	High	ROM Mono, 1419: Applause	L/R	Off
C#8	High	ROM Mono, 1276: Industry Hit 13	L/R	Off
D8	High	ROM Mono, 1454: Gun Shot	L/R	Off
D#8	High	ROM Mono, 1092: Jew's Harp 10	L/R	Off
	M Hi	ROM Mono, 1086: Jew's Harp 04		
	M Lo	ROM Mono, 1085: Jew's Harp 03		
E8	High	ROM Mono, 1336: Voice 28	L/R	Off
	M Hi	ROM Mono, 1340: Voice 32		
F8	High	ROM Mono, 1407: CompuVoice-Noise	L/R	Off
	M Hi	ROM Mono, 1406: CompuVoice-BEEP		
	M Lo	ROM Mono, 1408: CompuVoice-Chi		
	Low	ROM Mono, 1409: CompuVoice-Do it		
G9	High	ROM Mono, 1424: Click 1	L/R	Off

08 (INT): Insane FX Kit

Key		Drumsample	Bus	Ex
C-1	High	ROM Mono, 1424: Click 1	L/R	Off
E0	High	ROM Mono, 0569: Hi-Hat Dance 11	IFX3	Off
	M Hi	ROM Mono, 0569: Hi-Hat Dance 11		
F0	High	ROM Mono, 0534: Hi-Hat Heavy 2-Closed ff	IFX3	4
	M Hi	ROM Mono, 0533: Hi-Hat Heavy 2-Closed f		
	M Lo	ROM Mono, 0531: Hi-Hat Heavy 2-Closed mp		
F#0	High	ROM Mono, 0536: Hi-Hat Heavy 2-Open f	IFX3	4
G0	High	ROM Mono, 0566: Hi-Hat Dance 08	IFX3	5
	M Hi	ROM Mono, 0566: Hi-Hat Dance 08		
G#0	High	ROM Mono, 0600: Hi-Hat-Crisp Open	IFX3	5
A0	High	ROM Mono, 0565: Hi-Hat Dance 07	IFX3	Off
	M Hi	ROM Mono, 0565: Hi-Hat Dance 07		
A#0	High	ROM Mono, 0545: Hi-Hat Basic 4-Open 2	IFX3	Off
	M Hi	ROM Mono, 0599: Hi-Hat-Ambi		
	M Lo	ROM Mono, 0545: Hi-Hat Basic 4-Open 2		
B0	High	ROM Mono, 0593: Hi-Hat WS-HalfOpen	IFX3	Off
	M Hi	ROM Mono, 0592: Hi-Hat WS-Closed		
C1	High	ROM Mono, 0072: BD-Dance 08	IFX2	Off
	M Hi	ROM Mono, 0040: BD-08-amb ff		
	M Lo	ROM Mono, 0072: BD-Dance 08		
C#1	High	ROM Mono, 0112: BD-Dance 42	IFX2	Off
	M Hi	ROM Mono, 0111: BD-Dance 41		
D1	High	ROM Mono, 0107: BD-Dance 37	IFX2	Off
	M Hi	ROM Mono, 1084: Jew's Harp 02		
D#1	High	ROM Mono, 0137: BD-Dance 65	IFX2	Off
	M Hi	ROM Mono, 1088: Jew's Harp 06		
	M Lo	ROM Mono, 0137: BD-Dance 65		
E1	High	ROM Mono, 0901: Cabasa 2 L-Roll	IFX2	Off
	M Hi	ROM Mono, 0134: BD-Dance 62		
	M Lo	ROM Mono, 0901: Cabasa 2 L-Roll		
F1	High	ROM Mono, 0366: SD-Dance 40	IFX1	Off
	M Hi	ROM Mono, 0398: SD-Dance 72		
F#1	High	ROM Mono, 0376: SD-Dance 50	IFX1	Off
	M Hi	ROM Mono, 0337: SD-Dance 11		
	M Lo	ROM Mono, 0376: SD-Dance 50		
G1	High	ROM Mono, 0388: SD-Dance 62	IFX1	Off
	M Hi	ROM Mono, 1150: Dance Claps 05		
G#1	High	ROM Mono, 0998: Djembe 5-ClosedSlap c	IFX1	Off
	M Hi	ROM Mono, 0278: SD-Off Center		
A1	High	ROM Mono, 1142: Dance Perc 01	IFX1	Off
	M Hi	ROM Mono, 1153: Dance Claps 08		
A#1	High	ROM Mono, 0639: Cymbal Reverse 1	IFX3	Off
B1	High	ROM Mono, 0265: SD-22-amb mf REV	IFX1	Off
C2	High	ROM Mono, 1106: WD-Big Hand 1	IFX2	Off
	M Hi	ROM Mono, 128: BD-Dance 56		
	M Lo	ROM Mono, 1106: WD-Big Hand 1		
C#2	High	ROM Mono, 1340: Voice 32	IFX2	Off
	M Hi	ROM Mono, 0090: BD-Dance 20		
D2	High	ROM Mono, 1340: Voice 32	IFX2	Off
	M Lo	ROM Mono, 1340: Voice 32		
D#2	High	ROM Mono, 0073: BD-Dance 09	IFX2	Off
	M Hi	ROM Mono, 0125: BD-Dance 55		
E2	High	ROM Mono, 0056: BD-Dance 01	IFX2	Off
	M Hi	ROM Mono, 0120: BD-Dance 50		
	M Lo	ROM Mono, 0125: BD-Dance 55		
F2	High	ROM Mono, 0120: BD-Dance 50	IFX1	Off
	M Hi	ROM Mono, 1172: Dance Perc 07 b		
	M Lo	ROM Mono, 1140: WD-Snake Drum 1		
F#2	High	ROM Mono, 0937: Triangle 1 L-Open a	IFX1	Off
	M Hi	ROM Mono, 0348: SD-Dance 22		
G2	High	ROM Mono, 0367: SD-Dance 41	IFX1	Off
	M Hi	ROM Mono, 0216: SD-12-amb mp		
G#2	High	ROM Mono, 0373: SD-Dance 47	IFX1	Off
	M Hi	ROM Mono, 0192: SD-09-amb ff		
	M Lo	ROM Mono, 0373: SD-Dance 47		
A2	High	ROM Mono, 0366: SD-Dance 40	IFX1	Off
	M Hi	ROM Mono, 0334: SD-Dance 08		
A#2	High	ROM Mono, 0392: SD-Dance 66	IFX1	Off
	M Hi	ROM Mono, 0370: SD-Dance 44		
B2	High	ROM Mono, 0101: BD-Dance 31	IFX2	Off
	M Hi	ROM Mono, 0028: BD-06-amb f		
	M Lo	ROM Mono, 0101: BD-Dance 31		
C3	High	ROM Mono, 0064: BD-Dance 03	IFX2	Off
	M Hi	ROM Mono, 0092: BD-Dance 22		
	M Lo	ROM Mono, 0064: BD-Dance 03		

Key		Drumsample	Bus	Ex
C#3	High	ROM Mono, 0325: SD-Sidestick 4 f	IFX1	Off
	M Hi	ROM Mono, 0402: SD-Sizzle		
D3	High	ROM Mono, 0258: SD-21-dry f	IFX1	Off
	M Hi	ROM Mono, 0203: SD-11-amb ff		
D#3	High	ROM Mono, 0684: Hand Claps 1	IFX3	Off
	M Hi	ROM Mono, 0685: Hand Claps 2-a -L		
E3	High	ROM Mono, 1152: Dance Claps 07	IFX1	Off
	M Hi	ROM Mono, 0363: SD-Dance 37		
F3	High	ROM Mono, 1143: Dance Perc 02	IFX1	Off
	M Hi	ROM Mono, 0486: Tom-Old R&B		
	M Lo	ROM Mono, 1143: Dance Perc 02		
F#3	High	ROM Mono, 0534: Hi-Hat Heavy 2-Closed ff	IFX3	1
	M Hi	ROM Mono, 0515: Hi-Hat Basic 2-Closed mp		
G3	High	ROM Mono, 1143: Dance Perc 02	IFX1	Off
	M Hi	ROM Mono, 0486: Tom-Old R&B		
G#3	M Lo	ROM Mono, 1143: Dance Perc 02	IFX3	Off
	High	ROM Mono, 0562: Hi-Hat Dance 04		
A3	M Hi	ROM Mono, 0562: Hi-Hat Dance 04	IFX1	Off
	M Lo	ROM Mono, 1143: Dance Perc 02		
A#3	High	ROM Mono, 0601: Hi-Hat-ClangyOpen	IFX3	1
	M Hi	ROM Mono, 0520: Hi-Hat Basic 2-Open f		
B3	High	ROM Mono, 0502: Tom Brush2 Floor	IFX1	Off
	M Hi	ROM Mono, 0445: Tom Vintage Lo f		
C4	High	ROM Mono, 0503: Tom Brush2 Hi	IFX1	Off
	M Hi	ROM Mono, 0448: Tom Vintage Mid mf -L		
C#4	High	ROM Mono, 0629: Crash Cymbal 8	IFX3	Off
	M Hi	ROM Mono, 0627: Crash Cymbal 7 f -L		
D4	High	ROM Mono, 0503: Tom Brush2 Hi	IFX1	Off
	M Hi	ROM Mono, 0454: Tom Vintage Hi mf -L		
D#4	High	ROM Mono, 0651: Ride Cymbal 3 f -L	IFX3	Off
	M Hi	ROM Mono, 0649: Ride Cymbal 3 mf -L		
E4	M Lo	ROM Mono, 0648: Ride Cymbal 3 mp	IFX3	Off
	High	ROM Mono, 0627: Crash Cymbal 7 f -L		
F4	M Hi	ROM Mono, 0627: Crash Cymbal 7 f -L	IFX3	Off
	High	ROM Mono, 0655: Ride Cymbal 4 f		
F#4	High	ROM Mono, 0877: Tambourine 2-Accent	IFX2	Off
	M Hi	ROM Mono, 0874: Tambourine 2-Push		
	M Lo	ROM Mono, 0875: Tambourine 2-Pull a		
G4	High	ROM Mono, 0679: Splash Cymbal 1 ff -R	IFX3	Off
	M Hi	ROM Mono, 0677: Splash Cymbal 1 f		
G#4	M Lo	ROM Mono, 0676: Splash Cymbal 1 mf	IFX2	Off
	High	ROM Mono, 0830: Cowbell 2		
A4	M Hi	ROM Mono, 0831: Cowbell 3	IFX3	Off
	High	ROM Mono, 0621: Crash Cymbal 5 mf		
A#4	M Hi	ROM Mono, 0620: Crash Cymbal 5 mp	IFX2	Off
B4	High	ROM Mono, 0853: Vibra-Slap	IFX3	Off
	M Hi	ROM Mono, 0646: Ride Cymbal 1 ff		
	M Lo	ROM Mono, 0644: Ride Cymbal 1 f -L		
C5	Low	ROM Mono, 0642: Ride Cymbal 1 mf -L	IFX2	Off
	High	ROM Mono, 0641: Ride Cymbal 1 mp		
	M Hi	ROM Mono, 0756: Bongo 1 Hi-Open f		
C#5	M Hi	ROM Mono, 0755: Bongo 1 Hi-Open mf	IFX2	Off
	M Lo	ROM Mono, 0756: Bongo 1 Hi-Open f		
	High	ROM Mono, 0744: Bongo 1 Lo-Muffled f		
D5	M Hi	ROM Mono, 0743: Bongo 1 Lo-Muffled mp	IFX2	Off
	M Lo	ROM Mono, 0745: Bongo 1 Lo-Closed		
D#5	High	ROM Mono, 0728: Conga Hi-ClosedSlap	IFX2	Off
	M Hi	ROM Mono, 0727: Conga Hi-Closed		
	High	ROM Mono, 0723: Conga Hi-OpenSlap		
E5	M Hi	ROM Mono, 0720: Conga Hi-Open mf	IFX2	Off
	M Lo	ROM Mono, 0721: Conga Hi-Open f		
	Low	ROM Mono, 0719: Conga Hi-Open mp		
F5	High	ROM Mono, 0709: Conga Lo-OpenSlap	IFX2	Off
	M Hi	ROM Mono, 0707: Conga Lo-Open mf		
F#5	M Lo	ROM Mono, 0708: Conga Lo-Open f	IFX2	Off
	High	ROM Mono, 0560: Hi-Hat Dance 02		
G5	M Hi	ROM Mono, 0560: Hi-Hat Dance 02	IFX2	Off
	M Lo	ROM Mono, 0570: Hi-Hat Dance 12		
	High	ROM Mono, 0571: Hi-Hat Dance 13	IFX2	Off
	M Hi	ROM Mono, 0888: Tri.& Tamb. k		
	High	ROM Mono, 0888: Tri.& Tamb. k	IFX2	Off
	M Hi	ROM Mono, 0890: Tri.& Tamb. m		
	M Lo	ROM Mono, 0888: Tri.& Tamb. k		

Key		Drumsample	Bus	Ex
G#5	High	ROM Mono,0888:Tri.& Tamb. k	IFX2	Off
	M Hi	ROM Mono,0890:Tri.& Tamb. m		
	M Lo	ROM Mono,0888:Tri.& Tamb. k		
A5	High	ROM Mono,0918:Shaker 2 b-Push	IFX2	Off
	M Hi	ROM Mono,0919:Shaker 2 b-Pull		
A#5	High	ROM Mono,0848:Maracas 2-Pull b	IFX2	Off
	M Hi	ROM Mono,0847:Maracas 2-Pull a		
	M Lo	ROM Mono,0846:Maracas 2-Push b		
	Low	ROM Mono,0845:Maracas 2-Push a		
B5	High	ROM Mono,1306:Industry Loop 2	IFX2	Off
	M Hi	ROM Mono,1283:Industry Hit 18		
C6	High	ROM Mono,1281:Industry Hit 16	IFX2	Off
	M Hi	ROM Mono,0057:BD-Cannon		
C#6	High	ROM Mono,0852:Guiro-Short b	IFX2	3
	M Hi	ROM Mono,0851:Guiro-Short a		
D6	High	ROM Mono,0850:Guiro-Long b	IFX2	3
	M Hi	ROM Mono,0849:Guiro-Long a		
D#6	High	ROM Mono,0840:Claves Hi b	IFX2	Off
	M Hi	ROM Mono,0839:Claves Hi a		
E6	High	ROM Mono,1053:Wood Block 4 a	IFX2	Off
	M Hi	ROM Mono,1054:Wood Block 4 b		
F6	High	ROM Mono,1051:Wood Block 3 a	IFX2	Off
	M Hi	ROM Mono,1052:Wood Block 3 b		
F#6	High	ROM Mono,0967:Cuica Hi c	IFX2	4
	M Hi	ROM Mono,0965:Cuica Hi a		
	M Lo	ROM Mono,0966:Cuica Hi b		
G6	High	ROM Mono,0962:Cuica Lo a	IFX2	4
	M Hi	ROM Mono,0962:Cuica Lo a		
G#6	High	ROM Mono,0947:Triangle 1 S-Mute a	IFX2	5
	M Hi	ROM Mono,0948:Triangle 1 S-Mute b		
A6	High	ROM Mono,0945:Triangle 1 S-Roll b	IFX2	5
	M Hi	ROM Mono,0944:Triangle 1 S-Roll a		
A#6	High	ROM Mono,0921:Shaker 2 d-Push	IFX2	Off
	M Hi	ROM Mono,0928:Shaker 3-Push		
B6	High	ROM Mono,0920:Shaker 2 c-Push	IFX2	Off
	M Hi	ROM Mono,0917:Shaker 2 a		
C7	High	ROM Mono,0111:BD-Dance 41	IFX2	Off
C#7	High	ROM Mono,0605:Hi-Hat Dance 36	IFX3	7
D7	High	ROM Mono,0389:SD-Dance 63	IFX1	Off
D#7	High	ROM Mono,0606:Hi-Hat Dance 37	IFX3	7
E7	High	ROM Mono,0636:Crash Dance 4	IFX3	Off
F7	High	ROM Mono,1186:Dance SynCowbell	IFX2	Off
F#7	High	ROM Mono,1146:Dance Claps 01	IFX2	Off
G7	High	ROM Mono,1187:Dance SynMaraca	IFX2	Off
G#7	High	ROM Mono,0315:SD-Orch.Roll	IFX1	8
A7	High	ROM Mono,0316:SD-Orchestral	IFX1	8
A#7	High	ROM Mono,1074:Bell Tree-Fast	IFX2	Off
	M Hi	ROM Mono,1073:Bell Tree-Slow		
B7	High	ROM Mono,1418:Stadium	IFX2	Off
C8	High	ROM Mono,1419:Applause	IFX2	Off
G9	High	ROM Mono,1424:Click 1	L/R	Off

09 (INT): Nu Style Kit

Key		Drumsample	Bus	Ex
C-1	High	ROM Mono, 1424: Click 1	L/R	Off
E0	High	ROM Mono, 0562: Hi-Hat Dance 04	L/R	Off
	M Hi	ROM Mono, 0562: Hi-Hat Dance 04		
F0	High	ROM Mono, 0551: Hi-Hat Brush-Closed f	L/R	2
	M Hi	ROM Mono, 0550: Hi-Hat Brush-Closed mf		
	M Lo	ROM Mono, 0549: Hi-Hat Brush-Closed mp		
F#0	High	ROM Mono, 0558: Hi-Hat Brush-Open ff	L/R	2
	M Hi	ROM Mono, 0555: Hi-Hat Brush-Open mp		
	M Lo	ROM Mono, 0556: Hi-Hat Brush-Open mf		
G0	High	ROM Mono, 0587: Hi-Hat Dance 29	L/R	3
	M Hi	ROM Mono, 0586: Hi-Hat Dance 28		
G#0	High	ROM Mono, 0588: Hi-Hat Dance 30	L/R	3
A0	High	ROM Mono, 0573: Hi-Hat Dance 15	L/R	4
	M Hi	ROM Mono, 0572: Hi-Hat Dance 14		
A#0	High	ROM Mono, 0574: Hi-Hat Dance 16	L/R	4
B0	High	ROM Mono, 0599: Hi-Hat-Ambi	L/R	1
	M Hi	ROM Mono, 0599: Hi-Hat-Ambi		
	M Lo	ROM Mono, 0599: Hi-Hat-Ambi		
C1	High	ROM Mono, 0854: Toy Drum	IFX2	Off
	M Hi	ROM Mono, 0698: Tumba-Open 1 f		
	M Lo	ROM Mono, 0854: Toy Drum		
C#1	High	ROM Mono, 0974: Dumbek-a	IFX2	Off
	M Hi	ROM Mono, 0070: BD-Dance 06		
	M Lo	ROM Mono, 0974: Dumbek-a		
D1	High	ROM Mono, 0715: Conga Lo-Heel	IFX2	Off
	M Hi	ROM Mono, 0066: BD-Dance 04		
	M Lo	ROM Mono, 0715: Conga Lo-Heel		
D#1	High	ROM Mono, 0103: BD-Dance 33	IFX2	Off
	M Hi	ROM Mono, 0098: BD-Dance 28		
	M Lo	ROM Mono, 0103: BD-Dance 33		
E1	High	ROM Mono, 0125: BD-Dance 55	IFX2	Off
	M Hi	ROM Mono, 0104: BD-Dance 34		
	M Lo	ROM Mono, 0125: BD-Dance 55		
F1	High	ROM Mono, 0855: Toy Drum-Rim	IFX1	Off
	M Hi	ROM Mono, 0855: Toy Drum-Rim		
	High	ROM Mono, 1090: Jew's Harp 08		
F#1	M Hi	ROM Mono, 0282: SD-25-dry Brush Tap mp-L	IFX1	Off
	M Lo	ROM Mono, 1090: Jew's Harp 08		
	High	ROM Mono, 1108: WD-Big Hand 3		
G1	M Hi	ROM Mono, 0351: SD-Dance 25	IFX1	Off
	M Lo	ROM Mono, 1106: WD-Big Hand 1		
	High	ROM Mono, 0389: SD-Dance 63		
G#1	M Hi	ROM Mono, 0348: SD-Dance 22	IFX1	Off
	M Lo	ROM Mono, 0389: SD-Dance 63		
	High	ROM Mono, 0392: SD-Dance 66		
A1	M Hi	ROM Mono, 1341: Voice 33	IFX1	Off
	High	ROM Mono, 0640: Cymbal Reverse 2		
B1	High	ROM Mono, 0265: SD-22-amb mf REV	IFX1	Off
C2	High	ROM Mono, 0088: BD-Dance 18	IFX2	Off
	M Hi	ROM Mono, 0117: BD-Dance 47		
C#2	High	ROM Mono, 1129: WD-Gothic 4	IFX2	Off
	M Hi	ROM Mono, 0128: BD-Dance 56		
	M Lo	ROM Mono, 1128: WD-Gothic 3		
D2	High	ROM Mono, 1136: WD-Kangaroo 5	IFX2	Off
	M Hi	ROM Mono, 0102: BD-Dance 32		
	M Lo	ROM Mono, 1134: WD-Kangaroo 3		
D#2	High	ROM Mono, 1389: Vocoder Voice 07	IFX2	Off
	M Hi	ROM Mono, 1103: WD-Native Drum 2		
	M Lo	ROM Mono, 1390: Vocoder Voice 08		
E2	High	ROM Mono, 1126: WD-Gothic 1	IFX2	Off
	M Hi	ROM Mono, 0093: BD-Dance 23		
	M Lo	ROM Mono, 1128: WD-Gothic 3		
F2	High	ROM Mono, 1095: Jew's Harp 13	IFX1	Off
	M Hi	ROM Mono, 1127: WD-Gothic 2		
	M Lo	ROM Mono, 1093: Jew's Harp 11		
F#2	High	ROM Mono, 1469: Old Telephone-Ring	IFX1	Off
	M Hi	ROM Mono, 0351: SD-Dance 25		
G2	High	ROM Mono, 1125: WD-Ethno SD 6	IFX1	Off
	M Hi	ROM Mono, 0339: SD-Dance 13		
	M Lo	ROM Mono, 1125: WD-Ethno SD 6		
G#2	High	ROM Mono, 1126: WD-Gothic 1	IFX1	Off
	M Hi	ROM Mono, 1094: Jew's Harp 12		
	M Lo	ROM Mono, 1126: WD-Gothic 1		

Key		Drumsample	Bus	Ex
A2	High	ROM Mono, 0337: SD-Dance 11	IFX1	Off
	M Hi	ROM Mono, 1139: WD-Kangaroo 8		
	M Lo	ROM Mono, 0337: SD-Dance 11		
A#2	High	ROM Mono, 0358: SD-Dance 32	IFX1	Off
	M Hi	ROM Mono, 1141: WD-Snake Drum 2		
	M Lo	ROM Mono, 0358: SD-Dance 32		
B2	High	ROM Mono, 1108: WD-Big Hand 3	IFX2	Off
	M Hi	ROM Mono, 0043: BD-09-dry mf -L		
	M Lo	ROM Mono, 1107: WD-Big Hand 2		
C3	High	ROM Mono, 1141: WD-Snake Drum 2	IFX2	Off
	M Hi	ROM Mono, 0090: BD-Dance 20		
	M Lo	ROM Mono, 1140: WD-Snake Drum 1		
C#3	High	ROM Mono, 0569: Hi-Hat Dance 11	IFX1	Off
	M Hi	ROM Mono, 0419: SD-Dance Rimshot		
D3	High	ROM Mono, 0258: SD-21-dry f	IFX1	Off
	M Hi	ROM Mono, 0359: SD-Dance 33		
	M Lo	ROM Mono, 0224: SD-14-dry mf		
D#3	High	ROM Mono, 0684: Hand Claps 1	IFX1	Off
	M Hi	ROM Mono, 1150: Dance Claps 05		
E3	High	ROM Mono, 0388: SD-Dance 62	IFX1	Off
	M Hi	ROM Mono, 1401: Vocoder Voice 19		
	M Lo	ROM Mono, 0388: SD-Dance 62		
F3	High	ROM Mono, 1143: Dance Perc 02	IFX2	Off
F#3	High	ROM Mono, 0504: Hi-Hat Basic 1-Closed mp	L/R	1
	M Hi	ROM Mono, 0576: Hi-Hat Dance 18		
G3	High	ROM Mono, 1143: Dance Perc 02	IFX2	Off
G#3	High	ROM Mono, 0599: Hi-Hat-Ambi	L/R	Off
	M Hi	ROM Mono, 0602: Hi-Hat-Whispy		
A3	High	ROM Mono, 1143: Dance Perc 02	IFX2	Off
A#3	High	ROM Mono, 0518: Hi-Hat Basic 2-Open mp	L/R	1
	M Hi	ROM Mono, 0590: Hi-Hat Dance 32		
B3	High	ROM Mono, 0502: Tom Brush2 Floor	IFX2	Off
	M Hi	ROM Mono, 0425: Tom Basic Lo ff		
C4	High	ROM Mono, 0503: Tom Brush2 Hi	IFX2	Off
	M Hi	ROM Mono, 0430: Tom Basic MidHi mp		
C#4	High	ROM Mono, 0635: Crash Dance 3	L/R	Off
	M Hi	ROM Mono, 0627: Crash Cymbal 7 f -L		
	M Lo	ROM Mono, 0635: Crash Dance 3		
D4	High	ROM Mono, 0503: Tom Brush2 Hi	IFX2	Off
	M Hi	ROM Mono, 0454: Tom Vintage Hi mf -L		
D#4	High	ROM Mono, 0653: Ride Cymbal 3 ff	L/R	Off
	M Hi	ROM Mono, 0654: Ride Cymbal 4 mp		
E4	High	ROM Mono, 0617: Crash Cymbal 4 mf	L/R	Off
	M Hi	ROM Mono, 0616: Crash Cymbal 4 mp		
F4	High	ROM Mono, 0658: Ride Cymbal 5 f	L/R	Off
	M Hi	ROM Mono, 0657: Ride Cymbal 5 mf		
	High	ROM Mono, 0885: Tri.& Tamb. h		
F#4	M Hi	ROM Mono, 0886: Tri.& Tamb. i	IFX3	Off
	M Lo	ROM Mono, 0887: Tri.& Tamb. j		
G4	High	ROM Mono, 0681: Splash Cymbal 2 ff	L/R	Off
	M Hi	ROM Mono, 0680: Splash Cymbal 2 mp		
G#4	High	ROM Mono, 0830: Cowbell 2	IFX3	Off
	M Hi	ROM Mono, 0831: Cowbell 3		
A4	High	ROM Mono, 0621: Crash Cymbal 5 mf	L/R	Off
	M Hi	ROM Mono, 0623: Crash Cymbal 6 mf -L		
A#4	High	ROM Mono, 0870: Pandeiro-Glissando b	IFX3	Off
	M Hi	ROM Mono, 1457: Laser Gun		
B4	High	ROM Mono, 0667: Ride Dance 1	L/R	Off
	M Hi	ROM Mono, 0668: Ride Dance 2		
C5	High	ROM Mono, 0761: Bongo 1 Hi-Stick	IFX3	Off
	M Hi	ROM Mono, 0762: Bongo 1 Hi-StickEdge mf		
	M Lo	ROM Mono, 0764: Bongo 1 Hi-StickBounce		
C#5	High	ROM Mono, 0749: Bongo 1 Lo-StickEdge mf	IFX3	Off
	M Hi	ROM Mono, 0750: Bongo 1 Lo-StickEdge f		
	M Lo	ROM Mono, 0748: Bongo 1 Lo-Stick		
D5	Low	ROM Mono, 0751: Bongo 1 Lo-StickBounce	IFX3	Off
	High	ROM Mono, 0728: Conga Hi-ClosedSlap		
	M Hi	ROM Mono, 0727: Conga Hi-Closed		
D#5	High	ROM Mono, 0723: Conga Hi-OpenSlap	IFX3	Off
	M Hi	ROM Mono, 0720: Conga Hi-Open mf		
	M Lo	ROM Mono, 0721: Conga Hi-Open f		
E5	Low	ROM Mono, 0719: Conga Hi-Open mp	IFX3	Off
	High	ROM Mono, 0709: Conga Lo-OpenSlap		
	M Hi	ROM Mono, 0707: Conga Lo-Open mf		
M Lo	High	ROM Mono, 0708: Conga Lo-Open f	IFX3	Off



Key		Drumsample	Bus	Ex
F5	High	ROM Mono,0547:Hi-Hat Basic 5-Closed 2	L/R	5
	M Hi	ROM Mono,0546:Hi-Hat Basic 5-Closed 1		
F#5	High	ROM Mono,0544:Hi-Hat Basic 4-Open 1	L/R	5
	M Hi	ROM Mono,0545:Hi-Hat Basic 4-Open 2		
G5	High	ROM Mono,1164:Dance Perc 03-Closed	IFX3	12
G#5	High	ROM Mono,1165:Dance Perc 03-Open	IFX3	12
A5	High	ROM Mono,0958:Recoreco-Long	IFX3	Off
	M Hi	ROM Mono,0960:Recoreco-Short b		
A#5	High	ROM Mono,0929:Shaker 3-Pull	IFX3	Off
	M Hi	ROM Mono,0928:Shaker 3-Push		
B5	High	ROM Mono,1121:WD-Ethno SD 2	IFX3	2
	M Hi	ROM Mono,1122:WD-Ethno SD 3		
	M Lo	ROM Mono,1122:WD-Ethno SD 3		
C6	High	ROM Mono,1124:WD-Ethno SD 5	IFX3	2
	M Hi	ROM Mono,1123:WD-Ethno SD 4		
	M Lo	ROM Mono,1123:WD-Ethno SD 4		
C#6	High	ROM Mono,1120:WD-Ethno SD 1	IFX3	2
	M Hi	ROM Mono,1119:WD-Brazilia 2		
D6	High	ROM Mono,1173:Dance Perc 08	IFX3	Off
	M Hi	ROM Mono,0887:Tri.& Tamb. j		
D#6	High	ROM Mono,1428:Dog	IFX3	Off
	M Hi	ROM Mono,1430:Crickets 1		
E6	High	ROM Mono,1085:Jew's Harp 03	IFX3	Off
	M Hi	ROM Mono,1092:Jew's Harp 10		
F6	High	ROM Mono,1385:Vocoder Voice 03	IFX3	Off
	M Hi	ROM Mono,1387:Vocoder Voice 05		
	M Lo	ROM Mono,1388:Vocoder Voice 06		
	Low	ROM Mono,1383:Vocoder Voice 01		
F#6	High	ROM Mono,0597:Hi-Hat-Hip	L/R	Off
G6	High	ROM Mono,0588:Hi-Hat Dance 30	L/R	Off
	M Hi	ROM Mono,0587:Hi-Hat Dance 29		
	M Lo	ROM Mono,0586:Hi-Hat Dance 28		
G#6	High	ROM Mono,0952:Triangle 2-Closed c	IFX3	5
	M Hi	ROM Mono,0952:Triangle 2-Closed c		
A6	High	ROM Mono,0949:Triangle 2-Open	IFX3	5
	M Hi	ROM Mono,0949:Triangle 2-Open		
A#6	High	ROM Mono,0921:Shaker 2 d-Push	IFX3	Off
	M Hi	ROM Mono,0928:Shaker 3-Push		
B6	High	ROM Mono,0915:Shaker 1-Roll b	IFX3	Off
C7	High	ROM Mono,0106:BD-Dance 36	IFX2	Off
C#7	High	ROM Mono,0580:Hi-Hat Dance 22	L/R	7
D7	High	ROM Mono,0386:SD-Dance 60	IFX1	Off
D#7	High	ROM Mono,0581:Hi-Hat Dance 23	L/R	7
E7	High	ROM Mono,0636:Crash Dance 4	L/R	Off
F7	High	ROM Mono,1186:Dance SynCowbell	IFX3	Off
F#7	High	ROM Mono,1146:Dance Claps 01	IFX3	Off
G7	High	ROM Mono,1187:Dance SynMaraca	IFX3	Off
G#7	High	ROM Mono,0315:SD-Orch.Roll	IFX1	8
A7	High	ROM Mono,0316:SD-Orchestral	IFX1	8
A#7	High	ROM Mono,1074:Bell Tree-Fast	IFX3	Off
	M Hi	ROM Mono,1073:Bell Tree-Slow		
B7	High	ROM Mono,1418:Stadium	IFX3	Off
C8	High	ROM Mono,1419:Applause	IFX3	Off
C#8	High	ROM Mono,0125:BD-Dance 55	IFX2	Off
	M Hi	ROM Mono,0104:BD-Dance 34		
	M Lo	ROM Mono,0103:BD-Dance 33		
D8	High	ROM Mono,1105:WD-Native Drum 4	IFX3	9
	M Hi	ROM Mono,1104:WD-Native Drum 3		
D#8	High	ROM Mono,1102:WD-Native Drum 1	IFX3	9
	M Hi	ROM Mono,1102:WD-Native Drum 1		
E8	High	ROM Mono,1462:Thunder	IFX3	Off
	M Hi	ROM Mono,1462:Thunder		
G9	High	ROM Mono,1424:Click 1	L/R	Off



Key		Drumsample	Bus	Ex
D6	High	ROM Mono, 1234: DJ Vinyl Sliced 10	IFX3	Off
	M Hi	ROM Mono, 1233: DJ Vinyl Sliced 09		
D#6	High	ROM Mono, 1225: DJ Vinyl Sliced 01	IFX3	Off
	M Hi	ROM Mono, 1226: DJ Vinyl Sliced 02		
E6	High	ROM Mono, 1320: Voice 12	IFX3	Off
	M Hi	ROM Mono, 1323: Voice 15		
	M Lo	ROM Mono, 1322: Voice 14		
	Low	ROM Mono, 1325: Voice 17		
F6	High	ROM Mono, 1316: Voice 08	IFX3	Off
	M Hi	ROM Mono, 1315: Voice 07		
	M Lo	ROM Mono, 1314: Voice 06		
	Low	ROM Mono, 1313: Voice 05		
F#6	High	ROM Mono, 1356: Voice 48	IFX3	Off
	M Hi	ROM Mono, 1353: Voice 45		
	M Lo	ROM Mono, 1352: Voice 44		
	Low	ROM Mono, 1355: Voice 47		
G6	High	ROM Mono, 1258: DJ-Record Stop	IFX3	4
	M Hi	ROM Mono, 1259: DJ-Reverse		
G#6	High	ROM Mono, 0947: Triangle 1 S-Mute a	IFX3	5
	M Hi	ROM Mono, 0948: Triangle 1 S-Mute b		
A6	High	ROM Mono, 0945: Triangle 1 S-Roll b	IFX3	5
	M Hi	ROM Mono, 0944: Triangle 1 S-Roll a		
A#6	High	ROM Mono, 0912: Shaker 1-Slow b	IFX3	Off
	M Hi	ROM Mono, 0912: Shaker 1-Slow b		
B6	High	ROM Mono, 1075: Marc Tree	IFX3	Off
	M Hi	ROM Mono, 1075: Marc Tree		
C7	High	ROM Mono, 0135: BD-Dance 63	IFX2	Off
C#7	High	ROM Mono, 0603: Hi-Hat Dance 34	L/R	7
D7	High	ROM Mono, 0417: SD-Dance 77	IFX1	Off
D#7	High	ROM Mono, 0604: Hi-Hat Dance 35	L/R	7
E7	High	ROM Mono, 0636: Crash Dance 4	L/R	Off
F7	High	ROM Mono, 1186: Dance SynCowbell	IFX3	Off
F#7	High	ROM Mono, 1146: Dance Claps 01	IFX3	Off
G7	High	ROM Mono, 1187: Dance SynMaraca	IFX3	Off
G#7	High	ROM Mono, 1319: Voice 11	IFX3	Off
	M Hi	ROM Mono, 1312: Voice 04		
A7	High	ROM Mono, 1317: Voice 09	IFX3	Off
	M Hi	ROM Mono, 1318: Voice 10		
	M Lo	ROM Mono, 1311: Voice 03		
A#7	High	ROM Mono, 1074: Bell Tree-Fast	IFX3	Off
	M Hi	ROM Mono, 1073: Bell Tree-Slow		
B7	High	ROM Mono, 1418: Stadium	IFX3	Off
C8	High	ROM Mono, 1419: Applause	IFX3	Off
C#8	High	ROM Mono, 0316: SD-Orchestral	IFX1	Off
	M Hi	ROM Mono, 0315: SD-Orch.Roll		
D8	High	ROM Mono, 1329: Voice 21	IFX3	Off
	M Hi	ROM Mono, 1330: Voice 22		
D#8	High	ROM Mono, 1331: Voice 23	IFX3	Off
E8	High	ROM Mono, 1332: Voice 24	IFX3	Off
F8	High	ROM Mono, 1333: Voice 25	IFX3	Off
F#8	High	ROM Mono, 1334: Voice 26	IFX3	Off
G8	High	ROM Mono, 1454: Gun Shot	IFX3	Off
G9	High	ROM Mono, 1424: Click 1	L/R	Off

11 (INT): Tricki kit

Key		Drumsample	Bus	Ex
C-1	High	ROM Mono, 1424: Click 1	L/R	Off
E0	High	ROM Mono, 0584: Hi-Hat Dance 26	IFX3	Off
	M Hi	ROM Mono, 0583: Hi-Hat Dance 25		
	M Lo	ROM Mono, 0582: Hi-Hat Dance 24		
F0	High	ROM Mono, 0585: Hi-Hat Dance 27	IFX3	Off
	M Hi	ROM Mono, 0584: Hi-Hat Dance 26		
	M Lo	ROM Mono, 0584: Hi-Hat Dance 26		
F#0	High	ROM Mono, 0602: Hi-Hat Dance 05	IFX3	Off
	M Hi	ROM Mono, 0560: Hi-Hat Dance 02		
G0	High	ROM Mono, 0583: Hi-Hat Dance 25	IFX3	Off
	M Hi	ROM Mono, 0582: Hi-Hat Dance 24		
G#0	High	ROM Mono, 0828: Timbales Hi-Paila f	L/R	Off
	M Hi	ROM Mono, 0922: Shaker 2 d-Pull		
A0	High	ROM Mono, 0600: Hi-Hat-Crisp Open	IFX1	Off
	M Hi	ROM Mono, 0595: Hi-Hat-Chili		
	M Lo	ROM Mono, 0602: Hi-Hat-Whispy		
A#0	High	ROM Mono, 0596: Hi-Hat-Vintage	IFX1	Off
	M Hi	ROM Mono, 0596: Hi-Hat-Vintage		
B0	High	ROM Mono, 0543: Hi-Hat Basic 4-FootOpen	IFX1	Off
	M Hi	ROM Mono, 0540: Hi-Hat Basic 4-Closed 1		
	M Lo	ROM Mono, 0542: Hi-Hat Basic 4-Foot		
C1	High	ROM Mono, 0130: BD-Dance 58	IFX2	Off
	M Hi	ROM Mono, 0277: SD-Dry		
C#1	High	ROM Mono, 0090: BD-Dance 20	IFX2	Off
D1	High	ROM Mono, 0130: BD-Dance 58	IFX2	Off
D#1	High	ROM Mono, 0135: BD-Dance 63	IFX2	Off
E1	High	ROM Mono, 0141: BD-Dance 69	IFX2	Off
F1	High	ROM Mono, 0368: SD-Dance 42	IFX1	Off
	M Hi	ROM Mono, 0377: SD-Dance 51		
F#1	High	ROM Mono, 1152: Dance Claps 07	IFX1	Off
	M Hi	ROM Mono, 0351: SD-Dance 25		
	M Lo	ROM Mono, 0351: SD-Dance 25		
G1	High	ROM Mono, 0369: SD-Dance 43	IFX1	Off
	M Hi	ROM Mono, 0376: SD-Dance 50		
G#1	High	ROM Mono, 0345: SD-Dance 19	IFX1	Off
	M Hi	ROM Mono, 0567: Hi-Hat Dance 09		
A1	High	ROM Mono, 1155: Dance Claps 10	IFX1	Off
	M Hi	ROM Mono, 0395: SD-Dance 69		
A#1	High	ROM Mono, 0639: Cymbal Reverse 1	IFX1	Off
B1	High	ROM Mono, 0265: SD-22-amb mf REV	IFX1	Off
C2	High	ROM Mono, 0094: BD-Dance 24	IFX2	Off
C#2	High	ROM Mono, 0093: BD-Dance 23	IFX2	Off
D2	High	ROM Mono, 0135: BD-Dance 63	IFX2	Off
D#2	High	ROM Mono, 0058: BD-B.B.D. 1	IFX2	Off
	M Hi	ROM Mono, 0058: BD-B.B.D. 1		
E2	High	ROM Mono, 0137: BD-Dance 65	IFX2	Off
	M Hi	ROM Mono, 0138: BD-Dance 66		
F2	High	ROM Mono, 0384: SD-Dance 58	IFX1	Off
	M Hi	ROM Mono, 0391: SD-Dance 65		
F#2	High	ROM Mono, 0380: SD-Dance 54	IFX1	Off
	M Hi	ROM Mono, 0380: SD-Dance 54		
G2	High	ROM Mono, 0361: SD-Dance 35	IFX1	Off
	M Hi	ROM Mono, 0341: SD-Dance 15		
	M Lo	ROM Mono, 0338: SD-Dance 12		
G#2	High	ROM Mono, 0359: SD-Dance 33	IFX1	Off
	M Hi	ROM Mono, 0339: SD-Dance 13		
	M Lo	ROM Mono, 0337: SD-Dance 11		
A2	High	ROM Mono, 0356: SD-Dance 30	IFX1	Off
	M Hi	ROM Mono, 0336: SD-Dance 10		
	M Lo	ROM Mono, 0337: SD-Dance 11		
A#2	High	ROM Mono, 0382: SD-Dance 56	IFX1	Off
	M Hi	ROM Mono, 0381: SD-Dance 55		
	M Lo	ROM Mono, 0375: SD-Dance 49		
B2	High	ROM Mono, 0108: BD-Dance 38	IFX2	Off
	M Hi	ROM Mono, 0084: BD-Dance 14		
C3	High	ROM Mono, 0134: BD-Dance 62	IFX2	Off
	M Hi	ROM Mono, 0083: BD-Dance 13		
C#3	High	ROM Mono, 0340: SD-Dance 14	IFX1	Off
	M Hi	ROM Mono, 1176: Dance Perc 09 b		
	M Lo	ROM Mono, 1175: Dance Perc 09 a		
D3	High	ROM Mono, 0884: Tri.& Tamb. g	IFX1	Off
	M Hi	ROM Mono, 0348: SD-Dance 22		
	M Lo	ROM Mono, 0371: SD-Dance 45		

Key		Drumsample	Bus	Ex
D#3	High	ROM Mono, 0693: Hand Claps 2-g -L	IFX1	Off
	M Hi	ROM Mono, 0687: Hand Claps 2-b		
	M Lo	ROM Mono, 0687: Hand Claps 2-b		
E3	High	ROM Mono, 0370: SD-Dance 44	IFX1	Off
	M Hi	ROM Mono, 0381: SD-Dance 55		
	M Lo	ROM Mono, 0374: SD-Dance 48		
F3	High	ROM Mono, 0440: Tom Basic Hi f	IFX2	Off
	M Hi	ROM Mono, 0440: Tom Basic Hi f		
F#3	High	ROM Mono, 0568: Hi-Hat Dance 10	IFX3	1
	M Hi	ROM Mono, 0526: Hi-Hat Heavy 1-Closed mp		
G3	High	ROM Mono, 0442: Tom Soul f	IFX2	Off
	M Hi	ROM Mono, 0442: Tom Soul f		
G#3	High	ROM Mono, 0571: Hi-Hat Dance 13	IFX3	1
	M Hi	ROM Mono, 0530: Hi-Hat Heavy 1-HalfOpen		
	M Lo	ROM Mono, 0530: Hi-Hat Heavy 1-HalfOpen		
A3	High	ROM Mono, 0442: Tom Soul f	IFX2	Off
	M Hi	ROM Mono, 0442: Tom Soul f		
A#3	High	ROM Mono, 0579: Hi-Hat Dance 21	IFX3	1
	M Hi	ROM Mono, 0535: Hi-Hat Heavy 2-Open mf		
	M Lo	ROM Mono, 0535: Hi-Hat Heavy 2-Open mf		
B3	High	ROM Mono, 0865: Pandeiro-ClosedAcca	IFX2	1
	M Hi	ROM Mono, 0444: Tom Vintage Lo mf		
C4	High	ROM Mono, 0865: Pandeiro-ClosedAcca	IFX2	1
	M Hi	ROM Mono, 0448: Tom Vintage Mid mf -L		
C#4	High	ROM Mono, 0629: Crash Cymbal 8	IFX3	Off
	M Hi	ROM Mono, 0633: Crash Dance 1		
D4	High	ROM Mono, 0865: Pandeiro-ClosedAcca	IFX2	1
	M Hi	ROM Mono, 0456: Tom Vintage Hi f		
D#4	High	ROM Mono, 0669: Ride Dance 3	IFX3	Off
	M Hi	ROM Mono, 0651: Ride Cymbal 3 f -L		
E4	High	ROM Mono, 0564: Hi-Hat Dance 06	IFX3	Off
	M Hi	ROM Mono, 0634: Crash Dance 2		
F4	High	ROM Mono, 0648: Ride Cymbal 3 mp	IFX3	Off
	High	ROM Mono, 0873: Tambourine 1-Accent		
F#4	M Hi	ROM Mono, 0871: Tambourine 1-Push	L/R	Off
	M Lo	ROM Mono, 0872: Tambourine 1-Pull		
	High	ROM Mono, 1258: DJ-Record Stop		
G4	M Hi	ROM Mono, 1256: DJ-BD Rub	L/R	Off
	M Lo	ROM Mono, 1258: DJ-Record Stop		
	High	ROM Mono, 0832: Cowbell 4-Open		
G#4	M Hi	ROM Mono, 0833: Cowbell 4-Mute	L/R	Off
	M Lo	ROM Mono, 0833: Cowbell 4-Mute		
A4	High	ROM Mono, 0635: Crash Dance 3	IFX3	Off
	High	ROM Mono, 1418: Stadium		
A#4	M Hi	ROM Mono, 1418: Stadium	L/R	Off
	High	ROM Mono, 0648: Ride Cymbal 3 mp		
	M Hi	ROM Mono, 0648: Ride Cymbal 3 mp		
B4	M Lo	ROM Mono, 0648: Ride Cymbal 3 mp	IFX3	Off
	High	ROM Mono, 1120: WD-Ethno SD 1		
	M Hi	ROM Mono, 1124: WD-Ethno SD 5		
	M Lo	ROM Mono, 1123: WD-Ethno SD 4		
	Low	ROM Mono, 1121: WD-Ethno SD 2		
C5	High	ROM Mono, 1135: WD-Kangaroo 4	L/R	Off
	M Hi	ROM Mono, 1132: WD-Kangaroo 1		
	M Lo	ROM Mono, 1133: WD-Kangaroo 2		
	Low	ROM Mono, 1134: WD-Kangaroo 3		
D5	High	ROM Mono, 0728: Conga Hi-ClosedSlap	L/R	Off
	M Hi	ROM Mono, 0727: Conga Hi-Closed		
	M Lo	ROM Mono, 0720: Conga Hi-Open mf		
D#5	Low	ROM Mono, 0730: Conga Hi-Toe	L/R	Off
	High	ROM Mono, 0738: Quinto-ClosedSlap		
	M Hi	ROM Mono, 0737: Quinto-Closed		
	M Lo	ROM Mono, 0733: Quinto-Open f		
E5	Low	ROM Mono, 0742: Quinto-Toe	L/R	Off
	High	ROM Mono, 0714: Conga Lo-ClosedSlap		
	M Hi	ROM Mono, 0713: Conga Lo-Closed		
F5	M Lo	ROM Mono, 0707: Conga Lo-Open mf	L/R	Off
	Low	ROM Mono, 0716: Conga Lo-Toe		
	High	ROM Mono, 0571: Hi-Hat Dance 13		
F#5	M Hi	ROM Mono, 0571: Hi-Hat Dance 13	IFX3	2
	High	ROM Mono, 0578: Hi-Hat Dance 20		
G5	M Hi	ROM Mono, 0574: Hi-Hat Dance 16	IFX3	2
	High	ROM Mono, 0882: Tri.& Tamb. e		
G#5	M Hi	ROM Mono, 0881: Tri.& Tamb. d	L/R	Off
	High	ROM Mono, 0902: Cabasa 2 S-Stack a		
A5	M Hi	ROM Mono, 0903: Cabasa 2 S-Stack b	L/R	Off

Key		Drumsample	Bus	Ex
A#5	High	ROM Mono,0845:Maracas 2-Push a	L/R	Off
	M Hi	ROM Mono,0848:Maracas 2-Pull b		
	M Lo	ROM Mono,0847:Maracas 2-Pull a		
	Low	ROM Mono,0847:Maracas 2-Pull a		
B5	High	ROM Mono,1461:Explosion	L/R	Off
	M Hi	ROM Mono,1461:Explosion		
C6	High	ROM Mono,1257:DJ-SD Rub	L/R	Off
	M Hi	ROM Mono,1256:DJ-BD Rub		
C#6	High	ROM Mono,0569:Hi-Hat Dance 11	IFX3	Off
	M Hi	ROM Mono,0583:Hi-Hat Dance 25		
D6	High	ROM Mono,0924:Shaker 2 e-Pull	L/R	Off
	M Hi	ROM Mono,0924:Shaker 2 e-Pull		
D#6	High	ROM Mono,1191:Zap 2	IFX1	Off
	M Hi	ROM Mono,1191:Zap 2		
E6	High	ROM Mono,1057:Wood Block 6 a	L/R	Off
	M Hi	ROM Mono,1055:Wood Block 5 a		
F6	High	ROM Mono,0349:SD-Dance 23	IFX1	Off
F#6	High	ROM Mono,0420:SD-Dance Sidestick	L/R	Off
	M Hi	ROM Mono,0420:SD-Dance Sidestick		
G6	High	ROM Mono,1401:Vocoder Voice 19	L/R	Off
	M Hi	ROM Mono,1400:Vocoder Voice 18		
	M Lo	ROM Mono,1398:Vocoder Voice 16		
	Low	ROM Mono,1397:Vocoder Voice 15		
G#6	High	ROM Mono,0954:Triangle 2-Mute b	L/R	3
	M Hi	ROM Mono,0952:Triangle 2-Closed c		
A6	High	ROM Mono,0949:Triangle 2-Open	L/R	3
	M Hi	ROM Mono,0951:Triangle 2-Closed b		
A#6	High	ROM Mono,0921:Shaker 2 d-Push	L/R	Off
	M Hi	ROM Mono,0922:Shaker 2 d-Pull		
	M Lo	ROM Mono,0922:Shaker 2 d-Pull		
B6	High	ROM Mono,1075:Marc Tree	L/R	Off
	M Hi	ROM Mono,1075:Marc Tree		
C7	High	ROM Mono,0119:BD-Dance 49	IFX2	Off
C#7	High	ROM Mono,1594:HarpGliss	IFX3	Off
D7	High	ROM Mono,1437:Glass Crash	IFX3	Off
D#7	High	ROM Mono,0841:Maracas 1-Push a	L/R	Off
E7	High	ROM Mono,1343:Voice 35	L/R	Off
F7	High	ROM Mono,0644:Ride Cymbal 1 f-L	IFX3	Off
	M Hi	ROM Mono,0644:Ride Cymbal 1 f-L		
	M Lo	ROM Mono,0644:Ride Cymbal 1 f-L		
F#7	High	ROM Mono,0327:SD-Dance 01	IFX1	Off
G7	High	ROM Mono,1516:GtCutNois 2	IFX3	Off
G#7	High	ROM Mono,0264:SD-22-amb mf	IFX1	4
A7	High	ROM Mono,0264:SD-22-amb mf	IFX1	4
A#7	High	ROM Mono,1074:Bell Tree-Fast	L/R	Off
B7	High	ROM Mono,1232:DJ Vinyl Sliced 08	L/R	Off
	M Hi	ROM Mono,1232:DJ Vinyl Sliced 08		
C8	High	ROM Mono,1257:DJ-SD Rub	L/R	Off
	M Hi	ROM Mono,1256:DJ-BD Rub		
G9	High	ROM Mono,1424:Click 1	L/R	Off

12 (INT): Mashed Kit

Key		Drumsample	Bus	Ex
C-1	High	ROM Mono, 1424: Click 1	L/R	Off
E0	High	ROM Mono, 0550: Hi-Hat Brush-Closed mf	L/R	4
	M Hi	ROM Mono, 0549: Hi-Hat Brush-Closed mp		
F0	High	ROM Mono, 0557: Hi-Hat Brush-Open f	L/R	4
	M Hi	ROM Mono, 0556: Hi-Hat Brush-Open mf		
F#0	High	ROM Mono, 0517: Hi-Hat Basic 2-Closed f	L/R	4
	M Hi	ROM Mono, 0516: Hi-Hat Basic 2-Closed mf		
G0	High	ROM Mono, 0573: Hi-Hat Dance 15	L/R	Off
	M Hi	ROM Mono, 0572: Hi-Hat Dance 14		
G#0	High	ROM Mono, 0574: Hi-Hat Dance 16	L/R	Off
	M Hi	ROM Mono, 0575: Hi-Hat Dance 17		
A0	High	ROM Mono, 0587: Hi-Hat Dance 29	L/R	Off
	M Hi	ROM Mono, 0586: Hi-Hat Dance 28		
A#0	High	ROM Mono, 1170: Dance Perc 06 b	L/R	Off
	M Hi	ROM Mono, 1169: Dance Perc 06 a		
B0	High	ROM Mono, 1342: Voice 34	L/R	Off
	M Hi	ROM Mono, 1346: Voice 38		
	M Lo	ROM Mono, 1344: Voice 36		
C1	High	ROM Mono, 0130: BD-Dance 58	IFX2	Off
	M Hi	ROM Mono, 0277: SD-Dry		
C#1	High	ROM Mono, 0090: BD-Dance 20	IFX2	Off
D1	High	ROM Mono, 0093: BD-Dance 23	IFX2	Off
	M Hi	ROM Mono, 0093: BD-Dance 23		
D#1	High	ROM Mono, 0109: BD-Dance 39	IFX2	Off
	M Hi	ROM Mono, 0109: BD-Dance 39		
E1	High	ROM Mono, 0097: BD-Dance 27	IFX2	Off
	M Hi	ROM Mono, 0086: BD-Dance 16		
	M Lo	ROM Mono, 0087: BD-Dance 17		
	Low	ROM Mono, 0085: BD-Dance 15		
F1	High	ROM Mono, 0369: SD-Dance 43	IFX1	Off
	M Hi	ROM Mono, 0360: SD-Dance 34		
F#1	High	ROM Mono, 0351: SD-Dance 25	IFX1	Off
	M Hi	ROM Mono, 0357: SD-Dance 31		
G1	High	ROM Mono, 0250: SD-20-dry f	IFX1	Off
	M Hi	ROM Mono, 0172: SD-05-dry mp		
G#1	High	ROM Mono, 0149: SD-01-dry mf	IFX1	Off
	M Hi	ROM Mono, 0157: SD-02-dry ff		
A1	High	ROM Mono, 0124: BD-Dance 54	IFX1	Off
	M Hi	ROM Mono, 0156: SD-02-dry f		
A#1	High	ROM Mono, 0639: Cymbal Reverse 1	L/R	Off
B1	High	ROM Mono, 0265: SD-22-amb mf REV	IFX1	Off
	High	ROM Mono, 0076: BD-Hip 2		
	M Hi	ROM Mono, 0080: BD-Dance Soft		
C2	M Lo	ROM Mono, 0080: BD-Dance Soft	IFX2	Off
	High	ROM Mono, 0091: BD-Dance 21		
	M Hi	ROM Mono, 0091: BD-Dance 21		
C#2	High	ROM Mono, 0130: BD-Dance 58	IFX2	Off
	M Hi	ROM Mono, 0089: BD-Dance 19		
	M Lo	ROM Mono, 0089: BD-Dance 19		
D2	High	ROM Mono, 0121: BD-Dance 51	IFX2	Off
	M Hi	ROM Mono, 0112: BD-Dance 42		
	High	ROM Mono, 0113: BD-Dance 43		
E2	M Hi	ROM Mono, 0110: BD-Dance 40	IFX2	Off
	M Lo	ROM Mono, 0113: BD-Dance 43		
	High	ROM Mono, 0332: SD-Dance 06		
F2	M Hi	ROM Mono, 0336: SD-Dance 10	IFX1	Off
	High	ROM Mono, 0373: SD-Dance 47		
F#2	M Hi	ROM Mono, 0358: SD-Dance 32	IFX1	Off
	High	ROM Mono, 0379: SD-Dance 53		
G2	M Hi	ROM Mono, 0376: SD-Dance 50	IFX1	Off
	High	ROM Mono, 0348: SD-Dance 22		
G#2	M Hi	ROM Mono, 0381: SD-Dance 55	IFX1	Off
	High	ROM Mono, 0347: SD-Dance 21		
A2	M Hi	ROM Mono, 0346: SD-Dance 20	IFX1	Off
	High	ROM Mono, 0399: SD-Dance 73		
A#2	M Hi	ROM Mono, 0328: SD-Dance 02	IFX1	Off
	High	ROM Mono, 0080: BD-Dance Soft		
B2	M Hi	ROM Mono, 0088: BD-Dance 18	IFX2	Off
	High	ROM Mono, 0099: BD-Dance 29		
C3	M Hi	ROM Mono, 0099: BD-Dance 29	IFX2	Off
	High	ROM Mono, 0319: SD-Sidestick 1 f		
C#3	M Hi	ROM Mono, 0319: SD-Sidestick 1 f	IFX1	Off
	M Lo	ROM Mono, 0319: SD-Sidestick 1 f		
	Low	ROM Mono, 0319: SD-Sidestick 1 f		

Key		Drumsample	Bus	Ex
D3	High	ROM Mono, 0330: SD-Dance 04	IFX1	Off
	M Hi	ROM Mono, 0331: SD-Dance 05		
D#3	High	ROM Mono, 1151: Dance Claps 06	IFX3	Off
	M Hi	ROM Mono, 1151: Dance Claps 06		
	M Lo	ROM Mono, 1151: Dance Claps 06		
	Low	ROM Mono, 1151: Dance Claps 06		
E3	High	ROM Mono, 0341: SD-Dance 15	IFX1	Off
	M Hi	ROM Mono, 0336: SD-Dance 10		
F3	High	ROM Mono, 0451: Tom Vintage Mid ff -L	IFX2	Off
	M Hi	ROM Mono, 0450: Tom Vintage Mid f		
	M Lo	ROM Mono, 0448: Tom Vintage Mid mf -L		
	Low	ROM Mono, 0447: Tom Vintage Mid mp		
F#3	High	ROM Mono, 0576: Hi-Hat Dance 18	L/R	1
	M Hi	ROM Mono, 0576: Hi-Hat Dance 18		
G3	High	ROM Mono, 0457: Tom Vintage Hi ff -L	IFX2	Off
	M Hi	ROM Mono, 0456: Tom Vintage Hi f		
	M Lo	ROM Mono, 0454: Tom Vintage Hi mf -L		
	Low	ROM Mono, 0453: Tom Vintage Hi mp		
G#3	High	ROM Mono, 0580: Hi-Hat Dance 22	L/R	1
	M Hi	ROM Mono, 0580: Hi-Hat Dance 22		
A3	High	ROM Mono, 0457: Tom Vintage Hi ff -L	IFX2	Off
	M Hi	ROM Mono, 0456: Tom Vintage Hi f		
	M Lo	ROM Mono, 0454: Tom Vintage Hi mf -L		
	Low	ROM Mono, 0453: Tom Vintage Hi mp		
A#3	High	ROM Mono, 0590: Hi-Hat Dance 32	L/R	1
	M Hi	ROM Mono, 0579: Hi-Hat Dance 21		
B3	High	ROM Mono, 0993: Djembe S-Basstone c	IFX2	Off
	M Hi	ROM Mono, 1102: WD-Native Drum 1		
C4	High	ROM Mono, 0993: Djembe S-Basstone c	IFX2	1
	M Hi	ROM Mono, 1102: WD-Native Drum 1		
C#4	High	ROM Mono, 0633: Crash Dance 1	L/R	Off
	High	ROM Mono, 0993: Djembe S-Basstone c		
D4	M Hi	ROM Mono, 1102: WD-Native Drum 1	IFX2	Off
	High	ROM Mono, 0653: Ride Cymbal 3 ff		
	M Hi	ROM Mono, 0651: Ride Cymbal 3 f -L		
	M Lo	ROM Mono, 0651: Ride Cymbal 3 f -L		
D#4	M Lo	ROM Mono, 0651: Ride Cymbal 3 f -L	L/R	Off
	Low	ROM Mono, 0651: Ride Cymbal 3 f -L		
E4	High	ROM Mono, 0633: Crash Dance 1	L/R	Off
F4	High	ROM Mono, 0669: Ride Dance 3	L/R	Off
	High	ROM Mono, 0873: Tambourine 1-Accent		
	M Hi	ROM Mono, 0871: Tambourine 1-Push		
F#4	M Lo	ROM Mono, 0872: Tambourine 1-Pull	IFX3	Off
	High	ROM Mono, 1239: DJ Vinyl Sliced 15		
	M Hi	ROM Mono, 1239: DJ Vinyl Sliced 15		
G4	M Lo	ROM Mono, 1238: DJ Vinyl Sliced 14	IFX3	Off
	High	ROM Mono, 0832: Cowbell 4-Open		
G#4	M Hi	ROM Mono, 0833: Cowbell 4-Mute	IFX3	Off
	High	ROM Mono, 0635: Crash Dance 3		
A4	High	ROM Mono, 0666: BD-Dance 04	L/R	Off
	M Hi	ROM Mono, 1385: Vocoder Voice 03		
	M Lo	ROM Mono, 1386: Vocoder Voice 04		
	Low	ROM Mono, 1391: Vocoder Voice 09		
B4	High	ROM Mono, 1070: Finger Cymbal	L/R	Off
	M Hi	ROM Mono, 1070: Finger Cymbal		
	M Lo	ROM Mono, 1070: Finger Cymbal		
C5	High	ROM Mono, 0770: Bongo 2 Hi-Open a	IFX3	Off
	M Hi	ROM Mono, 0771: Bongo 2 Hi-Open b		
	M Lo	ROM Mono, 0772: Bongo 2 Hi-Muffled		
	Low	ROM Mono, 0770: Bongo 2 Hi-Open a		
C#5	High	ROM Mono, 0767: Bongo 2 Lo-Open a	IFX3	Off
	M Hi	ROM Mono, 0768: Bongo 2 Lo-Open b		
	M Lo	ROM Mono, 0767: Bongo 2 Lo-Open a		
	Low	ROM Mono, 0769: Bongo 2 Lo-Mute		
D5	High	ROM Mono, 0728: Conga Hi-ClosedSlap	IFX3	Off
	M Hi	ROM Mono, 0727: Conga Hi-Closed		
	M Lo	ROM Mono, 0720: Conga Hi-Open mf		
	Low	ROM Mono, 0730: Conga Hi-Toe		
D#5	High	ROM Mono, 0738: Quinto-ClosedSlap	IFX3	Off
	M Hi	ROM Mono, 0737: Quinto-Closed		
	M Lo	ROM Mono, 0733: Quinto-Open f		
E5	Low	ROM Mono, 0742: Quinto-Toe	IFX3	Off
	High	ROM Mono, 0714: Conga Lo-ClosedSlap		
	M Hi	ROM Mono, 0713: Conga Lo-Closed		
	M Lo	ROM Mono, 0707: Conga Lo-Open mf		
	Low	ROM Mono, 0716: Conga Lo-Toe		

Key		Drumsample	Bus	Ex
F5	High	ROM Mono,0565:Hi-Hat Dance 07	L/R	Off
	M Hi	ROM Mono,0559:Hi-Hat Dance 01		
F#5	High	ROM Mono,0584:Hi-Hat Dance 26	L/R	Off
	M Hi	ROM Mono,0583:Hi-Hat Dance 25		
	M Lo	ROM Mono,0582:Hi-Hat Dance 24		
G5	High	ROM Mono,0882:Tri.& Tamb. e	IFX3	Off
G#5	High	ROM Mono,0881:Tri.& Tamb. d	IFX3	Off
A5	High	ROM Mono,0902:Cabasa 2 S-Stack a	IFX3	Off
	M Hi	ROM Mono,0903:Cabasa 2 S-Stack b		
A#5	High	ROM Mono,0845:Maracas 2-Push a	IFX3	Off
	M Hi	ROM Mono,0848:Maracas 2-Pull b		
	M Lo	ROM Mono,0847:Maracas 2-Pull a		
	Low	ROM Mono,0847:Maracas 2-Pull a		
B5	High	ROM Mono,0362:SD-Dance 36	IFX3	Off
	M Hi	ROM Mono,1458:Cannon 1		
C6	High	ROM Mono,0192:SD-09-amb ff	IFX1	Off
	M Hi	ROM Mono,0264:SD-22-amb mf		
	M Lo	ROM Mono,0192:SD-09-amb ff		
	Low	ROM Mono,0264:SD-22-amb mf		
C#6	High	ROM Mono,0569:Hi-Hat Dance 11	L/R	Off
	M Hi	ROM Mono,0583:Hi-Hat Dance 25		
D6	High	ROM Mono,0924:Shaker 2 e-Pull	IFX3	Off
	M Hi	ROM Mono,0924:Shaker 2 e-Pull		
D#6	High	ROM Mono,1120:WD-Ethno SD 1	IFX3	Off
	M Hi	ROM Mono,1124:WD-Ethno SD 5		
	M Lo	ROM Mono,1123:WD-Ethno SD 4		
	Low	ROM Mono,1121:WD-Ethno SD 2		
E6	High	ROM Mono,1057:Wood Block 6 a	IFX3	Off
	M Hi	ROM Mono,1056:Wood Block 5 b		
F6	High	ROM Mono,1171:Dance Perc 07 a	IFX3	Off
	M Hi	ROM Mono,1172:Dance Perc 07 b		
F#6	High	ROM Mono,1436:Sword 2	IFX3	Off
	M Hi	ROM Mono,1436:Sword 2		
	M Lo	ROM Mono,1436:Sword 2		
	Low	ROM Mono,1435:Sword 1		
G6	High	ROM Mono,1177:Dance Perc 09 c	IFX3	Off
	M Hi	ROM Mono,1177:Dance Perc 09 c		
	M Lo	ROM Mono,1175:Dance Perc 09 a		
G#6	High	ROM Mono,0954:Triangle 2-Mute b	IFX3	3
	M Hi	ROM Mono,0952:Triangle 2-Closed c		
A6	High	ROM Mono,0949:Triangle 2-Open	IFX3	3
	M Hi	ROM Mono,0951:Triangle 2-Closed b		
A#6	High	ROM Mono,0923:Shaker 2 e-Push	IFX3	Off
	M Hi	ROM Mono,0924:Shaker 2 e-Pull		
B6	High	ROM Mono,1075:Marc Tree	IFX3	Off
	M Hi	ROM Mono,1075:Marc Tree		
C7	High	ROM Mono,0641:Ride Cymbal 1 mp	L/R	Off
	M Hi	ROM Mono,0641:Ride Cymbal 1 mp		
	M Lo	ROM Mono,0641:Ride Cymbal 1 mp		
C#7	High	ROM Mono,0642:Ride Cymbal 1 mf -L	L/R	Off
	M Hi	ROM Mono,0642:Ride Cymbal 1 mf -L		
	M Lo	ROM Mono,0642:Ride Cymbal 1 mf -L		
D7	High	ROM Mono,0644:Ride Cymbal 1 f -L	L/R	Off
	M Hi	ROM Mono,0644:Ride Cymbal 1 f -L		
	M Lo	ROM Mono,0644:Ride Cymbal 1 f -L		
D#7	High	ROM Mono,0648:Ride Cymbal 3 mp	L/R	Off
	M Hi	ROM Mono,0648:Ride Cymbal 3 mp		
	M Lo	ROM Mono,0648:Ride Cymbal 3 mp		
E7	High	ROM Mono,1343:Voice 35	IFX3	Off
F7	High	ROM Mono,1230:DJ Vinyl Sliced 06	IFX3	Off
	M Hi	ROM Mono,1231:DJ Vinyl Sliced 07		
	M Lo	ROM Mono,1238:DJ Vinyl Sliced 14		
F#7	High	ROM Mono,1288:Industry Hit 23	IFX3	Off
	M Hi	ROM Mono,1290:Industry Hit 25		
G7	High	ROM Mono,0923:Shaker 2 e-Push	IFX3	Off
	M Hi	ROM Mono,0924:Shaker 2 e-Pull		
G#7	High	ROM Mono,0265:SD-22-amb mf REV	IFX1	5
A7	High	ROM Mono,0264:SD-22-amb mf	IFX1	5
A#7	High	ROM Mono,1074:Bell Tree-Fast	IFX3	Off
B7	High	ROM Mono,1461:Explosion	IFX3	Off
	M Hi	ROM Mono,1461:Explosion		
C8	High	ROM Mono,0841:Maracas 1-Push a	IFX3	Off
C#8	High	ROM Mono,1516:GtCutNois 2	IFX3	Off
G9	High	ROM Mono,1424:Click 1	L/R	Off





Key		Drumsample	Bus	Ex
G#6	High	ROM Mono,0952:Triangle 2-Closed c	IFX1	3
	M Hi	ROM Mono,0954:Triangle 2-Mute b		
A6	High	ROM Mono,0949:Triangle 2-Open	IFX1	3
	M Hi	ROM Mono,0951:Triangle 2-Closed b		
A#6	High	ROM Mono,0924:Shaker 2 e-Pull	IFX1	Off
	M Hi	ROM Mono,0924:Shaker 2 e-Pull		
B6	High	ROM Mono,1440:Door Creak	IFX1	3
C7	High	ROM Mono,1350:Voice 42	IFX1	Off
	M Hi	ROM Mono,1351:Voice 43		
C#7	High	ROM Mono,0580:Hi-Hat Dance 22	L/R	3
D7	High	ROM Mono,1285:Industry Hit 20	IFX1	Off
	M Hi	ROM Mono,1285:Industry Hit 20		
D#7	High	ROM Mono,1281:Industry Hit 16	IFX1	Off
	M Hi	ROM Mono,1281:Industry Hit 16		
E7	High	ROM Mono,1291:Industry Hit 26	IFX1	Off
	M Hi	ROM Mono,1291:Industry Hit 26		
F7	High	ROM Mono,1384:Vocoder Voice 02	IFX1	Off
	M Hi	ROM Mono,1401:Vocoder Voice 19		
F#7	High	ROM Mono,1286:Industry Hit 21	IFX1	Off
	M Hi	ROM Mono,1261:Industry Hit 02		
G7	High	ROM Mono,1516:GtCutNois 2	IFX1	Off
G#7	High	ROM Mono,1337:Voice 29	IFX1	Off
	M Hi	ROM Mono,1338:Voice 30		
A7	High	ROM Mono,1343:Voice 35	IFX1	Off
A#7	High	ROM Mono,1074:Bell Tree-Fast	IFX1	Off
B7	High	ROM Mono,1418:Stadium	IFX1	Off
	M Hi	ROM Mono,1418:Stadium		
C8	High	ROM Mono,1074:Bell Tree-Fast	IFX1	Off
C#8	High	ROM Mono,1317:Voice 09	IFX1	Off
	M Hi	ROM Mono,1319:Voice 11		
	M Lo	ROM Mono,1312:Voice 04		
D8	High	ROM Mono,1326:Voice 18	IFX1	Off
	M Hi	ROM Mono,1324:Voice 16		
	M Lo	ROM Mono,1320:Voice 12		
D#8	High	ROM Mono,1351:Voice 43	IFX1	Off
	M Hi	ROM Mono,1349:Voice 41		
E8	High	ROM Mono,0061:BD-Jungle 2	IFX3	Off
	M Hi	ROM Mono,0060:BD-Jungle 1		
	M Lo	ROM Mono,0060:BD-Jungle 1		
G9	High	ROM Mono,1424:Click 1	L/R	Off



Key		Drumsample	Bus	Ex
D#6	High	ROM Mono, 1120:WD-Ethno SD 1	IFX3	Off
	M Hi	ROM Mono, 1124:WD-Ethno SD 5		
	M Lo	ROM Mono, 1123:WD-Ethno SD 4		
	Low	ROM Mono, 1121:WD-Ethno SD 2		
E6	High	ROM Mono, 1057:Wood Block 6 a	IFX3	Off
	M Hi	ROM Mono, 1057:Wood Block 6 a		
F6	High	ROM Mono, 1171:Dance Perc 07 a	IFX3	Off
	M Hi	ROM Mono, 1171:Dance Perc 07 a		
F#6	High	ROM Mono, 1437:Glass Crash	IFX3	Off
	M Hi	ROM Mono, 1437:Glass Crash		
G6	High	ROM Mono, 1172:Dance Perc 07 b	IFX3	Off
	M Hi	ROM Mono, 1172:Dance Perc 07 b		
G#6	High	ROM Mono, 0954:Triangle 2-Mute b	IFX3	3
	M Hi	ROM Mono, 0952:Triangle 2-Closed c		
A6	High	ROM Mono, 0949:Triangle 2-Open	IFX3	3
	M Hi	ROM Mono, 0951:Triangle 2-Closed b		
A#6	High	ROM Mono, 0923:Shaker 2 e-Push	IFX3	Off
	M Hi	ROM Mono, 0924:Shaker 2 e-Pull		
B6	High	ROM Mono, 0924:Shaker 2 e-Pull	IFX3	Off
	M Hi	ROM Mono, 0924:Shaker 2 e-Pull		
C7	High	ROM Mono, 1087:Jew's Harp 05	IFX3	Off
	M Hi	ROM Mono, 1089:Jew's Harp 07		
C#7	High	ROM Mono, 1352:Voice 44	IFX3	Off
D7	High	ROM Mono, 1434:Tribe	IFX3	Off
D#7	High	ROM Mono, 1081:Bull Roar	IFX3	Off
	M Hi	ROM Mono, 1081:Bull Roar		
E7	High	ROM Mono, 1077:Rainstick 1 b	IFX3	Off
	M Hi	ROM Mono, 1077:Rainstick 1 b		
F7	High	ROM Mono, 1339:Voice 31	IFX3	Off
	M Hi	ROM Mono, 1339:Voice 31		
F#7	High	ROM Mono, 1307:Industry Loop 3	IFX3	Off
G7	High	ROM Mono, 1516:GtCutNois 2	IFX3	Off
	M Hi	ROM Mono, 1515:GtCutNois 1		
G#7	High	ROM Mono, 1516:GtCutNois 2	IFX3	Off
A7	High	ROM Mono, 1074:Bell Tree-Fast	IFX3	Off
A#7	High	ROM Mono, 1343:Voice 35	IFX3	Off
B7	High	ROM Mono, 1461:Explosion	IFX3	Off
	M Hi	ROM Mono, 1461:Explosion		
C8	High	ROM Mono, 0841:Maracas 1-Push a	IFX3	Off
G9	High	ROM Mono, 1424:Click 1	L/R	Off

15 (INT): Trance Kit

Key		Drumsample	Bus	Ex
C-1	High	ROM Mono, 1424: Click 1	L/R	Off
E0	High	ROM Mono, 0562: Hi-Hat Dance 04	L/R	Off
	M Hi	ROM Mono, 0562: Hi-Hat Dance 04		
F0	High	ROM Mono, 0587: Hi-Hat Dance 29	L/R	5
	M Hi	ROM Mono, 0587: Hi-Hat Dance 29		
	M Lo	ROM Mono, 0587: Hi-Hat Dance 29		
F#0	High	ROM Mono, 0588: Hi-Hat Dance 30	L/R	5
	M Hi	ROM Mono, 0588: Hi-Hat Dance 30		
G0	High	ROM Mono, 0573: Hi-Hat Dance 15	L/R	4
	M Hi	ROM Mono, 0572: Hi-Hat Dance 14		
G#0	High	ROM Mono, 0578: Hi-Hat Dance 20	L/R	4
A0	High	ROM Mono, 0581: Hi-Hat Dance 23	L/R	Off
A#0	High	ROM Mono, 1167: Dance Perc 04-Open	L/R	Off
	M Hi	ROM Mono, 1166: Dance Perc 04-Closed		
B0	High	ROM Mono, 0579: Hi-Hat Dance 21	L/R	Off
C1	High	ROM Mono, 0075: BD-Pop	IFX2	Off
	M Hi	ROM Mono, 0090: BD-Dance 20		
C#1	High	ROM Mono, 1086: Jew's Harp 04	IFX2	Off
	M Hi	ROM Mono, 117: BD-Dance 47		
	M Lo	ROM Mono, 1090: Jew's Harp 08		
D1	High	ROM Mono, 0131: BD-Dance 59	IFX2	Off
	M Hi	ROM Mono, 0133: BD-Dance 61		
D#1	High	ROM Mono, 0092: BD-Dance 22	IFX2	Off
	M Hi	ROM Mono, 0088: BD-Dance 18		
E1	High	ROM Mono, 0081: BD-Dance Short	IFX2	Off
F1	High	ROM Mono, 0339: SD-Dance 13	IFX3	Off
	M Hi	ROM Mono, 1291: Industry Hit 26		
F#1	High	ROM Mono, 0394: SD-Dance 68	IFX1	Off
G1	High	ROM Mono, 1155: Dance Claps 10	IFX3	Off
	M Hi	ROM Mono, 1348: Voice 40		
G#1	High	ROM Mono, 0395: SD-Dance 69	IFX1	Off
	M Hi	ROM Mono, 1348: Voice 40		
A1	High	ROM Mono, 0346: SD-Dance 20	IFX1	Off
A#1	High	ROM Mono, 0639: Cymbal Reverse 1	L/R	Off
B1	High	ROM Mono, 0265: SD-22-amb mf REV	L/R	Off
C2	High	ROM Mono, 0129: BD-Dance 57	IFX2	Off
	M Hi	ROM Mono, 0144: BD-Dance 72		
C#2	High	ROM Mono, 0097: BD-Dance 27	IFX2	Off
	M Hi	ROM Mono, 1261: Industry Hit 02		
	High	ROM Mono, 127: BD-Dance Zap 2		
D2	M Hi	ROM Mono, 127: BD-Dance Zap 2	IFX2	Off
	M Lo	ROM Mono, 127: BD-Dance Zap 2		
	Low	ROM Mono, 127: BD-Dance Zap 2		
	High	ROM Mono, 126: BD-Dance Zap 1		
D#2	M Hi	ROM Mono, 126: BD-Dance Zap 1	IFX2	Off
	M Lo	ROM Mono, 0126: BD-Dance Zap 1		
	Low	ROM Mono, 0126: BD-Dance Zap 1		
E2	High	ROM Mono, 1191: Zap 2	IFX2	Off
	M Hi	ROM Mono, 131: BD-Dance 59		
	M Lo	ROM Mono, 131: BD-Dance 59		
F2	High	ROM Mono, 0413: SD-WS 08 (Tenny)	IFX1	Off
	M Hi	ROM Mono, 0402: SD-Sizzle		
F#2	High	ROM Mono, 0386: SD-Dance 60	IFX1	Off
	M Hi	ROM Mono, 0333: SD-Dance 07		
G2	High	ROM Mono, 0271: SD-24-dry f -R	IFX1	Off
	M Hi	ROM Mono, 0270: SD-24-dry f -L		
G#2	High	ROM Mono, 1149: Dance Claps 04	IFX1	Off
	M Hi	ROM Mono, 0685: Hand Claps 2-a -L		
A2	High	ROM Mono, 0401: SD-Noise	IFX1	Off
	M Hi	ROM Mono, 1167: Dance Perc 04-Open		
A#2	High	ROM Mono, 0402: SD-Sizzle	IFX1	Off
B2	High	ROM Mono, 0142: BD-Dance 70	IFX2	Off
	M Hi	ROM Mono, 0133: BD-Dance 61		
C3	High	ROM Mono, 0141: BD-Dance 69	IFX2	Off
	M Hi	ROM Mono, 0134: BD-Dance 62		
C#3	High	ROM Mono, 1147: Dance Claps 02	IFX1	Off
	M Hi	ROM Mono, 1149: Dance Claps 04		
	M Lo	ROM Mono, 1147: Dance Claps 02		
D3	High	ROM Mono, 0385: SD-Dance 59	IFX1	Off
	M Hi	ROM Mono, 0384: SD-Dance 58		
	M Lo	ROM Mono, 0384: SD-Dance 58		
	Low	ROM Mono, 0384: SD-Dance 58		

Key		Drumsample	Bus	Ex
D#3	High	ROM Mono, 1149: Dance Claps 04	IFX1	Off
	M Hi	ROM Mono, 1149: Dance Claps 04		
	M Lo	ROM Mono, 1149: Dance Claps 04		
E3	High	ROM Mono, 0387: SD-Dance 61	IFX1	Off
F3	High	ROM Mono, 0333: SD-Dance 07	IFX3	Off
	M Hi	ROM Mono, 0348: SD-Dance 22		
F#3	High	ROM Mono, 0576: Hi-Hat Dance 18	L/R	1
	M Hi	ROM Mono, 1169: Dance Perc 06 a		
	M Lo	ROM Mono, 0572: Hi-Hat Dance 14		
G3	High	ROM Mono, 0348: SD-Dance 22	IFX3	Off
	M Hi	ROM Mono, 0348: SD-Dance 22		
G#3	High	ROM Mono, 0577: Hi-Hat Dance 19	L/R	1
	M Hi	ROM Mono, 1171: Dance Perc 07 a		
	M Lo	ROM Mono, 0573: Hi-Hat Dance 15		
A3	High	ROM Mono, 0333: SD-Dance 07	IFX3	Off
	M Hi	ROM Mono, 0348: SD-Dance 22		
A#3	High	ROM Mono, 0575: Hi-Hat Dance 17	L/R	1
	M Hi	ROM Mono, 1172: Dance Perc 07 b		
	M Lo	ROM Mono, 0574: Hi-Hat Dance 16		
B3	High	ROM Mono, 0353: SD-Dance 27	IFX3	Off
	M Hi	ROM Mono, 0348: SD-Dance 22		
C4	High	ROM Mono, 1188: E.Tom 1	IFX3	Off
C#4	High	ROM Mono, 0635: Crash Dance 3	L/R	Off
D4	High	ROM Mono, 1189: E.Tom 2	IFX3	Off
D#4	High	ROM Mono, 0667: Ride Dance 1	L/R	Off
	M Hi	ROM Mono, 0668: Ride Dance 2		
E4	High	ROM Mono, 0633: Crash Dance 1	L/R	Off
F4	High	ROM Mono, 0669: Ride Dance 3	L/R	Off
F#4	High	ROM Mono, 0579: Hi-Hat Dance 21	L/R	Off
	M Hi	ROM Mono, 1172: Dance Perc 07 b		
G4	High	ROM Mono, 1165: Dance Perc 03-Open	IFX3	Off
	M Hi	ROM Mono, 1482: Noise-VPM Mod		
G#4	High	ROM Mono, 0584: Hi-Hat Dance 26	L/R	Off
A4	High	ROM Mono, 0637: Crash Dance 5	L/R	Off
A#4	High	ROM Mono, 0585: Hi-Hat Dance 27	L/R	Off
B4	High	ROM Mono, 1484: Meditation Tree	L/R	Off
	M Hi	ROM Mono, 1484: Meditation Tree		
C5	High	ROM Mono, 1171: Dance Perc 07 a	L/R	Off
	M Hi	ROM Mono, 1169: Dance Perc 06 a		
C#5	High	ROM Mono, 1187: Dance SynMaraca	L/R	Off
	M Hi	ROM Mono, 1171: Dance Perc 07 a		
D5	High	ROM Mono, 0723: Conga Hi-OpenSlap	IFX3	Off
	M Hi	ROM Mono, 0730: Conga Hi-Toe		
D#5	High	ROM Mono, 0720: Conga Hi-Open mf	IFX3	Off
	M Hi	ROM Mono, 0727: Conga Hi-Closed		
E5	High	ROM Mono, 0707: Conga Lo-Open mf	IFX3	Off
	M Hi	ROM Mono, 0713: Conga Lo-Closed		
F5	High	ROM Mono, 0586: Hi-Hat Dance 28	L/R	7
F#5	High	ROM Mono, 0588: Hi-Hat Dance 30	L/R	7
G5	High	ROM Mono, 0889: Tri.& Tamb.l	IFX3	Off
	M Hi	ROM Mono, 0888: Tri.& Tamb.k		
G#5	High	ROM Mono, 0889: Tri.& Tamb.l	IFX3	Off
	M Hi	ROM Mono, 0890: Tri.& Tamb.m		
A5	High	ROM Mono, 0898: Cabasa 1 S b-up	IFX3	Off
	M Hi	ROM Mono, 0896: Cabasa 1 S a-Up		
A#5	High	ROM Mono, 0897: Cabasa 1 S b-Down	IFX3	Off
	M Hi	ROM Mono, 0898: Cabasa 1 S b-up		
B5	High	ROM Mono, 0058: BD-B.B.D. 1	IFX2	Off
	M Hi	ROM Mono, 0133: BD-Dance 61		
C6	High	ROM Mono, 1154: Dance Claps 09	IFX3	Off
	M Hi	ROM Mono, 1347: Voice 39		
C#6	High	ROM Mono, 01435: Sword 1	IFX3	Off
	M Hi	ROM Mono, 1436: Sword 2		
D6	High	ROM Mono, 1439: Ice Drop	IFX3	Off
D#6	High	ROM Mono, 1459: Cannon 2	IFX3	Off
	High	ROM Mono, 1400: Vocoder Voice 18		
	M Hi	ROM Mono, 1402: Vocoder Voice 20		
E6	M Lo	ROM Mono, 1398: Vocoder Voice 16	IFX3	Off
	High	ROM Mono, 1401: Vocoder Voice 19		
	M Hi	ROM Mono, 1398: Vocoder Voice 16		
F6	High	ROM Mono, 1343: Voice 35	IFX1	Off
	M Hi	ROM Mono, 1345: Voice 37		
F#6	High	ROM Mono, 1335: Voice 27	IFX3	Off
	M Hi	ROM Mono, 1417: Psycho Voice		

Key		Drumsample	Bus	Ex
G#6	High	ROM Mono,0954:Triangle 2-Mute b	IFX3	4
	M Hi	ROM Mono,0952:Triangle 2-Closed c		
A6	High	ROM Mono,0949:Triangle 2-Open	IFX3	4
	M Hi	ROM Mono,0951:Triangle 2-Closed b		
A#6	High	ROM Mono,0924:Shaker 2 e-Pull	IFX3	3
	M Hi	ROM Mono,0924:Shaker 2 e-Pull		
B6	High	ROM Mono,1075:Marc Tree	IFX3	Off
	M Hi	ROM Mono,1075:Marc Tree		
C7	High	ROM Mono,0143:BD-Dance 71	IFX1	Off
C#7	High	ROM Mono,1167:Dance Perc 04-Open	IFX3	Off
	M Hi	ROM Mono,1166:Dance Perc 04-Closed		
D7	High	ROM Mono,1000:Udu-HalfOpen b	IFX3	Off
	M Hi	ROM Mono,1119:WD-Brazilia 2		
D#7	High	ROM Mono,1281:Industry Hit 16	IFX3	Off
E7	High	ROM Mono,1001:Udu-HalfOpen c	IFX3	Off
	M Hi	ROM Mono,0999:Udu-HalfOpen a		
F7	High	ROM Mono,1007:Udu-Bell b	IFX3	Off
	M Hi	ROM Mono,1007:Udu-Bell b		
F#7	High	ROM Mono,0342:SD-Dance 16	IFX3	Off
	M Hi	ROM Mono,1290:Industry Hit 25		
G7	High	ROM Mono,0923:Shaker 2 e-Push	IFX3	3
	M Hi	ROM Mono,0923:Shaker 2 e-Push		
G#7	High	ROM Mono,1073:Bell Tree-Slow	L/R	Off
A7	High	ROM Mono,1074:Bell Tree-Fast	L/R	Off
A#7	High	ROM Mono,0640:Cymbal Reverse 2	L/R	Off
B7	High	ROM Mono,1418:Stadium	IFX3	Off
	M Hi	ROM Mono,1418:Stadium		
C8	High	ROM Mono,1419:Applause	L/R	Off
C#8	High	ROM Mono,1077:Rainstick 1 b	L/R	Off
D8	High	ROM Mono,1461:Explosion	L/R	Off
	M Hi	ROM Mono,1461:Explosion		
G9	High	ROM Mono,1424:Click 1	L/R	Off



Key		Drumsample	Bus	Ex
G6	High	ROM Mono, 1335:Voice 27	IFX3	Off
	M Hi	ROM Mono, 1337:Voice 29		
G#6	High	ROM Mono, 0954:Triangle 2-Mute b	IFX3	3
	M Hi	ROM Mono, 0952:Triangle 2-Closed c		
A6	High	ROM Mono, 0949:Triangle 2-Open	IFX3	3
	M Hi	ROM Mono, 0951:Triangle 2-Closed b		
A#6	High	ROM Mono, 0923:Shaker 2 e-Push	IFX3	Off
	M Hi	ROM Mono, 0924:Shaker 2 e-Pull		
B6	High	ROM Mono, 1077:Rainstick 1 b	IFX3	Off
	M Hi	ROM Mono, 1077:Rainstick 1 b		
C7	High	ROM Mono, 1087:Jew's Harp 05	IFX3	Off
	M Hi	ROM Mono, 0089:BD-Dance 19		
	M Lo	ROM Mono, 1087:Jew's Harp 05		
C#7	High	ROM Mono, 1516:GtCutNois 2	IFX3	15
	M Hi	ROM Mono, 1515:GtCutNois 1		
D7	High	ROM Mono, 1434:Tribe	IFX3	Off
	M Hi	ROM Mono, 1316:Voice 08		
D#7	High	ROM Mono, 0973:Whistle 5	IFX3	15
E7	High	ROM Mono, 1307:Industry Loop 3	IFX3	Off
F7	High	ROM Mono, 1339:Voice 31	IFX3	Off
	M Hi	ROM Mono, 1339:Voice 31		
F#7	High	ROM Mono, 1125:WD-Ethno SD 6	IFX3	Off
	M Hi	ROM Mono, 1124:WD-Ethno SD 5		
	M Lo	ROM Mono, 1123:WD-Ethno SD 4		
	Low	ROM Mono, 1122:WD-Ethno SD 3		
G7	High	ROM Mono, 0924:Shaker 2 e-Pull	IFX3	Off
	M Hi	ROM Mono, 0924:Shaker 2 e-Pull		
G#7	High	ROM Mono, 1352:Voice 44	IFX3	Off
	M Hi	ROM Mono, 1354:Voice 46		
A7	High	ROM Mono, 1343:Voice 35	IFX3	Off
A#7	High	ROM Mono, 1074:Bell Tree-Fast	IFX3	Off
B7	High	ROM Mono, 1461:Explosion	IFX3	Off
	M Hi	ROM Mono, 1461:Explosion		
C8	High	ROM Mono, 0841:Maracas 1-Push a	IFX3	Off
C#8	High	ROM Mono, 0577:Hi-Hat Dance 19	L/R	1
	M Hi	ROM Mono, 0573:Hi-Hat Dance 15		
	M Lo	ROM Mono, 0572:Hi-Hat Dance 14		
D8	High	ROM Mono, 0513:Hi-Hat Basic 1-Open f	L/R	Off
	M Hi	ROM Mono, 0510:Hi-Hat Basic 1-Pedal f		
	M Lo	ROM Mono, 0508:Hi-Hat Basic 1-Pedal mp		
D#8	High	ROM Mono, 0579:Hi-Hat Dance 21	L/R	1
E8	High	ROM Mono, 0573:Hi-Hat Dance 15	L/R	2
	M Hi	ROM Mono, 0572:Hi-Hat Dance 14		
F8	High	ROM Mono, 0575:Hi-Hat Dance 17	L/R	2
F#8	High	ROM Mono, 0146:BD-Dance Revers	L/R	Off
G8	High	ROM Mono, 1232:DJ Vinyl Sliced 08	L/R	Off
G#8	High	ROM Mono, 0668:Ride Dance 2	L/R	Off
A8	High	ROM Mono, 0881:Tri.& Tamb. d	IFX3	Off
	M Hi	ROM Mono, 0879:Tri.& Tamb. b		
G9	High	ROM Mono, 1424:Click 1	L/R	Off

17 (INT): Psycho-Chill Kit

Key		Drumsample	Bus	Ex
C-1	High	ROM Mono, 1424: Click 1	L/R	Off
E0	High	ROM Mono, 0569: Hi-Hat Dance 11	L/R	Off
	M Hi	ROM Mono, 0569: Hi-Hat Dance 11		
F0	High	ROM Mono, 0534: Hi-Hat Heavy 2-Closed ff	L/R	4
	M Hi	ROM Mono, 0533: Hi-Hat Heavy 2-Closed f		
	M Lo	ROM Mono, 0531: Hi-Hat Heavy 2-Closed mp		
F#0	High	ROM Mono, 0519: Hi-Hat Basic 2-Open mf	L/R	4
G0	High	ROM Mono, 0566: Hi-Hat Dance 08	L/R	5
	M Hi	ROM Mono, 0566: Hi-Hat Dance 08		
G#0	High	ROM Mono, 0600: Hi-Hat-Crisp Open	L/R	5
A0	High	ROM Mono, 0565: Hi-Hat Dance 07	L/R	Off
	M Hi	ROM Mono, 0565: Hi-Hat Dance 07		
A#0	High	ROM Mono, 0545: Hi-Hat Basic 4-Open 2	L/R	Off
	M Hi	ROM Mono, 0599: Hi-Hat-Ambi		
	M Lo	ROM Mono, 0545: Hi-Hat Basic 4-Open 2		
B0	High	ROM Mono, 0593: Hi-Hat WS-HalfOpen	L/R	Off
	M Hi	ROM Mono, 0592: Hi-Hat WS-Closed		
C1	High	ROM Mono, 0101: BD-Dance 31	IFX2	Off
	M Hi	ROM Mono, 1393: Vocoder Voice 11		
	M Lo	ROM Mono, 0101: BD-Dance 31		
C#1	High	ROM Mono, 0097: BD-Dance 27	IFX2	Off
	M Hi	ROM Mono, 0057: BD-Cannon		
D1	High	ROM Mono, 1138: WD-Kangaroo 7	IFX2	Off
	M Hi	ROM Mono, 0091: BD-Dance 21		
	M Lo	ROM Mono, 1138: WD-Kangaroo 7		
D#1	High	ROM Mono, 0138: BD-Dance 66	IFX2	Off
	M Hi	ROM Mono, 0859: Pandeiro-Jingle b		
	M Lo	ROM Mono, 0138: BD-Dance 66		
E1	High	ROM Mono, 0847: Maracas 2-Pull a	IFX2	Off
	M Hi	ROM Mono, 0102: BD-Dance 32		
	M Lo	ROM Mono, 0846: Maracas 2-Push b		
F1	High	ROM Mono, 1450: Railroad Crossing	IFX1	Off
	M Hi	ROM Mono, 0398: SD-Dance 72		
F#1	High	ROM Mono, 1152: Dance Claps 07	IFX1	Off
	M Hi	ROM Mono, 0400: SD-Dance 74		
G1	High	ROM Mono, 1280: Industry Hit 15	IFX1	Off
	M Hi	ROM Mono, 1150: Dance Claps 05		
G#1	High	ROM Mono, 0785: Iya Chacha-OpenSlap ff	IFX1	Off
	M Hi	ROM Mono, 0279: SD-Jazz Ring		
A1	High	ROM Mono, 1167: Dance Perc 04-Open	IFX1	Off
	M Hi	ROM Mono, 0391: SD-Dance 65		
	M Lo	ROM Mono, 1167: Dance Perc 04-Open		
A#1	High	ROM Mono, 0639: Cymbal Reverse 1	L/R	Off
B1	High	ROM Mono, 0265: SD-22-amb mf REV	IFX1	Off
	High	ROM Mono, 0088: BD-Dance 18		
C2	M Hi	ROM Mono, 0070: BD-Dance 06	IFX2	Off
	M Lo	ROM Mono, 0088: BD-Dance 18		
C#2	High	ROM Mono, 0125: BD-Dance 55	IFX2	Off
	M Hi	ROM Mono, 0118: BD-Dance 48		
D2	High	ROM Mono, 0121: BD-Dance 51	IFX2	Off
	M Hi	ROM Mono, 0064: BD-Dance 03		
D#2	High	ROM Mono, 0029: BD-06-amb ff	IFX2	Off
	M Hi	ROM Mono, 1063: Timpani mf		
	M Lo	ROM Mono, 0029: BD-06-amb ff		
E2	High	ROM Mono, 0986: Djembe L-Basstone b	IFX2	Off
	M Hi	ROM Mono, 0134: BD-Dance 62		
	M Lo	ROM Mono, 0986: Djembe L-Basstone b		
F2	High	ROM Mono, 0344: SD-Dance 18	IFX1	Off
	M Hi	ROM Mono, 0343: SD-Dance 17		
	M Lo	ROM Mono, 0344: SD-Dance 18		
F#2	High	ROM Mono, 0376: SD-Dance 50	IFX1	Off
	M Hi	ROM Mono, 1479: Noise		
	M Lo	ROM Mono, 0376: SD-Dance 50		
G2	High	ROM Mono, 0866: Pandeiro-ClosedAcc.b	IFX1	Off
	M Hi	ROM Mono, 0868: Pandeiro-SideEdge		
	M Lo	ROM Mono, 1125: WD-Ethno SD 6		
G#2	High	ROM Mono, 0328: SD-Dance 02	IFX1	Off
	M Hi	ROM Mono, 0360: SD-Dance 34		
	M Lo	ROM Mono, 0328: SD-Dance 02		
A2	High	ROM Mono, 1284: Industry Hit 19	IFX1	Off
	M Hi	ROM Mono, 0350: SD-Dance 24		
A#2	High	ROM Mono, 0351: SD-Dance 25	IFX1	Off
	M Hi	ROM Mono, 0348: SD-Dance 22		

Key		Drumsample	Bus	Ex
B2	High	ROM Mono, 0120: BD-Dance 50	IFX2	Off
	M Hi	ROM Mono, 0125: BD-Dance 55		
	M Lo	ROM Mono, 0120: BD-Dance 50		
C3	High	ROM Mono, 0088: BD-Dance 18	IFX2	Off
	M Hi	ROM Mono, 0088: BD-Dance 18		
	M Lo	ROM Mono, 0088: BD-Dance 18		
C#3	High	ROM Mono, 0325: SD-Sidestick 4 f	IFX1	Off
	M Hi	ROM Mono, 1482: Noise-VPM Mod		
D3	High	ROM Mono, 0691: Hand Claps 2-e	IFX1	Off
	M Hi	ROM Mono, 1137: WD-Kangaroo 6		
D#3	High	ROM Mono, 1152: Dance Claps 07	IFX3	Off
	M Hi	ROM Mono, 0685: Hand Claps 2-a -L		
E3	High	ROM Mono, 0367: SD-Dance 41	IFX1	Off
	M Hi	ROM Mono, 0218: SD-12-amb fff		
F3	High	ROM Mono, 0502: Tom Brush2 Floor	IFX1	Off
	M Hi	ROM Mono, 0445: Tom Vintage Lo f		
F#3	High	ROM Mono, 0587: Hi-Hat Dance 29	L/R	1
	M Hi	ROM Mono, 0586: Hi-Hat Dance 28		
G3	High	ROM Mono, 0503: Tom Brush2 Hi	IFX1	Off
	M Hi	ROM Mono, 0448: Tom Vintage Mid mf -L		
G#3	High	ROM Mono, 0562: Hi-Hat Dance 04	L/R	Off
	M Hi	ROM Mono, 0562: Hi-Hat Dance 04		
A3	High	ROM Mono, 0503: Tom Brush2 Hi	IFX1	Off
	M Hi	ROM Mono, 0454: Tom Vintage Hi mf -L		
A#3	High	ROM Mono, 0588: Hi-Hat Dance 30	L/R	1
	High	ROM Mono, 1143: Dance Perc 02		
B3	M Hi	ROM Mono, 1478: Swish Terra	IFX1	Off
	M Lo	ROM Mono, 1143: Dance Perc 02		
	High	ROM Mono, 1143: Dance Perc 02		
C4	M Hi	ROM Mono, 1478: Swish Terra	IFX1	Off
	M Lo	ROM Mono, 1143: Dance Perc 02		
	High	ROM Mono, 0621: Crash Cymbal 5 mf		
C#4	High	ROM Mono, 0621: Crash Cymbal 5 mf	L/R	Off
	M Hi	ROM Mono, 1143: Dance Perc 02		
D4	M Hi	ROM Mono, 1478: Swish Terra	IFX1	Off
	M Lo	ROM Mono, 1143: Dance Perc 02		
	High	ROM Mono, 0651: Ride Cymbal 3 f -L		
D#4	M Hi	ROM Mono, 0649: Ride Cymbal 3 mf -L	L/R	Off
	M Lo	ROM Mono, 0648: Ride Cymbal 3 mp		
	High	ROM Mono, 0627: Crash Cymbal 7 f -L		
E4	M Hi	ROM Mono, 0627: Crash Cymbal 7 f -L	L/R	Off
	M Hi	ROM Mono, 0627: Crash Cymbal 7 f -L		
F4	High	ROM Mono, 0655: Ride Cymbal 4 f	L/R	Off
	High	ROM Mono, 0877: Tambourine 2-Accent		
F#4	M Hi	ROM Mono, 0874: Tambourine 2-Push	IFX3	Off
	M Lo	ROM Mono, 0875: Tambourine 2-Pull a		
	High	ROM Mono, 0679: Splash Cymbal 1 ff -R		
G4	M Hi	ROM Mono, 0677: Splash Cymbal 1 f	L/R	Off
	M Lo	ROM Mono, 0676: Splash Cymbal 1 mf		
	High	ROM Mono, 1091: Jew's Harp 09		
G#4	M Hi	ROM Mono, 1398: Vocoder Voice 16	IFX3	Off
	M Lo	ROM Mono, 1091: Jew's Harp 09		
	High	ROM Mono, 0630: Crash Cymbal 9		
A4	M Hi	ROM Mono, 0630: Crash Cymbal 9	L/R	Off
	M Hi	ROM Mono, 0630: Crash Cymbal 9		
A#4	High	ROM Mono, 0973: Whistle 5	IFX3	Off
B4	High	ROM Mono, 0641: Ride Cymbal 1 mp	L/R	Off
	M Hi	ROM Mono, 0641: Ride Cymbal 1 mp		
C5	High	ROM Mono, 0756: Bongo 1 Hi-Open f	IFX3	Off
	M Hi	ROM Mono, 0755: Bongo 1 Hi-Open mf		
	M Lo	ROM Mono, 0756: Bongo 1 Hi-Open f		
C#5	High	ROM Mono, 0744: Bongo 1 Lo-Muffled f	IFX3	Off
	M Hi	ROM Mono, 0743: Bongo 1 Lo-Muffled mp		
	M Lo	ROM Mono, 0745: Bongo 1 Lo-Closed		
D5	High	ROM Mono, 0728: Conga Hi-ClosedSlap	IFX3	Off
	M Hi	ROM Mono, 0727: Conga Hi-Closed		
D#5	High	ROM Mono, 0723: Conga Hi-OpenSlap	IFX3	Off
	M Hi	ROM Mono, 0720: Conga Hi-Open mf		
	M Lo	ROM Mono, 0721: Conga Hi-Open f		
E5	Low	ROM Mono, 0719: Conga Hi-Open mp	IFX3	Off
	High	ROM Mono, 0709: Conga Lo-OpenSlap		
	M Hi	ROM Mono, 0707: Conga Lo-Open mf		
F5	M Lo	ROM Mono, 0708: Conga Lo-Open f	L/R	7
	High	ROM Mono, 0605: Hi-Hat Dance 36		
F#5	M Hi	ROM Mono, 0605: Hi-Hat Dance 36	L/R	7
	High	ROM Mono, 0606: Hi-Hat Dance 37		



Key		Drumsample	Bus	Ex
G5	High	ROM Mono,0888:Tri.& Tamb. k	IFX3	Off
	M Hi	ROM Mono,0890:Tri.& Tamb. m		
	M Lo	ROM Mono,0888:Tri.& Tamb. k		
G#5	High	ROM Mono,0888:Tri.& Tamb. k	IFX3	Off
	M Hi	ROM Mono,0890:Tri.& Tamb. m		
	M Lo	ROM Mono,0888:Tri.& Tamb. k		
A5	High	ROM Mono,0918:Shaker 2 b-Push	IFX3	Off
	M Hi	ROM Mono,0919:Shaker 2 b-Pull		
A#5	High	ROM Mono,0848:Maracas 2-Pull b	IFX3	Off
	M Hi	ROM Mono,0847:Maracas 2-Pull a		
	M Lo	ROM Mono,0846:Maracas 2-Push b		
	Low	ROM Mono,0845:Maracas 2-Push a		
B5	High	ROM Mono,1282:Industry Hit 17	IFX3	Off
	M Hi	ROM Mono,1455:Rifle Shot		
C6	High	ROM Mono,1471:Telephone-Ring	IFX3	Off
	M Hi	ROM Mono,1470:Telephone-Call		
	M Lo	ROM Mono,1472:Telephone-Busy		
C#6	High	ROM Mono,1075:Marc Tree	IFX3	Off
	M Hi	ROM Mono,1075:Marc Tree		
D6	High	ROM Mono,1005:Udu-Open d	IFX3	Off
	M Hi	ROM Mono,1000:Udu-HalfOpen b		
	M Lo	ROM Mono,1006:Udu-Bell a		
	Low	ROM Mono,1007:Udu-Bell b		
D#6	High	ROM Mono,0840:Claves Hi b	IFX3	Off
	M Hi	ROM Mono,0839:Claves Hi a		
E6	High	ROM Mono,1053:Wood Block 4 a	IFX3	Off
	M Hi	ROM Mono,1054:Wood Block 4 b		
F6	High	ROM Mono,1276:Industry Hit 13	IFX3	Off
F#6	High	ROM Mono,0963:Cuica Lo b	IFX3	Off
G6	High	ROM Mono,1439:Ice Drop	IFX3	Off
G#6	High	ROM Mono,0948:Triangle 1 S-Mute b	IFX3	11
	M Hi	ROM Mono,0947:Triangle 1 S-Mute a		
A6	High	ROM Mono,0943:Triangle 1 S-Open b	IFX3	11
	M Hi	ROM Mono,0942:Triangle 1 S-Open a		
A#6	High	ROM Mono,0921:Shaker 2 d-Push	IFX3	Off
	M Hi	ROM Mono,0928:Shaker 3-Push		
B6	High	ROM Mono,0920:Shaker 2 c-Push	IFX3	Off
	M Hi	ROM Mono,0917:Shaker 2 a		
C7	High	ROM Mono,0111:BD-Dance 41	IFX2	Off
C#7	High	ROM Mono,1471:Telephone-Ring	L/R	9
	M Hi	ROM Mono,0504:Hi-Hat Basic 1-Closed mp		
D7	High	ROM Mono,0396:SD-Dance 70	IFX1	Off
D#7	High	ROM Mono,0519:Hi-Hat Basic 2-Open mf	L/R	9
	M Hi	ROM Mono,1471:Telephone-Ring		
E7	High	ROM Mono,0636:Crash Dance 4	L/R	Off
F7	High	ROM Mono,1306:Industry Loop 2	IFX3	Off
	M Hi	ROM Mono,1277:Industry Hit 14		
F#7	High	ROM Mono,1146:Dance Claps 01	IFX1	Off
G7	High	ROM Mono,1187:Dance SynMaraca	IFX3	Off
G#7	High	ROM Mono,0315:SD-Orch.Roll	IFX1	8
A7	High	ROM Mono,0316:SD-Orchestral	IFX1	8
A#7	High	ROM Mono,1074:Bell Tree-Fast	IFX3	Off
	M Hi	ROM Mono,1073:Bell Tree-Slow		
B7	High	ROM Mono,1418:Stadium	IFX3	Off
C8	High	ROM Mono,1419:Applause	IFX3	Off
G9	High	ROM Mono,1424:Click 1	L/R	Off



Key		Drumsample	Bus	Ex
F#7	High	ROM Mono, 1146: Dance Claps 01	IFX3	Off
G7	High	ROM Mono, 1187: Dance SynMaraca	IFX3	Off
G#7	High	ROM Mono, 0348: SD-Dance 22	IFX1	8
A7	High	ROM Mono, 0316: SD-Orchestral	IFX1	8
A#7	High	ROM Mono, 1074: Bell Tree-Fast	IFX3	Off
	M Hi	ROM Mono, 1073: Bell Tree-Slow		
B7	High	ROM Mono, 1418: Stadium	IFX3	Off
C8	High	ROM Mono, 1419: Applause	IFX3	Off

19 (INT): Orch.-Ethnic Kit

Key		Drumsample	Bus	Ex
C-1	High	ROM Mono, 1424: Click 1	L/R	Off
C1	High	ROM Mono, 1198: Orch Hit 7	L/R	Off
C#1	High	ROM Mono, 1198: Orch Hit 7	L/R	Off
D1	High	ROM Mono, 1198: Orch Hit 7	L/R	Off
D#1	High	ROM Mono, 1198: Orch Hit 7	L/R	Off
E1	High	ROM Mono, 1198: Orch Hit 7	L/R	Off
F1	High	ROM Mono, 1198: Orch Hit 7	L/R	Off
F#1	High	ROM Mono, 1198: Orch Hit 7	L/R	Off
G1	High	ROM Mono, 1198: Orch Hit 7	L/R	Off
G#1	High	ROM Mono, 1198: Orch Hit 7	L/R	Off
A1	High	ROM Mono, 1198: Orch Hit 7	IFX2	Off
A#1	High	ROM Mono, 0631: Orchestral Cymbal-Open	L/R	Off
B1	High	ROM Mono, 0631: Orchestral Cymbal-Open	L/R	Off
C2	High	ROM Mono, 0054: BD-Orchestral	IFX2	Off
	M Hi	ROM Mono, 0054: BD-Orchestral		
C#2	High	ROM Mono, 0305: SD-Roll-Open 3 b	IFX1	1
	M Hi	ROM Mono, 0304: SD-Roll-Open 3 a		
D2	High	ROM Mono, 0154: SD-02-dry mf -L	IFX1	1
	M Hi	ROM Mono, 0152: SD-02-dry mp -L		
D#2	High	ROM Mono, 0311: SD-Roll-Closed 3 b -L	IFX1	1
	M Hi	ROM Mono, 0310: SD-Roll-Closed 3 a		
E2	High	ROM Mono, 0156: SD-02-dry f	IFX1	1
	M Hi	ROM Mono, 0152: SD-02-dry mp -L		
F2	High	ROM Mono, 0631: Orchestral Cymbal-Open	L/R	2
F#2	High	ROM Mono, 0632: Orchestral Cymbal-Closed	L/R	2
G2	High	ROM Mono, 1044: Taiko-Open	IFX2	Off
	M Hi	ROM Mono, 1044: Taiko-Open		
G#2	High	ROM Mono, 0301: SD-Roll-Open 1 c	IFX1	3
	M Hi	ROM Mono, 0300: SD-Roll-Open 1 b		
A2	High	ROM Mono, 0231: SD-15-dry mf	IFX1	3
	M Hi	ROM Mono, 0229: SD-15-dry mp -L		
A#2	High	ROM Mono, 0308: SD-Roll-Closed 1 b	IFX1	3
B2	High	ROM Mono, 0232: SD-15-dry f -L	IFX1	3
	M Hi	ROM Mono, 0229: SD-15-dry mp -L		
C3	High	ROM Mono, 0947: Triangle 1 S-Mute a	IFX1	4
	M Hi	ROM Mono, 0948: Triangle 1 S-Mute b		
C#3	High	ROM Mono, 0946: Triangle 1 S-Roll c	IFX1	4
D3	High	ROM Mono, 0945: Triangle 1 S-Roll b	IFX1	4
	M Hi	ROM Mono, 0944: Triangle 1 S-Roll a		
D#3	High	ROM Mono, 1069: Chinese Gong	L/R	Off
E3	High	ROM Mono, 0877: Tambourine 2-Accent	IFX1	Off
F3	High	ROM Mono, 1048: Wood Block 1 b	IFX1	Off
F#3	High	ROM Mono, 1061: Castanet 1 c	IFX1	Off
G3	High	ROM Mono, 1050: Wood Block 2 b	IFX1	Off
G#3	High	ROM Mono, 1059: Castanet 1 a	IFX2	Off
A3	High	ROM Mono, 1051: Wood Block 3 a	IFX1	Off
A#3	High	ROM Mono, 1060: Castanet 1 b	IFX1	Off
B3	High	ROM Mono, 1053: Wood Block 4 a	IFX1	Off
C4	High	ROM Mono, 1055: Wood Block 5 a	IFX1	Off
C#4	High	ROM Mono, 1064: Timpani ff	IFX2	Off
	M Hi	ROM Mono, 1063: Timpani mf		
D4	High	ROM Mono, 1064: Timpani ff	IFX2	Off
	M Hi	ROM Mono, 1063: Timpani mf		
D#4	High	ROM Mono, 1064: Timpani ff	IFX2	Off
	M Hi	ROM Mono, 1063: Timpani mf		
E4	High	ROM Mono, 1064: Timpani ff	IFX2	Off
	M Hi	ROM Mono, 1063: Timpani mf		
F4	High	ROM Mono, 0986: Djembe L-Basstone b	IFX2	Off
	M Hi	ROM Mono, 0985: Djembe L-Basstone a		
F#4	High	ROM Mono, 0990: Djembe L-ClosedSlap	IFX2	Off
	M Hi	ROM Mono, 0989: Djembe L-OpenSlap		
	M Lo	ROM Mono, 0988: Djembe L-Open		
G4	High	ROM Mono, 0990: Djembe L-ClosedSlap	IFX2	Off
G#4	High	ROM Mono, 1016: Caxixi 3 b	IFX1	Off
	M Hi	ROM Mono, 1016: Caxixi 3 b		
	M Lo	ROM Mono, 1015: Caxixi 3 a		
A4	High	ROM Mono, 1072: Sleigh Bell	IFX1	Off
	M Hi	ROM Mono, 1072: Sleigh Bell		
A#4	High	ROM Mono, 0892: Cabasa 1 L a-Up	IFX1	Off
	M Hi	ROM Mono, 0891: Cabasa 1 L a-Down		
B4	High	ROM Mono, 1070: Finger Cymbal	IFX1	Off
C5	High	ROM Mono, 1041: Baya-Up	IFX2	Off
	M Hi	ROM Mono, 1040: Baya-Ge		
C#5	High	ROM Mono, 1043: Baya-UpDown b	IFX2	Off
	M Hi	ROM Mono, 1042: Baya-UpDown a		

Key		Drumsample	Bus	Ex
D5	High	ROM Mono, 1036: Baya-KaToe b	IFX2	Off
D#5	High	ROM Mono, 1032: Baya-GheUp a	IFX2	Off
	M Hi	ROM Mono, 1033: Baya-GheUp b		
E5	High	ROM Mono, 1035: Baya-KaToe a	IFX2	Off
F5	High	ROM Mono, 1034: Baya-KaPalm	IFX2	Off
F#5	High	ROM Mono, 1039: Baya-Nail c	IFX2	Off
	M Hi	ROM Mono, 1037: Baya-Nail a		
G5	High	ROM Mono, 1022: Tabla-Na c	IFX2	Off
	M Hi	ROM Mono, 1021: Tabla-Na b		
	M Lo	ROM Mono, 1020: Tabla-Na a		
G#5	High	ROM Mono, 1024: Tabla-Tun b	IFX2	Off
	M Hi	ROM Mono, 1023: Tabla-Tun a		
A5	High	ROM Mono, 1031: Tabla-Tera	IFX2	Off
A#5	High	ROM Mono, 1028: Tabla-Ti a	IFX2	Off
B5	High	ROM Mono, 1030: Tabla-Ti c	IFX2	Off
	M Hi	ROM Mono, 1029: Tabla-Ti b		
C6	High	ROM Mono, 1027: Tabla-Tele c	IFX2	Off
	M Hi	ROM Mono, 1025: Tabla-Tele a		
C#6	High	ROM Mono, 1031: Tabla-Tera	IFX2	Off
D6	High	ROM Mono, 1044: Taiko-Open	IFX2	Off
	M Hi	ROM Mono, 1044: Taiko-Open		
D#6	High	ROM Mono, 1046: Tsuzumi	IFX2	Off
	M Hi	ROM Mono, 1046: Tsuzumi		
E6	High	ROM Mono, 1045: Taiko-Rim	IFX2	Off
F6	High	ROM Mono, 0709: Conga Lo-OpenSlap	IFX2	Off
	M Hi	ROM Mono, 0707: Conga Lo-Open mf		
	M Lo	ROM Mono, 0708: Conga Lo-Open f		
F#6	High	ROM Mono, 0714: Conga Lo-ClosedSlap	IFX2	Off
	M Hi	ROM Mono, 0713: Conga Lo-Closed		
G6	High	ROM Mono, 0723: Conga Hi-OpenSlap	IFX2	Off
	M Hi	ROM Mono, 0720: Conga Hi-Open mf		
	M Lo	ROM Mono, 0721: Conga Hi-Open f		
	Low	ROM Mono, 0719: Conga Hi-Open mp		
G#6	High	ROM Mono, 0728: Conga Hi-ClosedSlap	IFX2	Off
	M Hi	ROM Mono, 0727: Conga Hi-Closed		
A6	High	ROM Mono, 1079: Rainstick-OneShot Down	IFX2	Off
	M Hi	ROM Mono, 1080: Rainstick-OneShot Up		
A#6	High	ROM Mono, 1077: Rainstick 1 b	IFX2	Off
B6	High	ROM Mono, 1594: HarpGliss	IFX2	Off
	M Hi	ROM Mono, 1594: HarpGliss		
C7	High	ROM Mono, 1076: Rainstick 1 a	IFX2	Off
C#7	High	ROM Mono, 1486: Gamelan	IFX2	Off
D7	High	ROM Mono, 1486: Gamelan	IFX2	Off
D#7	High	ROM Mono, 1486: Gamelan	IFX2	Off
E7	High	ROM Mono, 1486: Gamelan	IFX2	Off
F7	High	ROM Mono, 1486: Gamelan	IFX2	Off
F#7	High	ROM Mono, 1486: Gamelan	IFX2	Off
G7	High	ROM Mono, 1486: Gamelan	IFX2	Off
G#7	High	ROM Mono, 1486: Gamelan	IFX2	Off
A7	High	ROM Mono, 1486: Gamelan	IFX2	Off
A#7	High	ROM Mono, 1486: Gamelan	IFX2	Off
B7	High	ROM Mono, 1486: Gamelan	IFX2	Off
C8	High	ROM Mono, 1486: Gamelan	IFX2	Off
G9	High	ROM Mono, 1424: Click 1	L/R	Off





Key		Drumsample	Bus	Ex
G6	High	ROM Mono,0877:Tambourine 2-Accent	IFX1	Off
G#6	High	ROM Mono,0874:Tambourine 2-Push	IFX1	Off
A6	High	ROM Mono,0883:Tri.& Tamb. f	IFX1	Off
A#6	High	ROM Mono,1072:Sleigh Bell	IFX1	Off
	M Hi	ROM Mono,1072:Sleigh Bell		
B6	High	ROM Mono,0969:Whistle 2	IFX1	4
C7	High	ROM Mono,0972:Whistle 4-Short	IFX1	4
C#7	High	ROM Mono,1074: Bell Tree-Fast	IFX1	Off
	M Hi	ROM Mono,1073: Bell Tree-Slow		
D7	High	ROM Mono,0971:Whistle 4-Long	IFX1	4
D#7	High	ROM Mono,1075:Marc Tree	IFX1	Off
E7	High	ROM Mono,0970:Whistle 3	IFX1	4
F7	High	ROM Mono,1071: Rap Sleigh Bell	IFX1	Off
	M Hi	ROM Mono,1071: Rap Sleigh Bell		
F#7	High	ROM Mono,1077: Rainstick 1 b	IFX1	Off
	M Hi	ROM Mono,1077: Rainstick 1 b		
	M Lo	ROM Mono,1076: Rainstick 1 a		
G7	High	ROM Mono,1069: Chinese Gong	IFX1	Off
	M Hi	ROM Mono,1069: Chinese Gong		
G#7	High	ROM Mono,1426: Bird 1	IFX1	Off
A7	High	ROM Mono,1427: Bird 2	IFX1	Off
A#7	High	ROM Mono,1426: Bird 1	IFX1	Off
B7	High	ROM Mono,1430: Crickets 1	IFX1	Off
C8	High	ROM Mono,1075: Marc Tree	IFX1	Off
G9	High	ROM Mono,1424: Click 1	L/R	Off

21 (INT): Brazilian Perc

Key		Drumsample	Bus	Ex
C-1	High	ROM Mono, 1424: Click 1	L/R	Off
A#0	High	ROM Mono, 1599: Berimbau-Phrase1 Loop	IFX1	Off
B0	High	ROM Mono, 1604: Berimbau-Phrase2 Loop	IFX1	Off
C1	High	ROM Mono, 1595: Berimbau-Wah-Lo	IFX1	Off
	M Hi	ROM Mono, 1595: Berimbau-Wah-Lo		
C#1	High	ROM Mono, 1596: Berimbau-Wah-Hi	IFX1	Off
	M Hi	ROM Mono, 1596: Berimbau-Wah-Hi		
D1	High	ROM Mono, 1597: Berimbau-HO	IFX1	Off
	M Hi	ROM Mono, 1597: Berimbau-HO		
D#1	High	ROM Mono, 1598: Berimbau-PO	IFX1	Off
	M Hi	ROM Mono, 1598: Berimbau-PO		
E1	High	ROM Mono, 1600: Berimbau-Phrase1-1	IFX1	Off
	M Hi	ROM Mono, 1600: Berimbau-Phrase1-1		
F1	High	ROM Mono, 1601: Berimbau-Phrase1-2	IFX1	Off
F#1	High	ROM Mono, 1602: Berimbau-Phrase1-3	IFX1	Off
G1	High	ROM Mono, 1603: Berimbau-Phrase1-4	IFX1	Off
G#1	High	ROM Mono, 1605: Berimbau-Phrase2-1	IFX1	Off
A1	High	ROM Mono, 1606: Berimbau-Phrase2-2	IFX1	Off
A#1	High	ROM Mono, 1607: Berimbau-Phrase2-3	IFX1	Off
B1	High	ROM Mono, 1608: Berimbau-Phrase2-4	IFX1	Off
	High	ROM Mono, 0940: Triangle 1 L-Mute b		
C2	M Hi	ROM Mono, 0941: Triangle 1 L-Mute c	IFX1	1
	High	ROM Mono, 0939: Triangle 1 L-Mute a		
C#2	M Hi	ROM Mono, 0940: Triangle 1 L-Mute b	IFX1	1
	High	ROM Mono, 0938: Triangle 1 L-Open a		
D2	High	ROM Mono, 0937: Triangle 1 L-Open a	IFX1	1
E2	High	ROM Mono, 0947: Triangle 1 S-Mute a	IFX1	2
	M Hi	ROM Mono, 0948: Triangle 1 S-Mute b		
F2	High	ROM Mono, 0945: Triangle 1 S-Roll b	IFX1	2
	M Hi	ROM Mono, 0945: Triangle 1 S-Roll a		
F#2	High	ROM Mono, 0945: Triangle 1 S-Roll b	IFX1	2
	M Hi	ROM Mono, 0944: Triangle 1 S-Roll a		
	M Lo	ROM Mono, 0944: Triangle 1 S-Roll a		
G2	High	ROM Mono, 0946: Triangle 1 S-Roll c	IFX1	2
	M Hi	ROM Mono, 0946: Triangle 1 S-Roll c		
G#2	High	ROM Mono, 1059: Castanet 1 a	IFX1	Off
	M Hi	ROM Mono, 1059: Castanet 1 a		
A2	High	ROM Mono, 0850: Guiro-Long b	IFX1	3
	M Hi	ROM Mono, 0849: Guiro-Long a		
A#2	High	ROM Mono, 0852: Guiro-Short b	IFX1	3
	M Hi	ROM Mono, 0851: Guiro-Short a		
B2	High	ROM Mono, 0852: Guiro-Short b	IFX1	3
	M Hi	ROM Mono, 0851: Guiro-Short a		
C3	High	ROM Mono, 0853: Vibra-Slap	IFX1	Off
	High	ROM Mono, 0840: Claves Hi b		
C#3	M Hi	ROM Mono, 0839: Claves Hi a	IFX1	Off
	High	ROM Mono, 0838: Claves Lo b		
D3	M Hi	ROM Mono, 0837: Claves Lo a	IFX1	Off
	High	ROM Mono, 0962: Cuica Lo a		
D#3	M Hi	ROM Mono, 0963: Cuica Lo b	IFX1	4
	High	ROM Mono, 0964: Cuica Lo c		
E3	M Hi	ROM Mono, 0963: Cuica Lo b	IFX1	4
	High	ROM Mono, 0965: Cuica Hi a		
F3	M Hi	ROM Mono, 0965: Cuica Hi a	IFX1	4
	High	ROM Mono, 0966: Cuica Hi b		
F#3	M Hi	ROM Mono, 0966: Cuica Hi b	IFX1	4
	High	ROM Mono, 0967: Cuica Hi c		
G3	M Hi	ROM Mono, 0967: Cuica Hi c	IFX1	4
	High	ROM Mono, 1011: Caxixi 1 b		
G#3	M Hi	ROM Mono, 1010: Caxixi 1 a	IFX1	Off
	M Lo	ROM Mono, 1012: Caxixi 1 c		
	High	ROM Mono, 1017: Caxixi 3 c		
A3	M Hi	ROM Mono, 1016: Caxixi 3 b	IFX1	Off
	M Lo	ROM Mono, 1015: Caxixi 3 a		
A#3	High	ROM Mono, 0859: Pandeiro-Jingle b	IFX1	Off
	M Hi	ROM Mono, 0858: Pandeiro-Jingle a		
B3	High	ROM Mono, 0862: Pandeiro-Open c	IFX1	Off
	M Hi	ROM Mono, 0861: Pandeiro-Open b		
C4	High	ROM Mono, 0860: Pandeiro-Open a	IFX1	Off
	M Hi	ROM Mono, 0862: Pandeiro-Open c		
C#4	High	ROM Mono, 0864: Pandeiro-Choke b	IFX1	Off
	M Hi	ROM Mono, 0863: Pandeiro-Choke a		
D4	High	ROM Mono, 0867: Pandeiro-ClosedAcc.c	IFX1	Off
	M Hi	ROM Mono, 0866: Pandeiro-ClosedAcc.b		
	M Lo	ROM Mono, 0865: Pandeiro-ClosedAcc.a		

Key		Drumsample	Bus	Ex
D#4	High	ROM Mono, 0868: Pandeiro-SideEdge	IFX1	9
E4	High	ROM Mono, 0869: Pandeiro-Glissando a	IFX1	9
	M Hi	ROM Mono, 0869: Pandeiro-Glissando a		
	M Lo	ROM Mono, 0869: Pandeiro-Glissando a		
F4	High	ROM Mono, 0958: Recoreco-Long	IFX1	5
	M Hi	ROM Mono, 0958: Recoreco-Long		
	M Lo	ROM Mono, 0958: Recoreco-Long		
	Low	ROM Mono, 0958: Recoreco-Long		
F#4	High	ROM Mono, 0959: Recoreco-Short a	IFX1	5
	M Hi	ROM Mono, 0960: Recoreco-Short b		
	M Lo	ROM Mono, 0960: Recoreco-Short b		
	Low	ROM Mono, 0960: Recoreco-Short b		
G4	High	ROM Mono, 0959: Recoreco-Short a	IFX1	5
	M Hi	ROM Mono, 0961: Recoreco-Short c		
	M Lo	ROM Mono, 0961: Recoreco-Short c		
	Low	ROM Mono, 0961: Recoreco-Short c		
G#4	High	ROM Mono, 0857: Surdo-Mute	IFX1	6
A4	High	ROM Mono, 0856: Surdo-Open	IFX1	6
A#4	High	ROM Mono, 0631: Orchestral Cymbal-Open	IFX1	8
B4	High	ROM Mono, 0632: Orchestral Cymbal-Closed	IFX1	8
	M Hi	ROM Mono, 0891: Cabasa 1 L a-Down		
C5	High	ROM Mono, 0894: Cabasa 1 L b-Up	IFX1	Off
	M Hi	ROM Mono, 0891: Cabasa 1 L a-Down		
C#5	High	ROM Mono, 0901: Cabasa 2 L-Roll	IFX1	Off
	M Hi	ROM Mono, 0901: Cabasa 2 L-Roll		
	M Lo	ROM Mono, 0901: Cabasa 2 L-Roll		
D5	High	ROM Mono, 0893: Cabasa 1 L b-Down	IFX1	Off
	M Hi	ROM Mono, 0892: Cabasa 1 L a-Up		
D#5	High	ROM Mono, 0900: Cabasa 2 L-Stack b	IFX1	Off
	M Hi	ROM Mono, 0899: Cabasa 2 L-Stack a		
E5	High	ROM Mono, 0898: Cabasa 1 S b-up	IFX1	Off
	M Hi	ROM Mono, 0897: Cabasa 1 S b-Down		
F5	High	ROM Mono, 0896: Cabasa 1 S a-Up	IFX1	Off
	M Hi	ROM Mono, 0895: Cabasa 1 S a-Down		
F#5	High	ROM Mono, 0904: Cabasa 2 S-Roll	IFX1	Off
	M Hi	ROM Mono, 0904: Cabasa 2 S-Roll		
	M Lo	ROM Mono, 0904: Cabasa 2 S-Roll		
G5	High	ROM Mono, 0902: Cabasa 2 S-Stack a	IFX1	Off
	M Hi	ROM Mono, 0903: Cabasa 2 S-Stack b		
G#5	High	ROM Mono, 0934: Agogo 2 Lo-Open	IFX1	Off
	M Hi	ROM Mono, 0936: Agogo-Belltone		
A5	High	ROM Mono, 0935: Agogo 2 Hi-Open	IFX1	Off
	M Hi	ROM Mono, 0936: Agogo-Belltone		
A#5	High	ROM Mono, 0932: Agogo 1 Lo-Open	IFX1	Off
	M Hi	ROM Mono, 0936: Agogo-Belltone		
B5	High	ROM Mono, 0933: Agogo 1 Hi-Open	IFX1	Off
	M Hi	ROM Mono, 0936: Agogo-Belltone		
C6	High	ROM Mono, 0907: Shaker 1-Pull a	IFX1	Off
	M Hi	ROM Mono, 0908: Shaker 1-Pull b		
C#6	High	ROM Mono, 0906: Shaker 1-Push b	IFX1	Off
	M Hi	ROM Mono, 0905: Shaker 1-Push a		
D6	High	ROM Mono, 0909: Shaker 1-Accent a	IFX1	Off
	M Hi	ROM Mono, 0910: Shaker 1-Accent b		
D#6	High	ROM Mono, 0913: Shaker 1-Slow c	IFX1	Off
	M Hi	ROM Mono, 0913: Shaker 1-Slow c		
E6	High	ROM Mono, 0912: Shaker 1-Slow b	IFX1	Off
	M Hi	ROM Mono, 0911: Shaker 1-Slow a		
F6	High	ROM Mono, 0914: Shaker 1-Roll a	IFX1	Off
	M Hi	ROM Mono, 0916: Shaker 1-Roll c		
F#6	High	ROM Mono, 0875: Tambourine 2-Pull a	IFX1	Off
G6	High	ROM Mono, 0877: Tambourine 2-Accent	IFX1	Off
G#6	High	ROM Mono, 0874: Tambourine 2-Push	IFX1	Off
A6	High	ROM Mono, 0883: Tri.& Tamb. f	IFX1	Off
A#6	High	ROM Mono, 0886: Tri.& Tamb. i	IFX1	Off
	M Hi	ROM Mono, 0887: Tri.& Tamb. j		
B6	High	ROM Mono, 0969: Whistle 2	IFX1	7
C7	High	ROM Mono, 0972: Whistle 4-Short	IFX1	7
C#7	High	ROM Mono, 0973: Whistle 5	IFX1	Off
D7	High	ROM Mono, 0971: Whistle 4-Long	IFX1	7
D#7	High	ROM Mono, 0968: Whistle 1	IFX1	Off
E7	High	ROM Mono, 0970: Whistle 3	IFX1	7
F7	High	ROM Mono, 1071: Rap Sleigh Bell	IFX1	Off
	M Hi	ROM Mono, 1071: Rap Sleigh Bell		



Key		Drumsample	Bus	Ex
F#7	High	ROM Mono, 1077: Rainstick 1 b	IFX1	Off
	M Hi	ROM Mono, 1077: Rainstick 1 b		
	M Lo	ROM Mono, 1076: Rainstick 1 a		
G7	High	ROM Mono, 1069: Chinese Gong	IFX1	Off
	M Hi	ROM Mono, 1069: Chinese Gong		
G#7	High	ROM Mono, 1426: Bird 1	IFX1	Off
A7	High	ROM Mono, 1427: Bird 2	IFX1	Off
A#7	High	ROM Mono, 1426: Bird 1	IFX1	Off
B7	High	ROM Mono, 1430: Crickets 1	IFX1	Off
C8	High	ROM Mono, 1075: Marc Tree	IFX1	Off
G9	High	ROM Mono, 1424: Click 1	L/R	Off



Key		Drumsample	Bus	Ex
A#6	High	ROM Mono,0751: Bongo 1 Lo-StickBounce	IFX1	Off
	M Hi	ROM Mono,0751: Bongo 1 Lo-StickBounce		
	M Lo	ROM Mono,0751: Bongo 1 Lo-StickBounce		
B6	High	ROM Mono,0750: Bongo 1 Lo-StickEdge f	IFX1	Off
	M Hi	ROM Mono,0749: Bongo 1 Lo-StickEdge mf		
C7	High	ROM Mono,0756: Bongo 1 Hi-Open f	IFX1	Off
	M Hi	ROM Mono,0755: Bongo 1 Hi-Open mf		
C#7	High	ROM Mono,0765: Bongo 1 Hi-Cuptone	IFX1	Off
	M Hi	ROM Mono,0765: Bongo 1 Hi-Cuptone		
D7	High	ROM Mono,0757: Bongo 1 Hi-Pops	IFX1	Off
	M Hi	ROM Mono,0756: Bongo 1 Hi-Open f		
D#7	High	ROM Mono,0760: Bongo 1 Hi-Fingernail	IFX1	Off
	M Hi	ROM Mono,0760: Bongo 1 Hi-Fingernail		
E7	High	ROM Mono,0758: Bongo 1 Hi-Hightone	IFX1	Off
	M Hi	ROM Mono,0758: Bongo 1 Hi-Hightone		
F7	High	ROM Mono,0766: Bongo 1 Hi-Slap	IFX1	Off
	M Hi	ROM Mono,0766: Bongo 1 Hi-Slap		
	M Lo	ROM Mono,0756: Bongo 1 Hi-Open f		
	Low	ROM Mono,0755: Bongo 1 Hi-Open mf		
F#7	High	ROM Mono,0759: Bongo 1 Hi-OpenFlam	IFX1	Off
G7	High	ROM Mono,0762: Bongo 1 Hi-StickEdge mf	IFX1	Off
	M Hi	ROM Mono,0761: Bongo 1 Hi-Stick		
G#7	High	ROM Mono,0764: Bongo 1 Hi-StickBounce	IFX1	Off
	M Hi	ROM Mono,0764: Bongo 1 Hi-StickBounce		
	M Lo	ROM Mono,0764: Bongo 1 Hi-StickBounce		
A7	High	ROM Mono,0763: Bongo 1 Hi-StickEdge f	IFX1	Off
	M Hi	ROM Mono,0762: Bongo 1 Hi-StickEdge mf		
A#7	High	ROM Mono,0678: Splash Cymbal 1 ff -L	IFX1	Off
	M Hi	ROM Mono,0677: Splash Cymbal 1 f		
	M Lo	ROM Mono,0676: Splash Cymbal 1 mf		
	Low	ROM Mono,0675: Splash Cymbal 1 mp		
B7	High	ROM Mono,0661: Ride Cymbal 6 f -L	IFX1	Off
	M Hi	ROM Mono,0659: Ride Cymbal 6 mf -L		
C8	High	ROM Mono,0663: Ride Cymbal 7-Cup -L	IFX1	Off
	M Hi	ROM Mono,0654: Ride Cymbal 4 mp		
	M Lo	ROM Mono,0655: Ride Cymbal 4 f		
	Low	ROM Mono,0656: Ride Cymbal 4 ff		
G9	High	ROM Mono,1424: Click 1	L/R	Off



Key		Drumsample	Bus	Ex
A#7	High	ROM Mono, 1114:WD-Bongo Open	IFX1	Off
B7	High	ROM Mono, 1115:WD-Bongo OpenSlap	IFX1	Off
C8	High	ROM Mono, 1117:WD-Bongo ClosedSlap	IFX1	Off
	M Hi	ROM Mono, 1116:WD-Bongo Closed		
G9	High	ROM Mono, 1424:Click 1	L/R	Off



Key		Drumsample	Bus	Ex
G#6	High	ROM Mono,0874:Tambourine 2-Push	IFX1	Off
A6	High	ROM Mono,0883:Tri.& Tamb. f	IFX1	Off
A#6	High	ROM Mono,1072:Sleigh Bell	IFX1	Off
	M Hi	ROM Mono,1072:Sleigh Bell		
B6	High	ROM Mono,0969:Whistle 2	IFX1	4
C7	High	ROM Mono,0972:Whistle 4-Short	IFX1	4
C#7	High	ROM Mono,1074: Bell Tree-Fast	IFX1	Off
	M Hi	ROM Mono,1073: Bell Tree-Slow		
D7	High	ROM Mono,0971:Whistle 4-Long	IFX1	4
D#7	High	ROM Mono,1075: Marc Tree	IFX1	Off
E7	High	ROM Mono,0970:Whistle 3	IFX1	4
F7	High	ROM Mono,1071: Rap Sleigh Bell	IFX1	Off
	M Hi	ROM Mono,1071: Rap Sleigh Bell		
F#7	High	ROM Mono,1077: Rainstick 1 b	IFX1	Off
	M Hi	ROM Mono,1077: Rainstick 1 b		
	M Lo	ROM Mono,1076: Rainstick 1 a		
G7	High	ROM Mono,1069: Chinese Gong	IFX1	Off
	M Hi	ROM Mono,1069: Chinese Gong		
G#7	High	ROM Mono,1426: Bird 1	IFX1	Off
A7	High	ROM Mono,1427: Bird 2	IFX1	Off
A#7	High	ROM Mono,1426: Bird 1	IFX1	Off
B7	High	ROM Mono,1430: Crickets 1	IFX1	Off
C8	High	ROM Mono,1075: Marc Tree	IFX1	Off
G9	High	ROM Mono,1424: Click 1	L/R	Off





Key		Drumsample	Bus	Ex
F#7	High	ROM Mono, 0922: Shaker 2 d-Pull	L/R	Off
	M Hi	ROM Mono, 0927: Shaker 2 f-Accent		
G7	High	ROM Mono, 0925: Shaker 2 f-Push	L/R	Off
	M Hi	ROM Mono, 0920: Shaker 2 c-Push		
G#7	High	ROM Mono, 0767: Bongo 2 Lo-Open a	L/R	Off
	M Hi	ROM Mono, 0560: Hi-Hat Dance 02		
A7	High	ROM Mono, 0769: Bongo 2 Lo-Mute	L/R	Off
	M Hi	ROM Mono, 0329: SD-Dance 03		
A#7	High	ROM Mono, 0774: Bongo 2 Lo-Heel	L/R	Off
	M Hi	ROM Mono, 0559: Hi-Hat Dance 01		
B7	High	ROM Mono, 0772: Bongo 2 Hi-Muffled	L/R	Off
	M Hi	ROM Mono, 0329: SD-Dance 03		
C8	High	ROM Mono, 0771: Bongo 2 Hi-Open b	L/R	Off
	M Hi	ROM Mono, 0563: Hi-Hat Dance 05		
C#8	High	ROM Mono, 0775: Bongo 2 Hi-Slap	L/R	Off
	M Hi	ROM Mono, 0329: SD-Dance 03		
D8	High	ROM Mono, 0768: Bongo 2 Lo-Open b	L/R	Off
	M Hi	ROM Mono, 0581: Hi-Hat Dance 23		
D#8	High	ROM Mono, 0773: Bongo 2 Lo-Muffled	L/R	Off
	M Hi	ROM Mono, 0581: Hi-Hat Dance 23		
G9	High	ROM Mono, 1424: Click 1	L/R	Off

26 (INT): DJ-BeatBox Kit

Key		Drumsample	Bus	Ex
C-1	High	ROM Mono, 1424: Click 1	L/R	Off
C1	High	ROM Mono, 1454: Gun Shot	L/R	Off
C#1	High	ROM Mono, 1174: Perc-WS 02 (Tick Hit)	L/R	Off
D1	High	ROM Mono, 1449: Train Horn	L/R	Off
D#1	High	ROM Mono, 1447: Car Horn	L/R	Off
E1	High	ROM Mono, 1473: Telephone-Tone 1	L/R	Off
F1	High	ROM Mono, 1470: Telephone-Call	L/R	Off
F#1	High	ROM Mono, 1471: Telephone-Ring	L/R	Off
G1	High	ROM Mono, 1472: Telephone-Busy	L/R	Off
G#1	High	ROM Mono, 1474: Telephone-Tone 2	L/R	Off
A1	High	ROM Mono, 1475: Telephone-Tone 3	L/R	Off
A#1	High	ROM Mono, 1476: Telephone-Tone 4	L/R	Off
B1	High	ROM Mono, 1477: Telephone-Tone 5	L/R	Off
C2	High	ROM Mono, 0121: BD-Dance 51	IFX1	Off
C#2	High	ROM Mono, 0066: BD-Dance 04	IFX1	Off
D2	High	ROM Mono, 0045: BD-PhatJaz	IFX1	Off
D#2	High	ROM Mono, 0096: BD-Dance 26	IFX1	Off
E2	High	ROM Mono, 1190: Zap 1	IFX1	Off
F2	High	ROM Mono, 0369: SD-Dance 43	IFX1	Off
F#2	High	ROM Mono, 1240: DJ Vinyl Sliced 16	IFX1	Off
G2	High	ROM Mono, 0413: SD-WS 08 (Tenny)	IFX1	Off
G#2	High	ROM Mono, 0400: SD-Dance 74	IFX1	Off
A2	High	ROM Mono, 0381: SD-Dance 55	IFX1	Off
A#2	High	ROM Mono, 0411: SD-WS 06 (Gated)	IFX1	Off
B2	High	ROM Mono, 1327: Voice 19	IFX2	Off
C3	High	ROM Mono, 1239: DJ Vinyl Sliced 15	IFX2	Off
C#3	High	ROM Mono, 0338: SD-Dance 12	IFX1	Off
D3	High	ROM Mono, 0418: SD-Dance 78	IFX1	Off
D#3	High	ROM Mono, 1156: Dance Claps 11	IFX1	Off
E3	High	ROM Mono, 1328: Voice 20	IFX1	Off
F3	High	ROM Mono, 1243: DJ Vinyl Sliced 19	IFX2	Off
F#3	High	ROM Mono, 0607: Hi-Hat WS Syn-Closed	IFX2	1
G3	High	ROM Mono, 1243: DJ Vinyl Sliced 19	IFX2	Off
G#3	High	ROM Mono, 0607: Hi-Hat WS Syn-Closed	IFX2	1
A3	High	ROM Mono, 1243: DJ Vinyl Sliced 19	IFX2	Off
A#3	High	ROM Mono, 0608: Hi-Hat WS Syn-Open	IFX2	1
B3	High	ROM Mono, 1243: DJ Vinyl Sliced 19	IFX2	Off
C4	High	ROM Mono, 1243: DJ Vinyl Sliced 19	IFX2	Off
C#4	High	ROM Mono, 0637: Crash Dance 5	IFX2	Off
D4	High	ROM Mono, 1243: DJ Vinyl Sliced 19	IFX2	Off
D#4	High	ROM Mono, 0670: Ride Dance WS	IFX2	Off
E4	High	ROM Mono, 1444: Car Stop	L/R	Off
F4	High	ROM Mono, 1439: Ice Drop	L/R	Off
F#4	High	ROM Mono, 1298: Industry Hit 33	L/R	Off
G4	High	ROM Mono, 1179: Dance Perc 11	L/R	Off
G#4	High	ROM Mono, 1224: Vinyl Hit 2	L/R	Off
A4	High	ROM Mono, 1457: Laser Gun	L/R	Off
A#4	High	ROM Mono, 1225: DJ Vinyl Sliced 01	L/R	Off
B4	High	ROM Mono, 0594: Hi-Hat WS-Open	IFX2	Off
C5	High	ROM Mono, 1191: Zap 2	L/R	Off
C#5	High	ROM Mono, 1242: DJ Vinyl Sliced 18	L/R	Off
D5	High	ROM Mono, 1241: DJ Vinyl Sliced 17	L/R	Off
D#5	High	ROM Mono, 1223: Vinyl Hit 1	IFX5	Off
E5	High	ROM Mono, 1229: DJ Vinyl Sliced 05	L/R	Off
F5	High	ROM Mono, 1253: DJ Vinyl Sliced 29	L/R	Off
F#5	High	ROM Mono, 1331: Voice 23	IFX2	Off
G5	High	ROM Mono, 1227: DJ Vinyl Sliced 03	L/R	Off
G#5	High	ROM Mono, 1329: Voice 21	IFX2	Off
A5	High	ROM Mono, 1246: DJ Vinyl Sliced 22	L/R	Off
A#5	High	ROM Mono, 1334: Voice 26	IFX2	Off
B5	High	ROM Mono, 1245: DJ Vinyl Sliced 21	L/R	Off
C6	High	ROM Mono, 1252: DJ Vinyl Sliced 28	L/R	Off
C#6	High	ROM Mono, 1237: DJ Vinyl Sliced 13	L/R	Off
D6	High	ROM Mono, 1250: DJ Vinyl Sliced 26	L/R	Off
D#6	High	ROM Mono, 1256: DJ-BD Rub	L/R	Off
E6	High	ROM Mono, 1257: DJ-SD Rub	L/R	Off
F6	High	ROM Mono, 1232: DJ Vinyl Sliced 08	L/R	Off
F#6	High	ROM Mono, 1228: DJ Vinyl Sliced 04	L/R	Off
G6	High	ROM Mono, 1229: DJ Vinyl Sliced 05	L/R	Off
G#6	High	ROM Mono, 0957: Triangle WS-Closed	L/R	3
A6	High	ROM Mono, 0956: Triangle WS-Open	L/R	3
A#6	High	ROM Mono, 1246: DJ Vinyl Sliced 22	L/R	Off
B6	High	ROM Mono, 1226: DJ Vinyl Sliced 02	L/R	Off
C7	High	ROM Mono, 1230: DJ Vinyl Sliced 06	L/R	Off
C#7	High	ROM Mono, 1231: DJ Vinyl Sliced 07	L/R	Off

Key		Drumsample	Bus	Ex
D7	High	ROM Mono, 1244: DJ Vinyl Sliced 20	L/R	Off
D#7	High	ROM Mono, 1233: DJ Vinyl Sliced 09	L/R	Off
E7	High	ROM Mono, 1234: DJ Vinyl Sliced 10	L/R	Off
F7	High	ROM Mono, 1248: DJ Vinyl Sliced 24	L/R	Off
F#7	High	ROM Mono, 1235: DJ Vinyl Sliced 11	L/R	Off
G7	High	ROM Mono, 1236: DJ Vinyl Sliced 12	L/R	Off
G#7	High	ROM Mono, 1247: DJ Vinyl Sliced 23	L/R	Off
A7	High	ROM Mono, 1251: DJ Vinyl Sliced 27	L/R	Off
A#7	High	ROM Mono, 1519: El.Gtr-Dead Note 3	L/R	Off
B7	High	ROM Mono, 1249: DJ Vinyl Sliced 25	L/R	Off
C8	High	ROM Mono, 1242: DJ Vinyl Sliced 18	L/R	Off
F#8	High	ROM Mono, 1419: Applause	L/R	Off
G8	High	ROM Mono, 0338: SD-Dance 12	L/R	Off
G9	High	ROM Mono, 1424: Click 1	L/R	Off

27 (INT): Rap-Gospel Kit

Key		Drumsample	Bus	Ex
C-1	High	ROM Mono, 1424: Click 1	L/R	Off
C2	High	ROM Mono, 1144: Perc-WS 01 (Vox Box)	IFX1	Off
C#2	High	ROM Mono, 0068: BD-WS 4 (Gated)	IFX1	Off
D2	High	ROM Mono, 0047: BD-WS 2 (Tite)	IFX1	Off
D#2	High	ROM Mono, 0046: BD-WS 1	IFX1	Off
E2	High	ROM Mono, 0053: BD-WS 3 (Ambi)	IFX1	Off
F2	High	ROM Mono, 0407: SD-WS 02 (Crack)	IFX1	Off
F#2	High	ROM Mono, 0276: SD-WS 01	L/R	Off
G2	High	ROM Mono, 0408: SD-WS 03 (Amb)	L/R	Off
G#2	High	ROM Mono, 0410: SD-WS 05 (BeatBox)	L/R	Off
A2	High	ROM Mono, 0412: SD-WS 07 (Noise)	L/R	Off
A#2	High	ROM Mono, 0411: SD-WS 06 (Gated)	L/R	Off
B2	High	ROM Mono, 1327: Voice 19	IFX1	Off
C3	High	ROM Mono, 1324: Voice 16	IFX1	Off
C#3	High	ROM Mono, 1357: Voice 49	IFX1	Off
D3	High	ROM Mono, 1347: Voice 39	IFX1	Off
D#3	High	ROM Mono, 0695: Hand Claps 3-Gospel	L/R	Off
E3	High	ROM Mono, 1328: Voice 20	IFX1	Off
F3	High	ROM Mono, 1309: Voice 01	IFX2	Off
F#3	High	ROM Mono, 1329: Voice 21	IFX2	1
G3	High	ROM Mono, 1309: Voice 01	IFX2	Off
G#3	High	ROM Mono, 1331: Voice 23	IFX2	1
A3	High	ROM Mono, 1309: Voice 01	IFX2	Off
A#3	High	ROM Mono, 1334: Voice 26	IFX2	1
B3	High	ROM Mono, 1374: Voice 66	IFX2	Off
C4	High	ROM Mono, 1374: Voice 66	IFX2	Off
C#4	High	ROM Mono, 1302: Industry Hit 37	IFX2	Off
D4	High	ROM Mono, 1374: Voice 66	IFX2	Off
D#4	High	ROM Mono, 1382: Voice 74	IFX2	Off
E4	High	ROM Mono, 1300: Industry Hit 35	IFX2	Off
F4	High	ROM Mono, 1381: Voice 73	IFX2	Off
F#4	High	ROM Mono, 1333: Voice 25	IFX2	Off
G4	High	ROM Mono, 1364: Voice 56	IFX2	Off
G#4	High	ROM Mono, 1316: Voice 08	IFX2	Off
A4	High	ROM Mono, 1284: Industry Hit 19	IFX2	Off
A#4	High	ROM Mono, 1417: Psycho Voice	IFX2	Off
B4	High	ROM Mono, 1312: Voice 04	IFX2	Off
C5	High	ROM Mono, 1314: Voice 06	IFX2	Off
C#5	High	ROM Mono, 1322: Voice 14	IFX5	Off
D5	High	ROM Mono, 1315: Voice 07	IFX2	Off
D#5	High	ROM Mono, 1352: Voice 44	IFX2	Off
E5	High	ROM Mono, 1352: Voice 44	IFX2	Off
F5	High	ROM Mono, 1358: Voice 50	IFX2	Off
F#5	High	ROM Mono, 1358: Voice 50	IFX2	Off
G5	High	ROM Mono, 1310: Voice 02	IFX2	Off
G#5	High	ROM Mono, 1310: Voice 02	IFX2	Off
A5	High	ROM Mono, 1330: Voice 22	IFX2	Off
A#5	High	ROM Mono, 1319: Voice 11	IFX2	Off
B5	High	ROM Mono, 1319: Voice 11	IFX2	Off
C6	High	ROM Mono, 1363: Voice 55	IFX2	Off
C#6	High	ROM Mono, 1363: Voice 55	IFX2	Off
D6	High	ROM Mono, 1321: Voice 13	IFX2	Off
D#6	High	ROM Mono, 1321: Voice 13	IFX2	Off
E6	High	ROM Mono, 1311: Voice 03	IFX2	Off
F6	High	ROM Mono, 1320: Voice 12	IFX2	Off
F#6	High	ROM Mono, 1320: Voice 12	IFX2	Off
G6	High	ROM Mono, 1320: Voice 12	IFX2	Off
G#6	High	ROM Mono, 1359: Voice 51	IFX2	Off
A6	High	ROM Mono, 1360: Voice 52	IFX2	Off
A#6	High	ROM Mono, 1332: Voice 24	IFX2	Off
B6	High	ROM Mono, 1354: Voice 46	IFX2	Off
C7	High	ROM Mono, 1354: Voice 46	IFX2	Off
C#7	High	ROM Mono, 1356: Voice 48	IFX2	Off
D7	High	ROM Mono, 1356: Voice 48	IFX2	Off
D#7	High	ROM Mono, 1361: Voice 53	IFX2	Off
E7	High	ROM Mono, 1362: Voice 54	IFX2	Off
F7	High	ROM Mono, 1362: Voice 54	IFX2	Off
F#7	High	ROM Mono, 1365: Voice 57	IFX2	Off
G7	High	ROM Mono, 1353: Voice 45	IFX2	Off
G#7	High	ROM Mono, 1318: Voice 10	IFX2	Off
A7	High	ROM Mono, 1317: Voice 09	IFX2	Off
A#7	High	ROM Mono, 1326: Voice 18	IFX2	Off
B7	High	ROM Mono, 1326: Voice 18	IFX2	Off
C8	High	ROM Mono, 1355: Voice 47	IFX2	Off
C#8	High	ROM Mono, 1355: Voice 47	IFX2	Off

Key		Drumsample	Bus	Ex
D8	High	ROM Mono, 1355: Voice 47	IFX2	Off
D#8	High	ROM Mono, 1313: Voice 05	IFX2	Off
E8	High	ROM Mono, 1313: Voice 05	IFX2	Off
F8	High	ROM Mono, 1313: Voice 05	IFX2	Off
G9	High	ROM Mono, 1424: Click 1	IFX5	Off

**28 (INT): Industry-Vocal Kit**

Key		Drumsample	Bus	Ex
C-1	High	ROM Mono, 1424: Click 1	L/R	Off
C1	High	ROM Mono, 0057: BD-Cannon	IFX1	Off
C#1	High	ROM Mono, 1453: Fireworks	IFX1	Off
D1	High	ROM Mono, 1458: Cannon 1	IFX1	Off
D#1	High	ROM Mono, 1455: Rifle Shot	IFX1	Off
E1	High	ROM Mono, 1300: Industry Hit 35	IFX1	Off
F1	High	ROM Mono, 1416: Machine Voice	IFX1	Off
F#1	High	ROM Mono, 1296: Industry Hit 31	IFX1	Off
G1	High	ROM Mono, 1294: Industry Hit 29	IFX1	Off
G#1	High	ROM Mono, 1439: Ice Drop	IFX1	Off
A1	High	ROM Mono, 1292: Industry Hit 27	IFX1	Off
A#1	High	ROM Mono, 1299: Industry Hit 34	IFX1	Off
B1	High	ROM Mono, 1301: Industry Hit 36	IFX1	Off
C2	High	ROM Mono, 1369: Voice 61	IFX1	Off
C#2	High	ROM Mono, 1373: Voice 65	IFX1	Off
D2	High	ROM Mono, 1374: Voice 66	IFX1	Off
D#2	High	ROM Mono, 1144: Perc-WS 01 (Vox Box)	IFX1	Off
E2	High	ROM Mono, 1578: El.Bs-SlapGhostSlide 3	IFX1	Off
F2	High	ROM Mono, 0413: SD-WS 08 (Tenny)	IFX1	Off
F#2	High	ROM Mono, 1398: Vocoder Voice 16	IFX1	Off
G2	High	ROM Mono, 1400: Vocoder Voice 18	IFX1	Off
G#2	High	ROM Mono, 1399: Vocoder Voice 17	IFX1	Off
A2	High	ROM Mono, 1401: Vocoder Voice 19	IFX1	Off
A#2	High	ROM Mono, 1383: Vocoder Voice 01	IFX1	Off
B2	High	ROM Mono, 1397: Vocoder Voice 15	IFX1	Off
C3	High	ROM Mono, 1389: Vocoder Voice 07	IFX1	Off
C#3	High	ROM Mono, 1280: Industry Hit 15	IFX1	Off
D3	High	ROM Mono, 1384: Vocoder Voice 02	IFX1	Off
D#3	High	ROM Mono, 1407: CompuVoice-Noise	IFX1	Off
E3	High	ROM Mono, 0400: SD-Dance 74	IFX1	Off
F3	High	ROM Mono, 1304: Industry Hit 39	IFX1	Off
F#3	High	ROM Mono, 1392: Vocoder Voice 10	IFX1	1
G3	High	ROM Mono, 1304: Industry Hit 39	IFX1	Off
G#3	High	ROM Mono, 1394: Vocoder Voice 12	IFX1	1
A3	High	ROM Mono, 1304: Industry Hit 39	IFX1	Off
A#3	High	ROM Mono, 1396: Vocoder Voice 14	IFX1	1
B3	High	ROM Mono, 1181: Perc-WS 03 (SynTom)	IFX1	Off
C4	High	ROM Mono, 1181: Perc-WS 03 (SynTom)	IFX1	Off
C#4	High	ROM Mono, 1303: Industry Hit 38	IFX1	Off
D4	High	ROM Mono, 1181: Perc-WS 03 (SynTom)	IFX1	Off
D#4	High	ROM Mono, 1281: Industry Hit 16	IFX1	Off
E4	High	ROM Mono, 1299: Industry Hit 34	IFX1	Off
F4	High	ROM Mono, 1276: Industry Hit 13	IFX1	Off
F#4	High	ROM Mono, 1388: Vocoder Voice 06	IFX1	Off
G4	High	ROM Mono, 1282: Industry Hit 17	IFX1	Off
G#4	High	ROM Mono, 1415: PC Voice 1-06	IFX1	Off
A4	High	ROM Mono, 1302: Industry Hit 37	IFX1	Off
A#4	High	ROM Mono, 1438: Glass Scratch	IFX1	Off
B4	High	ROM Mono, 1282: Industry Hit 17	IFX1	Off
C5	High	ROM Mono, 1385: Vocoder Voice 03	IFX1	Off
C#5	High	ROM Mono, 1386: Vocoder Voice 04	IFX1	Off
D5	High	ROM Mono, 1405: Vocoder Voice 23	IFX1	Off
D#5	High	ROM Mono, 1387: Vocoder Voice 05	IFX1	Off
E5	High	ROM Mono, 1393: Vocoder Voice 11	IFX1	Off
F5	High	ROM Mono, 1403: Vocoder Voice 21	IFX1	Off
F#5	High	ROM Mono, 1396: Vocoder Voice 14	IFX1	Off
G5	High	ROM Mono, 1404: Vocoder Voice 22	IFX1	Off
G#5	High	ROM Mono, 1390: Vocoder Voice 08	IFX1	Off
A5	High	ROM Mono, 1395: Vocoder Voice 13	IFX1	Off
A#5	High	ROM Mono, 1391: Vocoder Voice 09	IFX1	Off
B5	High	ROM Mono, 1395: Vocoder Voice 13	IFX1	Off
C6	High	ROM Mono, 1284: Industry Hit 19	IFX1	Off
C#6	High	ROM Mono, 1288: Industry Hit 23	IFX1	Off
D6	High	ROM Mono, 1285: Industry Hit 20	IFX1	Off
D#6	High	ROM Mono, 1406: CompuVoice-BEEP	IFX1	Off
E6	High	ROM Mono, 1297: Industry Hit 32	IFX1	Off
F6	High	ROM Mono, 1261: Industry Hit 02	IFX1	Off
F#6	High	ROM Mono, 1286: Industry Hit 21	IFX1	Off
G6	High	ROM Mono, 1298: Industry Hit 33	IFX1	Off
G#6	High	ROM Mono, 1276: Industry Hit 13	IFX1	Off
A6	High	ROM Mono, 1295: Industry Hit 30	IFX1	Off
A#6	High	ROM Mono, 1299: Industry Hit 34	IFX1	Off
B6	High	ROM Mono, 1283: Industry Hit 18	IFX1	Off
C7	High	ROM Mono, 1442: Door Slam 2	IFX1	Off
C#7	High	ROM Mono, 1293: Industry Hit 28	L/R	2

Key		Drumsample	Bus	Ex
D7	High	ROM Mono, 1290: Industry Hit 25	IFX1	Off
D#7	High	ROM Mono, 1282: Industry Hit 17	IFX1	2
E7	High	ROM Mono, 1281: Industry Hit 16	IFX1	Off
F7	High	ROM Mono, 1298: Industry Hit 33	IFX1	Off
F#7	High	ROM Mono, 1280: Industry Hit 15	IFX1	Off
G7	High	ROM Mono, 1179: Dance Perc 11	IFX1	Off
G#7	High	ROM Mono, 1305: Industry Loop 1	IFX1	3
A7	High	ROM Mono, 1289: Industry Hit 24	IFX1	3
A#7	High	ROM Mono, 1291: Industry Hit 26	IFX1	Off
B7	High	ROM Mono, 1306: Industry Loop 2	IFX1	Off
C8	High	ROM Mono, 1308: Industry Loop 4	IFX1	Off
G9	High	ROM Mono, 1424: Click 1	L/R	Off



29 (INT): BD-SD Catalog Kit

Key		Drumsample	Bus	Ex
E0	High	ROM Mono,0143:BD-Dance 71	IFX2	Off
	M Hi	ROM Stereo,0002:BD-02-amb mf -L		
	M Lo	ROM Mono,0143:BD-Dance 71		
F0	High	ROM Mono,0116:BD-Dance 46	IFX2	Off
	M Hi	ROM Mono,0017:BD-05-amb mp		
	M Lo	ROM Mono,0116:BD-Dance 46		
F#0	High	ROM Mono,0022:BD-06-dry mp -L	IFX2	Off
	M Hi	ROM Mono,0070:BD-Dance 06		
G0	High	ROM Mono,0076:BD-Hip 2	IFX2	Off
	M Hi	ROM Mono,0027:BD-06-amb mf		
	M Lo	ROM Mono,0076:BD-Hip 2		
G#0	High	ROM Mono,0032:BD-07-dry f -L	IFX2	Off
	M Hi	ROM Mono,0076:BD-Hip 2		
	M Lo	ROM Mono,0030:BD-07-dry mf -L		
A0	High	ROM Mono,0024:BD-06-dry f -L	IFX2	Off
	M Hi	ROM Stereo,0016:BD-09-dry mp -L		
	M Lo	ROM Mono,0022:BD-06-dry mp -L		
A#0	High	ROM Mono,0043:BD-09-dry mf -L	IFX2	Off
	M Hi	ROM Mono,0076:BD-Hip 2		
	M Lo	ROM Mono,0041:BD-09-dry mp -L		
B0	High	ROM Mono,0008:BD-03-amb mf -L	IFX2	Off
	M Hi	ROM Mono,0082:BD-Dark		
	M Lo	ROM Mono,0008:BD-03-amb mf -L		
C1	High	ROM Mono,0004:BD-02-amb mf -L	IFX2	Off
	M Hi	ROM Mono,0076:BD-Hip 2		
	M Lo	ROM Mono,0004:BD-02-amb mf -L		
C#1	High	ROM Mono,0123:BD-Dance 53	IFX2	Off
	M Hi	ROM Stereo,0016:BD-09-dry mp -L		
	M Lo	ROM Mono,0123:BD-Dance 53		
D1	High	ROM Mono,0043:BD-09-dry mf -L	IFX2	Off
	M Hi	ROM Mono,0053:BD-WS 3 (Ambi)		
	M Lo	ROM Mono,0041:BD-09-dry mp -L		
D#1	High	ROM Mono,0095:BD-Dance 25	IFX2	Off
	M Hi	ROM Mono,0022:BD-06-dry mp -L		
	M Lo	ROM Mono,0095:BD-Dance 25		
E1	High	ROM Mono,0071:BD-Dance 07	IFX2	Off
	M Hi	ROM Mono,0049:BD-Soft		
	M Lo	ROM Mono,0071:BD-Dance 07		
F1	High	ROM Mono,0022:BD-06-dry mp -L	IFX2	Off
	M Hi	ROM Mono,0022:BD-06-dry mp -L		
	High	ROM Mono,0077:BD-Hip 3		
F#1	M Hi	ROM Mono,0082:BD-Dark	IFX2	Off
	M Lo	ROM Mono,0077:BD-Hip 3		
	High	ROM Mono,0076:BD-Hip 2		
G1	M Hi	ROM Mono,0074:BD-Dance 10	IFX2	Off
	M Lo	ROM Mono,0076:BD-Hip 2		
	High	ROM Mono,0013:BD-04-amb mf -L		
G#1	M Hi	ROM Mono,0064:BD-Dance 03	IFX2	Off
	M Lo	ROM Mono,0013:BD-04-amb mf -L		
	High	ROM Mono,0082:BD-Dark		
A1	M Hi	ROM Stereo,0016:BD-09-dry mp -L	IFX2	Off
	M Lo	ROM Mono,0082:BD-Dark		
	High	ROM Mono,0006:BD-02-amb f -L		
A#1	M Hi	ROM Mono,0076:BD-Hip 2	IFX2	Off
	M Lo	ROM Mono,0004:BD-02-amb mf -L		
	High	ROM Mono,0018:BD-05-amb mf -L		
B1	M Hi	ROM Mono,0098:BD-Dance 28	IFX2	Off
	M Lo	ROM Mono,0018:BD-05-amb mf -L		
	High	ROM Mono,0099:BD-Dance 29		
C2	M Hi	ROM Mono,0076:BD-Hip 2	IFX2	Off
	M Lo	ROM Mono,0099:BD-Dance 29		
	High	ROM Mono,0020:BD-05-amb f -L		
C#2	M Hi	ROM Mono,0053:BD-WS 3 (Ambi)	IFX2	Off
	M Lo	ROM Mono,0017:BD-05-amb mp		
	High	ROM Mono,0078:BD-Dance 11		
D2	M Hi	ROM Mono,0013:BD-04-amb mf -L	IFX2	Off
	M Lo	ROM Mono,0078:BD-Dance 11		
	High	ROM Mono,0072:BD-Dance 08		
D#2	M Hi	ROM Mono,0108:BD-Dance 38	IFX2	Off
	M Lo	ROM Mono,0072:BD-Dance 08		
	High	ROM Mono,0095:BD-Dance 25		
E2	M Hi	ROM Mono,0038:BD-08-amb mf	IFX2	Off
	M Lo	ROM Mono,0082:BD-Dark		

Key		Drumsample	Bus	Ex
F2	High	ROM Mono,0139:BD-Dance 67	IFX2	Off
	M Hi	ROM Stereo,0017:BD-09-dry mf -L		
	M Lo	ROM Mono,0139:BD-Dance 67		
F#2	High	ROM Mono,0027:BD-06-amb mf	IFX2	Off
	M Hi	ROM Mono,0053:BD-WS 3 (Ambi)		
	M Lo	ROM Mono,0026:BD-06-amb mp		
G2	High	ROM Mono,0103:BD-Dance 33	IFX2	Off
	M Hi	ROM Stereo,0015:BD-08-dry f -L		
	M Lo	ROM Mono,0103:BD-Dance 33		
G#2	High	ROM Mono,0135:BD-Dance 63	IFX2	Off
	M Hi	ROM Mono,0042:BD-09-dry mp -R		
	M Lo	ROM Mono,0135:BD-Dance 63		
A2	High	ROM Mono,0047:BD-WS 2 (Tite)	IFX2	Off
	M Hi	ROM Mono,0103:BD-Dance 33		
	M Lo	ROM Mono,0047:BD-WS 2 (Tite)		
A#2	High	ROM Mono,0107:BD-Dance 37	IFX2	Off
	M Hi	ROM Stereo,0017:BD-09-dry mf -L		
	M Lo	ROM Mono,0107:BD-Dance 37		
B2	High	ROM Mono,0024:BD-06-dry f -L	IFX2	Off
	M Hi	ROM Mono,0038:BD-08-amb mf		
	M Lo	ROM Mono,0022:BD-06-dry mp -L		
C3	High	ROM Stereo,0001:BD-01-amb ff -L	IFX2	Off
	M Hi	ROM Stereo,0000:BD-01-amb f -L		
	M Lo	ROM Stereo,0000:BD-01-amb f -L		
C#3	High	ROM Stereo,0003:BD-02-amb mf -L	IFX2	Off
	M Hi	ROM Stereo,0002:BD-02-amb mf -L		
	M Lo	ROM Stereo,0002:BD-02-amb mf -L		
D3	High	ROM Stereo,0005:BD-03-amb f -L	IFX2	Off
	M Hi	ROM Stereo,0006:BD-04-amb mf -L		
	M Lo	ROM Stereo,0004:BD-03-amb mf -L		
D#3	High	ROM Stereo,0007:BD-04-amb f -L	IFX2	Off
	M Hi	ROM Stereo,0007:BD-04-amb f -L		
	M Lo	ROM Stereo,0006:BD-04-amb mf -L		
E3	Low	ROM Stereo,0006:BD-04-amb mf -L	IFX2	Off
	High	ROM Stereo,0009:BD-05-amb f -L		
	M Hi	ROM Stereo,0008:BD-05-amb mf -L		
F3	M Lo	ROM Stereo,0008:BD-05-amb mf -L	IFX2	Off
	High	ROM Stereo,0011:BD-06-dry f -L		
	M Hi	ROM Stereo,0030:SD-06-dry mf -L		
F#3	M Lo	ROM Stereo,0010:BD-06-dry mp -L	IFX2	Off
	High	ROM Stereo,0013:BD-07-dry f -L		
	M Hi	ROM Stereo,0012:BD-07-dry mf -L		
G3	M Lo	ROM Stereo,0012:BD-07-dry mf -L	IFX2	Off
	High	ROM Stereo,0015:BD-08-dry f -L		
	M Hi	ROM Stereo,0014:BD-08-dry mf -L		
G#3	M Lo	ROM Stereo,0014:BD-08-dry mf -L	IFX2	Off
	High	ROM Mono,0040:BD-08-amb ff		
	M Hi	ROM Mono,0039:BD-08-amb f		
A3	M Lo	ROM Mono,0038:BD-08-amb mf	IFX2	Off
	High	ROM Stereo,0017:BD-09-dry mf -L		
	M Hi	ROM Stereo,0016:BD-09-dry mp -L		
A#3	M Lo	ROM Stereo,0016:BD-09-dry mp -L	IFX2	Off
	High	ROM Mono,0008:BD-03-amb mf -L		
	M Hi	ROM Mono,0082:BD-Dark		
B3	M Lo	ROM Mono,0008:BD-03-amb mf -L	IFX2	Off
	High	ROM Mono,0022:BD-06-dry mp -L		
	M Hi	ROM Mono,0076:BD-Hip 2		
C4	M Lo	ROM Mono,0022:BD-06-dry mp -L	IFX1	Off
	High	ROM Stereo,0019:SD-01-dry f -L		
	M Hi	ROM Stereo,0018:SD-01-dry mp -L		
C#4	M Lo	ROM Stereo,0018:SD-01-dry mp -L	IFX1	Off
	High	ROM Mono,0157:SD-02-dry ff		
	M Hi	ROM Mono,0156:SD-02-dry f		
D4	M Lo	ROM Mono,0154:SD-02-dry mf -L	IFX1	Off
	Low	ROM Mono,0152:SD-02-dry mp -L		
	High	ROM Mono,0161:SD-03-dry f -L		
D#4	M Hi	ROM Mono,0159:SD-03-dry mf -L	IFX1	Off
	M Lo	ROM Mono,0158:SD-03-dry mp		
	Low	ROM Mono,0158:SD-03-dry mp		
E#4	High	ROM Stereo,0027:SD-04-amb ff -L	IFX1	Off
	M Hi	ROM Stereo,0026:SD-04-amb mf -L		
	M Lo	ROM Stereo,0025:SD-04-amb mp -L		
	Low	ROM Stereo,0024:SD-04-amb p -L		

Key		Drumsample	Bus	Ex
E4	High	ROM Mono,0175:SD-05-dry ff -L	IFX1	Off
	M Hi	ROM Mono,0174:SD-05-dry f -R		
	M Lo	ROM Mono,0172:SD-05-dry mp		
	Low	ROM Mono,0172:SD-05-dry mp		
F4	High	ROM Stereo,0031:SD-06-dry f -L	IFX1	Off
	M Hi	ROM Stereo,0030:SD-06-dry mf -L		
	M Lo	ROM Stereo,0030:SD-06-dry mf -L		
F#4	High	ROM Mono,0182:SD-07-amb f	IFX1	Off
	M Hi	ROM Mono,0181:SD-07-amb mf		
	M Lo	ROM Mono,0181:SD-07-amb mf		
G4	High	ROM Stereo,0033:SD-08-dry ff -L	IFX1	Off
	M Hi	ROM Stereo,0032:SD-08-dry f -L		
	M Lo	ROM Stereo,0032:SD-08-dry f -L		
G#4	High	ROM Stereo,0035:SD-09-dry ff -L	IFX1	Off
	M Hi	ROM Stereo,0034:SD-09-dry f -L		
	M Lo	ROM Stereo,0034:SD-09-dry f -L		
A4	High	ROM Mono,0192:SD-09-amb ff	IFX1	Off
	M Hi	ROM Mono,0192:SD-09-amb ff		
	M Lo	ROM Mono,0191:SD-09-amb f		
	Low	ROM Mono,0191:SD-09-amb f		
A#4	High	ROM Stereo,0037:SD-10-dry ff -L	IFX1	Off
	M Hi	ROM Stereo,0036:SD-10-dry f -L		
	M Lo	ROM Stereo,0036:SD-10-dry f -L		
B4	High	ROM Stereo,0039:SD-11-dry ff -L	IFX1	Off
	M Hi	ROM Stereo,0039:SD-11-dry ff -L		
	M Lo	ROM Stereo,0038:SD-11-dry mf -L		
	Low	ROM Stereo,0038:SD-11-dry mf -L		
C5	High	ROM Stereo,0045:SD-12-dry fff -L	IFX1	Off
	M Hi	ROM Stereo,0044:SD-12-dry ff -L		
	M Lo	ROM Stereo,0043:SD-12-dry f -L		
	Low	ROM Stereo,0040:SD-12-dry p -L		
C#5	High	ROM Mono,0218:SD-12-amb fff	IFX1	Off
	M Hi	ROM Mono,0217:SD-12-amb f		
	M Lo	ROM Mono,0216:SD-12-amb mp		
	Low	ROM Mono,0216:SD-12-amb mp		
D5	High	ROM Stereo,0047:SD-13-dry ff -L	IFX1	Off
	M Hi	ROM Stereo,0046:SD-13-dry mf -L		
	M Lo	ROM Stereo,0046:SD-13-dry mf -L		
D#5	High	ROM Stereo,0049:SD-14-dry ff -L	IFX1	Off
	M Hi	ROM Stereo,0048:SD-14-dry f -L		
	M Lo	ROM Stereo,0048:SD-14-dry f -L		
E5	High	ROM Mono,0232:SD-15-dry f -L	IFX1	Off
	M Hi	ROM Stereo,0051:SD-15-dry f -L		
	M Lo	ROM Stereo,0050:SD-15-dry mp -L		
	Low	ROM Stereo,0050:SD-15-dry mp -L		
F5	High	ROM Stereo,0053:SD-16-dry ff -L	IFX1	Off
	M Hi	ROM Stereo,0052:SD-16-dry f -L		
	M Lo	ROM Stereo,0052:SD-16-dry f -L		
F#5	High	ROM Mono,0240:SD-17-dry f	IFX1	Off
	M Hi	ROM Mono,0239:SD-17-dry mf		
	M Lo	ROM Mono,0238:SD-17-dry mp		
G5	High	ROM Mono,0244:SD-18-amb ff	IFX1	Off
	M Hi	ROM Mono,0244:SD-18-amb ff		
	M Lo	ROM Mono,0243:SD-18-amb f		
	Low	ROM Mono,0243:SD-18-amb f		
G#5	High	ROM Mono,0247:SD-19-amb f	IFX1	Off
	M Hi	ROM Mono,0246:SD-19-amb mf		
	M Lo	ROM Mono,0245:SD-19-amb mp		
A5	High	ROM Mono,0250:SD-20-dry f	IFX1	Off
	M Hi	ROM Mono,0249:SD-20-dry mp		
	M Lo	ROM Mono,0249:SD-20-dry mp		
A#5	High	ROM Mono,0253:SD-20-amb f	IFX1	Off
	M Hi	ROM Mono,0252:SD-20-amb mp		
	M Lo	ROM Mono,0252:SD-20-amb mp		
B5	High	ROM Mono,0259:SD-21-dry ff -L	IFX1	Off
	M Hi	ROM Mono,0258:SD-21-dry f		
	M Lo	ROM Mono,0256:SD-21-dry mf -L		
	Low	ROM Mono,0255:SD-21-dry mp		
C6	High	ROM Mono,0262:SD-21-amb ff	IFX1	Off
	M Hi	ROM Mono,0261:SD-21-amb f		
	M Lo	ROM Mono,0261:SD-21-amb f		
C#6	High	ROM Mono,0263:SD-22-dry f	IFX1	Off
	M Hi	ROM Mono,0263:SD-22-dry f		
	M Lo	ROM Mono,0255:SD-21-dry mp		

Key		Drumsample	Bus	Ex
D6	High	ROM Stereo,0056:SD-24-dry f -L	IFX1	Off
	M Hi	ROM Stereo,0056:SD-24-dry f -L		
	M Lo	ROM Stereo,0056:SD-24-dry f -L		
D#6	High	ROM Mono,0267:SD-23-dry mf	IFX1	Off
	M Hi	ROM Mono,0266:SD-23-dry mp		
	M Lo	ROM Mono,0266:SD-23-dry mp		
E6	High	ROM Stereo,0057:SD-24-dry ff -L	IFX1	Off
	M Hi	ROM Stereo,0056:SD-24-dry f -L		
	M Lo	ROM Stereo,0056:SD-24-dry f -L		
F6	High	ROM Mono,0319:SD-Sidestick 1 f	IFX1	Off
	M Hi	ROM Mono,0317:SD-Sidestick 1 mf -L		
	M Lo	ROM Mono,0317:SD-Sidestick 1 mf -L		
F#6	High	ROM Mono,0320:SD-Sidestick 2 mf	IFX1	Off
	M Hi	ROM Mono,0320:SD-Sidestick 2 mf		
G6	High	ROM Stereo,0072:SD-Sidestick 3 mf -L	IFX1	Off
	M Hi	ROM Stereo,0072:SD-Sidestick 3 mf -L		
G#6	High	ROM Stereo,0073:SD-Sidestick 4 mf -L	IFX1	Off
	M Hi	ROM Stereo,0073:SD-Sidestick 4 mf -L		
	M Hi	ROM Stereo,0073:SD-Sidestick 4 mf -L		
A6	High	ROM Stereo,0060:SD-25-dry Brush Tap f-L	IFX1	Off
	M Hi	ROM Stereo,0060:SD-25-dry Brush Tap f-L		
	M Lo	ROM Stereo,0059:SD-25-dry Brush Tap mp-L		
	Low	ROM Stereo,0059:SD-25-dry Brush Tap mp-L		
A#6	High	ROM Stereo,0063:SD-26-dry Brush Tap f-L	IFX1	Off
	M Hi	ROM Stereo,0063:SD-26-dry Brush Tap f-L		
	M Lo	ROM Stereo,0062:SD-26-dry Brush Tap mf-L		
	Low	ROM Stereo,0061:SD-26-dry Brush Tap mp-L		
B6	High	ROM Stereo,0065:SD-26-dry BrushSwirl a-L	IFX1	Off
C7	High	ROM Stereo,0066:SD-26-dry BrushSwirl b-L	IFX1	Off
C#7	High	ROM Stereo,0064:SD-26-dry BrushTriplet-L	IFX1	Off
D7	High	ROM Mono,0242:SD-17-dry GhostRoll f	IFX1	Off
	M Hi	ROM Mono,0241:SD-17-dry GhostRoll mf		
D#7	High	ROM Mono,0248:SD-19-amb GhostRoll	IFX1	Off
E7	High	ROM Mono,0251:SD-20-dry GhostRoll	IFX1	Off
F7	High	ROM Mono,0254:SD-20-amb GhostRoll	IFX1	Off
F#7	High	ROM Mono,0269:SD-24-dry mp	IFX1	Off
G7	High	ROM Mono,0268:SD-23-dry GhostRoll	IFX1	Off
G#7	High	ROM Stereo,0058:SD-24-dry GhostRoll -L	IFX1	Off
	M Hi	ROM Mono,0300:SD-Roll-Open 1 b		
A7	M Hi	ROM Mono,0298:SD-Roll-Open 1 a -L	IFX1	Off
	M Hi	ROM Mono,0298:SD-Roll-Open 1 a -L		
A#7	High	ROM Stereo,0068:SD-Roll-Open 2 -L	IFX1	Off
	High	ROM Mono,0305:SD-Roll-Open 3 b		
B7	M Hi	ROM Mono,0304:SD-Roll-Open 3 a	IFX1	Off
	M Hi	ROM Mono,0304:SD-Roll-Open 3 a		
C8	High	ROM Mono,0311:SD-Roll-Closed 3 b -L	IFX1	Off
	M Hi	ROM Mono,0310:SD-Roll-Closed 3 a		
C#8	High	ROM Mono,0308:SD-Roll-Closed 1 b	IFX1	Off
	M Hi	ROM Mono,0306:SD-Roll-Closed 1 a -L		
	M Hi	ROM Mono,0306:SD-Roll-Closed 1 a -L		
D8	High	ROM Mono,0314:SD-Roll-Closed 5	IFX1	Off
D#8	High	ROM Mono,0313:SD-Roll-Closed 4	IFX1	Off
E8	High	ROM Mono,0309:SD-Roll-Closed 2	IFX1	Off
F8	High	ROM Mono,0506:Hi-Hat Basic 1-Closed f	L/R	1
	M Hi	ROM Mono,0505:Hi-Hat Basic 1-Closed mf		
	M Lo	ROM Mono,0504:Hi-Hat Basic 1-Closed mp		
F#8	High	ROM Mono,0514:Hi-Hat Basic 1-Open ff	L/R	1
	M Hi	ROM Mono,0512:Hi-Hat Basic 1-Open mf		
	M Lo	ROM Mono,0507:Hi-Hat Basic 1-Closed ff		
G8	High	ROM Mono,0611:Crash Cymbal 1 ff	L/R	Off
	M Hi	ROM Mono,0610:Crash Cymbal 1 f		
	M Lo	ROM Mono,0609:Crash Cymbal 1 mf		

30 (INT): BD-SD Catalog Kit 2

Key		Drumsample	Bus	Ex
E0	High	ROM Mono,0051:BD-Tubby	IFX2	Off
	M Hi	ROM Mono,0051:BD-Tubby		
F0	High	ROM Mono,0049:BD-Soft	IFX2	Off
	M Hi	ROM Mono,0049:BD-Soft		
F#0	High	ROM Mono,0134:BD-Dance 62	IFX2	Off
	M Hi	ROM Mono,0134:BD-Dance 62		
G0	High	ROM Mono,0052:BD-Gated	IFX2	Off
	M Hi	ROM Mono,0082:BD-Dark		
G#0	High	ROM Mono,1023:Tabla-Tun a	IFX2	Off
	M Hi	ROM Mono,0100:BD-Dance 30		
	M Lo	ROM Mono,0143:BD-Dance 71		
A0	High	ROM Mono,0055:BD-Hip 1	IFX2	Off
	M Hi	ROM Mono,0076:BD-Hip 2		
A#0	High	ROM Mono,0065:BD-Ambi	IFX2	Off
	M Hi	ROM Mono,0065:BD-Ambi		
B0	High	ROM Mono,0070:BD-Dance 06	IFX2	Off
	M Hi	ROM Mono,0070:BD-Dance 06		
C1	High	ROM Mono,0072:BD-Dance 08	IFX2	Off
	M Hi	ROM Mono,0072:BD-Dance 08		
C#1	High	ROM Mono,0074:BD-Dance 10	IFX2	Off
	M Hi	ROM Mono,0074:BD-Dance 10		
D1	High	ROM Mono,0096:BD-Dance 26	IFX2	Off
	M Hi	ROM Mono,0096:BD-Dance 26		
D#1	High	ROM Mono,0138:BD-Dance 66	IFX2	Off
	M Hi	ROM Mono,0138:BD-Dance 66		
E1	High	ROM Mono,0053:BD-WS 3 (Ambi)	IFX2	Off
	M Hi	ROM Mono,0114:BD-Dance 44		
F1	High	ROM Mono,0079:BD-Dance 12	IFX2	Off
	M Hi	ROM Mono,0079:BD-Dance 12		
F#1	High	ROM Mono,0080:BD-Dance Soft	IFX2	Off
	M Hi	ROM Mono,0080:BD-Dance Soft		
G1	High	ROM Mono,0143:BD-Dance 71	IFX2	Off
	M Hi	ROM Mono,0143:BD-Dance 71		
G#1	High	ROM Mono,0123:BD-Dance 53	IFX2	Off
	M Hi	ROM Mono,0123:BD-Dance 53		
A1	High	ROM Mono,0075:BD-Pop	IFX2	Off
	M Hi	ROM Mono,0075:BD-Pop		
A#1	High	ROM Mono,0092:BD-Dance 22	IFX2	Off
	M Hi	ROM Mono,0092:BD-Dance 22		
B1	High	ROM Mono,0094:BD-Dance 24	IFX2	Off
	M Hi	ROM Mono,0094:BD-Dance 24		
C2	High	ROM Mono,0098:BD-Dance 28	IFX2	Off
	M Hi	ROM Mono,0098:BD-Dance 28		
C#2	High	ROM Mono,0099:BD-Dance 29	IFX2	Off
	M Hi	ROM Mono,0123:BD-Dance 53		
D2	High	ROM Mono,0987:Djembe L-Basstone c	IFX2	Off
	M Hi	ROM Mono,0133:BD-Dance 61		
	M Lo	ROM Mono,0985:Djembe L-Basstone a		
D#2	High	ROM Mono,0103:BD-Dance 33	IFX2	Off
	M Hi	ROM Mono,0103:BD-Dance 33		
E2	High	ROM Mono,0099:BD-Dance 29	IFX2	Off
	M Hi	ROM Mono,0142:BD-Dance 70		
F2	High	ROM Mono,1489:Ac.Gtr Ghost Hit-Slide	IFX2	Off
	M Hi	ROM Mono,0132:BD-Dance 60		
G2	High	ROM Mono,0130:BD-Dance 58	IFX2	Off
	M Hi	ROM Mono,0130:BD-Dance 58		
G#2	High	ROM Mono,0118:BD-Dance 48	IFX2	Off
	M Hi	ROM Mono,0118:BD-Dance 48		
A2	High	ROM Mono,0089:BD-Dance 19	IFX2	Off
	M Hi	ROM Mono,0088:BD-Dance 18		
A#2	High	ROM Mono,0125:BD-Dance 55	IFX2	Off
	M Hi	ROM Mono,0125:BD-Dance 55		
B2	High	ROM Mono,0135:BD-Dance 63	IFX2	Off
	M Hi	ROM Mono,0135:BD-Dance 63		
C3	High	ROM Mono,0139:BD-Dance 67	IFX2	Off
	M Hi	ROM Mono,0139:BD-Dance 67		
C#3	High	ROM Mono,0131:BD-Dance 59	IFX2	Off
	M Hi	ROM Mono,0131:BD-Dance 59		
D3	High	ROM Mono,0075:BD-Pop	IFX2	Off
	M Hi	ROM Mono,0075:BD-Pop		
D#3	High	ROM Mono,1239:DJ Vinyl Sliced 15	IFX2	Off
	M Hi	ROM Mono,1237:DJ Vinyl Sliced 13		
E3	High	ROM Mono,0140:BD-Dance 68	IFX2	Off
	M Hi	ROM Mono,0140:BD-Dance 68		

Key		Drumsample	Bus	Ex
F3	High	ROM Mono,0111:BD-Dance 41	IFX2	Off
	M Hi	ROM Mono,0082:BD-Dark		
F#3	High	ROM Mono,0112:BD-Dance 42	IFX2	Off
	M Hi	ROM Mono,0112:BD-Dance 42		
G3	High	ROM Mono,1327:Voice 19	IFX2	Off
	M Hi	ROM Mono,0143:BD-Dance 71		
G#3	M Lo	ROM Mono,1327:Voice 19	IFX2	Off
	High	ROM Mono,0054:BD-Orchestral		
A3	M Hi	ROM Mono,0125:BD-Dance 55	IFX2	Off
	High	ROM Mono,0091:BD-Dance 21		
A#3	M Hi	ROM Mono,0091:BD-Dance 21	IFX2	Off
	High	ROM Mono,0076:BD-Hip 2		
B3	M Hi	ROM Mono,0070:BD-Dance 06	IFX2	Off
	M Lo	ROM Mono,0076:BD-Hip 2		
C4	High	ROM Mono,0141:BD-Dance 69	IFX2	Off
	M Hi	ROM Mono,0141:BD-Dance 69		
C#4	High	ROM Mono,0331:SD-Dance 05	IFX1	Off
	M Hi	ROM Mono,0331:SD-Dance 05		
D4	High	ROM Mono,0338:SD-Dance 12	IFX1	Off
	M Hi	ROM Mono,0337:SD-Dance 11		
D#4	High	ROM Mono,1437:Glass Crash	IFX1	Off
	M Hi	ROM Mono,0326:SD-Sidestick WS		
E4	M Lo	ROM Mono,1437:Glass Crash	IFX1	Off
	High	ROM Mono,0352:SD-Dance 26		
F4	M Hi	ROM Mono,0352:SD-Dance 26	IFX1	Off
	High	ROM Mono,0390:SD-Dance 64		
F#4	M Hi	ROM Mono,0402:SD-Sizzle	IFX1	Off
	M Lo	ROM Mono,1424:Click 1		
G4	High	ROM Mono,0340:SD-Dance 14	IFX1	Off
	M Hi	ROM Mono,1424:Click 1		
G#4	High	ROM Stereo,0031:SD-06-dry f-L	IFX1	Off
	M Hi	ROM Mono,0333:SD-Dance 07		
A4	High	ROM Mono,0392:SD-Dance 66	IFX1	Off
	M Hi	ROM Mono,1328:Voice 20		
A#4	M Lo	ROM Mono,0392:SD-Dance 66	IFX1	Off
	High	ROM Mono,0384:SD-Dance 58		
B4	M Hi	ROM Mono,0386:SD-Dance 60	IFX1	Off
	High	ROM Mono,0396:SD-Dance 70		
C5	M Hi	ROM Mono,0396:SD-Dance 70	IFX1	Off
	High	ROM Mono,1391:Vocoder Voice 09		
C#5	M Hi	ROM Mono,0344:SD-Dance 18	IFX1	Off
	M Lo	ROM Mono,1391:Vocoder Voice 09		
D5	High	ROM Mono,0412:SD-WS 07 (Noise)	IFX1	Off
	M Hi	ROM Mono,0412:SD-WS 07 (Noise)		
D#5	High	ROM Mono,0397:SD-Dance 71	IFX1	Off
	M Hi	ROM Mono,0397:SD-Dance 71		
E5	High	ROM Mono,0327:SD-Dance 01	IFX1	Off
	M Hi	ROM Mono,0327:SD-Dance 01		
F5	High	ROM Mono,0405:SD-AmbiCrackle 2	IFX1	Off
	M Hi	ROM Mono,0405:SD-AmbiCrackle 2		
F#5	High	ROM Mono,0564:Hi-Hat Dance 06	IFX1	Off
	M Hi	ROM Mono,1151:Dance Claps 06		
G5	High	ROM Mono,0380:SD-Dance 54	IFX1	Off
	M Hi	ROM Mono,0380:SD-Dance 54		
G#5	High	ROM Mono,0409:SD-WS 04 (Nasty)	IFX1	Off
	M Hi	ROM Mono,0409:SD-WS 04 (Nasty)		
A5	High	ROM Mono,0410:SD-WS 05 (BeatBox)	IFX1	Off
	M Hi	ROM Mono,0410:SD-WS 05 (BeatBox)		
A#5	High	ROM Mono,0411:SD-WS 06 (Gated)	IFX1	Off
	M Hi	ROM Mono,0411:SD-WS 06 (Gated)		
B5	High	ROM Mono,0400:SD-Dance 74	IFX1	Off
	M Hi	ROM Mono,1101:Jew's Harp 19		
C6	M Lo	ROM Mono,0400:SD-Dance 74	IFX1	Off
	High	ROM Mono,0413:SD-WS 08 (Tenny)		
C#6	M Hi	ROM Mono,0413:SD-WS 08 (Tenny)	IFX1	Off
	High	ROM Mono,0414:SD-Vocal		
D6	M Hi	ROM Mono,0414:SD-Vocal	IFX1	Off
	High	ROM Mono,0415:SD-Dance 75		
E6	M Hi	ROM Mono,0415:SD-Dance 75	IFX1	Off
	High	ROM Mono,1427:Bird 2		
F6	M Hi	ROM Mono,0327:SD-Dance 01	IFX1	Off
	M Lo	ROM Mono,1427:Bird 2		
G6	High	ROM Mono,0417:SD-Dance 77	IFX1	Off
	M Hi	ROM Mono,0417:SD-Dance 77		



Key		Drumsample	Bus	Ex
D6	High	ROM Mono,0418:SD-Dance 78	IFX1	Off
	M Hi	ROM Mono,0418:SD-Dance 78		
D#6	High	ROM Mono,0419:SD-Dance Rimshot	IFX1	Off
	M Hi	ROM Mono,0419:SD-Dance Rimshot		
E6	High	ROM Mono,1146:Dance Claps 01	IFX1	Off
	M Hi	ROM Mono,1146:Dance Claps 01		
F6	High	ROM Mono,0420:SD-Dance Sidestick	IFX1	Off
	M Hi	ROM Mono,0420:SD-Dance Sidestick		
F#6	High	ROM Mono,1071:Rap Sleigh Bell	IFX1	Off
	M Hi	ROM Mono,0332:SD-Dance 06		
G6	High	ROM Mono,1108:WD-Big Hand 3	IFX1	Off
	M Hi	ROM Mono,0340:SD-Dance 14		
G#6	High	ROM Mono,1120:WD-Ethno SD 1	IFX1	Off
	M Hi	ROM Mono,0359:SD-Dance 33		
A6	High	ROM Mono,1125:WD-Ethno SD 6	IFX1	Off
	M Hi	ROM Mono,0374:SD-Dance 48		
A#6	High	ROM Mono,1126:WD-Gothic 1	IFX1	Off
	M Hi	ROM Mono,0391:SD-Dance 65		
B6	High	ROM Mono,1134:WD-Kangaroo 3	IFX1	Off
	M Hi	ROM Mono,0353:SD-Dance 27		
C7	High	ROM Mono,1341:Voice 33	IFX1	Off
	M Hi	ROM Mono,0361:SD-Dance 35		
	M Lo	ROM Mono,1341:Voice 33		
C#7	High	ROM Mono,1347:Voice 39	IFX1	Off
	M Hi	ROM Mono,0357:SD-Dance 31		
	M Lo	ROM Mono,1347:Voice 39		
D7	High	ROM Mono,1387:Vocoder Voice 05	IFX1	Off
	M Hi	ROM Mono,0353:SD-Dance 27		
	M Lo	ROM Mono,1383:Vocoder Voice 01		
D#7	High	ROM Mono,0398:SD-Dance 72	IFX1	Off
	M Hi	ROM Mono,0691:Hand Claps 2-e		
E7	High	ROM Mono,1390:Vocoder Voice 08	IFX1	Off
	M Hi	ROM Mono,0342:SD-Dance 16		
	M Lo	ROM Mono,1390:Vocoder Voice 08		
F7	High	ROM Mono,0393:SD-Dance 67	IFX1	Off
	M Hi	ROM Mono,1099:Jew's Harp 17		
F#7	High	ROM Mono,0416:SD-Dance 76	IFX1	Off
	M Hi	ROM Mono,0416:SD-Dance 76		
G7	High	ROM Mono,0345:SD-Dance 19	IFX1	Off
	M Hi	ROM Mono,0345:SD-Dance 19		
G#7	High	ROM Mono,1444:Car Stop	IFX1	Off
	M Hi	ROM Mono,0326:SD-Sidestick WS		
	M Lo	ROM Mono,1444:Car Stop		
A7	High	ROM Mono,1492:El.Gtr-Glissando Down 2	IFX1	Off
	M Hi	ROM Mono,0255:SD-21-dry mp		
	M Lo	ROM Mono,1492:El.Gtr-Glissando Down 2		
A#7	High	ROM Mono,1390:Vocoder Voice 08	IFX1	Off
	M Hi	ROM Mono,0371:SD-Dance 45		
	M Lo	ROM Mono,1390:Vocoder Voice 08		
B7	High	ROM Mono,0383:SD-Dance 57	IFX1	Off
	M Hi	ROM Mono,0383:SD-Dance 57		
C8	High	ROM Mono,0388:SD-Dance 62	IFX1	Off
	M Hi	ROM Mono,0388:SD-Dance 62		
C#8	High	ROM Mono,0406:SD-Whopper	IFX1	Off
	M Hi	ROM Mono,0406:SD-Whopper		
D8	High	ROM Mono,0687:Hand Claps 2-b	IFX1	Off
	M Hi	ROM Mono,1146:Dance Claps 01		
D#8	High	ROM Mono,1150:Dance Claps 05	IFX1	Off
	M Hi	ROM Mono,1153:Dance Claps 08		
E8	High	ROM Mono,1119:WD-Brazilia 2	IFX1	Off
	M Hi	ROM Mono,0341:SD-Dance 15		
F8	High	ROM Mono,0577:Hi-Hat Dance 19	L/R	1
	M Hi	ROM Mono,0576:Hi-Hat Dance 18		
F#8	High	ROM Mono,0579:Hi-Hat Dance 21	L/R	1
	M Hi	ROM Mono,0579:Hi-Hat Dance 21		
G8	High	ROM Mono,0619:Crash Cymbal 4 ff	L/R	Off
	M Hi	ROM Mono,0635:Crash Dance 3		

31 (INT): Cymbal Catalog Kit

Key		Drumsample	Bus	Ex
B0	High	ROM Mono,0000:BD-01-amb f-L	L/R	Off
C1	High	ROM Mono,0561:Hi-Hat Dance 03	L/R	Off
	M Hi	ROM Mono,0561:Hi-Hat Dance 03		
C#1	High	ROM Mono,0559:Hi-Hat Dance 01	L/R	Off
	M Hi	ROM Mono,0559:Hi-Hat Dance 01		
D1	High	ROM Mono,0560:Hi-Hat Dance 02	L/R	Off
D#1	High	ROM Mono,0563:Hi-Hat Dance 05	L/R	Off
E1	High	ROM Mono,0562:Hi-Hat Dance 04	L/R	Off
F1	High	ROM Mono,0572:Hi-Hat Dance 14	L/R	1
F#1	High	ROM Mono,0573:Hi-Hat Dance 15	L/R	1
G1	High	ROM Mono,0574:Hi-Hat Dance 16	L/R	1
G#1	High	ROM Mono,0579:Hi-Hat Dance 21	L/R	1
A1	High	ROM Mono,0580:Hi-Hat Dance 22	L/R	2
A#1	High	ROM Mono,0581:Hi-Hat Dance 23	L/R	2
B1	High	ROM Mono,0584:Hi-Hat Dance 26	L/R	3
	M Hi	ROM Mono,0583:Hi-Hat Dance 25		
	M Lo	ROM Mono,0582:Hi-Hat Dance 24		
C2	High	ROM Mono,0585:Hi-Hat Dance 27	L/R	3
C#2	High	ROM Mono,0587:Hi-Hat Dance 29	L/R	4
	M Hi	ROM Mono,0586:Hi-Hat Dance 28		
D2	High	ROM Mono,0588:Hi-Hat Dance 30	L/R	4
D#2	High	ROM Mono,0603:Hi-Hat Dance 34	L/R	5
	M Hi	ROM Mono,0603:Hi-Hat Dance 34		
E2	High	ROM Mono,0604:Hi-Hat Dance 35	L/R	5
	M Hi	ROM Mono,0604:Hi-Hat Dance 35		
F2	High	ROM Mono,0605:Hi-Hat Dance 36	L/R	6
F#2	High	ROM Mono,0606:Hi-Hat Dance 37	L/R	6
G2	High	ROM Mono,0599:Hi-Hat-Ambi	L/R	7
	M Hi	ROM Mono,0599:Hi-Hat-Ambi		
G#2	High	ROM Mono,0601:Hi-Hat-ClangyOpen	L/R	7
A2	High	ROM Mono,1166:Dance Perc 04-Closed	L/R	8
A#2	High	ROM Mono,1167:Dance Perc 04-Open	L/R	8
B2	High	ROM Mono,1295:Industry Hit 30	L/R	Off
	M Hi	ROM Mono,1294:Industry Hit 29		
C3	High	ROM Mono,0505:Hi-Hat Basic 1-Closed mf	L/R	9
	M Hi	ROM Mono,0504:Hi-Hat Basic 1-Closed mp		
C#3	High	ROM Mono,0506:Hi-Hat Basic 1-Closed f	L/R	9
	M Hi	ROM Mono,0505:Hi-Hat Basic 1-Closed mf		
D3	High	ROM Mono,0507:Hi-Hat Basic 1-Closed ff	L/R	9
	M Hi	ROM Mono,0505:Hi-Hat Basic 1-Closed mf		
D#3	High	ROM Mono,0513:Hi-Hat Basic 1-Open f	L/R	9
	M Hi	ROM Mono,0512:Hi-Hat Basic 1-Open mf		
	High	ROM Mono,0510:Hi-Hat Basic 1-Pedal f		
E3	M Hi	ROM Mono,0509:Hi-Hat Basic 1-Pedal mf	L/R	9
	M Lo	ROM Mono,0508:Hi-Hat Basic 1-Pedal mp		
	High	ROM Mono,0516:Hi-Hat Basic 2-Closed mf		
F3	High	ROM Mono,0515:Hi-Hat Basic 2-Closed mp	L/R	10
	M Hi	ROM Mono,0517:Hi-Hat Basic 2-Closed f		
F#3	High	ROM Mono,0517:Hi-Hat Basic 2-Closed f	L/R	10
	M Hi	ROM Mono,0517:Hi-Hat Basic 2-Closed f		
G3	High	ROM Mono,0520:Hi-Hat Basic 2-Open f	L/R	10
	M Hi	ROM Mono,0518:Hi-Hat Basic 2-Open mp		
G#3	High	ROM Mono,0522:Hi-Hat Basic 3-Closed mf	L/R	11
	M Hi	ROM Mono,0521:Hi-Hat Basic 3-Closed mp		
A3	High	ROM Mono,0523:Hi-Hat Basic 3-Closed f	L/R	11
	M Hi	ROM Mono,0522:Hi-Hat Basic 3-Closed mf		
A#3	High	ROM Mono,0525:Hi-Hat Basic 3-Open	L/R	11
	M Hi	ROM Mono,0525:Hi-Hat Basic 3-Open		
B3	High	ROM Mono,0528:Hi-Hat Heavy 1-Closed f	L/R	12
	M Hi	ROM Mono,0526:Hi-Hat Heavy 1-Closed mp		
C4	High	ROM Mono,0530:Hi-Hat Heavy 1-HalfOpen	L/R	12
	M Hi	ROM Mono,0530:Hi-Hat Heavy 1-HalfOpen		
C#4	High	ROM Mono,0529:Hi-Hat Heavy 1-Open f	L/R	12
	M Hi	ROM Mono,0529:Hi-Hat Heavy 1-Open f		
D4	High	ROM Mono,0532:Hi-Hat Heavy 2-Closed mf	L/R	13
	M Hi	ROM Mono,0531:Hi-Hat Heavy 2-Closed mp		
D#4	High	ROM Mono,0534:Hi-Hat Heavy 2-Closed ff	L/R	13
	M Hi	ROM Mono,0533:Hi-Hat Heavy 2-Closed f		
E4	High	ROM Mono,0536:Hi-Hat Heavy 2-Open f	L/R	13
	M Hi	ROM Mono,0535:Hi-Hat Heavy 2-Open mp		
F4	High	ROM Mono,0538:Hi-Hat Heavy 2-Pedal f	L/R	13
	M Hi	ROM Mono,0537:Hi-Hat Heavy 2-Pedal mf		
F#4	High	ROM Mono,0539:Hi-Hat Heavy 2-FootOpen	L/R	13
	M Hi	ROM Mono,0541:Hi-Hat Basic 4-Closed 2		
G4	High	ROM Mono,0541:Hi-Hat Basic 4-Closed 2	L/R	14
	M Hi	ROM Mono,0540:Hi-Hat Basic 4-Closed 1		

Key		Drumsample	Bus	Ex
G#4	High	ROM Mono,0544:Hi-Hat Basic 4-Open 1	L/R	14
	M Hi	ROM Mono,0545:Hi-Hat Basic 4-Open 2		
A4	High	ROM Mono,0543:Hi-Hat Basic 4-FootOpen	L/R	14
	M Hi	ROM Mono,0542:Hi-Hat Basic 4-Foot		
A#4	High	ROM Mono,0547:Hi-Hat Basic 5-Closed 2	L/R	15
	M Hi	ROM Mono,0546:Hi-Hat Basic 5-Closed 1		
B4	High	ROM Mono,0548:Hi-Hat Basic 5-Open	L/R	15
	M Hi	ROM Mono,0548:Hi-Hat Basic 5-Open		
C5	High	ROM Mono,0550:Hi-Hat Brush-Closed mf	L/R	16
	M Hi	ROM Mono,0549:Hi-Hat Brush-Closed mp		
C#5	High	ROM Mono,0551:Hi-Hat Brush-Closed f	L/R	16
	M Hi	ROM Mono,0550:Hi-Hat Brush-Closed mf		
D5	High	ROM Mono,0557:Hi-Hat Brush-Open f	L/R	16
	M Hi	ROM Mono,0555:Hi-Hat Brush-Open mp		
D#5	High	ROM Mono,0554:Hi-Hat Brush-Pedal ff	L/R	16
	M Hi	ROM Mono,0553:Hi-Hat Brush-Pedal mf		
E5	High	ROM Mono,0653:Ride Cymbal 3 ff	L/R	Off
	M Hi	ROM Mono,0651:Ride Cymbal 3 f-L		
	M Lo	ROM Mono,0649:Ride Cymbal 3 mf-L		
F5	Low	ROM Mono,0648:Ride Cymbal 3 mp	L/R	Off
	High	ROM Mono,0656:Ride Cymbal 4 ff		
	M Hi	ROM Mono,0655:Ride Cymbal 4 f		
	M Lo	ROM Mono,0654:Ride Cymbal 4 mp		
F#5	Low	ROM Mono,0654:Ride Cymbal 4 mp	L/R	Off
	High	ROM Mono,0658:Ride Cymbal 5 f		
	M Hi	ROM Mono,0657:Ride Cymbal 5 mf		
G5	M Lo	ROM Mono,0657:Ride Cymbal 5 mf	L/R	Off
	High	ROM Stereo,0108:Ride Cymbal 6 f-L		
G#5	M Hi	ROM Stereo,0107:Ride Cymbal 6 mf-L	L/R	Off
	M Lo	ROM Stereo,0107:Ride Cymbal 6 mf-L		
	High	ROM Stereo,0110:Ride Cymbal 8-L		
A5	M Hi	ROM Stereo,0110:Ride Cymbal 8-L	L/R	Off
	High	ROM Mono,0611:Crash Cymbal 1 ff		
A#5	M Hi	ROM Mono,0610:Crash Cymbal 1 f	L/R	Off
	M Lo	ROM Mono,0609:Crash Cymbal 1 mf		
	Low	ROM Mono,0609:Crash Cymbal 1 mf		
	High	ROM Mono,0614:Crash Cymbal 2 ff		
B5	M Hi	ROM Mono,0612:Crash Cymbal 2 f-L	L/R	Off
	M Lo	ROM Mono,0612:Crash Cymbal 2 f-L		
C6	High	ROM Stereo,0100:Crash Cymbal 2 f-L	L/R	Off
	M Hi	ROM Stereo,0100:Crash Cymbal 2 f-L		
C#6	High	ROM Mono,0615:Crash Cymbal 3 ff	L/R	Off
	M Hi	ROM Mono,0615:Crash Cymbal 3 ff		
	High	ROM Mono,0619:Crash Cymbal 4 ff		
	M Hi	ROM Mono,0618:Crash Cymbal 4 f		
D6	M Lo	ROM Mono,0617:Crash Cymbal 4 mf	L/R	Off
	Low	ROM Mono,0616:Crash Cymbal 4 mp		
	High	ROM Mono,0622:Crash Cymbal 5 ff		
D#6	M Hi	ROM Mono,0621:Crash Cymbal 5 mf	L/R	Off
	M Lo	ROM Mono,0620:Crash Cymbal 5 mp		
	Low	ROM Mono,0620:Crash Cymbal 5 mp		
E6	High	ROM Mono,0625:Crash Cymbal 6 ff	L/R	Off
	M Hi	ROM Mono,0623:Crash Cymbal 6 mf-L		
F6	M Hi	ROM Mono,0623:Crash Cymbal 6 mf-L	L/R	Off
	High	ROM Mono,0627:Crash Cymbal 7 f-L		
G6	M Hi	ROM Mono,0626:Crash Cymbal 7 mf	L/R	Off
	High	ROM Stereo,0111:China Cymbal 1-L		
F#6	M Hi	ROM Stereo,0111:China Cymbal 1-L	L/R	Off
	High	ROM Mono,0673:China Cymbal 2		
G#6	M Hi	ROM Mono,0673:China Cymbal 2	L/R	Off
	High	ROM Stereo,0111:China Cymbal 1-L		
A6	M Hi	ROM Stereo,0111:China Cymbal 1-L	L/R	Off
	High	ROM Mono,0678:Splash Cymbal 1 ff-L		
	M Lo	ROM Mono,0677:Splash Cymbal 1 f		
A#6	M Lo	ROM Mono,0676:Splash Cymbal 1 mf	L/R	Off
	High	ROM Mono,0675:Splash Cymbal 1 mp		
B6	High	ROM Mono,0681:Splash Cymbal 2 ff	L/R	Off
	M Hi	ROM Mono,0680:Splash Cymbal 2 mp		
C7	M Lo	ROM Mono,0680:Splash Cymbal 2 mp	L/R	Off
	High	ROM Stereo,0112:Splash Cymbal 1 ff-L		
B#6	M Hi	ROM Mono,0114:BD-Dance 44	L/R	Off
	High	ROM Mono,0640:Cymbal Reverse 2		
C#7	High	ROM Mono,0633:Crash Dance 1	L/R	Off
	M Hi	ROM Mono,0633:Crash Dance 1		

Key		Drumsample	Bus	Ex
C#7	High	ROM Mono, 0634: Crash Dance 2	L/R	Off
	M Hi	ROM Mono, 0634: Crash Dance 2		
D7	High	ROM Mono, 0635: Crash Dance 3	L/R	Off
	M Hi	ROM Mono, 0635: Crash Dance 3		
D#7	High	ROM Mono, 0636: Crash Dance 4	L/R	Off
	M Hi	ROM Mono, 0636: Crash Dance 4		
E7	High	ROM Mono, 0636: Crash Dance 4	L/R	Off
	M Hi	ROM Mono, 0636: Crash Dance 4		
F7	High	ROM Mono, 0667: Ride Dance 1	L/R	Off
F#7	High	ROM Mono, 0619: Crash Cymbal 4 ff	L/R	Off
	M Hi	ROM Mono, 0619: Crash Cymbal 4 ff		
G7	High	ROM Mono, 1290: Industry Hit 25	L/R	Off
	M Hi	ROM Mono, 1290: Industry Hit 25		
G#7	High	ROM Mono, 1291: Industry Hit 26	L/R	Off
	M Hi	ROM Mono, 1291: Industry Hit 26		
A7	High	ROM Mono, 1306: Industry Loop 2	L/R	Off
	M Hi	ROM Mono, 1306: Industry Loop 2		
A#7	High	ROM Mono, 1339: Voice 31	L/R	Off
	M Hi	ROM Mono, 1339: Voice 31		
B7	High	ROM Mono, 1454: Gun Shot	L/R	Off
	M Hi	ROM Mono, 1454: Gun Shot		
C8	High	ROM Mono, 1418: Stadium	L/R	Off
	M Hi	ROM Mono, 1418: Stadium		

## GM Drum Kit

## 48 (GM): STANDARD

Key		Drumsample	Bus	Ex
D#1	High	ROM Mono, 1191: Zap 2	L/R	Off
E1	High	ROM Mono, 1481: Noise-White	L/R	Off
F1	High	ROM Mono, 1254: DJ-Scratch 1	L/R	7
F#1	High	ROM Mono, 1254: DJ-Scratch 1	L/R	7
G1	High	ROM Mono, 0682: Drumstick Hit	L/R	Off
G#1	High	ROM Mono, 1190: Zap 1	L/R	Off
A1	High	ROM Mono, 1424: Click 1	L/R	Off
A#1	High	ROM Mono, 0955: Triangle 3 Lp	L/R	Off
B1	High	ROM Mono, 0024: BD-06-dry f -L	IFX1	Off
	M Hi	ROM Mono, 0022: BD-06-dry mp -L		
C2	High	ROM Mono, 0010: BD-03-amb f -L	IFX1	Off
	M Hi	ROM Mono, 0008: BD-03-amb mf -L		
C#2	High	ROM Mono, 0319: SD-Sidestick 1 f	L/R	Off
	M Hi	ROM Mono, 0317: SD-Sidestick 1 mf -L		
D2	High	ROM Mono, 0214: SD-12-dry fff -L	IFX2	Off
	M Hi	ROM Mono, 0210: SD-12-dry f -L		
D#2	High	ROM Mono, 0693: Hand Claps 2-g -L	L/R	Off
	M Hi	ROM Mono, 0689: Hand Claps 2-d -L		
E2	High	ROM Mono, 0227: SD-14-dry fff -L	IFX2	Off
	M Hi	ROM Mono, 0225: SD-14-dry f -L		
F2	High	ROM Mono, 0425: Tom Basic Lo ff	IFX3	Off
	M Hi	ROM Mono, 0423: Tom Basic Lo f -L		
F#2	High	ROM Mono, 0507: Hi-Hat Basic 1-Closed ff	IFX4	1
	M Hi	ROM Mono, 0506: Hi-Hat Basic 1-Closed f		
G2	High	ROM Mono, 0425: Tom Basic Lo ff	IFX3	Off
	M Hi	ROM Mono, 0423: Tom Basic Lo f -L		
G#2	High	ROM Mono, 0510: Hi-Hat Basic 1-Pedal f	IFX4	1
	M Hi	ROM Mono, 0508: Hi-Hat Basic 1-Pedal mp		
A2	High	ROM Mono, 0428: Tom Basic MidLo f -L	IFX3	Off
	M Hi	ROM Mono, 0426: Tom Basic MidLo mf -L		
A#2	High	ROM Mono, 0514: Hi-Hat Basic 1-Open ff	IFX4	1
	M Hi	ROM Mono, 0513: Hi-Hat Basic 1-Open f		
B2	High	ROM Mono, 0435: Tom Basic MidHi ff	IFX3	Off
	M Hi	ROM Mono, 0433: Tom Basic MidHi f -L		
C3	High	ROM Mono, 0440: Tom Basic Hi f	IFX3	Off
	M Hi	ROM Mono, 0438: Tom Basic Hi mf -L		
C#3	High	ROM Mono, 0625: Crash Cymbal 6 ff	IFX4	Off
	M Hi	ROM Mono, 0623: Crash Cymbal 6 mf -L		
D3	High	ROM Mono, 0440: Tom Basic Hi f	IFX3	Off
	M Hi	ROM Mono, 0438: Tom Basic Hi mf -L		
D#3	High	ROM Mono, 0653: Ride Cymbal 3 ff	IFX4	Off
	M Hi	ROM Mono, 0651: Ride Cymbal 3 f -L		
E3	High	ROM Mono, 0673: China Cymbal 2	IFX4	Off
	M Hi	ROM Mono, 0671: China Cymbal 1 -L		Off
F3	High	ROM Mono, 0663: Ride Cymbal 7-Cup -L	IFX4	Off
	M Hi	ROM Mono, 0663: Ride Cymbal 7-Cup -L		
F#3	High	ROM Mono, 0877: Tambourine 2-Accent	IFX5	Off
	M Hi	ROM Mono, 0874: Tambourine 2-Push		
G3	High	ROM Mono, 0678: Splash Cymbal 1 ff -L	IFX4	Off
	M Hi	ROM Mono, 0676: Splash Cymbal 1 mf		
G#3	High	ROM Mono, 0830: Cowbell 2	IFX5	Off
	M Hi	ROM Mono, 0831: Cowbell 3		
A3	High	ROM Mono, 0627: Crash Cymbal 7 f -L	IFX4	Off
	M Hi	ROM Mono, 0626: Crash Cymbal 7 mf		
A#3	High	ROM Mono, 0853: Vibra-Slap	IFX5	Off
B3	High	ROM Mono, 0646: Ride Cymbal 1 ff	IFX4	Off
	M Hi	ROM Mono, 0644: Ride Cymbal 1 f -L		
C4	High	ROM Mono, 0756: Bongo 1 Hi-Open f	IFX5	Off
	M Hi	ROM Mono, 0755: Bongo 1 Hi-Open mf		
C#4	High	ROM Mono, 0744: Bongo 1 Lo-Muffled f	IFX5	Off
	M Hi	ROM Mono, 0743: Bongo 1 Lo-Muffled mp		
D4	High	ROM Mono, 0728: Conga Hi-ClosedSlap	IFX5	Off
	M Hi	ROM Mono, 0727: Conga Hi-Closed		
D#4	High	ROM Mono, 0723: Conga Hi-OpenSlap	IFX5	Off
	M Hi	ROM Mono, 0720: Conga Hi-Open mf		
E4	High	ROM Mono, 0709: Conga Lo-OpenSlap	IFX5	Off
	M Hi	ROM Mono, 0707: Conga Lo-Open mf		
F4	High	ROM Mono, 0823: Timbales Hi-RimShot ff	IFX5	Off
	M Hi	ROM Mono, 0821: Timbales Hi-RimShot mf		
F#4	High	ROM Mono, 0811: Timbales Lo-Edge f	IFX5	Off
	M Hi	ROM Mono, 0808: Timbales Lo-Open mp		
G4	High	ROM Mono, 0935: Agogo 2 Hi-Open	IFX5	Off
G#4	High	ROM Mono, 0934: Agogo 2 Lo-Open	IFX5	Off

Key		Drumsample	Bus	Ex
A4	High	ROM Mono, 0892: Cabasa 1 L a-Up	IFX5	Off
	M Hi	ROM Mono, 0891: Cabasa 1 L a-Down		
A#4	High	ROM Mono, 0848: Maracas 2-Pull b	IFX5	Off
	M Hi	ROM Mono, 0846: Maracas 2-Push b		
B4	High	ROM Mono, 0972: Whistle 4-Short	IFX5	2
C5	High	ROM Mono, 0969: Whistle 2	IFX5	2
C#5	High	ROM Mono, 0852: Guiro-Short b	IFX5	3
	M Hi	ROM Mono, 0851: Guiro-Short a		
D5	High	ROM Mono, 0850: Guiro-Long b	IFX5	3
	M Hi	ROM Mono, 0849: Guiro-Long a		
D#5	High	ROM Mono, 0840: Claves Hi b	IFX5	Off
	M Hi	ROM Mono, 0839: Claves Hi a		
E5	High	ROM Mono, 1053: Wood Block 4 a	IFX5	Off
	M Hi	ROM Mono, 1054: Wood Block 4 b		
F5	High	ROM Mono, 1051: Wood Block 3 a	IFX5	Off
	M Hi	ROM Mono, 1052: Wood Block 3 b		
F#5	High	ROM Mono, 0965: Cuica Hi a	IFX5	4
	M Hi	ROM Mono, 0966: Cuica Hi b		
G5	High	ROM Mono, 0964: Cuica Lo c	IFX5	4
	M Hi	ROM Mono, 0962: Cuica Lo a		
G#5	High	ROM Mono, 0948: Triangle 1 S-Mute b	IFX5	5
	M Hi	ROM Mono, 0947: Triangle 1 S-Mute a		
A5	High	ROM Mono, 0943: Triangle 1 S-Open b	IFX5	5
	M Hi	ROM Mono, 0942: Triangle 1 S-Open a		
A#5	High	ROM Mono, 0912: Shaker 1-Slow b	IFX5	Off
	M Hi	ROM Mono, 0911: Shaker 1-Slow a		
B5	High	ROM Mono, 1072: Sleigh Bell	IFX5	Off
C6	High	ROM Mono, 1075: Marc Tree	L/R	Off
C#6	High	ROM Mono, 1062: Castanet 2	IFX5	Off
D6	High	ROM Mono, 0857: Surdo-Mute	IFX5	6
D#6	High	ROM Mono, 0856: Surdo-Open	IFX5	6
E6	High	ROM Mono, 1418: Stadium	IFX4	Off

## 49 (GM): ROOM

Key		Drumsample	Bus	Ex
D#1	High	ROM Mono, 1191: Zap 2	L/R	Off
E1	High	ROM Mono, 1481: Noise-White	L/R	Off
F1	High	ROM Mono, 1254: DJ-Scratch 1	L/R	7
F#1	High	ROM Mono, 1254: DJ-Scratch 1	L/R	7
G1	High	ROM Mono, 0682: Drumstick Hit	L/R	Off
G#1	High	ROM Mono, 1190: Zap 1	L/R	Off
A1	High	ROM Mono, 1424: Click 1	L/R	Off
A#1	High	ROM Mono, 0955: Triangle 3 Lp	L/R	Off
B1	High	ROM Mono, 0006: BD-02-amb f -L	IFX1	Off
	M Hi	ROM Mono, 0004: BD-02-amb mf -L		
C2	High	ROM Mono, 0010: BD-03-amb f -L	IFX1	Off
	M Hi	ROM Mono, 0008: BD-03-amb mf -L		
C#2	High	ROM Mono, 0319: SD-Sidestick 1 f	L/R	Off
	M Hi	ROM Mono, 0317: SD-Sidestick 1 mf -L		
D2	High	ROM Mono, 0240: SD-17-dry f	IFX2	Off
	M Hi	ROM Mono, 0239: SD-17-dry mf		
D#2	High	ROM Mono, 0693: Hand Claps 2-g -L	L/R	Off
	M Hi	ROM Mono, 0689: Hand Claps 2-d -L		
E2	High	ROM Mono, 0218: SD-12-amb fff	IFX2	Off
	M Hi	ROM Mono, 0217: SD-12-amb f		
F2	High	ROM Mono, 0469: Tom Rock1-dry Hi ff -L	IFX3	Off
	M Hi	ROM Mono, 0467: Tom Rock1-dry Hi f -L		
F#2	High	ROM Mono, 0507: Hi-Hat Basic 1-Closed ff	IFX4	1
	M Hi	ROM Mono, 0506: Hi-Hat Basic 1-Closed f		
G2	High	ROM Mono, 0469: Tom Rock1-dry Hi ff -L	IFX3	Off
	M Hi	ROM Mono, 0467: Tom Rock1-dry Hi f -L		
G#2	High	ROM Mono, 0510: Hi-Hat Basic 1-Pedal f	IFX4	1
	M Hi	ROM Mono, 0508: Hi-Hat Basic 1-Pedal mp		
A2	High	ROM Mono, 0469: Tom Rock1-dry Hi ff -L	IFX3	Off
	M Hi	ROM Mono, 0467: Tom Rock1-dry Hi f -L		
A#2	High	ROM Mono, 0514: Hi-Hat Basic 1-Open ff	IFX4	1
	M Hi	ROM Mono, 0513: Hi-Hat Basic 1-Open f		
B2	High	ROM Mono, 0469: Tom Rock1-dry Hi ff -L	IFX3	Off
	M Hi	ROM Mono, 0467: Tom Rock1-dry Hi f -L		
C3	High	ROM Mono, 0469: Tom Rock1-dry Hi ff -L	IFX3	Off
	M Hi	ROM Mono, 0467: Tom Rock1-dry Hi f -L		
C#3	High	ROM Mono, 0625: Crash Cymbal 6 ff	IFX4	Off
	M Hi	ROM Mono, 0623: Crash Cymbal 6 mf -L		
D3	High	ROM Mono, 0469: Tom Rock1-dry Hi ff -L	IFX3	Off
	M Hi	ROM Mono, 0467: Tom Rock1-dry Hi f -L		
D#3	High	ROM Mono, 0653: Ride Cymbal 3 ff	IFX4	Off
	M Hi	ROM Mono, 0651: Ride Cymbal 3 f -L		
E3	High	ROM Mono, 0673: China Cymbal 2	IFX4	Off
	M Hi	ROM Mono, 0671: China Cymbal 1 -L		
F3	High	ROM Mono, 0663: Ride Cymbal 7-Cup -L	IFX4	Off
	M Hi	ROM Mono, 0663: Ride Cymbal 7-Cup -L		
F#3	High	ROM Mono, 0877: Tambourine 2-Accent	IFX5	Off
	M Hi	ROM Mono, 0874: Tambourine 2-Push		
G3	High	ROM Mono, 0678: Splash Cymbal 1 ff -L	IFX4	Off
	M Hi	ROM Mono, 0676: Splash Cymbal 1 mf		
G#3	High	ROM Mono, 0830: Cowbell 2	IFX5	Off
	M Hi	ROM Mono, 0831: Cowbell 3		
A3	High	ROM Mono, 0627: Crash Cymbal 7 f -L	IFX4	Off
	M Hi	ROM Mono, 0626: Crash Cymbal 7 mf		
A#3	High	ROM Mono, 0853: Vibra-Slap	IFX5	Off
B3	High	ROM Mono, 0646: Ride Cymbal 1 ff	IFX4	Off
	M Hi	ROM Mono, 0644: Ride Cymbal 1 f -L		
C4	High	ROM Mono, 0756: Bongo 1 Hi-Open f	IFX5	Off
	M Hi	ROM Mono, 0755: Bongo 1 Hi-Open mf		
C#4	High	ROM Mono, 0744: Bongo 1 Lo-Muffled f	IFX5	Off
	M Hi	ROM Mono, 0743: Bongo 1 Lo-Muffled mp		
D4	High	ROM Mono, 0728: Conga Hi-ClosedSlap	IFX5	Off
	M Hi	ROM Mono, 0727: Conga Hi-Closed		
D#4	High	ROM Mono, 0723: Conga Hi-OpenSlap	IFX5	Off
	M Hi	ROM Mono, 0720: Conga Hi-Open mf		
E4	High	ROM Mono, 0709: Conga Lo-OpenSlap	IFX5	Off
	M Hi	ROM Mono, 0707: Conga Lo-Open mf		
F4	High	ROM Mono, 0823: Timbales Hi-RimShot ff	IFX5	Off
	M Hi	ROM Mono, 0821: Timbales Hi-RimShot mf		
F#4	High	ROM Mono, 0811: Timbales Lo-Edge f	IFX5	Off
	M Hi	ROM Mono, 0808: Timbales Lo-Open mp		
G4	High	ROM Mono, 0935: Agogo 2 Hi-Open	IFX5	Off
G#4	High	ROM Mono, 0934: Agogo 2 Lo-Open	IFX5	Off

Key		Drumsample	Bus	Ex
A4	High	ROM Mono, 0943: Triangle 1 S-Open b	IFX5	Off
	M Hi	ROM Mono, 0942: Triangle 1 S-Open a		
A#4	High	ROM Mono, 0848: Maracas 2-Pull b	IFX5	Off
	M Hi	ROM Mono, 0846: Maracas 2-Push b		
B4	High	ROM Mono, 0972: Whistle 4-Short	IFX5	2
C5	High	ROM Mono, 0969: Whistle 2	IFX5	2
C#5	High	ROM Mono, 0852: Guiro-Short b	IFX5	3
	M Hi	ROM Mono, 0851: Guiro-Short a		
D5	High	ROM Mono, 0850: Guiro-Long b	IFX5	3
	M Hi	ROM Mono, 0849: Guiro-Long a		
D#5	High	ROM Mono, 0840: Claves Hi b	IFX5	Off
	M Hi	ROM Mono, 0839: Claves Hi a		
E5	High	ROM Mono, 1053: Wood Block 4 a	IFX5	Off
	M Hi	ROM Mono, 1054: Wood Block 4 b		
F5	High	ROM Mono, 1051: Wood Block 3 a	IFX5	Off
	M Hi	ROM Mono, 1052: Wood Block 3 b		
F#5	High	ROM Mono, 0965: Cuica Hi a	IFX5	4
	M Hi	ROM Mono, 0966: Cuica Hi b		
G5	High	ROM Mono, 0964: Cuica Lo c	IFX5	4
	M Hi	ROM Mono, 0962: Cuica Lo a		
G#5	High	ROM Mono, 0948: Triangle 1 S-Mute b	IFX5	5
	M Hi	ROM Mono, 0947: Triangle 1 S-Mute a		
A5	High	ROM Mono, 0817: Timbales Lo-Paila mf	IFX5	5
	M Hi	ROM Mono, 0816: Timbales Lo-Mute f		
A#5	High	ROM Mono, 0912: Shaker 1-Slow b	IFX5	Off
	M Hi	ROM Mono, 0911: Shaker 1-Slow a		
B5	High	ROM Mono, 1072: Sleigh Bell	IFX5	Off
C6	High	ROM Mono, 1075: Marc Tree	L/R	Off
C#6	High	ROM Mono, 1062: Castanet 2	IFX5	Off
D6	High	ROM Mono, 0857: Surdo-Mute	IFX5	6
D#6	High	ROM Mono, 0856: Surdo-Open	IFX5	6
E6	High	ROM Mono, 1418: Stadium	IFX4	Off

## 50 (GM): POWER

Key		Drumsample	Bus	Ex
D#1	High	ROM Mono, 1191: Zap 2	L/R	Off
E1	High	ROM Mono, 1481: Noise-White	L/R	Off
F1	High	ROM Mono, 1254: DJ-Scratch 1	L/R	7
F#1	High	ROM Mono, 1254: DJ-Scratch 1	L/R	7
G1	High	ROM Mono, 0682: Drumstick Hit	L/R	Off
G#1	High	ROM Mono, 1190: Zap 1	L/R	Off
A1	High	ROM Mono, 1424: Click 1	L/R	Off
A#1	High	ROM Mono, 0955: Triangle 3 Lp	L/R	Off
B1	High	ROM Mono, 0052: BD-Gated		Off
	M Hi	ROM Mono, 0052: BD-Gated	IFX1	
C2	High	ROM Mono, 0050: BD-Mondo Kill		Off
	M Hi	ROM Mono, 0050: BD-Mondo Kill	IFX1	
C#2	High	ROM Mono, 0319: SD-Sidestick 1 f		Off
	M Hi	ROM Mono, 0317: SD-Sidestick 1 mf -L	L/R	
D2	High	ROM Mono, 0247: SD-19-amb f		Off
	M Hi	ROM Mono, 0246: SD-19-amb mf	IFX2	
D#2	High	ROM Mono, 0693: Hand Claps 2-g -L		Off
	M Hi	ROM Mono, 0689: Hand Claps 2-d -L	L/R	
E2	High	ROM Mono, 0281: SD-Atomic		Off
	M Hi	ROM Mono, 0281: SD-Atomic	IFX2	
F2	High	ROM Mono, 0469: Tom Rock1-dry Hi ff -L		Off
	M Hi	ROM Mono, 0467: Tom Rock1-dry Hi f -L	IFX3	
F#2	High	ROM Mono, 0507: Hi-Hat Basic 1-Closed ff		1
	M Hi	ROM Mono, 0506: Hi-Hat Basic 1-Closed f	IFX4	
G2	High	ROM Mono, 0469: Tom Rock1-dry Hi ff -L		Off
	M Hi	ROM Mono, 0467: Tom Rock1-dry Hi f -L	IFX3	
G#2	High	ROM Mono, 0510: Hi-Hat Basic 1-Pedal f		1
	M Hi	ROM Mono, 0508: Hi-Hat Basic 1-Pedal mp	IFX4	
A2	High	ROM Mono, 0469: Tom Rock1-dry Hi ff -L		Off
	M Hi	ROM Mono, 0467: Tom Rock1-dry Hi f -L	IFX3	
A#2	High	ROM Mono, 0514: Hi-Hat Basic 1-Open ff		1
	M Hi	ROM Mono, 0513: Hi-Hat Basic 1-Open f	IFX4	
B2	High	ROM Mono, 0469: Tom Rock1-dry Hi ff -L		Off
	M Hi	ROM Mono, 0467: Tom Rock1-dry Hi f -L	IFX3	
C3	High	ROM Mono, 0469: Tom Rock1-dry Hi ff -L		Off
	M Hi	ROM Mono, 0467: Tom Rock1-dry Hi f -L	IFX3	
C#3	High	ROM Mono, 0625: Crash Cymbal 6 ff		Off
	M Hi	ROM Mono, 0623: Crash Cymbal 6 mf -L	IFX4	
D3	High	ROM Mono, 0469: Tom Rock1-dry Hi ff -L		Off
	M Hi	ROM Mono, 0467: Tom Rock1-dry Hi f -L	IFX3	
D#3	High	ROM Mono, 0653: Ride Cymbal 3 ff		Off
	M Hi	ROM Mono, 0651: Ride Cymbal 3 f -L	IFX4	
E3	High	ROM Mono, 0673: China Cymbal 2		Off
	M Hi	ROM Mono, 0671: China Cymbal 1 -L	IFX4	
F3	High	ROM Mono, 0663: Ride Cymbal 7-Cup -L		Off
	M Hi	ROM Mono, 0663: Ride Cymbal 7-Cup -L	IFX4	
F#3	High	ROM Mono, 0877: Tambourine 2-Accent		Off
	M Hi	ROM Mono, 0874: Tambourine 2-Push	IFX5	
G3	High	ROM Mono, 0678: Splash Cymbal 1 ff -L		Off
	M Hi	ROM Mono, 0676: Splash Cymbal 1 mf	IFX4	
G#3	High	ROM Mono, 0830: Cowbell 2		Off
	M Hi	ROM Mono, 0831: Cowbell 3	IFX5	
A3	High	ROM Mono, 0627: Crash Cymbal 7 f -L		Off
	M Hi	ROM Mono, 0626: Crash Cymbal 7 mf	IFX4	
A#3	High	ROM Mono, 0853: Vibra-Slap		Off
B3	High	ROM Mono, 0646: Ride Cymbal 1 ff		Off
	M Hi	ROM Mono, 0644: Ride Cymbal 1 f -L	IFX4	
C4	High	ROM Mono, 0756: Bongo 1 Hi-Open f		Off
	M Hi	ROM Mono, 0755: Bongo 1 Hi-Open mf	IFX5	
C#4	High	ROM Mono, 0744: Bongo 1 Lo-Muffled f		Off
	M Hi	ROM Mono, 0743: Bongo 1 Lo-Muffled mp	IFX5	
D4	High	ROM Mono, 0728: Conga Hi-ClosedSlap		Off
	M Hi	ROM Mono, 0727: Conga Hi-Closed	IFX5	
D#4	High	ROM Mono, 0723: Conga Hi-OpenSlap		Off
	M Hi	ROM Mono, 0720: Conga Hi-Open mf	IFX5	
E4	High	ROM Mono, 0709: Conga Lo-OpenSlap		Off
	M Hi	ROM Mono, 0707: Conga Lo-Open mf	IFX5	
F4	High	ROM Mono, 0823: Timbales Hi-RimShot ff		Off
	M Hi	ROM Mono, 0821: Timbales Hi-RimShot mf	IFX5	
F#4	High	ROM Mono, 0811: Timbales Lo-Edge f		Off
	M Hi	ROM Mono, 0808: Timbales Lo-Open mp	IFX5	
G4	High	ROM Mono, 0935: Agogo 2 Hi-Open		Off
	M Hi	ROM Mono, 0934: Agogo 2 Lo-Open	IFX5	
G#4	High	ROM Mono, 0935: Agogo 2 Hi-Open		Off
	M Hi	ROM Mono, 0892: Cabasa 1 L a-Up	IFX5	
A4	High	ROM Mono, 0892: Cabasa 1 L a-Up		Off
	M Hi	ROM Mono, 0891: Cabasa 1 L a-Down	IFX5	

Key		Drumsample	Bus	Ex
A#4	High	ROM Mono, 0848: Maracas 2-Pull b		Off
	M Hi	ROM Mono, 0846: Maracas 2-Push b	IFX5	
B4	High	ROM Mono, 0972: Whistle 4-Short		2
C5	High	ROM Mono, 0969: Whistle 2		2
C#5	High	ROM Mono, 0852: Guiro-Short b		3
	M Hi	ROM Mono, 0851: Guiro-Short a	IFX5	
D5	High	ROM Mono, 0850: Guiro-Long b		3
	M Hi	ROM Mono, 0849: Guiro-Long a	IFX5	
D#5	High	ROM Mono, 0840: Claves Hi b		Off
	M Hi	ROM Mono, 0839: Claves Hi a	IFX5	
E5	High	ROM Mono, 1053: Wood Block 4 a		Off
	M Hi	ROM Mono, 1054: Wood Block 4 b	IFX5	
F5	High	ROM Mono, 1051: Wood Block 3 a		Off
	M Hi	ROM Mono, 1052: Wood Block 3 b	IFX5	
F#5	High	ROM Mono, 0965: Cuica Hi a		4
	M Hi	ROM Mono, 0966: Cuica Hi b	IFX5	
G5	High	ROM Mono, 0964: Cuica Lo c		4
	M Hi	ROM Mono, 0962: Cuica Lo a	IFX5	
G#5	High	ROM Mono, 0948: Triangle 1 S-Mute b		5
	M Hi	ROM Mono, 0947: Triangle 1 S-Mute a	IFX5	
A5	High	ROM Mono, 0943: Triangle 1 S-Open b		5
	M Hi	ROM Mono, 0942: Triangle 1 S-Open a	IFX5	
A#5	High	ROM Mono, 0912: Shaker 1-Slow b		Off
	M Hi	ROM Mono, 0911: Shaker 1-Slow a	IFX5	
B5	High	ROM Mono, 1072: Sleigh Bell		Off
C6	High	ROM Mono, 1075: Marc Tree	L/R	Off
C#6	High	ROM Mono, 1062: Castanet 2		Off
D6	High	ROM Mono, 0857: Surdo-Mute		6
D#6	High	ROM Mono, 0856: Surdo-Open		6
E6	High	ROM Mono, 1418: Stadium	IFX4	Off

## 51 (GM): ELECTRONIC

Key		Drumsample	Bus	Ex
D#1	High	ROM Mono, 1191: Zap 2	L/R	Off
E1	High	ROM Mono, 1481: Noise-White	L/R	Off
F1	High	ROM Mono, 1254: DJ-Scratch 1	L/R	7
F#1	High	ROM Mono, 1254: DJ-Scratch 1	L/R	7
G1	High	ROM Mono, 0682: Drumstick Hit	L/R	Off
G#1	High	ROM Mono, 1190: Zap 1	L/R	Off
A1	High	ROM Mono, 1424: Click 1	L/R	Off
A#1	High	ROM Mono, 0067: BD-floor	L/R	Off
B1	High	ROM Mono, 0075: BD-Pop	IFX1	Off
	M Hi	ROM Mono, 0075: BD-Pop		
C2	High	ROM Mono, 0067: BD-floor	IFX1	Off
	M Hi	ROM Mono, 0067: BD-floor		
C#2	High	ROM Mono, 0319: SD-Sidestick 1 f	L/R	Off
	M Hi	ROM Mono, 0317: SD-Sidestick 1 mf -L		
D2	High	ROM Mono, 0380: SD-Dance 54	IFX2	Off
D#2	High	ROM Mono, 0693: Hand Claps 2-g -L	L/R	Off
	M Hi	ROM Mono, 0689: Hand Claps 2-d -L		
E2	High	ROM Mono, 0416: SD-Dance 76	IFX2	Off
	M Hi	ROM Mono, 0416: SD-Dance 76		
F2	High	ROM Mono, 1189: E.Tom 2	IFX3	Off
F#2	High	ROM Mono, 0507: Hi-Hat Basic 1-Closed ff	IFX4	1
	M Hi	ROM Mono, 0506: Hi-Hat Basic 1-Closed f		
G2	High	ROM Mono, 1189: E.Tom 2	IFX3	Off
G#2	High	ROM Mono, 0510: Hi-Hat Basic 1-Pedal f	IFX4	1
	M Hi	ROM Mono, 0508: Hi-Hat Basic 1-Pedal mp		
A2	High	ROM Mono, 1189: E.Tom 2	IFX3	Off
A#2	High	ROM Mono, 0514: Hi-Hat Basic 1-Open ff	IFX4	1
	M Hi	ROM Mono, 0513: Hi-Hat Basic 1-Open f		
B2	High	ROM Mono, 1189: E.Tom 2	IFX3	Off
C3	High	ROM Mono, 1189: E.Tom 2	IFX3	Off
C#3	High	ROM Mono, 0625: Crash Cymbal 6 ff	IFX4	Off
	M Hi	ROM Mono, 0623: Crash Cymbal 6 mf -L		
D3	High	ROM Mono, 1189: E.Tom 2	IFX3	Off
D#3	High	ROM Mono, 0653: Ride Cymbal 3 ff	IFX4	Off
	M Hi	ROM Mono, 0651: Ride Cymbal 3 f -L		
E3	High	ROM Mono, 0673: China Cymbal 2	IFX4	Off
	M Hi	ROM Mono, 0671: China Cymbal 1 -L		
F3	High	ROM Mono, 0663: Ride Cymbal 7-Cup -L	IFX4	Off
	M Hi	ROM Mono, 0663: Ride Cymbal 7-Cup -L		
F#3	High	ROM Mono, 0877: Tambourine 2-Accent	IFX5	Off
	M Hi	ROM Mono, 0874: Tambourine 2-Push		
G3	High	ROM Mono, 0678: Splash Cymbal 1 ff -L	IFX4	Off
	M Hi	ROM Mono, 0676: Splash Cymbal 1 mf		
G#3	High	ROM Mono, 0830: Cowbell 2	IFX5	Off
	M Hi	ROM Mono, 0831: Cowbell 3		
A3	High	ROM Mono, 0627: Crash Cymbal 7 f -L	IFX4	Off
	M Hi	ROM Mono, 0626: Crash Cymbal 7 mf		
A#3	High	ROM Mono, 0853: Vibra-Slap	IFX5	Off
B3	High	ROM Mono, 0646: Ride Cymbal 1 ff	IFX4	Off
	M Hi	ROM Mono, 0644: Ride Cymbal 1 f -L		
C4	High	ROM Mono, 0756: Bongo 1 Hi-Open f	IFX5	Off
	M Hi	ROM Mono, 0755: Bongo 1 Hi-Open mf		
C#4	High	ROM Mono, 0744: Bongo 1 Lo-Muffled f	IFX5	Off
	M Hi	ROM Mono, 0743: Bongo 1 Lo-Muffled mp		
D4	High	ROM Mono, 0728: Conga Hi-ClosedSlap	IFX5	Off
	M Hi	ROM Mono, 0727: Conga Hi-Closed		
D#4	High	ROM Mono, 0723: Conga Hi-OpenSlap	IFX5	Off
	M Hi	ROM Mono, 0720: Conga Hi-Open mf		
E4	High	ROM Mono, 0709: Conga Lo-OpenSlap	IFX5	Off
	M Hi	ROM Mono, 0707: Conga Lo-Open mf		
F4	High	ROM Mono, 0823: Timbales Hi-RimShot ff	IFX5	Off
	M Hi	ROM Mono, 0821: Timbales Hi-RimShot mf		
F#4	High	ROM Mono, 0811: Timbales Lo-Edge f	IFX5	Off
	M Hi	ROM Mono, 0808: Timbales Lo-Open mp		
G4	High	ROM Mono, 0935: Agogo 2 Hi-Open	IFX5	Off
G#4	High	ROM Mono, 0934: Agogo 2 Lo-Open	IFX5	Off
A4	High	ROM Mono, 0892: Cabasa 1 L a-Up	IFX5	Off
	M Hi	ROM Mono, 0891: Cabasa 1 L a-Down		
A#4	High	ROM Mono, 0848: Maracas 2-Pull b	IFX5	Off
	M Hi	ROM Mono, 0846: Maracas 2-Push b		
B4	High	ROM Mono, 0972: Whistle 4-Short	IFX5	2
C5	High	ROM Mono, 0969: Whistle 2	IFX5	2
C#5	High	ROM Mono, 0852: Guiro-Short b	IFX5	3
	M Hi	ROM Mono, 0851: Guiro-Short a		

Key		Drumsample	Bus	Ex
D5	High	ROM Mono, 0850: Guiro-Long b	IFX5	3
	M Hi	ROM Mono, 0849: Guiro-Long a		
D#5	High	ROM Mono, 0840: Claves Hi b	IFX5	Off
	M Hi	ROM Mono, 0839: Claves Hi a		
E5	High	ROM Mono, 1053: Wood Block 4 a	IFX5	Off
	M Hi	ROM Mono, 1054: Wood Block 4 b		
F5	High	ROM Mono, 1051: Wood Block 3 a	IFX5	Off
	M Hi	ROM Mono, 1052: Wood Block 3 b		
F#5	High	ROM Mono, 0965: Cuica Hi a	IFX5	4
	M Hi	ROM Mono, 0966: Cuica Hi b		
G5	High	ROM Mono, 0964: Cuica Lo c	IFX5	4
	M Hi	ROM Mono, 0962: Cuica Lo a		
G#5	High	ROM Mono, 0948: Triangle 1 S-Mute b	IFX5	5
	M Hi	ROM Mono, 0947: Triangle 1 S-Mute a		
A5	High	ROM Mono, 0943: Triangle 1 S-Open b	IFX5	5
	M Hi	ROM Mono, 0942: Triangle 1 S-Open a		
A#5	High	ROM Mono, 0912: Shaker 1-Slow b	IFX5	Off
	M Hi	ROM Mono, 0911: Shaker 1-Slow a		
B5	High	ROM Mono, 1072: Sleigh Bell	IFX5	Off
C6	High	ROM Mono, 1075: Marc Tree	L/R	Off
C#6	High	ROM Mono, 1062: Castanet 2	IFX4	Off
D6	High	ROM Mono, 0857: Surdo-Mute	IFX5	6
D#6	High	ROM Mono, 0856: Surdo-Open	IFX5	6
E6	High	ROM Mono, 1418: Stadium	IFX4	Off

## 52 (GM): ANALOG

Key		Drumsample	Bus	Ex
D#1	High	ROM Mono, 1191: Zap 2	L/R	Off
E1	High	ROM Mono, 1481: Noise-White	L/R	Off
F1	High	ROM Mono, 1254: DJ-Scratch 1	L/R	7
F#1	High	ROM Mono, 1254: DJ-Scratch 1	L/R	7
G1	High	ROM Mono, 0682: Drumstick Hit	L/R	Off
G#1	High	ROM Mono, 1190: Zap 1	L/R	Off
A1	High	ROM Mono, 1424: Click 1	L/R	Off
A#1	High	ROM Mono, 0955: Triangle 3 Lp	L/R	Off
B1	High	ROM Mono, 0143: BD-Dance 71	IFX1	Off
C2	High	ROM Mono, 0140: BD-Dance 68	IFX1	Off
C#2	High	ROM Mono, 0419: SD-Dance Rimshot	L/R	Off
D2	High	ROM Mono, 0417: SD-Dance 77	IFX2	Off
D#2	High	ROM Mono, 1146: Dance Claps 01	L/R	Off
E2	High	ROM Mono, 0418: SD-Dance 78	IFX2	Off
F2	High	ROM Mono, 1182: Dance SynTom	IFX3	Off
F#2	High	ROM Mono, 0604: Hi-Hat Dance 35	IFX4	1
G2	High	ROM Mono, 1182: Dance SynTom	IFX3	Off
G#2	High	ROM Mono, 0604: Hi-Hat Dance 35	IFX4	1
A2	High	ROM Mono, 1182: Dance SynTom	IFX3	Off
A#2	High	ROM Mono, 0604: Hi-Hat Dance 35	IFX4	1
B2	High	ROM Mono, 1182: Dance SynTom	IFX3	Off
C3	High	ROM Mono, 1182: Dance SynTom	IFX3	Off
C#3	High	ROM Mono, 0636: Crash Dance 4	IFX4	Off
D3	High	ROM Mono, 1182: Dance SynTom	IFX3	Off
D#3	High	ROM Mono, 0669: Ride Dance 3	IFX4	Off
E3	High	ROM Mono, 0673: China Cymbal 2	IFX4	Off
	M Hi	ROM Mono, 0671: China Cymbal 1 -L		
F3	High	ROM Mono, 0663: Ride Cymbal 7-Cup -L	IFX4	Off
	M Hi	ROM Mono, 0663: Ride Cymbal 7-Cup -L		
F#3	High	ROM Mono, 0877: Tambourine 2-Accent	IFX5	Off
	M Hi	ROM Mono, 0874: Tambourine 2-Push		
G3	High	ROM Mono, 0678: Splash Cymbal 1 ff -L	IFX4	Off
	M Hi	ROM Mono, 0676: Splash Cymbal 1 mf		
G#3	High	ROM Mono, 1186: Dance SynCowbell	IFX5	Off
A3	High	ROM Mono, 0627: Crash Cymbal 7 f -L	IFX4	Off
	M Hi	ROM Mono, 0626: Crash Cymbal 7 mf		
A#3	High	ROM Mono, 0853: Vibra-Slap	IFX5	Off
B3	High	ROM Mono, 0646: Ride Cymbal 1 ff	IFX4	Off
	M Hi	ROM Mono, 0644: Ride Cymbal 1 f -L		
C4	High	ROM Mono, 1183: Dance SynConga	IFX5	Off
C#4	High	ROM Mono, 1183: Dance SynConga	IFX5	Off
D4	High	ROM Mono, 1182: Dance SynTom	IFX5	Off
D#4	High	ROM Mono, 1182: Dance SynTom	IFX5	Off
E4	High	ROM Mono, 1182: Dance SynTom	IFX5	Off
F4	High	ROM Mono, 0823: Timbales Hi-RimShot ff	IFX5	Off
	M Hi	ROM Mono, 0821: Timbales Hi-RimShot mf		
F#4	High	ROM Mono, 0811: Timbales Lo-Edge f	IFX5	Off
	M Hi	ROM Mono, 0808: Timbales Lo-Open mp		
G4	High	ROM Mono, 0935: Agogo 2 Hi-Open	IFX5	Off
G#4	High	ROM Mono, 0934: Agogo 2 Lo-Open	IFX5	Off
A4	High	ROM Mono, 0892: Cabasa 1 L a-Up	IFX5	Off
	M Hi	ROM Mono, 0891: Cabasa 1 L a-Down		
A#4	High	ROM Mono, 0848: Maracas 2-Pull b	IFX5	Off
	M Hi	ROM Mono, 0846: Maracas 2-Push b		
B4	High	ROM Mono, 0972: Whistle 4-Short	IFX5	2
C5	High	ROM Mono, 0969: Whistle 2	IFX5	2
C#5	High	ROM Mono, 0852: Guiro-Short b	IFX5	3
	M Hi	ROM Mono, 0851: Guiro-Short a		
D5	High	ROM Mono, 0850: Guiro-Long b	IFX5	3
	M Hi	ROM Mono, 0849: Guiro-Long a		
D#5	High	ROM Mono, 0840: Claves Hi b	IFX5	Off
	M Hi	ROM Mono, 0839: Claves Hi a		
E5	High	ROM Mono, 1053: Wood Block 4 a	IFX5	Off
	M Hi	ROM Mono, 1054: Wood Block 4 b		
F5	High	ROM Mono, 1051: Wood Block 3 a	IFX5	Off
	M Hi	ROM Mono, 1052: Wood Block 3 b		
F#5	High	ROM Mono, 0965: Cuica Hi a	IFX5	4
	M Hi	ROM Mono, 0966: Cuica Hi b		
G5	High	ROM Mono, 0964: Cuica Lo c	IFX5	4
	M Hi	ROM Mono, 0962: Cuica Lo a		
G#5	High	ROM Mono, 0948: Triangle 1 S-Mute b	IFX5	5
	M Hi	ROM Mono, 0947: Triangle 1 S-Mute a		
A5	High	ROM Mono, 0943: Triangle 1 S-Open b	IFX5	5
	M Hi	ROM Mono, 0942: Triangle 1 S-Open a		

Key		Drumsample	Bus	Ex
A#5	High	ROM Mono, 0912: Shaker 1-Slow b	IFX5	Off
	M Hi	ROM Mono, 0911: Shaker 1-Slow a		
B5	High	ROM Mono, 1072: Sleigh Bell	IFX5	Off
C6	High	ROM Mono, 1075: Marc Tree	L/R	Off
C#6	High	ROM Mono, 1062: Castanet 2	IFX4	Off
D6	High	ROM Mono, 0857: Surdo-Mute	IFX5	6
D#6	High	ROM Mono, 0856: Surdo-Open	IFX5	6
E6	High	ROM Mono, 1418: Stadium	IFX4	Off



## 53 (GM): JAZZ

Key		Drumsample	Bus	Ex
D#1	High	ROM Mono, 1191: Zap 2	L/R	Off
E1	High	ROM Mono, 1481: Noise-White	L/R	Off
F1	High	ROM Mono, 1254: DJ-Scratch 1	L/R	7
F#1	High	ROM Mono, 1254: DJ-Scratch 1	L/R	7
G1	High	ROM Mono, 0682: Drumstick Hit	L/R	Off
G#1	High	ROM Mono, 1190: Zap 1	L/R	Off
A1	High	ROM Mono, 1424: Click 1	L/R	Off
A#1	High	ROM Mono, 0955: Triangle 3 Lp	L/R	Off
B1	High	ROM Mono, 0020: BD-05-amb f-L	IFX1	Off
	M Hi	ROM Mono, 0018: BD-05-amb mf-L		
C2	High	ROM Mono, 0024: BD-06-dry f-L	IFX1	Off
	M Hi	ROM Mono, 0022: BD-06-dry mp-L		
C#2	High	ROM Mono, 0319: SD-Sidestick 1 f	L/R	Off
	M Hi	ROM Mono, 0317: SD-Sidestick 1 mf-L		
D2	High	ROM Mono, 0157: SD-02-dry ff	IFX2	Off
	M Hi	ROM Mono, 0156: SD-02-dry f		
D#2	High	ROM Mono, 0693: Hand Claps 2-g-L	L/R	Off
	M Hi	ROM Mono, 0689: Hand Claps 2-d-L		
	M Lo	ROM Mono, 0685: Hand Claps 2-a-L		
E2	High	ROM Mono, 0236: SD-16-dry ff-L	IFX2	Off
	M Hi	ROM Mono, 0234: SD-16-dry f-L		
F2	High	ROM Mono, 0446: Tom Vintage Lo ff	IFX3	Off
	M Hi	ROM Mono, 0445: Tom Vintage Lo f		
F#2	High	ROM Mono, 0507: Hi-Hat Basic 1-Closed ff	IFX4	1
	M Hi	ROM Mono, 0506: Hi-Hat Basic 1-Closed f		
G2	High	ROM Mono, 0446: Tom Vintage Lo ff	IFX3	Off
	M Hi	ROM Mono, 0445: Tom Vintage Lo f		
G#2	High	ROM Mono, 0510: Hi-Hat Basic 1-Pedal f	IFX4	1
	M Hi	ROM Mono, 0508: Hi-Hat Basic 1-Pedal mp		
A2	High	ROM Mono, 0451: Tom Vintage Mid ff-L	IFX3	Off
	M Hi	ROM Mono, 0450: Tom Vintage Mid f		
A#2	High	ROM Mono, 0514: Hi-Hat Basic 1-Open ff	IFX4	1
	M Hi	ROM Mono, 0513: Hi-Hat Basic 1-Open f		
B2	High	ROM Mono, 0451: Tom Vintage Mid ff-L	IFX3	Off
	M Hi	ROM Mono, 0450: Tom Vintage Mid f		
C3	High	ROM Mono, 0457: Tom Vintage Hi ff-L	IFX3	Off
	M Hi	ROM Mono, 0456: Tom Vintage Hi f		
C#3	High	ROM Mono, 0619: Crash Cymbal 4 ff	IFX4	Off
	M Hi	ROM Mono, 0618: Crash Cymbal 4 f		
D3	High	ROM Mono, 0457: Tom Vintage Hi ff-L	IFX3	Off
	M Hi	ROM Mono, 0456: Tom Vintage Hi f		
D#3	High	ROM Mono, 0646: Ride Cymbal 1 ff	IFX4	Off
	M Hi	ROM Mono, 0644: Ride Cymbal 1 f-L		
E3	High	ROM Mono, 0673: China Cymbal 2	IFX4	Off
	M Hi	ROM Mono, 0671: China Cymbal 1-L		
F3	High	ROM Mono, 0663: Ride Cymbal 7-Cup-L	IFX4	Off
	M Hi	ROM Mono, 0663: Ride Cymbal 7-Cup-L		
F#3	High	ROM Mono, 0877: Tambourine 2-Accent	IFX5	Off
	M Hi	ROM Mono, 0874: Tambourine 2-Push		
G3	High	ROM Mono, 0678: Splash Cymbal 1 ff-L	IFX4	Off
	M Hi	ROM Mono, 0676: Splash Cymbal 1 mf		
G#3	High	ROM Mono, 0830: Cowbell 2	IFX5	Off
	M Hi	ROM Mono, 0831: Cowbell 3		
A3	High	ROM Mono, 0627: Crash Cymbal 7 f-L	IFX4	Off
	M Hi	ROM Mono, 0626: Crash Cymbal 7 mf		
A#3	High	ROM Mono, 0853: Vibra-Slap	IFX5	Off
B3	High	ROM Mono, 0646: Ride Cymbal 1 ff	IFX4	Off
	M Hi	ROM Mono, 0644: Ride Cymbal 1 f-L		
C4	High	ROM Mono, 0756: Bongo 1 Hi-Open f	IFX5	Off
	M Hi	ROM Mono, 0755: Bongo 1 Hi-Open mf		
C#4	High	ROM Mono, 0744: Bongo 1 Lo-Muffled f	IFX5	Off
	M Hi	ROM Mono, 0743: Bongo 1 Lo-Muffled mp		
D4	High	ROM Mono, 0728: Conga Hi-ClosedSlap	IFX5	Off
	M Hi	ROM Mono, 0727: Conga Hi-Closed		
D#4	High	ROM Mono, 0723: Conga Hi-OpenSlap	IFX5	Off
	M Hi	ROM Mono, 0720: Conga Hi-Open mf		
E4	High	ROM Mono, 0709: Conga Lo-OpenSlap	IFX5	Off
	M Hi	ROM Mono, 0707: Conga Lo-Open mf		
F4	High	ROM Mono, 0823: Timbales Hi-RimShot ff	IFX5	Off
	M Hi	ROM Mono, 0821: Timbales Hi-RimShot mf		
F#4	High	ROM Mono, 0811: Timbales Lo-Edge f	IFX5	Off
	M Hi	ROM Mono, 0808: Timbales Lo-Open mp		
G4	High	ROM Mono, 0935: Agogo 2 Hi-Open	IFX5	Off
G#4	High	ROM Mono, 0934: Agogo 2 Lo-Open	IFX5	Off

Key		Drumsample	Bus	Ex
A4	High	ROM Mono, 0892: Cabasa 1 L a-Up	IFX5	Off
	M Hi	ROM Mono, 0891: Cabasa 1 L a-Down		
A#4	High	ROM Mono, 0848: Maracas 2-Pull b	IFX5	Off
	M Hi	ROM Mono, 0846: Maracas 2-Push b		
B4	High	ROM Mono, 0972: Whistle 4-Short	IFX5	2
C5	High	ROM Mono, 0969: Whistle 2	IFX5	2
C#5	High	ROM Mono, 0852: Guiro-Short b	IFX5	3
	M Hi	ROM Mono, 0851: Guiro-Short a		
D5	High	ROM Mono, 0850: Guiro-Long b	IFX5	3
	M Hi	ROM Mono, 0849: Guiro-Long a		
D#5	High	ROM Mono, 0840: Claves Hi b	IFX5	Off
	M Hi	ROM Mono, 0839: Claves Hi a		
E5	High	ROM Mono, 1053: Wood Block 4 a	IFX5	Off
	M Hi	ROM Mono, 1054: Wood Block 4 b		
F5	High	ROM Mono, 1051: Wood Block 3 a	IFX5	Off
	M Hi	ROM Mono, 1052: Wood Block 3 b		
F#5	High	ROM Mono, 0965: Cuica Hi a	IFX5	4
	M Hi	ROM Mono, 0966: Cuica Hi b		
G5	High	ROM Mono, 0964: Cuica Lo c	IFX5	4
	M Hi	ROM Mono, 0962: Cuica Lo a		
G#5	High	ROM Mono, 0948: Triangle 1 S-Mute b	IFX5	5
	M Hi	ROM Mono, 0947: Triangle 1 S-Mute a		
A5	High	ROM Mono, 0943: Triangle 1 S-Open b	IFX5	5
	M Hi	ROM Mono, 0942: Triangle 1 S-Open a		
A#5	High	ROM Mono, 0912: Shaker 1-Slow b	IFX5	Off
	M Hi	ROM Mono, 0911: Shaker 1-Slow a		
B5	High	ROM Mono, 1072: Sleigh Bell	IFX5	Off
C6	High	ROM Mono, 1075: Marc Tree	L/R	Off
C#6	High	ROM Mono, 1062: Castanet 2	IFX4	Off
D6	High	ROM Mono, 0857: Surdo-Mute	IFX5	6
D#6	High	ROM Mono, 0856: Surdo-Open	IFX5	6
E6	High	ROM Mono, 1418: Stadium	IFX4	Off

## 54 (GM): BRUSH

Key		Drumsample	Bus	Ex
D#1	High	ROM Mono, 1191: Zap 2	L/R	Off
E1	High	ROM Mono, 1481: Noise-White	L/R	Off
F1	High	ROM Mono, 1254: DJ-Scratch 1	L/R	7
F#1	High	ROM Mono, 1254: DJ-Scratch 1	L/R	7
G1	High	ROM Mono, 0682: Drumstick Hit	L/R	Off
G#1	High	ROM Mono, 1190: Zap 1	L/R	Off
A1	High	ROM Mono, 1424: Click 1	L/R	Off
A#1	High	ROM Mono, 0000: BD-01-amb f -L	L/R	Off
B1	High	ROM Mono, 0020: BD-05-amb f -L	IFX1	Off
	M Hi	ROM Mono, 0018: BD-05-amb mf -L		
C2	High	ROM Mono, 0002: BD-01-amb ff -L	IFX1	Off
	M Hi	ROM Mono, 0000: BD-01-amb f -L		
C#2	High	ROM Mono, 0319: SD-Sidestick 1 f	L/R	Off
	M Hi	ROM Mono, 0317: SD-Sidestick 1 mf -L		
D2	High	ROM Mono, 0288: SD-26-dry Brush Tap mf-L	IFX2	Off
	M Hi	ROM Mono, 0286: SD-26-dry Brush Tap mp-L		
D#2	High	ROM Mono, 0290: SD-26-dry Brush Tap f-L	IFX2	Off
	M Hi	ROM Mono, 0296: SD-26-dry BrushSwirl b-L		
E2	High	ROM Mono, 0294: SD-26-dry BrushSwirl a-L	IFX2	Off
	M Hi	ROM Mono, 0294: SD-26-dry BrushSwirl a-L		
F2	High	ROM Mono, 0490: Tom Brush1 Low ff -L	IFX3	Off
	M Hi	ROM Mono, 0489: Tom Brush1 Low f		
F#2	High	ROM Mono, 0507: Hi-Hat Basic 1-Closed ff	IFX4	1
	M Hi	ROM Mono, 0506: Hi-Hat Basic 1-Closed f		
G2	High	ROM Mono, 0490: Tom Brush1 Low ff -L	IFX3	Off
	M Hi	ROM Mono, 0489: Tom Brush1 Low f		
G#2	High	ROM Mono, 0510: Hi-Hat Basic 1-Pedal f	IFX4	1
	M Hi	ROM Mono, 0508: Hi-Hat Basic 1-Pedal mp		
A2	High	ROM Mono, 0495: Tom Brush1 Mid ff -L	IFX3	Off
	M Hi	ROM Mono, 0494: Tom Brush1 Mid f		
A#2	High	ROM Mono, 0514: Hi-Hat Basic 1-Open ff	IFX4	1
	M Hi	ROM Mono, 0513: Hi-Hat Basic 1-Open f		
B2	High	ROM Mono, 0495: Tom Brush1 Mid ff -L	IFX3	Off
	M Hi	ROM Mono, 0494: Tom Brush1 Mid f		
C3	High	ROM Mono, 0500: Tom Brush1 Hi ff -L	IFX3	Off
	M Hi	ROM Mono, 0500: Tom Brush1 Hi ff -L		
C#3	High	ROM Mono, 0619: Crash Cymbal 4 ff	IFX4	Off
	M Hi	ROM Mono, 0618: Crash Cymbal 4 f		
D3	High	ROM Mono, 0500: Tom Brush1 Hi ff -L	IFX3	Off
	M Hi	ROM Mono, 0500: Tom Brush1 Hi ff -L		
D#3	High	ROM Mono, 0646: Ride Cymbal 1 ff	IFX4	Off
	M Hi	ROM Mono, 0644: Ride Cymbal 1 f -L		
E3	High	ROM Mono, 0673: China Cymbal 2	IFX4	Off
	M Hi	ROM Mono, 0671: China Cymbal 1 -L		
F3	High	ROM Mono, 0663: Ride Cymbal 7-Cup -L	IFX4	Off
	M Hi	ROM Mono, 0663: Ride Cymbal 7-Cup -L		
F#3	High	ROM Mono, 0877: Tambourine 2-Accent	IFX5	Off
	M Hi	ROM Mono, 0874: Tambourine 2-Push		
G3	High	ROM Mono, 0678: Splash Cymbal 1 ff -L	IFX4	Off
	M Hi	ROM Mono, 0676: Splash Cymbal 1 mf		
G#3	High	ROM Mono, 0830: Cowbell 2	IFX5	Off
	M Hi	ROM Mono, 0831: Cowbell 3		
A3	High	ROM Mono, 0627: Crash Cymbal 7 f -L	IFX4	Off
	M Hi	ROM Mono, 0626: Crash Cymbal 7 mf		
A#3	High	ROM Mono, 0853: Vibra-Slap	IFX5	Off
	M Hi	ROM Mono, 0646: Ride Cymbal 1 ff		
B3	High	ROM Mono, 0644: Ride Cymbal 1 f -L	IFX4	Off
	M Hi	ROM Mono, 0644: Ride Cymbal 1 f -L		
C4	High	ROM Mono, 0756: Bongo 1 Hi-Open f	IFX5	Off
	M Hi	ROM Mono, 0755: Bongo 1 Hi-Open mf		
C#4	High	ROM Mono, 0744: Bongo 1 Lo-Muffled f	IFX5	Off
	M Hi	ROM Mono, 0743: Bongo 1 Lo-Muffled mp		
D4	High	ROM Mono, 0728: Conga Hi-ClosedSlap	IFX5	Off
	M Hi	ROM Mono, 0727: Conga Hi-Closed		
D#4	High	ROM Mono, 0723: Conga Hi-OpenSlap	IFX5	Off
	M Hi	ROM Mono, 0720: Conga Hi-Open mf		
E4	High	ROM Mono, 0709: Conga Lo-OpenSlap	IFX5	Off
	M Hi	ROM Mono, 0707: Conga Lo-Open mf		
F4	High	ROM Mono, 0823: Timbales Hi-RimShot ff	IFX5	Off
	M Hi	ROM Mono, 0821: Timbales Hi-RimShot mf		
F#4	High	ROM Mono, 0811: Timbales Lo-Edge f	IFX5	Off
	M Hi	ROM Mono, 0808: Timbales Lo-Open mp		
G4	High	ROM Mono, 0935: Agogo 2 Hi-Open	IFX5	Off
	M Hi	ROM Mono, 0934: Agogo 2 Lo-Open		
G#4	High	ROM Mono, 0892: Cabasa 1 L a-Up	IFX5	Off
	M Hi	ROM Mono, 0891: Cabasa 1 L a-Down		

Key		Drumsample	Bus	Ex
A#4	High	ROM Mono, 0848: Maracas 2-Pull b	IFX5	Off
	M Hi	ROM Mono, 0846: Maracas 2-Push b		
B4	High	ROM Mono, 0972: Whistle 4-Short	IFX5	2
C5	High	ROM Mono, 0969: Whistle 2	IFX5	2
C#5	High	ROM Mono, 0852: Guiro-Short b	IFX5	3
	M Hi	ROM Mono, 0851: Guiro-Short a		
D5	High	ROM Mono, 0850: Guiro-Long b	IFX5	3
	M Hi	ROM Mono, 0849: Guiro-Long a		
D#5	High	ROM Mono, 0840: Claves Hi b	IFX5	Off
	M Hi	ROM Mono, 0839: Claves Hi a		
E5	High	ROM Mono, 1053: Wood Block 4 a	IFX5	Off
	M Hi	ROM Mono, 1054: Wood Block 4 b		
F5	High	ROM Mono, 1051: Wood Block 3 a	IFX5	Off
	M Hi	ROM Mono, 1052: Wood Block 3 b		
F#5	High	ROM Mono, 0965: Cuica Hi a	IFX5	4
	M Hi	ROM Mono, 0966: Cuica Hi b		
G5	High	ROM Mono, 0964: Cuica Lo c	IFX5	4
	M Hi	ROM Mono, 0962: Cuica Lo a		
G#5	High	ROM Mono, 0948: Triangle 1 S-Mute b	IFX5	5
	M Hi	ROM Mono, 0947: Triangle 1 S-Mute a		
A5	High	ROM Mono, 0943: Triangle 1 S-Open b	IFX5	5
	M Hi	ROM Mono, 0942: Triangle 1 S-Open a		
A#5	High	ROM Mono, 0912: Shaker 1-Slow b	IFX5	Off
	M Hi	ROM Mono, 0911: Shaker 1-Slow a		
B5	High	ROM Mono, 1072: Sleigh Bell	IFX5	Off
C6	High	ROM Mono, 1075: Marc Tree	L/R	Off
C#6	High	ROM Mono, 1062: Castanet 2	IFX4	Off
D6	High	ROM Mono, 0857: Surdo-Mute	IFX5	6
D#6	High	ROM Mono, 0856: Surdo-Open	IFX5	6
E6	High	ROM Mono, 1418: Stadium	IFX4	Off

## 55 (GM): ORCHESTRA

Key		Drumsample	Bus	Ex
D#1	High	ROM Mono,0550:Hi-Hat Brush-Closed mf	L/R	1
	M Hi	ROM Mono,0549:Hi-Hat Brush-Closed mp		
E1	High	ROM Mono,0553:Hi-Hat Brush-Pedal mf	L/R	1
	M Hi	ROM Mono,0554:Hi-Hat Brush-Pedal ff		
F1	High	ROM Mono,0558:Hi-Hat Brush-Open ff	L/R	1
	M Hi	ROM Mono,0557:Hi-Hat Brush-Open f		
F#1	High	ROM Mono,0644:Ride Cymbal 1 f -L	L/R	Off
	M Hi	ROM Mono,0642:Ride Cymbal 1 mf -L		
G1	High	ROM Mono,0682:Drumstick Hit	L/R	Off
G#1	High	ROM Mono,1190:Zap 1	L/R	Off
A1	High	ROM Mono,1424:Click 1	L/R	Off
A#1	High	ROM Mono,0955:Triangle 3 Lp	L/R	Off
B1	High	ROM Mono,0043:BD-09-dry mf -L	L/R	Off
	M Hi	ROM Mono,0041:BD-09-dry mp -L		
C2	High	ROM Mono,0054:BD-Orchestral	L/R	Off
C#2	High	ROM Mono,0320:SD-Sidestick 2 mf	L/R	Off
	M Hi	ROM Mono,0320:SD-Sidestick 2 mf		
D2	High	ROM Mono,0316:SD-Orchestral	L/R	Off
D#2	High	ROM Mono,1059:Castanet 1 a	L/R	Off
	M Hi	ROM Mono,1061:Castanet 1 c		
E2	High	ROM Mono,0316:SD-Orchestral	L/R	Off
F2	High	ROM Mono,1064:Timpani ff	IFX3	Off
	M Hi	ROM Mono,1063:Timpani mf		
F#2	High	ROM Mono,1064:Timpani ff	IFX3	Off
	M Hi	ROM Mono,1063:Timpani mf		
G2	High	ROM Mono,1064:Timpani ff	IFX3	Off
	M Hi	ROM Mono,1063:Timpani mf		
G#2	High	ROM Mono,1064:Timpani ff	IFX3	Off
	M Hi	ROM Mono,1063:Timpani mf		
A2	High	ROM Mono,1064:Timpani ff	IFX3	Off
	M Hi	ROM Mono,1063:Timpani mf		
A#2	High	ROM Mono,1064:Timpani ff	IFX3	Off
	M Hi	ROM Mono,1063:Timpani mf		
B2	High	ROM Mono,1064:Timpani ff	IFX3	Off
	M Hi	ROM Mono,1063:Timpani mf		
C3	High	ROM Mono,1064:Timpani ff	IFX3	Off
	M Hi	ROM Mono,1063:Timpani mf		
C#3	High	ROM Mono,1064:Timpani ff	IFX3	Off
	M Hi	ROM Mono,1063:Timpani mf		
D3	High	ROM Mono,1064:Timpani ff	IFX3	Off
	M Hi	ROM Mono,1063:Timpani mf		
D#3	High	ROM Mono,1064:Timpani ff	IFX3	Off
	M Hi	ROM Mono,1063:Timpani mf		
E3	High	ROM Mono,1064:Timpani ff	IFX3	Off
	M Hi	ROM Mono,1063:Timpani mf		
F3	High	ROM Mono,1064:Timpani ff	IFX3	Off
	M Hi	ROM Mono,1063:Timpani mf		
F#3	High	ROM Mono,0877:Tambourine 2-Accent	IFX5	Off
	M Hi	ROM Mono,0874:Tambourine 2-Push		
G3	High	ROM Mono,0678:Splash Cymbal 1 ff -L	IFX4	Off
	M Hi	ROM Mono,0676:Splash Cymbal 1 mf		
G#3	High	ROM Mono,0830:Cowbell 2	IFX5	Off
	M Hi	ROM Mono,0831:Cowbell 3		
A3	High	ROM Mono,0627:Crash Cymbal 7 f -L	IFX4	Off
	M Hi	ROM Mono,0626:Crash Cymbal 7 mf		
A#3	High	ROM Mono,0853:Vibra-Slap	IFX5	Off
B3	High	ROM Mono,0631:Orchestral Cymbal-Open	IFX4	Off
	M Hi	ROM Mono,0756:Bongo 1 Hi-Open f		
C4	High	ROM Mono,0756:Bongo 1 Hi-Open f	IFX5	Off
	M Hi	ROM Mono,0755:Bongo 1 Hi-Open mf		
C#4	High	ROM Mono,0744:Bongo 1 Lo-Muffled f	IFX5	Off
	M Hi	ROM Mono,0743:Bongo 1 Lo-Muffled mp		
D4	High	ROM Mono,0728:Conga Hi-ClosedSlap	IFX5	Off
	M Hi	ROM Mono,0727:Conga Hi-Closed		
D#4	High	ROM Mono,0723:Conga Hi-OpenSlap	IFX5	Off
	M Hi	ROM Mono,0720:Conga Hi-Open mf		
E4	High	ROM Mono,0709:Conga Lo-OpenSlap	IFX5	Off
	M Hi	ROM Mono,0707:Conga Lo-Open mf		
F4	High	ROM Mono,0823:Timbales Hi-RimShot ff	IFX5	Off
	M Hi	ROM Mono,0821:Timbales Hi-RimShot mf		
F#4	High	ROM Mono,0811:Timbales Lo-Edge f	IFX5	Off
	M Hi	ROM Mono,0808:Timbales Lo-Open mp		
G4	High	ROM Mono,0935:Agogo 2 Hi-Open	IFX5	Off
G#4	High	ROM Mono,0934:Agogo 2 Lo-Open	IFX5	Off
A4	High	ROM Mono,0892:Cabasa 1 L a-Up	IFX5	Off
	M Hi	ROM Mono,0891:Cabasa 1 L a-Down		

Key		Drumsample	Bus	Ex
A#4	High	ROM Mono,0848:Maracas 2-Pull b	IFX5	Off
	M Hi	ROM Mono,0846:Maracas 2-Push b		
B4	High	ROM Mono,0972:Whistle 4-Short	IFX5	2
C5	High	ROM Mono,0969:Whistle 2	IFX5	2
C#5	High	ROM Mono,0852:Guiro-Short b	IFX5	3
	M Hi	ROM Mono,0851:Guiro-Short a		
D5	High	ROM Mono,0850:Guiro-Long b	IFX5	3
	M Hi	ROM Mono,0849:Guiro-Long a		
D#5	High	ROM Mono,0840:Claves Hi b	IFX5	Off
	M Hi	ROM Mono,0839:Claves Hi a		
E5	High	ROM Mono,1053:Wood Block 4 a	IFX5	Off
	M Hi	ROM Mono,1054:Wood Block 4 b		
F5	High	ROM Mono,1051:Wood Block 3 a	IFX5	Off
	M Hi	ROM Mono,1052:Wood Block 3 b		
F#5	High	ROM Mono,0965:Cuica Hi a	IFX5	4
	M Hi	ROM Mono,0966:Cuica Hi b		
G5	High	ROM Mono,0964:Cuica Lo c	IFX5	4
	M Hi	ROM Mono,0962:Cuica Lo a		
G#5	High	ROM Mono,0948:Triangle 1 S-Mute b	IFX5	5
	M Hi	ROM Mono,0947:Triangle 1 S-Mute a		
A5	High	ROM Mono,0943:Triangle 1 S-Open b	IFX5	5
	M Hi	ROM Mono,0942:Triangle 1 S-Open a		
A#5	High	ROM Mono,0912:Shaker 1-Slow b	IFX5	Off
	M Hi	ROM Mono,0911:Shaker 1-Slow a		
B5	High	ROM Mono,1072:Sleigh Bell	IFX5	Off
C6	High	ROM Mono,1075:Marc Tree	IFX2	Off
C#6	High	ROM Mono,1062:Castanet 2	IFX4	Off
D6	High	ROM Mono,0857:Surdo-Mute	IFX1	6
D#6	High	ROM Mono,0856:Surdo-Open	IFX4	6
E6	High	ROM Mono,1418:Stadium	IFX4	Off

56 (GM): SFX

Key		Drumsample	Bus	Ex
D#2	High	ROM Mono, 1191: Zap 2	L/R	Off
E2	High	ROM Mono, 1481: Noise-White	L/R	Off
F2	High	ROM Mono, 1254: DJ-Scratch 1	L/R	Off
F#2	High	ROM Mono, 1254: DJ-Scratch 1	L/R	Off
G2	High	ROM Mono, 0682: Drumstick Hit	L/R	Off
G#2	High	ROM Mono, 1190: Zap 1	L/R	Off
A2	High	ROM Mono, 1424: Click 1	L/R	Off
A#2	High	ROM Mono, 0955: Triangle 3 Lp	L/R	Off
B2	High	ROM Mono, 1520: El.Guitar-Fret Noise 1	L/R	Off
C3	High	ROM Mono, 1515: GtCutNois 1	L/R	Off
C#3	High	ROM Mono, 1516: GtCutNois 2	L/R	Off
D3	High	ROM Mono, 1569: Ac.Bs-String Slap	L/R	Off
D#3	High	ROM Mono, 0683: Finger Snap	L/R	Off
E3	High	ROM Mono, 1421: Laughing	IFX1	Off
F3	High	ROM Mono, 1420: Scream	IFX3	Off
F#3	High	ROM Mono, 1433: Punch	IFX4	1
G3	High	ROM Mono, 1432: Heart Beat	IFX3	Off
G#3	High	ROM Mono, 1423: Footstep 2	IFX4	1
A3	High	ROM Mono, 1422: Footstep 1	IFX4	1
A#3	High	ROM Mono, 1419: Applause	IFX4	1
B3	High	ROM Mono, 1440: Door Creak	IFX3	Off
C4	High	ROM Mono, 1441: Door Slam 1	IFX3	Off
C#4	High	ROM Mono, 1254: DJ-Scratch 1	IFX4	Off
D4	High	ROM Mono, 1075: Marc Tree	IFX3	Off
D#4	High	ROM Mono, 1443: Car Engine	IFX4	Off
E4	High	ROM Mono, 1444: Car Stop	IFX4	Off
F4	High	ROM Mono, 1445: Car Pass	IFX4	Off
F#4	High	ROM Mono, 1446: Car Crash	IFX4	Off
G4	High	ROM Mono, 1471: Telephone-Ring	IFX4	Off
G#4	High	ROM Mono, 1448: Train	IFX5	Off
A4	High	ROM Mono, 1481: Noise-White	IFX4	Off
A#4	High	ROM Mono, 1452: Helicopter	IFX5	Off
B4	High	ROM Mono, 1478: Swish Terra	IFX4	Off
C5	High	ROM Mono, 1454: Gun Shot	IFX5	Off
C#5	High	ROM Mono, 1456: Machine Gun	IFX5	Off
D5	High	ROM Mono, 1457: Laser Gun	IFX5	Off
D#5	High	ROM Mono, 1461: Explosion	IFX5	Off
E5	High	ROM Mono, 1428: Dog	IFX5	Off
F5	High	ROM Mono, 1429: Gallop	IFX5	Off
F#5	High	ROM Mono, 1426: Bird 1	IFX5	Off
G5	High	ROM Mono, 1078: Rainstick 2	IFX5	Off
G#5	High	ROM Mono, 1462: Thunder	IFX5	Off
A5	High	ROM Mono, 1463: Wind	IFX5	Off
A#5	High	ROM Mono, 1481: Noise-White	IFX5	Off
B5	High	ROM Mono, 1464: Stream	IFX5	2
C6	High	ROM Mono, 1465: Bubble	IFX5	2



## Drum Track Patterns/Preset Patterns

#	Name	#	Name	#	Name	#	Name
0000	Off	0075	Gospel Half Beat 2 [Std]	0150	R&B 7 [HipHop]	0225	Rock+Tamb [Rock]
0001	Pop & Balad 1 [Std]	0076	Funk Ballad [All]	0151	R&B 8 [HipHop]	0226	16th variations 1 [Std]
0002	Pop & Balad 2 [Std]	0077	Rock 1 [Process]	0152	R&B 9 [HipHop]	0227	16th variations 2 [Std]
0003	Pop & Balad 3 [Std]	0078	Rock 2 [Process]	0153	R&B 10 [HipHop]	0228	16th variations 3 [Std]
0004	Pop & Balad 4 [Std]	0079	Rock 3 [Process]	0154	R&B 11 [HipHop]	0229	16th variations 4 [Std]
0005	Pop & Balad 5 [Std]	0080	Rock 4 [Process]	0155	Jazz 1 [Jazz]	0230	Funky 16th 1 [Std]
0006	Pop & Balad 6 [Std]	0081	Rock 5 [Process]	0156	Jazz 2 [Jazz]	0231	Funky 16th 2 [Std]
0007	Pop & Balad 7 [Std]	0082	Rock 6 [Process]	0157	Jazz 3 [Jazz]	0232	Funky 16th 3 [Std]
0008	Pop & Balad 8 [Std]	0083	Rock 7 [Process]	0158	Jazz 4 [Jazz]	0233	Hip Funk Shuffle [Funk]
0009	Square Hit [All]	0084	Rock 8 [Process]	0159	Jazz 5 [Jazz]	0234	Funky Shuffle [Std]
0010	Dancing Perky [Std]	0085	Rock 9 [Process]	0160	Jazz 6 [Jazz]	0235	Latin Fusion 112bpm[Std]
0011	Pop 1 112bpm [Std]	0086	Rock 10 [Process]	0161	Jazz 7 [Jazz]	0236	Latin Rock 1 112bpm[Std]
0012	Pop 2 112bpm [Std]	0087	Rock 11 [Process]	0162	Simple Swing [Jazz]	0237	Latin Rock 2 112bpm[Std]
0013	Pop 3 94bpm [Std]	0088	Rock Tool Kit [Process]	0163	Jazz Swing out [Jazz]	0238	Latin 1 140bpm [Std]
0014	Pop 4 94bpm [Std]	0089	Revenge Rock [Process]	0164	Swing 1 152bpm [Std]	0239	Latin 2 140bpm [Std]
0015	Pop 5 86bpm [Std]	0090	Straight Moreish [Procs]	0165	Swing 2 165bpm [Std]	0240	Latin 3 140bpm [Std]
0016	Pop 6 98bpm [Std]	0091	Pop Rock 1 104bpm [Std]	0166	Swing 3 165bpm [Std]	0241	Afro-5 140bpm [Std]
0017	Pop 7 128bpm [Std]	0092	Pop Rock 2 104bpm [Std]	0167	4 Beat 118bpm [Std]	0242	Latin 5 110bpm [Std]
0018	EAG Beat [All]	0093	Rock 94bpm [Std]	0168	4 Beat-5 118bpm [Std]	0243	Latin 6 110bpm [Std]
0019	Sieling [Std]	0094	RocknRoll 1 145bpm[Rock]	0169	Foxtrot [Std]	0244	Afro 84bpm [Std]
0020	Funk constant [All]	0095	RocknRoll 2 150bpm[Rock]	0170	8 Beat Funk 120bpm [Std]	0245	Afro-S 84bpm [Std]
0021	Classic 8 Beat 1 [Std]	0096	RocknRoll 3 150bpm[Rock]	0171	8Beat Funk-S 110bpm[Std]	0246	FusionSamba1 102bpm[Std]
0022	Classic 8 Beat 2 [Std]	0097	RocknRoll 4 140bpm[Rock]	0172	Funk Fusion 112bpm [Std]	0247	FusnSamba1-5 92bpm [Std]
0023	Classic 8 Beat 3 [Std]	0098	RocknRoll 5 140bpm[Rock]	0173	Funky 1 100bpm [Std]	0248	FusionSamba2 108bpm[Std]
0024	Classic 8 Beat 4 [Std]	0099	RocknRoll 6 140bpm[Rock]	0174	Funky 2 100bpm [Std]	0249	Fusion Samba2-5(96)[Std]
0025	Classic 8 Beat 5 [Std]	0100	RocknRoll 7 140bpm[Rock]	0175	Funky 3 100bpm [Std]	0250	Marching 112bpm [Std]
0026	Classic 8 Beat 6 [Std]	0101	RocknRoll 8 135bpm[Rock]	0176	Funky 4 100bpm [Std]	0251	Marching-S 100bpm [Std]
0027	Pop Beat [Std]	0102	RocknRoll 9 135bpm[Rock]	0177	Funky 5 100bpm [Std]	0252	Tom Solo 112bpm [Std]
0028	Pop Chart 1 [Std]	0103	Light Rock 1 [Rock]	0178	Funky 6 100bpm [Std]	0253	Tom Solo-S 104bpm [Std]
0029	Pop Chart 2 [Std]	0104	Light Rock 2 [Rock]	0179	Funky 7 100bpm [Std]	0254	F.Tom Solo 106bpm [Std]
0030	Real 8 Beat 1 [Std]	0105	Light Rock 3 [Rock]	0180	Funky 8 100bpm [Std]	0255	F.Tom Solo-S 106bpm[Std]
0031	Real 8 Beat 2 [Std]	0106	Light Rock 4 [Rock]	0181	Funky 9 110bpm [Std]	0256	Tribal Toms [Ac.Pop]
0032	Real 8 Beat 3 [Std]	0107	Light Rock 5 [Rock]	0182	Funk "P" 84bpm 1 [Funk]	0257	Snare Solo 1 125bpm[Std]
0033	Slow Hop [Std]	0108	Monster Power [Rock]	0183	Funk "P" 84bpm 2 [Funk]	0258	Snare Solo 2 125bpm[Std]
0034	Soft Beat [Std]	0109	Twist 1 [All]	0184	Slow Funk 1 90bpm [Funk]	0259	New Orleans 1 92bpm[Std]
0035	Pop Blend [All]	0110	Twist 2 [All]	0185	Slow Funk 2 90bpm [Funk]	0260	New Orleans 2 92bpm[Std]
0036	Unplugged 8Beat 1 [Std]	0111	Country 86bpm [Std]	0186	Slow Funk 3 90bpm [Funk]	0261	Latin 1 [Funk]
0037	Unplugged 8Beat 2 [Std]	0112	8 Beat Tripl 96bpm [Std]	0187	Slow Funk 4 90bpm [Funk]	0262	Latin 2 [Funk]
0038	Unplugged 8Beat 3 [Std]	0113	TripletSlow 1 80bpm[Std]	0188	Funk Paisley [Funk]	0263	Latin 3 [Funk]
0039	8 Beat Pop 1 [Std]	0114	TripletSlow 2 80bpm[Std]	0189	Late Night Jam [Funk]	0264	Latin 4 [Funk]
0040	8 Beat Pop 2 [Std]	0115	Shuffle 1 115bpm [Std]	0190	Balinese Joy [Rock]	0265	Latin 5 [Funk]
0041	8 Beat Pop 3 [Std]	0116	Shuffle 2 115bpm [Std]	0191	Smooth Jazz 1 92bpm[Std]	0266	Latin 6 [Funk]
0042	8 Beat Pop 4 [Std]	0117	Shuffle 3 115bpm [Std]	0192	Smooth Jazz 2 92bpm[Std]	0267	Latin 7 [Funk]
0043	8 Beat Pop 5 [Std]	0118	Shuffle 4 115bpm [Std]	0193	Memphis 1 [Funk]	0268	Latin 8 [Funk]
0044	Pop Hits 1 [Std]	0119	Shuffle 5 115bpm [Std]	0194	Memphis 2 [Funk]	0269	Reggae 1 [Funk]
0045	Pop Hits 2 [Std]	0120	Aligator Swamp [Std]	0195	8 Beat 1 116bpm [Std]	0270	Reggae 2 [Funk]
0046	Gogo Drum [All]	0121	Pop Shuffle [Std]	0196	8 Beat 1-S 104bpm [Std]	0271	Reggae 3 [Funk]
0047	8 Beat Cool 1 [Std]	0122	6/8 Funk 1 [Std]	0197	8 Beat 2 96bpm [Std]	0272	Reggae 4 [Funk]
0048	8 Beat Cool 2 [Std]	0123	6/8 Funk 2 [Std]	0198	8 Beat 2-S 96bpm [Std]	0273	Reggae 5 [Funk]
0049	8 Beat Dance 1 [All]	0124	6/8 Funk 3 [Std]	0199	8 Beat Rim 90bpm [Std]	0274	Reggae 6 [Funk]
0050	8 Beat Dance 2 [All]	0125	6/8 Funk 4 [Std]	0200	8 Beat Rim-S 90bpm [Std]	0275	ReggaeBeat 1 155bpm[Std]
0051	Brit Funk [All]	0126	6/8 Funk 5 [Funk]	0201	8 Beat Rock 96bpm [Std]	0276	ReggaeBeat 2 155bpm[Std]
0052	British Pop 1 [Std]	0127	6/8 Ballad 1 128bpm[Std]	0202	8 Beat Rock-S 96bpm[Std]	0277	ReggaeBeat 3 135bpm[Std]
0053	British Pop 2 [Std]	0128	6/8 Ballad 2 128bpm[Std]	0203	Pop 16th 116bpm [Std]	0278	Country 1 [AcPop]
0054	Ballad 1 77bpm [Std]	0129	Slow 6/8 1 [Std]	0204	16 Beat 1 114bpm [Std]	0279	Country 2 [AcPop]
0055	Ballad 2 77bpm [Std]	0130	Slow 6/8 2 [Std]	0205	16 Beat 1-5 108bpm [Std]	0280	Country 3 [AcPop]
0056	Ballad 3 106bpm [Std]	0131	Triplet Pop [Std]	0206	16 Beat 2 114bpm [Std]	0281	Country 4 [AcPop]
0057	Ballad 4 106bpm [Std]	0132	Pop(6-8) 1 [Std]	0207	16 Beat 2-5 100bpm [Std]	0282	Halftime Beat [Ac.Pop]
0058	Easy Ballad 1 [Std]	0133	Pop(6-8) 2 [Std]	0208	16 Beat 3 110bpm [Std]	0283	Tingly Breath [Ac.Pop]
0059	Easy Ballad 2 [Std]	0134	Pop(6-8) 3 [Std]	0209	16 Beat 3-S 110bpm [Std]	0284	Fab Beat [Ac.Pop]
0060	Slow Ballad [Std]	0135	3/4 8 Beat Pop [Std]	0210	16 Beat 4 122bpm [Std]	0285	New Orchestral [Ac.Pop]
0061	Groove Ballad 1 [Std]	0136	Waltz [Std]	0211	16 Beat 4-S 108bpm [Std]	0286	A Subtle Remark [Ac.Pop]
0062	Groove Ballad 2 [Std]	0137	Modern Waltz [Std]	0212	16 Beat 5 112bpm [Std]	0287	Walks into [Ac.Pop]
0063	Groove Ballad 3 [Std]	0138	Slow Waltz 1 [Jazz]	0213	16 Beat 5-S 112bpm [Std]	0288	a Jahmmin [Ac.Pop]
0064	Pop Ballad 1 [Std]	0139	Slow Waltz 2 [Jazz]	0214	16 Beat 6 104bpm [Std]	0289	Folk 1 [Jazz]
0065	Pop Ballad 2 [Std]	0140	Bluegrass Waltz [Jazz]	0215	16 Beat 6-S 92bpm [Std]	0290	Folk 2 [Jazz]
0066	Pop Ballad 3 [Std]	0141	Slow Waltz 3 [Ac.Pop]	0216	16 Beat 7 114bpm [Std]	0291	Folk 3 [Jazz]
0067	Half Time 1 [Std]	0142	Floyd 7/4 [Std]	0217	16 Beat 7-S 104bpm [Std]	0292	Folk 4 [Jazz]
0068	Half Time 2 [Std]	0143	Funk 7/4 [Std]	0218	16 Beat 8 94bpm [Std]	0293	E.Trad 1 [Std]
0069	Kool Half 1 [Std]	0144	R&B 1 [HipHop]	0219	16 Beat 8-S 92bpm [Std]	0294	E.Trad 2 [Std]
0070	Kool Half 2 [Std]	0145	R&B 2 [HipHop]	0220	16 Beat 9 102bpm [Std]	0295	E.Trad 3 [Std]
0071	Kool Half 3 [Std]	0146	R&B 3 [HipHop]	0221	16 Beat 9-S 86bpm [Std]	0296	E.Trad 4 [Std]
0072	Half Time Ballad 1 [Std]	0147	R&B 4 [HipHop]	0222	Pop 16 Beat 1 [Std]	0297	E.Trad(3-4) 1 [Std]
0073	Half Time Ballad 2 [Std]	0148	R&B 5 [HipHop]	0223	Pop 16 Beat 2 [Std]	0298	E.Trad(3-4) 2 [Std]
0074	Gospel Half Beat 1 [Std]	0149	R&B 6 [HipHop]	0224	16 Beat Ballad [Std]	0299	8th Triplet March [Orch]

#	Name	#	Name	#	Name	#	Name
0300	Burgler March [Orch]	0375	Techno Grv 2 [BrzPrc]	0450	Cool House 2 [House]	0525	Deep Chill 1 [Dance]
0301	Grand Entrance [Orch]	0376	Techno Grv 3 [BrzPrc]	0451	Cool House 3 [House]	0526	Deep Chill 2 [Dance]
0302	Hero March [Orch]	0377	Techno Grv 4 [BrzPrc]	0452	Cool House 4 [House]	0527	Deep Chill 3 [Dance]
0303	Procession March [Orch]	0378	World Grv 4 [BrzPrc]	0453	Cool House 5 [House]	0528	Deep Chill 4 [Dance]
0304	Proud March [Orch]	0379	World Grv 5 [BrzPrc]	0454	Cool House 6 [House]	0529	Deep Chill 5 [Dance]
0305	Wdblock March [Orch]	0380	World Grv 6 [BrzPrc]	0455	Cool House 7 [House]	0530	Deep Chill 6 [Dance]
0306	World Grv 1 [Orch]	0381	World Grv 7 [BrzPrc]	0456	Cool House 8 [House]	0531	Deep Chill 7 [Dance]
0307	World Grv 2 [Orch]	0382	World Grv 8 [BrzPrc]	0457	Cool House 9 [House]	0532	Deep Chill 8 [Dance]
0308	World Grv 3 [Orch]	0383	Celtic Perc [Cuban Perc]	0458	Cool House 10 [House]	0533	Deep Chill 9 [Dance]
0309	Tribal Grv [Orch]	0384	Jam on Pads [Cuban Perc]	0459	Cool House 11 [House]	0534	Deep Chill 10 [Dance]
0310	Arco String [Orch]	0385	Sprinkle [Cuban Perc]	0460	Matrix Rec. [House]	0535	Deep Chill 11 [Dance]
0311	Castle Concert 1 [Orch]	0386	Funky King [Misc Perc]	0461	Roller Boogie [House]	0536	Chillout Rest [Psy/Chi]
0312	Castle Concert 2 [Orch]	0387	Top Pop Grv [Misc Perc]	0462	Magical Moments [House]	0537	BongoScape [Psy/Chill]
0313	Love Scene 1 [Orch]	0388	DnB 1 [Misc Perc]	0463	Tech House 1a [Dance]	0538	Tirtian [Psy/Chill]
0314	Love Scene 2 [Orch]	0389	DnB 2 [Misc Perc]	0464	Tech House 1b [Dance]	0539	Pwr Intro [Psy/Chill]
0315	Love Scene 3 [Orch]	0390	Cho Jungle [Misc Perc]	0465	Tech House 2 [Dance]	0540	Reflective [Psy/Chill]
0316	Mixed Strings 1a [Orch]	0391	Metronome 1 note [All]	0466	Tech House 3 [Dance]	0541	Acid Jazz 1 [Jazz]
0317	Mixed Strings 1b [Orch]	0392	Metronome 2 note [All]	0467	Tech House 4a [Dance]	0542	Acid Jazz 2 [Jazz]
0318	Mixed Strings 2 [Orch]	0393	Techno Trance 1 [Trance]	0468	Tech House 4b [Dance]	0543	Acid Jazz 3 [Jazz]
0319	Grande Waltz 1 [Orch]	0394	Techno Trance 2 [Trance]	0469	Tech House 4c [Dance]	0544	Acid Jazz 4 [Jazz]
0320	Grande Waltz 2 [Orch]	0395	Techno Trance 3 [Trance]	0470	Hard House 1 [HardHouse]	0545	Acid Jazz 5 [Jazz]
0321	Love Winds 1 [Orch]	0396	Techno Trance 4 [Trance]	0471	Hard House 2 [HardHouse]	0546	Acid Jazz 6 [Jazz]
0322	Love Winds 2 [Orch]	0397	Techno Trance 5 [Trance]	0472	Hard House 3 [HardHouse]	0547	Acid Jazz 7 [Jazz]
0323	Love Winds 3 [Orch]	0398	Techno Trance 6 [Trance]	0473	Hard House 4 [HardHouse]	0548	Acid Jazz 8 [Jazz]
0324	Renaissance 1 [Orch]	0399	Techno Trance 7 [Trance]	0474	Hard House 5 [HardHouse]	0549	Acid Jazz 9 [Jazz]
0325	Renaissance 2 [Orch]	0400	Techno Trance 8 [Trance]	0475	Hard House 6 [HardHouse]	0550	Acid Jazz 10 [Jazz]
0326	Renaissance 3 [Orch]	0401	Techno Trance 9 [Trance]	0476	Hard House 7 [HardHouse]	0551	Acid Jazz 11 [Jazz]
0327	Sparse High End [Orch]	0402	Techno Trance10 [Trance]	0477	Hard House 8 [HardHouse]	0552	Hip Hop&Rap 1 [HipHop]
0328	String Dance 1 [Orch]	0403	Techno Trance11 [Trance]	0478	Hard House 9 [HardHouse]	0553	Hip Hop&Rap 2 [HipHop]
0329	String Dance 2 [Orch]	0404	Tribal Techno [Trance]	0479	Hard House10 [HardHouse]	0554	Hip Hop&Rap 3 [HipHop]
0330	String Dance 3 [Orch]	0405	Love for [Trance]	0480	Hard House11 [HardHouse]	0555	Hip Hop&Rap 4 [HipHop]
0331	Xpressive [Orch]	0406	Dance Station [Trance]	0481	Restless [HardHouse]	0556	Hip Hop&Rap 5 [HipHop]
0332	OrcheSnares [Orch]	0407	Follow Leader [Trance]	0482	Oriental Dance [Dance]	0557	Hip Hop&Rap 6 [HipHop]
0333	Simple Tango [Orch]	0408	Club UK [Trance]	0483	Underground [Dance]	0558	Hip Hop&Rap 7 [HipHop]
0334	Tango Live [Orch]	0409	Electronica 1 [Trance]	0484	Club Latin 1 [Dance]	0559	Hip Hop&Rap 8 [HipHop]
0335	DR-Scot March [Orch]	0410	Electronica 2 [Trance]	0485	Club Latin 2 [Dance]	0560	Hip Hop&Rap 9 [HipHop]
0336	Miracle [Orch]	0411	Welcoming [Trance]	0486	Disco 1 [Dance]	0561	Hip Hop&Rap 10 [HipHop]
0337	New Copland [Orch]	0412	Lost at Sea [Trance]	0487	Disco 2 [Dance]	0562	Hip Hop&Rap 11 [HipHop]
0338	Ceremony [Orch]	0413	Trance Ripple [Trance]	0488	Drum'n'Bass 1 [D'n'B]	0563	Lose It [HipHop]
0339	Matinee Orch [Orch]	0414	Teknotropic 1 [Dance]	0489	Drum'n'Bass 2 [D'n'B]	0564	Dust Storm [HipHop]
0340	Orch Triplets [Orch]	0415	Teknotropic 2 [Dance]	0490	Drum'n'Bass 3 [D'n'B]	0565	Eternal Vision [HipHop]
0341	Clave [Orig Perc]	0416	Teknotropic 3 [Dance]	0491	Drum'n'Bass 4 [D'n'B]	0566	Princess H's [HipHop]
0342	Latin 1a [Orig Perc]	0417	Teknotropic 4 [Dance]	0492	Drum'n'Bass 5 [D'n'B]	0567	JPop Cover Girl [HipHop]
0343	Latin 1b [Orig Perc]	0418	TechnoTrain K1+S1 [Dance]	0493	Drum'n'Bass 6 [D'n'B]	0568	Asian DJ [HipHop]
0344	Latin 1c [Orig Perc]	0419	TechnoTrain K2+S2 [Dance]	0494	Drum'n'Bass 7 [D'n'B]	0569	Fun Lovin [HipHop]
0345	Shakers 1 [Orig Perc]	0420	Train Tekno K3+S3 [Dance]	0495	Drum'n'Bass 8 [D'n'B]	0570	Indulgent Hop [HipHop]
0346	Shakers 2 [Orig Perc]	0421	Trancer K1+S1 [Dance]	0496	Drum'n'Bass 9 [D'n'B]	0571	Stealth Lovers [Dance]
0347	Shakers 3 [Orig Perc]	0422	Trancer K2+S2 [Dance]	0497	Drum'n'Bass 10 [D'n'B]	0572	Bad Luck Groove [B.Real]
0348	Triangle 1 [Orig Perc]	0423	Trancer K3+S3 [Dance]	0498	Drum'n'Bass 11 [D'n'B]	0573	Simple HipHop [B.Real]
0349	Triangle 2 [Orig Perc]	0424	4 on Floor Kik 1 [Dance]	0499	Watching the Virus [DnB]	0574	Rappilicious 1 [B.Real]
0350	Celtic Triplets [O.Perc]	0425	4 on Floor Kik 2 [Dance]	0500	Black Mass [D'n'B]	0575	Rappilicious 2 [B.Real]
0351	Conga Grv 1 [Conga]	0426	4 on Floor Kik 3 [Dance]	0501	Drum'n'Bass light [D'n'B]	0576	Rappilicious 3 [B.Real]
0352	Conga Grv 2 [Conga]	0427	4 on Floor Kik 4 [Dance]	0502	Drum'n'Bass Split [D'n'B]	0577	HipHop Rider [B.Real]
0353	Conga Grv 3 [Conga]	0428	4 on Floor Kik 5 [Dance]	0503	Your Too Late [D'n'B]	0578	Swing Hop Pop [B.Real]
0354	Conga Grv 4 [Conga]	0429	Teknotropic Kick [Dance]	0504	Safe from Storm [D'n'B]	0579	Hip Shuffl'long [B.Real]
0355	Breakbeat 2 [BrzPrc]	0430	4thFloor Kik+Ht1 [Dance]	0505	Dancehall [D'n'B]	0580	B.Cruel Groove [B.Real]
0356	Breakbeat 3 [BrzPrc]	0431	4thFloor Kik+Ht2 [Dance]	0506	Wizard Cymbals [D'n'B]	0581	HipHop Pop [B.Real]
0357	Breakbeat 4 [BrzPrc]	0432	4thFloor Kik+Ht3 [Dance]	0507	French Trip [D'n'B]	0582	Crunk Style Rap [B.Real]
0358	Breakbeat Tamb [BrzPrc]	0433	4thFloor Kik+Ht4 [Dance]	0508	Classic D'n'B [Dance]	0583	Crunk Lover [B.Real]
0359	Breakbeat Tri [BrzPrc]	0434	4thFloor Kik+Ht5 [Dance]	0509	Jungle 1 [Dance]	0584	Cool Low HipHop [B.Real]
0360	Clave [BrzPrc]	0435	4thFloor Kik+Ht6 [Dance]	0510	Jungle 2 [Dance]	0585	Real Slim Brady [B.Real]
0361	Hip Bossa 1 [BrzPrc]	0436	4thFloor Kik+Ht7 [Dance]	0511	Breakbeat 1 [Tricki]	0586	Gospel Hop 6/8 [B.Real]
0362	Hip Bossa 2 [BrzPrc]	0437	Techno Kids [Dance]	0512	Breakbeat 5 [Tricki]	0587	Prayer [Masked]
0363	Hip Bossa 3 [BrzPrc]	0438	Skippy Wants to [Dance]	0513	Breakbeat 6 [Tricki]	0588	Pod Doors [Masked]
0364	Hip Bossa Tamb [BrzPrc]	0439	Shifting Cells [Dance]	0514	Breakbeat 7 [Tricki]	0589	Smooth Jazzmi [Masked]
0365	Shakers 1 [BrzPrc]	0440	Koochie Groovy [Dance]	0515	Breakbeat 8 [Tricki]	0590	Lucid Dreamin [Masked]
0366	Shakers 2 [BrzPrc]	0441	Laid Back House [Dance]	0516	Breakbeat 9 [Tricki]	0591	Groove On [Masked]
0367	Shakers 3 [BrzPrc]	0442	Hero Last Stand [Dance]	0517	Breakbeat 10 [Tricki]	0592	Club Squeezed [Masked]
0368	Shakers 4 [BrzPrc]	0443	Started Crying [Dance]	0518	Breakbeat 11 [Tricki]	0593	Chile Pepper [Masked]
0369	SwingHop 1 [BrzPrc]	0444	No Sleep [Dance]	0519	Breakbeat 12 [Tricki]	0594	Pushed Beat [Masked]
0370	SwingHop 2 [BrzPrc]	0445	Fresh Beat [Dance]	0520	Breakbeat 13 [Tricki]	0595	Cool Drops [Masked]
0371	SwingHop 3 [BrzPrc]	0446	High End Grv 1 [All]	0521	Breakbeat 14 [Tricki]	0596	Garage Night [Masked]
0372	SwingHop Shkr [BrzPrc]	0447	High End Grv 2 [All]	0522	TrikaHolic [Tricki]	0597	Mallet Kalimba [Masked]
0373	SwingHop Tamb [BrzPrc]	0448	High End Grv 3 [All]	0523	Tricki Flash [Tricki]	0598	Jungle Harper [Masked]
0374	Techno Grv 1 [BrzPrc]	0449	Cool House 1 [House]	0524	DirtnGrind [Tricki]	0599	Ska Groove 1 [DJ]

#	Name
0600	Ska Groove 2 [DJ]
0601	Hip Beat [Dance]
0602	HipHop FunkPop [Dance]
0603	Shuffle Club Funk[Dance]
0604	Bumpin'Groove [Dance]
0605	O!School K1+S1 [Dance]
0606	O!School K2+S2 [Dance]
0607	O!School K3+S3 [Dance]
0608	PopHop K1+S1 [Dance]
0609	PopHop K2+S2 [Dance]
0610	RapHop K1+S1 [Dance]
0611	RapHop K2+S2 [Dance]
0612	Kar Krash 1 [DJ]
0613	Kar Krash 2 [DJ]
0614	O!School Rap 1 [DJ]
0615	O!School Rap 2 [DJ]
0616	O!School Rap 3 [DJ]
0617	Analog Beat 1 [Down]
0618	Analog Beat 2 [Down]
0619	Analog Beat 3 [Down]
0620	Analog Beat 4 [Down]
0621	8 Beat Analog 1 [Down]
0622	8 Beat Analog 2 [Down]
0623	PCM Pirates [Down]
0624	Homies Coming [Down]
0625	Rough Riders [Down]
0626	Tekno Town 1 [DJ]
0627	Tekno Town 2 [DJ]
0628	Tekno Town Hat [DJ]
0629	Tekno Town Kick [DJ]
0630	Cyber Jazz [DJ]
0631	Blazer 1 [Ind/voc]
0632	Blazer 2 [Ind/voc]
0633	Blazer 3 [Ind/voc]
0634	Cybergenetik 1[Ind/voc]
0635	Cybergenetik 2[Ind/voc]
0636	Cybergenetik 3[Ind/voc]
0637	CyberTek 1 [Ind/voc]
0638	CyberTek 2 [Ind/voc]
0639	CyberTek 3 [Ind/voc]
0640	Junglib 1 [Ind/voc]
0641	Junglib 2 [Ind/voc]
0642	Junglib 3 [Ind/voc]
0643	Metalshop 1 [Ind/voc]
0644	Metalshop 2 [Ind/voc]
0645	Metalshop 3 [Ind/voc]
0646	Noiz Kik+SD [Ind/voc]
0647	Dee Jay [Rap/Gosp]
0648	Elektro 1 [Rap/Gosp]
0649	Elektro 2 [Rap/Gosp]
0650	Eraser Head [Rap/Gosp]
0651	FunkHop 1 [Rap/Gosp]
0652	FunkHop 2 [Rap/Gosp]
0653	Slyvester [Rap/Gosp]
0654	Tekno Boy 1 [Rap/Gosp]
0655	Tekno Boy 2 [Rap/Gosp]
0656	Tekno Boy 3 [Rap/Gosp]
0657	Bellhop Ballad[Rap/Gosp]
0658	Beatbox [Rap/Gosp]
0659	Gamelan Dance[Nu Style]
0660	Dreaming [Nu Style]
0661	Tiger by Tail [Nu Style]
0662	Watching You [Insane]
0663	Breakbeat Jam [Electro]
0664	Suppa'Star [Electro]
0665	Daddy Comes Home [VLoop]
0666	HipHop Droid [Dance]
0667	Tablas 5 [Orch]
0668	Goa Drums [Dance]
0669	Vocoder Ac [All]
0670	Vocoder Android [All]
0671	High End Swing [All]

### Template song

#	Name
P00	Pop/Ballad
P01	Hard Rock
P02	R&B
P03	Jazz
P04	Latin
P05	Reggae
P06	Country
P07	Folk
P08	European Trad.
P09	Orchestral
P10	Techno/Trance
P11	Cool House
P12	Drum'n'Bass
P13	Breakbeat
P14	Deep Chill
P15	Hip Hop/Rap







#	Name	Length
U0225	Bs-Drum n'Bass 4	32
U0226	Bs-Dum Diddy Diddy	32
U0227	Bs-16th Rush	48
U0228	Bs-AFP Bass	16
U0229	Bs-Acid 1	16
U0230	Bs-Acid 2	16
U0231	Bs-Acid 5Step	5
U0232	Bs-Acres of Space	32
U0233	Bs-Always Watching	16
U0234	Bs-Bass Fewnotes	32
U0235	Bs-Bass Pump	32
U0236	Bs-Bass Simple	32
U0237	Bs-Beatbox 1	32
U0238	Bs-Beatbox 2	32
U0239	Bs-Bob Bob Diddit	32
U0240	Bs-BonBon	32
U0241	Bs-Breakbeat Riff	32
U0242	Bs-Bring It On	32
U0243	Bs-Brit Funk	32
U0244	Bs-CJazz	32
U0245	Bs-Chaser	32
U0246	Bs-Chromatical Error	32
U0247	Bs-Contrabasswing	48
U0248	Bs-Cool with Space	32
U0249	Bs-Crysis	32
U0250	Bs-Finger Bass Line	16
U0251	Bs-Finger Funk	32
U0252	Bs-Finger Bass Cool	32
U0253	Bs-Fingering Bass	32
U0254	Bs-Flash	32
U0255	Bs-Front Lick	32
U0256	Bs-Funk	32
U0257	Bs-Funkster	32
U0258	Bs-Funky Asian DJ	32
U0259	Bs-Funky Bass Player	32
U0260	Bs-Funky Line	16
U0261	Bs-Funky Rock	16
U0262	Bs-Funky Tekno	16
U0263	Bs-FunkyEssential	8
U0264	Bs-Future Arpeggio	16
U0265	Bs-Future Tech	8
U0266	Bs-Galinese Octave	16
U0267	Bs-Gamelan Dancer	16
U0268	Bs-Garage Funk Synth	32
U0269	Bs-Gospel Bass Notes	32
U0270	Bs-Gospel Bass NZ	48
U0271	Bs-Gospel Half Time	32
U0272	Bs-Grand Manan Man	32
U0273	Bs-Half Time	32
U0274	Bs-Half a Bass	32
U0275	Bs-Hard Tekno Riff	32
U0276	Bs-Hip Hop	32
U0277	Bs-Homie's Riff	32
U0278	Bs-Hop/Funk	32
U0279	Bs-Idle Bassline	32
U0280	Bs-JPop SlapRiff	32
U0281	Bs-Jacobass	16
U0282	Bs-Jam on Pad Riff	16
U0283	Bs-Jazzy Riff	16
U0284	Bs-Jungle Head	32
U0285	Bs-Kreeper	32
U0286	Bs-Late Night Riff	32
U0287	Bs-Latin 1	32
U0288	Bs-Latin 2	16
U0289	Bs-Legato Dotted	16
U0290	Bs-Long Bass	16
U0291	Bs-LongWlk Swing	48
U0292	Bs-Memento Mori	16
U0293	Bs-Monster BassRiff	32
U0294	Bs-Nanda Bass	16
U0295	Bs-Octave Pattern	16
U0296	Bs-On 2	48
U0297	Bs-One One Five	32
U0298	Bs-Open Funk 1	32
U0299	Bs-Open Funk 2	32

#	Name	Length
U0300	Bs-Opener	32
U0301	Bs-Octave Funk 1	32
U0302	Bs-Octave Funk 2	32
U0303	Bs-Paisley Hip Hop	32
U0304	Bs-Phunky Wah	32
U0305	Bs-Pirate Riff	16
U0306	Bs-Powerful Riff	16
U0307	Bs-Revolution	16
U0308	Bs-Root & Fifth 1	32
U0309	Bs-Root & Fifth 2	32
U0310	Bs-Rough Riff	32
U0311	Bs-Selfish Bass	24
U0312	Bs-Shaman	16
U0313	Bs-Simple BaseBasic	8
U0314	Bs-Skip and a Jumper	32
U0315	Bs-Skip's Jazz Riff	32
U0316	Bs-Skippy Riff	8
U0317	Bs-Slap Bass 1 Notes	32
U0318	Bs-Slap Bass 1 NZ	32
U0319	Bs-Slap Oct 8th notes	32
U0320	Bs-Slap Octaves	16
U0321	Bs-Slap Synth 1234	32
U0322	Bs-Slap Synth 5678	32
U0323	Bs-Slow Rocking	24
U0324	Bs-Smooth Rocking	32
U0325	Bs-Son Of Octaves	16
U0326	Bs-Soul	32
U0327	Bs-Stravy Bass	16
U0328	Bs-Syn Slap	32
U0329	Bs-Sync Legato	16
U0330	Bs-Synth Reggae	32
U0331	Bs-Take a shrt walk	32
U0332	Bs-Tribal	16
U0333	Bs-Tribal Chill	32
U0334	Bs-Twister Dance	16
U0335	Bs-Virus Riff	16
U0336	Bs-Visionary Riff	16
U0337	Bs-Walkin'	48
U0338	Bs-WalkingWalker	48
U0339	Bs-Winter Bass	32
U0340	Bs-Orchestra Bass	16
U0341	Bs-Woodwind Bass	16
U0342	Bs-Orchestra PizzyBass	32
U0343	Bs-1 & 5 Waltz	24
U0344	Bs-3/4 Slow Accent	12
U0345	Bs-Country 1/5 Bass	32
U0346	Bs-12/8 Groove	24
U0347	Bs-Fast pace walk	40
U0348	Syn-WS Velocity Riff	16
U0349	Syn-Breakbeat Riff	16
U0350	Syn-Always Watching	16
U0351	Syn-MONO T1 16th	16
U0352	Syn-8th Chunk	16
U0353	Syn-Follow Octave Lead	16
U0354	Syn-Agressiv Octaves Hit	32
U0355	Syn-4tone Velo Trip	16
U0356	Syn-MONO T1 Octaves	16
U0357	Syn-WS Bounce	48
U0358	Syn-Rough Riff	16
U0359	Syn-Matrix Arp	16
U0360	Syn-Powerful Riff	16
U0361	Syn-Wavestation M50	32
U0362	Syn-Bellhop Chordplay	8
U0363	Syn-Hit D'n'B	32
U0364	Syn-SynHit Riff	32
U0365	Syn-Waveseq Synco Bass	32
U0366	Syn-Tech House	16
U0367	Syn-WS-Saturn	32
U0368	Syn-Octave Bouncer	16
U0369	Syn-Electronic Octaves	32
U0370	Syn-Simple Riff	32
U0371	Syn-Triad Down Echo	32
U0372	Syn-OffBeat Impulse	16
U0373	Syn-MalletRoller	16
U0374	Syn-2tone Velo Trip 1	16

#	Name	Length
U0375	Syn-Throb	16
U0376	Syn-2tone Velo Trip 2	16
U0377	Syn-Groove Zoo	32
U0378	Syn-Chords UP 1 Step	2
U0379	Syn-Christmas	16
U0380	Syn-Skippy Chords Pulse	16
U0381	Syn-Dingaling	8
U0382	Syn-Echo Chords 1	16
U0383	Syn-Echo Chords 2	16
U0384	Syn-Echo Chords 3	16
U0385	Syn-Echo Chords 4	16
U0386	Syn-16th's On2&4	16
U0387	Syn-1/4 Note Chords	16
U0388	Syn-Tekno Ptn	8
U0389	Syn-Trance w/out Root	8
U0390	Syn-Wavesequence 2	16
U0391	Syn-16th Busy Chord	8
U0392	Syn-Vel Wave SQ	16
U0393	Syn-Subtle Riff	16
U0394	Syn-Hold	48
U0395	Syn-ONCE!	4
U0396	Syn-Repeat 1a	16
U0397	Syn-Repeat 1b	16
U0398	Syn-Poly WS100.5.10.15	8
U0399	Syn-Tek Chords	16
U0400	Syn-Simple Comp	16
U0401	Syn-Chord Pultitronik	16
U0402	Syn-Revolution 1	32
U0403	Syn-Trance Comp 1	16
U0404	Syn-Robot Comp	32
U0405	Syn-Long	32
U0406	Syn-Trance Chord	16
U0407	Syn-Chord Pulse w/o T0	16
U0408	Syn-Daddy ChordRiff	16
U0409	Syn-Synchro Pulse	32
U0410	Syn-Too Late Riff	16
U0411	Syn-Revolution 2	32
U0412	Syn-KO Elec Lab.	16
U0413	Syn-Compusonic	16
U0414	Syn-Accent Chords	32
U0415	Syn-Full&Accented	32
U0416	Syn-EuroPop Pulse	16
U0417	Syn-OrchXHit Dance	16
U0418	Syn-JPop ChdRiff	8
U0419	Syn-16Chord Beat	16
U0420	Syn-Groove Riff	16
U0421	Syn-Jazz ChdPulse	16
U0422	Syn-Jumping Synco	32
U0423	Syn-Exp Triad	12
U0424	Syn-Broken Chords	16
U0425	Syn-Stealth Rhythm	8
U0426	Syn-BPM Holder	32
U0427	Syn-Busy Reflective	32
U0428	Syn-1234 only	32
U0429	Syn-4tone Ride	16
U0430	Syn-4tone Trance	16
U0431	Syn-5 6 7 8	32
U0432	Syn-5678 only	32
U0433	Syn-Rhythmic	32
U0434	Syn-Stock Price	8
U0435	Syn-Tingly Riff	16
U0436	Syn-Voices Chords	32
U0437	Syn-WS Arp	16
U0438	Syn-WS Dream	32
U0439	Syn-Pest	16
U0440	Syn-Pod Pulsar	16
U0441	Syn-Perky Vox Riff	16
U0442	Syn-Waveseq Chords	32
U0443	Syn-MONO Brass Hit	16
U0444	Syn-Wavesequence 1	16
U0445	Syn-5tone Climb	8
U0446	Syn-Time & Space	32
U0447	Syn-Long Comp	32
U0448	Syn-5tone Velo Trip 1	16
U0449	Syn-5tone Velo Trip 2	16



#	Name	Length
U0681	Str-Solo Violin Arco	24
U0682	Str-Sostegno	8
U0683	Str-Spacial	32
U0684	Str-Stradivariation	32
U0685	Str-Strappato Triplets	48
U0686	Str-The Rite	32
U0687	Str-Pizzi Riff	32
U0688	Str-Pizzicato	8
U0689	Str-Pizzicatoriental	16
U0690	Str-Simple Pizzy	8
U0691	Str-Largo Pizzicato	32
U0692	Brs-Brass Riff 1	16
U0693	Brs-Brass Riff 2	16
U0694	Brs-Brass Riff 3	16
U0695	Brs-Brass Riff 4	16
U0696	Brs-Brass Riff 5	8
U0697	Brs-Brass Riff 6	32
U0698	Brs-Brass Riff 7	16
U0699	Brs-Brass Riff 8	32
U0700	Brs-Syncorhythm	16
U0701	Brs-TahDah Syncophrase	32
U0702	Brs-Accents	32
U0703	Brs-Brass Stabs	32
U0704	Brs-Brass 12 Bar	24
U0705	Brs-12/8 Accets	48
U0706	Brs-Sfz Hits	32
U0707	Brs-Tongue Stabs	32
U0708	Brs-Brass Riff 9	32
U0709	Brs-Funky Brass	32
U0710	Brs-Controlled Brasses	16
U0711	Brs-Riphrase	32
U0712	Brs-Wonder Brass 8T	6
U0713	Brs-Brazilian	16
U0714	Brs-4 Note for Swing	24
U0715	Brs-And Fire	16
U0716	Brs-Brown's Section	16
U0717	Brs-F.Horn Line	32
U0718	Brs-F.Horn Rhythm	32
U0719	Brs-F.Horns March	16
U0720	Brs-Funky Scat	32
U0721	Brs-Funky Stealth	32
U0722	Brs-Funky Trumpets	32
U0723	Brs-Funky Hop	16
U0724	Brs-Robot Brass	32
U0725	Brs-Swinging Riff	24
U0726	Brs-Take Tuba	32
U0727	Brs-Trombones & Tuba	16
U0728	Brs-Trumpet/Flugel	16
U0729	Brs-Triplet Brass Jump	48
U0730	Brs-Trumpet Melody	48
U0731	Brs-Open Line	48
U0732	Wod-Bassoon Riff	8
U0733	Wod-Bassoon Walk	16
U0734	Wod-Dyna Flute	32
U0735	Wod-Flute Figure	32
U0736	Wod-Flute Line	16
U0737	Wod-Flutes Lines	32
U0738	Wod-Hi Flute 16'	8
U0739	Wod-Flute Modal Riff	32
U0740	Wod-Flute Sect. Long	32
U0741	Wod-Flute Sect. Short	24
U0742	Wod-Pan Chords	16
U0743	Wod-PanFlute Attacks	16
U0744	Wod-Reed the Phrase	16
U0745	Wod-Shakuhachi	48
U0746	Wod-Octave Jump	16
U0747	Wod-Chromatic UP 32t	48
U0748	Orch-Up & Down	32
U0749	Orch-Fast	32
U0750	Orch-Orchestral	32
U0751	Orch-Wood/Strings 1	32
U0752	Orch-Wood/Strings 2	32
U0753	Bel-16th Chord Seq.	32
U0754	Bel-Balinese Meditative	16
U0755	Bel-Bells	16
U0756	Bel-Ceremony Riff	8
U0757	Bel-Chord then Riff	16

#	Name	Length
U0758	Bel-Gamelan Seq.	8
U0759	Bel-HiBellz Relax	32
U0760	Bel-Lucid Riff	16
U0761	Bel-Marimba Jungle	16
U0762	Bel-Mayan	48
U0763	Bel-Reflective Riff	16
U0764	Bel-Spacial Bells	48
U0765	Bel-Strum Bell Cycles	48
U0766	Bel-Thumb Piano	48
U0767	Bel-Tiger Riff	16
U0768	Bel-Tingly Riff	16
U0769	Bel-Random Bell 2 Bars	16
U0770	Malt-Gabrielizm	16
U0771	Malt-Marimba Dual Roll	16
U0772	Malt-Xilophonics	16
U0773	SE-Random	16
U0774	SE-Random Techno	16
U0775	SE-Random Up	32
U0776	SE-Up uP UP	8
U0777	SE-Up uP UPuP uP	8
U0778	SE-3.OctFundamentalSweep	8
U0779	SE-Down Strum	48
U0780	SE-Penta-Fall	32
U0781	SE-Minor3rds U/D	16
U0782	SE-Red Alert	8
U0783	SE-Space Groove	32
U0784	SE-Stormy	48
U0785	SE-Tubular E Major	32
U0786	SE-Wait for it..	48
U0787	SE-Whole Tone D/U	32
U0788	Dr-8 Beat	16
U0789	Dr-Straight	16
U0790	Dr-Basic Rock	32
U0791	Dr-Ghost Beat	32
U0792	Dr-Funk Kit Groove	32
U0793	Dr-SFX Shaman	32
U0794	Dr-Vintage Beat	32
U0795	Dr-SqGarage	32
U0796	Dr-FullForce	32
U0797	Dr-Stinky	32
U0798	Dr-Syncro	32
U0799	Dr-Degree Of Funk	32
U0800	Dr-Boy Bandz	16
U0801	Dr-Nu Style Groove	32
U0802	Dr-TROUBLE Town	16
U0803	Dr-Electro Beat	32
U0804	Dr-Funky MF	32
U0805	Dr-In The Pocket	32
U0806	Dr-Princessa	32
U0807	Dr-King Groove	32
U0808	Dr-16 Beat	32
U0809	Dr-BD/HH/SD 16ths	32
U0810	Dr-BD/HH 16ths	32
U0811	Dr-Jazz Drum	32
U0812	Dr-Jazz Swing	32
U0813	Dr-JazzySidestick	32
U0814	Dr-Easy Rider	32
U0815	Dr-Club Bossa 1	32
U0816	Dr-Club Bossa 2	32
U0817	Dr-R.Box Bossa	16
U0818	Dr-Swing type	48
U0819	Dr-Fast Swing	48
U0820	Dr-Sidestick Groove	32
U0821	Dr-HipHop 1	16
U0822	Dr-HipHop 2	32
U0823	Dr-HipHop FunkPop	32
U0824	Dr-Hook Me Up	16
U0825	Dr-NuHop Groove	32
U0826	Dr-Rap/HipHop	32
U0827	Dr-HipHop Groove	8
U0828	Dr-Psycho Groove	16
U0829	Dr-B.Real Groove	32
U0830	Dr-Acoustic Pop Groove	32
U0831	Dr-Miracle DRUMS	32
U0832	Dr-Drum'n'Bass 1	32
U0833	Dr-Drum'n'Bass 2	32
U0834	Dr-Jump Up D'n'B	32

#	Name	Length
U0835	Dr-House	8
U0836	Dr-Simple House	16
U0837	Dr-House 4on Floor	32
U0838	Dr-Straight House	32
U0839	Dr-Straight 4oF	32
U0840	Dr-Kontemplate	16
U0841	Dr-Remix City	32
U0842	Dr-New Disco 1	16
U0843	Dr-New Disco 2	16
U0844	Dr-25step Garage	32
U0845	Dr-Bodhran	12
U0846	Dr-EL DUGAN	32
U0847	Dr-Ireland	36
U0848	Dr-Raga-matic	48
U0849	Dr-Tricki Groove	32
U0850	Dr-Triky	32
U0851	Dr-Tude	32
U0852	Dr-Urban	32
U0853	Dr-Spare Me	32
U0854	Dr-Vocoder Ac Loop	32
U0855	Dr-Vocoder Android	32
U0856	Dr-Wild Rock Groove	32
U0857	Dr-DJ/BeatBox Groove	16
U0858	Dr-Vinyl Shaker	16
U0859	Dr-Vinyl Tabla Riff	16
U0860	Dr-Vinyl Tamb loop	8
U0861	Dr-Vinyl Disco	16
U0862	Dr-Woodland	32
U0863	Dr-HighEnd Groove	16
U0864	Dr-Higher Groove	32
U0865	Dr-Mayan Perc Groove	32
U0866	Dr-Ethnic Dance Perc.	48
U0867	Dr-Mixed Perc.	32
U0868	Dr-Percussions	32
U0869	Dr-Hook Up Perc./Vox	16
U0870	Dr-Misc. Perc. Groove	8
U0871	Dr-Chinese Percussions	32
U0872	Dr-AFRICATHUNDR	32
U0873	Dr-African Stomp	48
U0874	Dr-Djembalia	32
U0875	Dr-Tribal Think	32
U0876	Dr-Tablature	48
U0877	Dr-Delicatessen	32
U0878	Dr-Tablas + BD	32
U0879	Dr-Brazilian Groove	16
U0880	Dr-Perc/Latin	32
U0881	Dr-Cuban Clave Groove	16
U0882	Dr-Conga Vari Groove	16
U0883	Dr-Conga & Djembe	32
U0884	Dr-Conga & Shaker	32
U0885	Dr-Jaw Harp Pattern	32
U0886	Dr-Udu Pattern	32
U0887	Dr-Marktree	48
U0888	Dr-Orch.BD & Snare	32
U0889	Dr-Orch.Perc.1	48
U0890	Dr-Orch.Perc.2	16
U0891	Dr-Orch.Perc.3	32
U0892	Dr-Orch.Perc.4	32
U0893	Dr-Orch.Perc.5	48
U0894	Dr-Orch.Perc.6	32
U0895	Dr-Orch.Army	32
U0896	Dr-Slow March	16
U0897	Dr-Military March BD&SD	32
U0898	Dr-Copland TIMPANI	32
U0899	Dr-Timpani Roll	24

## Multisample

## ROM mono

#	Name	#	Name	#	Name	#	Name
0000	Acoustic Piano mp -L	0073	E.Organ-Gospel	0146	DoubleReed	0219	Voice-Male Dah
0001	Acoustic Piano mp -R	0074	E.Organ-Full	0147	Oboe p	0220	Voice-Doo
0002	Acoustic Piano mf -L	0075	E.Organ-Perc. 2	0148	Oboe f	0221	Voice-Wave
0003	Acoustic Piano mf -R	0076	E.Organ-Perc. 3rd	0149	English Horn	0222	Violin
0004	Acoustic Piano f -L	0077	E.Organ-Distortion	0150	Bassoon	0223	Violin-Vibrato
0005	Acoustic Piano f -R	0078	E.Organ-16'+5 1/3'	0151	Soprano Saxophone mf	0224	Viola
0006	Piano Tailpiece -L	0079	E.Organ-F Click	0152	Soprano Saxophone f	0225	Cello
0007	Piano Tailpiece -R	0080	E.Organ-Vox 1	0153	Soprano Saxophone-Growl	0226	Contrabass & Cello
0008	Acoustic Piano Mono	0081	E.Organ-Vox 2	0154	Alto Saxophone 1 mf	0227	Strings Quartet
0009	A.Piano-SG	0082	Positive Organ 1	0155	Alto Saxophone 1 f	0228	Strings Quartet-Vibrato1
0010	A.Piano-M1	0083	Positive Organ 2	0156	Alto Saxophone 1-Growl	0229	Strings Quartet-Vibrato2
0011	Electric Grand Piano	0084	Pipe Organ-Tuentiana	0157	Alto Saxophone 2	0230	Strings Ensemble 1 -L
0012	E.Piano-Suit Bright mp	0085	Pipe Organ-Reed	0158	Tenor Saxophone mf	0231	Strings Ensemble 1 -R
0013	E.Piano-Suit Bright mf	0086	Pipe Organ-Mixture 1	0159	Tenor Saxophone f	0232	Strings Ensemble 2
0014	E.Piano-Suit Bright f	0087	Pipe Organ-Mixture 2	0160	Tenor Saxophone-Growl	0233	Tape Strings Ensemble
0015	E.Piano-Suit Dark mp	0088	Pipe Organ-Full	0161	Baritone Saxophone mf	0234	Cello & Violin Ensemble
0016	E.Piano-Suit Dark mf	0089	Kalimba	0162	Baritone Saxophone f	0235	Strings Ensemble-Tremolo
0017	E.Piano-Suit Dark f	0090	Kalimba-Mute	0163	Baritone Saxophone-Growl	0236	Erhu-Vibrato
0018	E.Piano-Suit Soft	0091	Music Box 1	0164	Saxophone-Vibrato	0237	Pizzicato
0019	E.Piano-Suit Hard	0092	Music Box 2	0165	Musette	0238	Pizzicato Ensemble
0020	E.Piano-Suit Pure mp	0093	Marimba	0166	Accordion	0239	Nylon Guitar 1 p
0021	E.Piano-Suit Pure mf	0094	Xylophone 1 p	0167	Bandoneon	0240	Nylon Guitar 1 mf
0022	E.Piano-Suit Pure f	0095	Xylophone 1 mf	0168	Accordion 4'	0241	Nylon Guitar 1 f
0023	E.Piano-Suit Pure ff	0096	Xylophone 1 f	0169	Harmonica	0242	Ac.Steel Guitar-Pick p
0024	E.Piano-Stage Soft	0097	Xylophone 2	0170	Bagpipe	0243	Ac.Steel Guitar-Pick mf
0025	E.Piano-Stage Hard	0098	Xylophone 3	0171	Bagpipe & Drone	0244	Ac.Steel Guitar-Pick f
0026	E.Piano-Dyno 1 Soft	0099	Balaphone	0172	Uilleann Pipe	0245	Ac.Resonator Guitar
0027	E.Piano-Dyno 1 Medium	0100	Log Drum	0173	Trumpet mp	0246	Ac.12 Strings Guitar
0028	E.Piano-Dyno 1 Hard	0101	Vibraphone 1	0174	Trumpet ff	0247	El.Guitar Clean 1
0029	E.Piano-Dyno 2 Soft	0102	Vibraphone 2	0175	Trumpet Slow mp	0248	El.Guitar Clean 2 mf
0030	E.Piano-Dyno 2 Medium	0103	Celesta	0176	Trumpet Slow ff	0249	El.Guitar Clean 2 f
0031	E.Piano-Dyno 2 Hard	0104	Glockenspiel 1	0177	Trumpet-Overblown	0250	El.Guitar Clean 2-Slap
0032	E.Piano-Wurly 1 mp	0105	Glockenspiel 2	0178	Trumpet-Cup	0251	El.Guitar Clean 3-Stra
0033	E.Piano-Wurly 1 mf	0106	Tubular Bell	0179	Piccolo Trumpet	0252	El.Guitar Clean 3-Tele
0034	E.Piano-Wurly 1 f	0107	VPM Tubular	0180	Trumpet Tonguing mp	0253	El.Guitar Clean 4 p
0035	E.Piano-Wurly 2 mp	0108	Steel Drum mf	0181	Trumpet Tonguing ff	0254	El.Guitar Clean 4 f
0036	E.Piano-Wurly 2 mf	0109	Steel Drum f	0182	Trumpet Vibrato	0255	El.Guitar Clean 5 p
0037	E.Piano-Wurly 2 f	0110	Gamelan	0183	Trombone 1 mf	0256	El.Guitar Clean 5 f
0038	E.Piano-Wurly 2 ff	0111	Metal VPM Bell	0184	Trombone 1 ff	0257	El.Guitar Clean 6-Prkr
0039	E.Piano-VPM 1 mf	0112	Finger Cymbal	0185	Trombone 2	0258	El.Guitar Funky 1-Stra
0040	E.Piano-VPM 1 f	0113	VPM Solar	0186	Trombone-Muted	0259	El.Guitar Funky 2-Prkr
0041	E.Piano-VPM 1 ff	0114	Ensemble Bell	0187	Trombone Vibrato	0260	El.Guitar Jazz
0042	E.Piano-VPM 2	0115	VPM Glass Bell	0188	French Horn	0261	El.Guitar Muted 1 p
0043	E.Piano-VPM 3 mf	0116	VPM Pluck	0189	Tuba f	0262	El.Guitar Muted 1 mp
0044	E.Piano-VPM 3 f	0117	Glass Bell	0190	Tuba ff	0263	El.Guitar Muted 2
0045	E.Piano-VPM 3 ff	0118	Bottle Pop	0191	Trumpet-Fall	0264	El.Guitar Muted 3
0046	E.Piano-VPM 4	0119	Piccolo	0192	Trombone Fall	0265	Pedal Steel Guitar
0047	E.Piano Pad	0120	Flute	0193	Trombone SlurUp	0266	El.Guitar Harmonics
0048	Clavi 1	0121	Flute-Vibrato	0194	French Horn Ensemble	0267	El.Guitar Harmonics 32'
0049	Clavi 2	0122	Flute Jazz-Vibrato	0195	2 Trombones mf	0268	El.Guitar Dead
0050	Clavi 3	0123	Flute-Flutter Tonguing	0196	2 Trombones f	0269	El.Guitar OverDrive
0051	Clavi 4	0124	Flute-Voice	0197	Brass Ensemble 1 -L	0270	El.Guitar-Fret Noise 1
0052	Clavi-AC mf	0125	Flute-Attack p	0198	Brass Ensemble 1 -R	0271	El.Guitar Distortion1 mf
0053	Clavi-AC ff	0126	Flute-Attack f	0199	Brass Ensemble 2	0272	El.Guitar Distortion1 f
0054	Clavi-AD mf	0127	3 Flutes	0200	Brass Ensemble 3	0273	El.Guitar Distortion 2
0055	Clavi-AD ff	0128	Tape Flute	0201	Brass Ensemble 4 -L	0274	El.Guitar Distortion 3
0056	Clavi-BC mf	0129	Pan Flute	0202	Brass Ensemble 4 -R	0275	El.Guitar PickHarmonics1
0057	Clavi-BC ff	0130	Pan Flute-Attack	0203	Voice-Pop Ooh	0276	El.Guitar PickHarmonics2
0058	Clavi-BD mf	0131	Tin Whistle	0204	Voice-Pop Ooh LP	0277	El.Guitar DistMuted p
0059	Clavi-BD ff	0132	Tin Whistle-Voice	0205	Voice-Gospel Ah	0278	El.Guitar DistMuted mp
0060	Clavi 2-Muted	0133	Tin Whistle-Attack	0206	Voice-Pop Ah	0279	El.Guitar PowerChord 1
0061	Clavi 3-Muted	0134	Shakuhachi	0207	Voice-Choir	0280	El.Guitar PowerChord 2
0062	Clavi 4-Muted	0135	Shakuhachi-Attack	0208	Voice-Choir LP	0281	Ac.Steel Gtr-Pick p VAR
0063	Harpsichord-Single	0136	Nay	0209	Voice-Hoo	0282	Ac.Steel Gtr-Pick mf VAR
0064	Harpsichord-Double	0137	Bottle	0210	Voice-Yah	0283	Ac.Steel Gtr-Pick f VAR
0065	Harpsichord-Keyoff	0138	Bottleizer	0211	Voice-Eeh	0284	Ac.Resonator Guitar VAR
0066	E.Organ-Perc/Jazz 1	0139	Ocarina 1	0212	Voice-Female Wuuh	0285	Ac.12 Strings Guitar VAR
0067	E.Organ-Perc/Jazz 2	0140	Ocarina 2	0213	Voice-Female Woh	0286	El.Guitar Clean 1 VAR
0068	E.Organ-Perc. 1	0141	Native American Flute	0214	Voice-Female Wah	0287	El.Guitar Clean 2 mf VAR
0069	E.Organ-M1	0142	Recorder	0215	Voice-Female Dah	0288	El.Guitar Clean 2 f VAR
0070	E.Organ-N1	0143	Clarinet	0216	Voice-Male Wuh	0289	El.Gtr Clean 2-Slap VAR
0071	E.Organ-CX-3	0144	Bass Clarinet 1	0217	Voice-Male Woh	0290	El.Gtr Clean 3-Stra VAR
0072	E.Organ-Perc.2nd	0145	Bass Clarinet 2	0218	Voice-Male Wah	0291	El.Gtr Clean 3-Tele VAR

#	Name	#	Name	#	Name	#	Name
0292	El.Guitar Clean 4 p VAR	0365	Bass/Lead-MG	0438	Syn-Zingle	0511	VS88
0293	El.Guitar Clean 4 f VAR	0366	Bass/Lead-800DV 1	0439	Twinkler	0512	VS89
0294	El.Guitar Clean 5 p VAR	0367	Bass/Lead-800DV 2	0440	WaveSweep	0513	VS100
0295	El.Guitar Clean 5 f VAR	0368	SynLead-MG 1	0441	WaveSweep A	0514	VS109
0296	El.Gtr Clean 6-Prkr VAR	0369	SynLead-MG 2	0442	WaveSweep B	0515	VS111
0297	El.Gtr Funky 1-Stra VAR	0370	SynLead-Pro5	0443	PingPong Rez.Noise	0516	VS115
0298	El.Gtr Funky 2-Prkr VAR	0371	SynLead-700S 1	0444	Air Noise	0517	VS116
0299	El.Guitar Jazz VAR	0372	SynLead-700S 2	0445	Pole	0518	VS118
0300	El.Guitar Muted 1 p VAR	0373	SynLead-Poly6	0446	Xylo-Spectrum	0519	VS120
0301	El.Guitar Muted 1 mp VAR	0374	SynComp-Poly6	0447	Syn-FX02Z	0520	OBSAW3
0302	Acoustic Bass mp	0375	Bs/Lead-MG Rez 1	0448	TunRhythmix	0521	13-01
0303	Acoustic Bass mf	0376	Bs/Lead-MG Rez 2	0449	Syn-Clicker	0522	13-03i
0304	Acoustic Bass f	0377	Bass/Lead-M/poly	0450	Soft EP	0523	13-05i
0305	Acoustic Bass Noise a	0378	Bass/Lead-Dance	0451	Hard EP	0524	13-09
0306	Acoustic Bass Noise b	0379	Bass/Lead-DSP	0452	EP Tine	0525	resx001
0307	El.Bass-Finger 1	0380	Bs/Lead-DSPMetal	0453	EP Body1	0526	resx002
0308	El.Bass-Finger 2	0381	Syn-Phone Square	0454	EP Body2	0527	resx003
0309	El.Bass-Finger 3 PB	0382	Syn-Dist.Bs/Lead	0455	EP Body3	0528	resx004
0310	El.Bass-Finger 4	0383	Sync Wave 1	0456	Digi EP	0529	resx005
0311	El.Bass-Finger 5	0384	Sync Wave 2	0457	E_PIANO	0530	resx006
0312	El.Bass-Pick 1 SG	0385	Sync Wave 3	0458	CLAV_DSM	0531	resx007
0313	El.Bass-Pick 2 PB	0386	Sync	0459	Organ 1	0532	resx008
0314	El.Bass-Slap 1	0387	Sync-Comp	0460	Organ 2	0533	resx009
0315	El.Bass-Slap 2	0388	Syn-MS2K Sync	0461	Organ 3	0534	resx010
0316	El.Bass-Slap 3 SG	0389	Syn-M/Poly Sync	0462	Agogo	0535	resx011
0317	El.Bass-Slap 4 JB	0390	Syn Bass-Dist	0463	Crystal	0536	resx012
0318	El.Bass-Slap 5	0391	Syn Bass-Acid	0464	Thai Mrmba	0537	resx013
0319	Fretless Bass 1	0392	Syn Bass-Mpoly	0465	FluteTrans	0538	resx014
0320	Fretless Bass 2	0393	Klub Bass	0466	Bottle WS	0539	resx015
0321	El.Bass-Fret Noise	0394	Syn Bass-VPM	0467	SynString	0540	resx016
0322	Acoustic Bass mp VAR	0395	Knock Bass	0468	Voices	0541	resx017
0323	Acoustic Bass mf VAR	0396	Syn-Dark Bass	0469	Choir	0542	resx018
0324	Acoustic Bass f VAR	0397	Syn-ResBass 1	0470	ChromRes	0543	resx019
0325	El.Bass-Finger 1 VAR	0398	Syn-ResBass 2	0471	Tambourine	0544	resx020
0326	El.Bass-Finger 2 VAR	0399	Antic Bass	0472	Spectrm1	0545	resx021
0327	El.Bass-Finger 3 PB VAR	0400	Analog Strings 1	0473	Spectrm2	0546	resx022
0328	El.Bass-Finger 4 VAR	0401	Analog Strings 1 LP	0474	Spectrm3	0547	resx023
0329	El.Bass-Finger 5 VAR	0402	Analog Strings 2	0475	Spectrm4	0548	resx024
0330	El.Bass-Pick 1 SG VAR	0403	Brass-Pad	0476	Sonar	0549	resx025
0331	El.Bass-Pick 2 PB VAR	0404	Synth Brass	0477	KalimbaTR	0550	resx026
0332	El.Bass-Slap 1 VAR	0405	Detuned-Super 1	0478	GamelanTR	0551	resx027
0333	El.Bass-Slap 2 VAR	0406	Detuned-Super 1 LP	0479	MarimbaTR	0552	resx028
0334	El.Bass-Slap 3 SG VAR	0407	Detuned-Super 2	0480	Ticker	0553	resx029
0335	El.Bass-Slap 4 JB VAR	0408	POWER SAW	0481	Inharm1	0554	resx030
0336	El.Bass-Slap 5 VAR	0409	Detuned-Lead	0482	Inharm2	0555	resx031
0337	Fretless Bass 1 VAR	0410	Detuned-Quiet	0483	Inharm3	0556	resx032
0338	Fretless Bass 2 VAR	0411	StrEns-Slina	0484	Inharm4	0557	Min1-01a
0339	Sitar 1	0412	SynEns-A2600	0485	Inharm5	0558	Min1-02a
0340	Sitar 1 & Tambura	0413	Detuned-PWM	0486	Inharm6	0559	Min1-04a
0341	Sitar 2	0414	Detuned-PWM LP	0487	Inharm7	0560	Min1-05a
0342	Sitar 2 & Tambura	0415	Flag Pad	0488	Inharm8	0561	Min1-06a
0343	Bouzouki	0416	White Pad	0489	Inharm9	0562	Min1-07a
0344	Santur	0417	Glass Vox	0490	Inharm10	0563	Min1-08a
0345	Mandolin	0418	Syn-Air Vox	0491	Formant1	0564	Min1-09a
0346	Mandolin-Tremolo	0419	Vocoder-VP	0492	Formant2	0565	Min1-12a
0347	Oud 1	0420	Syn-Vocalscape	0493	Formant3	0566	Min1-13a
0348	Oud 2	0421	Syn-Ghostly	0494	Formant4	0567	Pres321
0349	Banjo	0422	Syn-Flute Pad	0495	Formant5	0568	Pres335
0350	Shamisen	0423	Cymbal Flute	0496	Formant6	0569	Pres349
0351	Koto	0424	ChoralMultitapped Flutes	0497	Formant7	0570	Pres363
0352	Harp	0425	Ghost	0498	Sine WS	0571	Pres377
0353	Harp-Harmonics	0426	SFX-Noise Spectra	0499	VS36	0572	Pres384
0354	DarkReso-MG	0427	Cricket Spectrum	0500	VS37	0573	Pres391
0355	SynDark-MG	0428	Noise Pad	0501	VS38	0574	Pres398
0356	SynReso-MG 1	0429	Rez Noize Pad	0502	VS42	0575	Pres110
0357	SynReso-MG 2	0430	Lore Pad	0503	VS44	0576	Pres3112
0358	ResoSquare-SH	0431	Noise Spectrum	0504	VS48	0577	Pres3119
0359	SynReso-A2600	0432	Noise 1	0505	VS49	0578	Pres3126
0360	SynReso-Pro5_1	0433	Swish Terra	0506	VS50	0579	MagicOrgan
0361	SynReso-Pro5_2	0434	Spectone	0507	VS58	0580	MagicOrgan LP
0362	SynReso-Poly6_1	0435	Spectraslicer	0508	VS66	0581	Noise 2
0363	SynReso-Poly6_2	0436	Dissonance	0509	VS69	0582	SynthPad
0364	SynArpg-Pro5	0437	Syn-Palawan	0510	VS86	0583	SynthPad LP

## Voice Name List

#	Name	#	Name	#	Name	#	Name
0584	AirSynth	0661	SawUp-Pro5	0738	Orch Hit 6	0815	Voice 15
0585	VoiceSyn	0662	SawUp-MG	0739	Orch Hit 7	0816	Voice 16
0586	VoiceSyn LP	0663	SawDown-MG	0740	Impact Hit	0817	Voice 17
0587	BellWind	0664	SawUp-A2600	0741	Orch Hits	0818	Voice 18
0588	TrashWave	0665	SawDown-A2600	0742	Band Hit 1	0819	Voice 19
0589	PsychoWave	0666	SawUp-MX12	0743	Band Hit 2	0820	Voice 20
0590	MiniBass	0667	SawDown-MX12	0744	Jazz Hit 1	0821	Voice 21
0591	Fretless	0668	Saw-EXB	0745	Jazz Hit 2	0822	Voice 22
0592	PanFlute	0669	Rez Saw-EXB	0746	Jazz Hit 3	0823	Voice 23
0593	Harmonium	0670	Pulse-08%	0747	Brass Fall	0824	Voice 24
0594	HrdKalimba	0671	Pulse-33%	0748	Dance Hit	0825	Voice 25
0595	SofKalimba	0672	Pulse-40%	0749	Band Hits	0826	Voice 26
0596	SofKalimba LP	0673	Pulse 10%-Pro5	0750	Organ Hit	0827	Voice 27 "Ha"
0597	Tom WS	0674	Pulse 20%-Pro5	0751	Dance Hits	0828	Voice 28 "Funky"
0598	HiHat Clos	0675	Pulse 30%-Pro5	0752	House Hits	0829	Voice 29 "Yeah"
0599	HiHat Open	0676	Pulse 40%-Pro5	0753	VibeChord	0830	Voice 30 "Bang"
0600	Pot Hit	0677	Pulse 10%-MX12	0754	W.E.P.Chord	0831	Voice 31 "Ahhh"
0601	VS131	0678	Pulse 20%-MX12	0755	Synth Hit Loop 1	0832	Voice 32 "Ooooh"
0602	VS132	0679	Pulse 35%-MX12	0756	Synth Hit Loop 2	0833	Voice 33 "Hrrrr"
0603	Gated Kick	0680	Pulse 20%-OB	0757	Synth Hit Loop 3	0834	Voice 34 "Trrrr"
0604	Gated SD	0681	Pulse 35%-OB	0758	Synth Hit Loop 4	0835	Voice 35 "Aow"
0605	SynthHat C	0682	Pulse-EXB	0759	Synth Hit Loop 5	0836	Voice 36 "TurnAround"
0606	SynthHat O	0683	Square	0760	Synth Hit Loop 6	0837	Voice 37 "Well"
0607	Tri Closed	0684	Square-MG3	0761	Synth Hit Loop 7	0838	Voice 38 "Turnin'Up"
0608	SRide	0685	Sqr-mMG	0762	Synth Hit Decay 1	0839	Voice 39 "Uuh"
0609	Claves	0686	Square-A2600	0763	Synth Hit Decay 2	0840	Voice 40 "Com'On"
0610	Woodblock	0687	Square-JP	0764	Synth Hit Decay 3	0841	Voice 41 "Yah"
0611	Log Drum WS	0688	Square-MX12	0765	Synth Hit Decay 4	0842	Voice 42 "Oohh"
0612	SynthCow	0689	Square-OB	0766	Vinyl Hit 1	0843	Voice 43 "Go"
0613	Spike	0690	Square-EXB	0767	Vinyl Hit 2	0844	Voice 44
0614	Gated Hit	0691	Saw+Sqr-EXB	0768	Scratch Hi	0845	Voice 45
0615	Agogo Loop	0692	Triangle-MG3	0769	Zap 1	0846	Voice 46
0616	LogDrumLoop	0693	Triangle-MG	0770	Zap 2	0847	Voice 47
0617	Wdblk Loop	0694	Triangle-EXB	0771	BD-Cannon	0848	Voice 48
0618	Tri O loop	0695	Ramp	0772	Industry Hit 01	0849	Vocoder Voice 01
0619	Amb Tom	0696	Ramp-mMG	0773	Industry Hit 02	0850	Vocoder Voice 02
0620	Big Hit	0697	Parabolic	0774	Industry Hit 03	0851	Vocoder Voice 03
0621	ShakerLoop	0698	Sine	0775	Industry Hit 04	0852	Vocoder Voice 04
0622	MiniBas1	0699	Sine-01/W	0776	Industry Hit 05	0853	Vocoder Voice 05
0623	MiniBas2	0700	Sine-JP	0777	Industry Hit 06	0854	Vocoder Voice 06
0624	MiniBas3	0701	Sine-MG	0778	Industry Hit 07	0855	Vocoder Voice 07
0625	X Bass	0702	Sine-EXB	0779	Industry Hit 08	0856	Vocoder Voice 08
0626	EtherBell	0703	DWGS-Syn Sine 1	0780	Industry Hit 09	0857	Vocoder Voice 09
0627	FreqShf1	0704	DWGS-Syn Sine 2	0781	Industry Hit 10	0858	Vocoder Voice 10
0628	FreqShf2	0705	DWGS-E.P.1	0782	Industry Hit 11	0859	Vocoder Voice 11
0629	FreqShf3	0706	DWGS-E.P.2	0783	Industry Hit 12	0860	Vocoder Voice 12
0630	StratPluck	0707	DWGS-E.P.3	0784	Industry Hit 13	0861	Vocoder Voice 13
0631	Down Zap	0708	DWGS-E.P.4	0785	Industry Hit 14	0862	Vocoder Voice 14
0632	Up&DownZap	0709	DWGS-E.P.5	0786	Industry Hit 15	0863	Vocoder Voice 15
0633	Cesium	0710	DWGS-Organ 1	0787	Industry Hit 16	0864	Vocoder Voice 16
0634	Cobalt	0711	DWGS-Organ 2	0788	Industry Hit 17	0865	Vocoder Voice 17
0635	Krypton	0712	DWGS-Organ 3	0789	Industry Hit 18	0866	Vocoder Voice 18
0636	Xenon	0713	DWGS-Organ 4	0790	Industry Hit 19	0867	Vocoder Voice 19
0637	WavMlt 1	0714	DWGS-Organ 5	0791	Industry Hit 20	0868	Vocoder Voice 20
0638	WavMlt 2	0715	DWGS-Accordion	0792	Industry Hit 21	0869	CompuVoice-BEEP
0639	WavMlt 3	0716	DWGS-Guitar 1	0793	Industry Hit 22	0870	CompuVoicd-Noise
0640	WavMlt 4	0717	DWGS-Guitar 2	0794	Industry Hit 23	0871	CompuVoicd-Chi
0641	WavMlt 5	0718	DWGS-Bell 1	0795	Industry Hit 24	0872	CompuVoicd-Do it
0642	WavMlt 6	0719	DWGS-Bell 2	0796	Industry Hit 25	0873	PC Voice 1-01 "Two"
0643	WavMlt 7	0720	DWGS-Bell 3	0797	Industry Hit 26	0874	PC Voice 1-02 "Five"
0644	WavMlt 8	0721	DWGS-Bell 4	0798	Industry Loop 1	0875	PC Voice 1-03
0645	WavMlt 9	0722	DWGS-Clav 1	0799	Industry Loop 2	0876	PC Voice 1-04
0646	WavMlt10	0723	DWGS-Clav 2	0800	Industry Loop 3	0877	PC Voice 1-05
0647	WavMlt11	0724	DWGS-Clav 3	0801	Voice 01	0878	Coin Thwack
0648	VoxFmt 1	0725	DWGS-Digi 1	0802	Voice 02	0879	Meditation Tree
0649	VoxFmt 2	0726	DWGS-Digi 2	0803	Voice 03	0880	G-BALL
0650	Res 1-1	0727	DWGS-Digi 3	0804	Voice 04	0881	Ac.Gtr Chord Hit 1
0651	Res 2-1	0728	DWGS-Wire 1	0805	Voice 05	0882	Ac.Gtr Ghost Hit 2
0652	Res 2-2	0729	DWGS-Wire 2	0806	Voice 06	0883	Ac.Gtr Ghost Hit 3
0653	Res 2-3	0730	DWGS-Sync 1	0807	Voice 07	0884	Ac.Gtr Ghost Hit-Slide
0654	Res 2-4	0731	DWGS-Sync 2	0808	Voice 08	0885	El.Gtr Chord Hit
0655	Res 2-5	0732	DWGS-Sync 3	0809	Voice 09	0886	El.Gtr-Glissando Down 1
0656	Res 2-6	0733	Orch Hit 1	0810	Voice 10	0887	El.Gtr-Glissando Down 2
0657	Res 2-7	0734	Orch Hit 2	0811	Voice 11	0888	El.Gtr-Glissando Down 3
0658	Saw	0735	Orch Hit 3	0812	Voice 12	0889	El.Gtr-Glissando Down 4
0659	Saw-MG3	0736	Orch Hit 4	0813	Voice 13	0890	El.Gtr-Glissando Up 1
0660	Saw-Chroma	0737	Orch Hit 5	0814	Voice 14	0891	El.Gtr-Glissando Up 2



#	Name
0892	El.Gtr-Glissando Up 3
0893	Vox-Wah Gtr
0894	El.Gtr-ChordGhost Down 1
0895	El.Gtr-ChordGhost Down 2
0896	El.Gtr-ChordGhost Down 3
0897	El.Gtr-ChordGhost Down 4
0898	El.Gtr-ChordGhost Down 5
0899	El.Gtr-ChordGhost Down 6
0900	El.Gtr-ChordGhost Up 1
0901	El.Gtr-ChordGhost Up 2
0902	El.Gtr-ChordGhost Up 3
0903	El.Gtr-ChordGhost Up 4
0904	El.Gtr-ChordGhost Up 5
0905	El.Gtr-ChordGhost Up 6
0906	El.Gtr-ChordGhost Up 7
0907	Gt.Cut Noise 1
0908	Gt.Cut Noise 2
0909	El.Gtr-Dead Note 1
0910	El.Gtr-Dead Note 2
0911	El.Gtr-DistSlideDown 1
0912	El.Gtr-DistSlideDown 2
0913	El.Gtr-DistScratchDown
0914	El.Gtr-DistMuted a
0915	El.Gtr-DistMuted b
0916	El.Gtr-DistMuted c
0917	El.Gtr-DistGhost 1 a
0918	El.Gtr-DistGhost 1 b
0919	El.Gtr-DistGhost 2 a
0920	El.Gtr-DistGhost 2 b
0921	El.Gtr-DistGhost 3 a
0922	El.Gtr-DistGhost 3 b
0923	El.Gtr-DistGhost 4 a
0924	El.Gtr-DistGhost 4 b
0925	El.Gtr-DistGhost 5 a
0926	El.Gtr-DistGhost 5 b
0927	El.Gtr-DistFretNoise 1 a
0928	El.Gtr-DistFretNoise 1 b
0929	El.Gtr-DistFretNoise 2 a
0930	El.Gtr-DistFretNoise 2 b
0931	El.Gtr-DistFretNoise 2 c
0932	El.Gtr-DistFretNoise 2 d
0933	Ac.Bs-Slide Up&Down 1
0934	Ac.Bs-Slide Up&Down 2
0935	Ac.Bs-Slide Up&Down 3
0936	Ac.Bs-Slide Down 1
0937	Ac.Bs-Slide Down 2
0938	Ac.Bs-Slide Down 3
0939	Ac.Bs-Slide Down 4
0940	Ac.Bs-Slide Up
0941	Ac.Bs-BumpThud 1
0942	Ac.Bs-BumpThud 2
0943	Ac.Bs-DeadNote 1
0944	Ac.Bs-DeadNote 2
0945	Ac.Bs-DeadPizz 1
0946	Ac.Bs-DeadPizz 2
0947	Ac.Bs-DeadPizz 3
0948	Ac.Bs-SlapTouch 1
0949	Ac.Bs-SlapTouch 2
0950	Ac.Bs-SlapTouch 3
0951	Ac.Bs-SlapTouch 4
0952	Ac.Bs-SlapTouch 5
0953	Ac.Bs-String Slap
0954	El.Bs-Slide Up&Down 1
0955	El.Bs-Slide Up&Down 2
0956	El.Bs-Slide Up&Down 3
0957	El.Bs-Slide Down 1
0958	El.Bs-Slide Down 2
0959	El.Bs-Slide Down 3
0960	El.Bs-SlapGhostSlide 1
0961	El.Bs-SlapGhostSlide 2
0962	El.Bs-SlapGhostSlide 3
0963	El.Bs-Fret Noise 1
0964	El.Bs-Fret Noise 2
0965	El.Bs-Fret Noise 3
0966	El.Bs-SlapGhostNote 01
0967	El.Bs-SlapGhostNote 02
0968	El.Bs-SlapGhostNote 03

#	Name
0969	El.Bs-SlapGhostNote 04
0970	El.Bs-SlapGhostNote 05
0971	El.Bs-SlapGhostNote 06
0972	El.Bs-SlapGhostNote 07
0973	El.Bs-SlapGhostNote 08
0974	El.Bs-SlapGhostNote 09
0975	El.Bs-SlapGhostNote 10
0976	El.Bs-SlapGhostNote 11
0977	Stadium
0978	Applause
0979	Scream
0980	Laughing
0981	Footstep 1
0982	Footstep 2
0983	Bird 1
0984	Bird 2
0985	Dog
0986	Gallop
0987	Crickets
0988	Heart Beat
0989	Punch
0990	Tribe
0991	Sword 1
0992	Sword 2
0993	Glass Crash
0994	Rainstick 1a
0995	Rainstick 1b
0996	Rainstick 2
0997	Ice Drop
0998	Door Creak
0999	Door Slam
1000	Car Engine
1001	Car Stop
1002	Car Pass
1003	Car Crash
1004	Train
1005	Railroad Crossing
1006	Helicopter
1007	Fireworks
1008	Gun Shot
1009	Rifle Shot
1010	Machine Gun
1011	Laser Gun
1012	Cannon 1
1013	Cannon 2
1014	Cannon 3
1015	Explosion
1016	Thunder
1017	Wind
1018	Stream
1019	Jungle
1020	Wet Jungles
1021	Forest
1022	Bubble
1023	ChurchBell
1024	ChurchBell REV
1025	Sleigh Bell
1026	Old Telephone-Ring
1027	Old Telephone-Ring REV
1028	Telephone-Call
1029	Telephone-Ring
1030	Telephone-Busy
1031	Bull Roar
1032	BD-Orchestral
1033	BD-Crunk
1034	BD Dance 55
1035	BD Dance 62
1036	BD Dance 63
1037	BD Dance 71
1038	BD Dance 72
1039	Timpani MAP1 mf
1040	Timpani MAP1 ff
1041	Timpani MAP2 mf
1042	Timpani MAP2 ff
1043	Timpani MAP3 mf
1044	Timpani MAP3 ff
1045	Timpani-Roll mf

#	Name
1046	Timpani-Roll ff
1047	Taiko
1048	Tom
1049	Tom-Reverb Lo
1050	Tom-Reverb Hi
1051	Tom-Processed
1052	Tom-Brush
1053	Real E.Tom
1054	88-Tom
1055	Dance Perc 03-Open
1056	Syn-Conga
1057	Orchestral Cymbal-Open
1058	Orchestral Cymbal-Closed
1059	Crash Cymbal 1 f
1060	Crash Cymbal 5 mf
1061	Crash Cymbal 6 mf
1062	Crash Cymbal 8
1063	Crash Cymbal 9
1064	Crash Dance 4
1065	Ride Cymbal 3 mp
1066	Ride Cymbal 3 mf
1067	Ride Cymbal 3 f
1068	Ride Cymbal 3 ff
1069	Ride Cymbal 8 mp
1070	Cymbal Reverse
1071	Chinese Gong
1072	Castanet
1073	Click 1
1074	Click 2
1075	Marc Tree
1076	Bell Tree slow

ROM stereo

#	Name
0000	Acoustic Piano mp
0001	Acoustic Piano mf
0002	Acoustic Piano f
0003	Piano Tailpiece
0004	Brass Ensemble 1
0005	Brass Ensemble 4
0006	Strings Ensemble 1

## Drumsample

## ROM mono

#	Name	#	Name	#	Name	#	Name
0000	BD-01-amb f-L	0073	BD-Dance 09	0146	BD-Dance Revers	0219	SD-13-dry mp
0001	BD-01-amb f-R	0074	BD-Dance 10	0147	SD-01-dry mp -L	0220	SD-13-dry mf -L
0002	BD-01-amb ff -L	0075	BD-Pop	0148	SD-01-dry mp -R	0221	SD-13-dry mf -R
0003	BD-01-amb ff -R	0076	BD-Hip 2	0149	SD-01-dry mf	0222	SD-13-dry ff -L
0004	BD-02-amb mf -L	0077	BD-Hip 3	0150	SD-01-dry f-L	0223	SD-13-dry ff -R
0005	BD-02-amb mf -R	0078	BD-Dance 11	0151	SD-01-dry f-R	0224	SD-14-dry mf
0006	BD-02-amb f-L	0079	BD-Dance 12	0152	SD-02-dry mp -L	0225	SD-14-dry f-L
0007	BD-02-amb f-R	0080	BD-Dance Soft	0153	SD-02-dry mp -R	0226	SD-14-dry f-R
0008	BD-03-amb mf -L	0081	BD-Dance Short	0154	SD-02-dry mf -L	0227	SD-14-dry ff -L
0009	BD-03-amb mf -R	0082	BD-Dark	0155	SD-02-dry mf -R	0228	SD-14-dry ff -R
0010	BD-03-amb f-L	0083	BD-Dance 13	0156	SD-02-dry f	0229	SD-15-dry mp -L
0011	BD-03-amb f-R	0084	BD-Dance 14	0157	SD-02-dry ff	0230	SD-15-dry mp -R
0012	BD-03-amb ff	0085	BD-Dance 15	0158	SD-03-dry mp	0231	SD-15-dry mf
0013	BD-04-amb mf -L	0086	BD-Dance 16	0159	SD-03-dry mf -L	0232	SD-15-dry f-L
0014	BD-04-amb mf -R	0087	BD-Dance 17	0160	SD-03-dry mf -R	0233	SD-15-dry f-R
0015	BD-04-amb f-L	0088	BD-Dance 18	0161	SD-03-dry f-L	0234	SD-16-dry f-L
0016	BD-04-amb f-R	0089	BD-Dance 19	0162	SD-03-dry f-R	0235	SD-16-dry f-R
0017	BD-05-amb mp	0090	BD-Dance 20	0163	SD-04-amb p-L	0236	SD-16-dry ff -L
0018	BD-05-amb mf -L	0091	BD-Dance 21	0164	SD-04-amb p-R	0237	SD-16-dry ff -R
0019	BD-05-amb mf -R	0092	BD-Dance 22	0165	SD-04-amb mp -L	0238	SD-17-dry mp
0020	BD-05-amb f-L	0093	BD-Dance 23	0166	SD-04-amb mp -R	0239	SD-17-dry mf
0021	BD-05-amb f-R	0094	BD-Dance 24	0167	SD-04-amb mf -L	0240	SD-17-dry f
0022	BD-06-dry mp -L	0095	BD-Dance 25	0168	SD-04-amb mf -R	0241	SD-17-dry GhostRoll mf
0023	BD-06-dry mp -R	0096	BD-Dance 26	0169	SD-04-amb f	0242	SD-17-dry GhostRoll f
0024	BD-06-dry f-L	0097	BD-Dance 27	0170	SD-04-amb ff -L	0243	SD-18-amb f
0025	BD-06-dry f-R	0098	BD-Dance 28	0171	SD-04-amb ff -R	0244	SD-18-amb ff
0026	BD-06-amb mp	0099	BD-Dance 29	0172	SD-05-dry mp	0245	SD-19-amb mp
0027	BD-06-amb mf	0100	BD-Dance 30	0173	SD-05-dry f-L	0246	SD-19-amb mf
0028	BD-06-amb f	0101	BD-Dance 31	0174	SD-05-dry f-R	0247	SD-19-amb f
0029	BD-06-amb ff	0102	BD-Dance 32	0175	SD-05-dry ff -L	0248	SD-19-amb GhostRoll
0030	BD-07-dry mf -L	0103	BD-Dance 33	0176	SD-05-dry ff -R	0249	SD-20-dry mp
0031	BD-07-dry mf -R	0104	BD-Dance 34	0177	SD-06-dry mf -L	0250	SD-20-dry f
0032	BD-07-dry f-L	0105	BD-Dance 35	0178	SD-06-dry mf -R	0251	SD-20-dry GhostRoll
0033	BD-07-dry f-R	0106	BD-Dance 36	0179	SD-06-dry f-L	0252	SD-20-amb mp
0034	BD-08-dry mf -L	0107	BD-Dance 37	0180	SD-06-dry f-R	0253	SD-20-amb f
0035	BD-08-dry mf -R	0108	BD-Dance 38	0181	SD-07-amb mf	0254	SD-20-amb GhostRoll
0036	BD-08-dry f-L	0109	BD-Dance 39	0182	SD-07-amb f	0255	SD-21-dry mp
0037	BD-08-dry f-R	0110	BD-Dance 40	0183	SD-08-dry f-L	0256	SD-21-dry mf -L
0038	BD-08-amb mf	0111	BD-Dance 41	0184	SD-08-dry f-R	0257	SD-21-dry mf -R
0039	BD-08-amb f	0112	BD-Dance 42	0185	SD-08-dry ff -L	0258	SD-21-dry f
0040	BD-08-amb ff	0113	BD-Dance 43	0186	SD-08-dry ff -R	0259	SD-21-dry ff -L
0041	BD-09-dry mp -L	0114	BD-Dance 44	0187	SD-09-dry f-L	0260	SD-21-dry ff -R
0042	BD-09-dry mp -R	0115	BD-Dance 45	0188	SD-09-dry f-R	0261	SD-21-amb f
0043	BD-09-dry mf -L	0116	BD-Dance 46	0189	SD-09-dry ff -L	0262	SD-21-amb ff
0044	BD-09-dry mf -R	0117	BD-Dance 47	0190	SD-09-dry ff -R	0263	SD-22-dry f
0045	BD-PhatJaz	0118	BD-Dance 48	0191	SD-09-amb f	0264	SD-22-amb mf
0046	BD-WS 1	0119	BD-Dance 49	0192	SD-09-amb ff	0265	SD-22-amb mf REV
0047	BD-WS 2 (Tite)	0120	BD-Dance 50	0193	SD-10-dry mp	0266	SD-23-dry mp
0048	BD-Dry	0121	BD-Dance 51	0194	SD-10-dry f-L	0267	SD-23-dry mf
0049	BD-Soft	0122	BD-Dance 52	0195	SD-10-dry f-R	0268	SD-23-dry GhostRoll
0050	BD-Mondo Kill	0123	BD-Dance 53	0196	SD-10-dry ff -L	0269	SD-24-dry mp
0051	BD-Tubby	0124	BD-Dance 54	0197	SD-10-dry ff -R	0270	SD-24-dry f-L
0052	BD-Gated	0125	BD-Dance 55	0198	SD-11-dry mf -L	0271	SD-24-dry f-R
0053	BD-WS 3 (Ambi)	0126	BD-Dance Zap 1	0199	SD-11-dry mf -R	0272	SD-24-dry ff -L
0054	BD-Orchestral	0127	BD-Dance Zap 2	0200	SD-11-dry ff -L	0273	SD-24-dry ff -R
0055	BD-Hip 1	0128	BD-Dance 56	0201	SD-11-dry ff -R	0274	SD-24-dry GhostRoll -L
0056	BD-Dance 01	0129	BD-Dance 57	0202	SD-11-amb mf	0275	SD-24-dry GhostRoll -R
0057	BD-Cannon	0130	BD-Dance 58	0203	SD-11-amb ff	0276	SD-WS 01
0058	BD-B.B.D. 1	0131	BD-Dance 59	0204	SD-12-dry p-L	0277	SD-Dry
0059	BD-B.B.D. 2	0132	BD-Dance 60	0205	SD-12-dry p-R	0278	SD-Off Center
0060	BD-Jungle 1	0133	BD-Dance 61	0206	SD-12-dry mp -L	0279	SD-Jazz Ring
0061	BD-Jungle 2	0134	BD-Dance 62	0207	SD-12-dry mp -R	0280	SD-Classic Room
0062	BD-Slugg	0135	BD-Dance 63	0208	SD-12-dry mf -L	0281	SD-Atomic
0063	BD-Dance 02	0136	BD-Dance 64	0209	SD-12-dry mf -R	0282	SD-25-dry Brush Tap mp-L
0064	BD-Dance 03	0137	BD-Dance 65	0210	SD-12-dry f-L	0283	SD-25-dry Brush Tap mp-R
0065	BD-Ambi	0138	BD-Dance 66	0211	SD-12-dry f-R	0284	SD-25-dry Brush Tap f-L
0066	BD-Dance 04	0139	BD-Dance 67	0212	SD-12-dry ff -L	0285	SD-25-dry Brush Tap f-R
0067	BD-floor	0140	BD-Dance 68	0213	SD-12-dry ff -R	0286	SD-26-dry Brush Tap mp-L
0068	BD-WS 4 (Gated)	0141	BD-Dance 69	0214	SD-12-dry fff -L	0287	SD-26-dry Brush Tap mp-R
0069	BD-Dance 05	0142	BD-Dance 70	0215	SD-12-dry fff -R	0288	SD-26-dry Brush Tap mf-L
0070	BD-Dance 06	0143	BD-Dance 71	0216	SD-12-amb mp	0289	SD-26-dry Brush Tap mf-R
0071	BD-Dance 07	0144	BD-Dance 72	0217	SD-12-amb f	0290	SD-26-dry Brush Tap f-L
0072	BD-Dance 08	0145	BD-Dance Crunk	0218	SD-12-amb fff	0291	SD-26-dry Brush Tap f-R

#	Name	#	Name	#	Name	#	Name
0292	SD-26-dry BrushTriplet-L	0365	SD-Dance 39	0438	Tom Basic Hi mf -L	0511	Hi-Hat Basic 1-Pedal ff
0293	SD-26-dry BrushTriplet-R	0366	SD-Dance 40	0439	Tom Basic Hi mf -R	0512	Hi-Hat Basic 1-Open mf
0294	SD-26-dry BrushSwirl a-L	0367	SD-Dance 41	0440	Tom Basic Hi f	0513	Hi-Hat Basic 1-Open f
0295	SD-26-dry BrushSwirl a-R	0368	SD-Dance 42	0441	Tom Soul mf	0514	Hi-Hat Basic 1-Open ff
0296	SD-26-dry BrushSwirl b-L	0369	SD-Dance 43	0442	Tom Soul f	0515	Hi-Hat Basic 2-Closed mp
0297	SD-26-dry BrushSwirl b-R	0370	SD-Dance 44	0443	Tom Vintage Lo mp	0516	Hi-Hat Basic 2-Closed mf
0298	SD-Roll-Open 1 a -L	0371	SD-Dance 45	0444	Tom Vintage Lo mf	0517	Hi-Hat Basic 2-Closed f
0299	SD-Roll-Open 1 a -R	0372	SD-Dance 46	0445	Tom Vintage Lo f	0518	Hi-Hat Basic 2-Open mp
0300	SD-Roll-Open 1 b	0373	SD-Dance 47	0446	Tom Vintage Lo ff	0519	Hi-Hat Basic 2-Open mf
0301	SD-Roll-Open 1 c	0374	SD-Dance 48	0447	Tom Vintage Mid mp	0520	Hi-Hat Basic 2-Open f
0302	SD-Roll-Open 2 -L	0375	SD-Dance 49	0448	Tom Vintage Mid mf -L	0521	Hi-Hat Basic 3-Closed mp
0303	SD-Roll-Open 2 -R	0376	SD-Dance 50	0449	Tom Vintage Mid mf -R	0522	Hi-Hat Basic 3-Closed mf
0304	SD-Roll-Open 3 a	0377	SD-Dance 51	0450	Tom Vintage Mid f	0523	Hi-Hat Basic 3-Closed f
0305	SD-Roll-Open 3 b	0378	SD-Dance 52	0451	Tom Vintage Mid ff -L	0524	Hi-Hat Basic 3-Closed ff
0306	SD-Roll-Closed 1 a -L	0379	SD-Dance 53	0452	Tom Vintage Mid ff -R	0525	Hi-Hat Basic 3-Open
0307	SD-Roll-Closed 1 a -R	0380	SD-Dance 54	0453	Tom Vintage Hi mp	0526	Hi-Hat Heavy 1-Closed mp
0308	SD-Roll-Closed 1 b	0381	SD-Dance 55	0454	Tom Vintage Hi mf -L	0527	Hi-Hat Heavy 1-Closed mf
0309	SD-Roll-Closed 2	0382	SD-Dance 56	0455	Tom Vintage Hi mf -R	0528	Hi-Hat Heavy 1-Closed f
0310	SD-Roll-Closed 3 a	0383	SD-Dance 57	0456	Tom Vintage Hi f	0529	Hi-Hat Heavy 1-Open f
0311	SD-Roll-Closed 3 b -L	0384	SD-Dance 58	0457	Tom Vintage Hi ff -L	0530	Hi-Hat Heavy 1-HalfOpen
0312	SD-Roll-Closed 3 b -R	0385	SD-Dance 59	0458	Tom Vintage Hi ff -R	0531	Hi-Hat Heavy 2-Closed mp
0313	SD-Roll-Closed 4	0386	SD-Dance 60	0459	Tom Rock1-dry Lo f -L	0532	Hi-Hat Heavy 2-Closed mf
0314	SD-Roll-Closed 5	0387	SD-Dance 61	0460	Tom Rock1-dry Lo f -R	0533	Hi-Hat Heavy 2-Closed f
0315	SD-Orch.Roll	0388	SD-Dance 62	0461	Tom Rock1-dry Lo ff -L	0534	Hi-Hat Heavy 2-Closed ff
0316	SD-Orchestral	0389	SD-Dance 63	0462	Tom Rock1-dry Lo ff -R	0535	Hi-Hat Heavy 2-Open mf
0317	SD-Sidestick 1 mf -L	0390	SD-Dance 64	0463	Tom Rock1-dry Mid f -L	0536	Hi-Hat Heavy 2-Open f
0318	SD-Sidestick 1 mf -R	0391	SD-Dance 65	0464	Tom Rock1-dry Mid f -R	0537	Hi-Hat Heavy 2-Pedal mf
0319	SD-Sidestick 1 f	0392	SD-Dance 66	0465	Tom Rock1-dry Mid ff -L	0538	Hi-Hat Heavy 2-Pedal f
0320	SD-Sidestick 2 mf	0393	SD-Dance 67	0466	Tom Rock1-dry Mid ff -R	0539	Hi-Hat Heavy 2-FootOpen
0321	SD-Sidestick 3 mf -L	0394	SD-Dance 68	0467	Tom Rock1-dry Hi f -L	0540	Hi-Hat Basic 4-Closed 1
0322	SD-Sidestick 3 mf -R	0395	SD-Dance 69	0468	Tom Rock1-dry Hi f -R	0541	Hi-Hat Basic 4-Closed 2
0323	SD-Sidestick 4 mf -L	0396	SD-Dance 70	0469	Tom Rock1-dry Hi ff -L	0542	Hi-Hat Basic 4-Foot
0324	SD-Sidestick 4 mf -R	0397	SD-Dance 71	0470	Tom Rock1-dry Hi ff -R	0543	Hi-Hat Basic 4-FootOpen
0325	SD-Sidestick 4 f	0398	SD-Dance 72	0471	Tom Rock2-dry Lo f -L	0544	Hi-Hat Basic 4-Open 1
0326	SD-Sidestick WS	0399	SD-Dance 73	0472	Tom Rock2-dry Lo f -R	0545	Hi-Hat Basic 4-Open 2
0327	SD-Dance 01	0400	SD-Dance 74	0473	Tom Rock2-dry Lo ff -L	0546	Hi-Hat Basic 5-Closed 1
0328	SD-Dance 02	0401	SD-Noise	0474	Tom Rock2-dry Lo ff -R	0547	Hi-Hat Basic 5-Closed 2
0329	SD-Dance 03	0402	SD-Sizzle	0475	Tom Rock2-dry MidLo mf	0548	Hi-Hat Basic 5-Open
0330	SD-Dance 04	0403	SD-Vintage	0476	Tom Rock2-dry MidLo ff	0549	Hi-Hat Brush-Closed mp
0331	SD-Dance 05	0404	SD-AmbiCrackle 1	0477	Tom Rock2-dry MidHi mf	0550	Hi-Hat Brush-Closed mf
0332	SD-Dance 06	0405	SD-AmbiCrackle 2	0478	Tom Rock2-dry MidHi ff	0551	Hi-Hat Brush-Closed f
0333	SD-Dance 07	0406	SD-Whopper	0479	Tom Rock2-dry Hi mf	0552	Hi-Hat Brush-Closed ff
0334	SD-Dance 08	0407	SD-WS 02 (Crack)	0480	Tom Rock2-dry Hi ff	0553	Hi-Hat Brush-Pedal mf
0335	SD-Dance 09	0408	SD-WS 03 (Amb)	0481	Tom Rock1-amb Low	0554	Hi-Hat Brush-Pedal ff
0336	SD-Dance 10	0409	SD-WS 04 (Nasty)	0482	Tom Rock1-amb Mid	0555	Hi-Hat Brush-Open mp
0337	SD-Dance 11	0410	SD-WS 05 (BeatBox)	0483	Tom Rock1-amb Hi	0556	Hi-Hat Brush-Open mf
0338	SD-Dance 12	0411	SD-WS 06 (Gated)	0484	Tom Rock2-amb Low	0557	Hi-Hat Brush-Open f
0339	SD-Dance 13	0412	SD-WS 07 (Noise)	0485	Tom Rock2-amb MidLo	0558	Hi-Hat Brush-Open ff
0340	SD-Dance 14	0413	SD-WS 08 (Tenny)	0486	Tom-Old R&B	0559	Hi-Hat Dance 01
0341	SD-Dance 15	0414	SD-Vocal	0487	Tom Brush1 Low mf -L	0560	Hi-Hat Dance 02
0342	SD-Dance 16	0415	SD-Dance 75	0488	Tom Brush1 Low mf -R	0561	Hi-Hat Dance 03
0343	SD-Dance 17	0416	SD-Dance 76	0489	Tom Brush1 Low f	0562	Hi-Hat Dance 04
0344	SD-Dance 18	0417	SD-Dance 77	0490	Tom Brush1 Low ff -L	0563	Hi-Hat Dance 05
0345	SD-Dance 19	0418	SD-Dance 78	0491	Tom Brush1 Low ff -R	0564	Hi-Hat Dance 06
0346	SD-Dance 20	0419	SD-Dance Rimshot	0492	Tom Brush1 Mid mf -L	0565	Hi-Hat Dance 07
0347	SD-Dance 21	0420	SD-Dance Sidestick	0493	Tom Brush1 Mid mf -R	0566	Hi-Hat Dance 08
0348	SD-Dance 22	0421	Tom Basic Lo mf -L	0494	Tom Brush1 Mid f	0567	Hi-Hat Dance 09
0349	SD-Dance 23	0422	Tom Basic Lo mf -R	0495	Tom Brush1 Mid ff -L	0568	Hi-Hat Dance 10
0350	SD-Dance 24	0423	Tom Basic Lo f -L	0496	Tom Brush1 Mid ff -R	0569	Hi-Hat Dance 11
0351	SD-Dance 25	0424	Tom Basic Lo f -R	0497	Tom Brush1 Hi mp	0570	Hi-Hat Dance 12
0352	SD-Dance 26	0425	Tom Basic Lo ff	0498	Tom Brush1 Hi mf -L	0571	Hi-Hat Dance 13
0353	SD-Dance 27	0426	Tom Basic MidLo mf -L	0499	Tom Brush1 Hi mf -R	0572	Hi-Hat Dance 14
0354	SD-Dance 28	0427	Tom Basic MidLo mf -R	0500	Tom Brush1 Hi ff -L	0573	Hi-Hat Dance 15
0355	SD-Dance 29	0428	Tom Basic MidLo f -L	0501	Tom Brush1 Hi ff -R	0574	Hi-Hat Dance 16
0356	SD-Dance 30	0429	Tom Basic MidLo f -R	0502	Tom Brush2 Floor	0575	Hi-Hat Dance 17
0357	SD-Dance 31	0430	Tom Basic MidHi mp	0503	Tom Brush2 Hi	0576	Hi-Hat Dance 18
0358	SD-Dance 32	0431	Tom Basic MidHi mf -L	0504	Hi-Hat Basic 1-Closed mp	0577	Hi-Hat Dance 19
0359	SD-Dance 33	0432	Tom Basic MidHi mf -R	0505	Hi-Hat Basic 1-Closed mf	0578	Hi-Hat Dance 20
0360	SD-Dance 34	0433	Tom Basic MidHi f -L	0506	Hi-Hat Basic 1-Closed f	0579	Hi-Hat Dance 21
0361	SD-Dance 35	0434	Tom Basic MidHi f -R	0507	Hi-Hat Basic 1-Closed ff	0580	Hi-Hat Dance 22
0362	SD-Dance 36	0435	Tom Basic MidHi ff	0508	Hi-Hat Basic 1-Pedal mp	0581	Hi-Hat Dance 23
0363	SD-Dance 37	0436	Tom Basic Hi mp -L	0509	Hi-Hat Basic 1-Pedal mf	0582	Hi-Hat Dance 24
0364	SD-Dance 38	0437	Tom Basic Hi mp -R	0510	Hi-Hat Basic 1-Pedal f	0583	Hi-Hat Dance 25

## Voice Name List

#	Name	#	Name	#	Name	#	Name
0584	Hi-Hat Dance 26	0661	Ride Cymbal 6 f -L	0738	Quinto-ClosedSlap	0815	Timbales Lo-Mute mf
0585	Hi-Hat Dance 27	0662	Ride Cymbal 6 f -R	0739	Quinto-CloseSlapFlam p	0816	Timbales Lo-Mute f
0586	Hi-Hat Dance 28	0663	Ride Cymbal 7-Cup -L	0740	Quinto-CloseSlapFlam f	0817	Timbales Lo-Paila mf
0587	Hi-Hat Dance 29	0664	Ride Cymbal 7-Cup -R	0741	Quinto-Heel	0818	Timbales Lo-Paila f
0588	Hi-Hat Dance 30	0665	Ride Cymbal 8 -L	0742	Quinto-Toe	0819	Timbales Hi-Open
0589	Hi-Hat Dance 31	0666	Ride Cymbal 8 -R	0743	Bongo 1 Lo-Muffled mp	0820	Timbales Hi-Edge
0590	Hi-Hat Dance 32	0667	Ride Dance 1	0744	Bongo 1 Lo-Muffled f	0821	Timbales Hi-RimShot mf
0591	Hi-Hat Dance 33	0668	Ride Dance 2	0745	Bongo 1 Lo-Closed	0822	Timbales Hi-RimShot f
0592	Hi-Hat WS-Closed	0669	Ride Dance 3	0746	Bongo 1 Lo-Flam	0823	Timbales Hi-RimShot ff
0593	Hi-Hat WS-HalfOpen	0670	Ride Dance WS	0747	Bongo 1 Lo-MuffledFlam	0824	Timbales Hi-Abanico 1
0594	Hi-Hat WS-Open	0671	China Cymbal 1 -L	0748	Bongo 1 Lo-Stick	0825	Timbales Hi-Abanico 2
0595	Hi-Hat-Chili	0672	China Cymbal 1 -R	0749	Bongo 1 Lo-StickEdge mf	0826	Timbales Hi-Mute
0596	Hi-Hat-Vintage	0673	China Cymbal 2	0750	Bongo 1 Lo-StickEdge f	0827	Timbales Hi-Paila mf
0597	Hi-Hat-Hip	0674	Broken Cymbal	0751	Bongo 1 Lo-StickBounce	0828	Timbales Hi-Paila f
0598	Hi-Hat-Crunk	0675	Splash Cymbal 1 mp	0752	Bongo 1 Lo-Fingernail	0829	Cowbell 1
0599	Hi-Hat-Ambi	0676	Splash Cymbal 1 mf	0753	Bongo 1 Lo-Cuptone	0830	Cowbell 2
0600	Hi-Hat-Crisp Open	0677	Splash Cymbal 1 f	0754	Bongo 1 Lo-Slap	0831	Cowbell 3
0601	Hi-Hat-ClangyOpen	0678	Splash Cymbal 1 ff -L	0755	Bongo 1 Hi-Open mf	0832	Cowbell 4-Open
0602	Hi-Hat-Whispy	0679	Splash Cymbal 1 ff -R	0756	Bongo 1 Hi-Open f	0833	Cowbell 4-Mute
0603	Hi-Hat Dance 34	0680	Splash Cymbal 2 mp	0757	Bongo 1 Hi-Pops	0834	Cowbell 5-Open a
0604	Hi-Hat Dance 35	0681	Splash Cymbal 2 ff	0758	Bongo 1 Hi-Hightone	0835	Cowbell 5-Open b
0605	Hi-Hat Dance 36	0682	Drumstick Hit	0759	Bongo 1 Hi-OpenFlam	0836	Cowbell 5-Mute
0606	Hi-Hat Dance 37	0683	Finger Snap	0760	Bongo 1 Hi-Fingernail	0837	Claves Lo a
0607	Hi-Hat WS Syn-Closed	0684	Hand Claps 1	0761	Bongo 1 Hi-Stick	0838	Claves Lo b
0608	Hi-Hat WS Syn-Open	0685	Hand Claps 2-a -L	0762	Bongo 1 Hi-StickEdge mf	0839	Claves Hi a
0609	Crash Cymbal 1 mf	0686	Hand Claps 2-a -R	0763	Bongo 1 Hi-StickEdge f	0840	Claves Hi b
0610	Crash Cymbal 1 f	0687	Hand Claps 2-b	0764	Bongo 1 Hi-StickBounce	0841	Maracas 1-Push a
0611	Crash Cymbal 1 ff	0688	Hand Claps 2-c	0765	Bongo 1 Hi-Cuptone	0842	Maracas 1-Push b
0612	Crash Cymbal 2 f -L	0689	Hand Claps 2-d -L	0766	Bongo 1 Hi-Slap	0843	Maracas 1-Pull a
0613	Crash Cymbal 2 f -R	0690	Hand Claps 2-d -R	0767	Bongo 2 Lo-Open a	0844	Maracas 1-Pull b
0614	Crash Cymbal 2 ff	0691	Hand Claps 2-e	0768	Bongo 2 Lo-Open b	0845	Maracas 2-Push a
0615	Crash Cymbal 3 ff	0692	Hand Claps 2-f	0769	Bongo 2 Lo-Mute	0846	Maracas 2-Push b
0616	Crash Cymbal 4 mp	0693	Hand Claps 2-g -L	0770	Bongo 2 Hi-Open a	0847	Maracas 2-Pull a
0617	Crash Cymbal 4 mf	0694	Hand Claps 2-g -R	0771	Bongo 2 Hi-Open b	0848	Maracas 2-Pull b
0618	Crash Cymbal 4 f	0695	Hand Claps 3-Gospel	0772	Bongo 2 Hi-Muffled	0849	Guiro-Long a
0619	Crash Cymbal 4 ff	0696	Tumba-Basstone	0773	Bongo 2 Lo-Muffled	0850	Guiro-Long b
0620	Crash Cymbal 5 mp	0697	Tumba-Open 1 mf	0774	Bongo 2 Lo-Heel	0851	Guiro-Short a
0621	Crash Cymbal 5 mf	0698	Tumba-Open 1 f	0775	Bongo 2 Hi-Slap	0852	Guiro-Short b
0622	Crash Cymbal 5 ff	0699	Tumba-Open2 mf	0776	Iya Boca-Open mp	0853	Vibra-Slap
0623	Crash Cymbal 6 mf -L	0700	Tumba-Open2 f	0777	Iya Boca-Open mf	0854	Toy Drum
0624	Crash Cymbal 6 mf -R	0701	Tumba-OpenFlam	0778	Iya Boca-Open f	0855	Toy Drum-Rim
0625	Crash Cymbal 6 ff	0702	Tumba-Glissando	0779	Iya Boca-Choke mp	0856	Surdo-Open
0626	Crash Cymbal 7 mf	0703	Tumba-OpenSlapFlam mf	0780	Iya Boca-Choke mf	0857	Surdo-Mute
0627	Crash Cymbal 7 f -L	0704	Tumba-OpenSlapFlam f	0781	Iya Boca-Choke f	0858	Pandeiro-Jingle a
0628	Crash Cymbal 7 f -R	0705	Tumba-Muffled	0782	Iya Chacha-OpenSlap mp	0859	Pandeiro-Jingle b
0629	Crash Cymbal 8	0706	Conga Lo-Basstone	0783	Iya Chacha-OpenSlap mf	0860	Pandeiro-Open a
0630	Crash Cymbal 9	0707	Conga Lo-Open mf	0784	Iya Chacha-OpenSlap f	0861	Pandeiro-Open b
0631	Orchestral Cymbal-Open	0708	Conga Lo-Open f	0785	Iya Chacha-OpenSlap ff	0862	Pandeiro-Open c
0632	Orchestral Cymbal-Closed	0709	Conga Lo-OpenSlap	0786	Itotele Boca-Open mp	0863	Pandeiro-Choke a
0633	Crash Dance 1	0710	Conga Lo-OpenSlapFlam	0787	Itotele Boca-Open mf	0864	Pandeiro-Choke b
0634	Crash Dance 2	0711	Conga Lo-Glissando	0788	Itotele Boca-Open f	0865	Pandeiro-ClosedAcc.a
0635	Crash Dance 3	0712	Conga Lo-Muffled	0789	Itotele Boca-Muffled mp	0866	Pandeiro-ClosedAcc.b
0636	Crash Dance 4	0713	Conga Lo-Closed	0790	Itotele Boca-Muffled mf	0867	Pandeiro-ClosedAcc.c
0637	Crash Dance 5	0714	Conga Lo-ClosedSlap	0791	Itotele Boca-Muffled f	0868	Pandeiro-SideEdge
0638	Crash-Jungle	0715	Conga Lo-Heel	0792	Itotele Cha-OpenSlap mp	0869	Pandeiro-Glissando a
0639	Cymbal Reverse 1	0716	Conga Lo-Toe	0793	Itotele Cha-OpenSlap mf	0870	Pandeiro-Glissando b
0640	Cymbal Reverse 2	0717	Conga Hi-Basstone mf	0794	Itotele Cha-OpenSlap f	0871	Tambourine 1-Push
0641	Ride Cymbal 1 mp	0718	Conga Hi-Basstone f	0795	Itotele Cha-ClosedSlap p	0872	Tambourine 1-Pull
0642	Ride Cymbal 1 mf -L	0719	Conga Hi-Open mp	0796	Itotele Cha-ClosedSlap f	0873	Tambourine 1-Accent
0643	Ride Cymbal 1 mf -R	0720	Conga Hi-Open mf	0797	Okonkolo Boca-Open mp	0874	Tambourine 2-Push
0644	Ride Cymbal 1 f -L	0721	Conga Hi-Open f	0798	Okonkolo Boca-Open mf	0875	Tambourine 2-Pull a
0645	Ride Cymbal 1 f -R	0722	Conga Hi-OpenFlam	0799	Okonkolo Boca-Open f	0876	Tambourine 2-Pull b
0646	Ride Cymbal 1 ff	0723	Conga Hi-OpenSlap	0800	Okonkolo Boca-Open ff	0877	Tambourine 2-Accent
0647	Ride Cymbal 2 mf	0724	Conga Hi-OpenSlapFlam	0801	Okonkolo Chacha-Open mp	0878	Tri.& Tamb. a
0648	Ride Cymbal 3 mp	0725	Conga Hi-ClosedSlapFlam	0802	Okonkolo Chacha-Open mf	0879	Tri.& Tamb. b
0649	Ride Cymbal 3 mf -L	0726	Conga Hi-Muffled	0803	Okonkolo Chacha-Open f	0880	Tri.& Tamb. c
0650	Ride Cymbal 3 mf -R	0727	Conga Hi-Closed	0804	Okonkolo Chacha-Open ff	0881	Tri.& Tamb. d
0651	Ride Cymbal 3 f -L	0728	Conga Hi-ClosedSlap	0805	Okonkolo Chacha-Slap mp	0882	Tri.& Tamb. e
0652	Ride Cymbal 3 f -R	0729	Conga Hi-Heel	0806	Okonkolo Chacha-Slap mf	0883	Tri.& Tamb. f
0653	Ride Cymbal 3 ff	0730	Conga Hi-Toe	0807	Okonkolo Chacha-Slap f	0884	Tri.& Tamb. g
0654	Ride Cymbal 4 mp	0731	Quinto-Basstone	0808	Timbales Lo-Open mp	0885	Tri.& Tamb. h
0655	Ride Cymbal 4 f	0732	Quinto-Open mp	0809	Timbales Lo-Open mf	0886	Tri.& Tamb. i
0656	Ride Cymbal 4 ff	0733	Quinto-Open f	0810	Timbales Lo-Edge mf	0887	Tri.& Tamb. j
0657	Ride Cymbal 5 mf	0734	Quinto-OpenFlam	0811	Timbales Lo-Edge f	0888	Tri.& Tamb. k
0658	Ride Cymbal 5 f	0735	Quinto-OpenSlap	0812	Timbales Lo-RimShot	0889	Tri.& Tamb. l
0659	Ride Cymbal 6 mf -L	0736	Quinto-Muffled	0813	Timbales Lo-Abanico	0890	Tri.& Tamb. m
0660	Ride Cymbal 6 mf -R	0737	Quinto-Closed	0814	Timbales Lo-Roll	0891	Cabasa 1 L a-Down

#	Name	#	Name	#	Name	#	Name
0892	Cabasa 1 L a-Up	0969	Whistle 2	1046	Tsuzumi	1123	WD-Ethno SD 4
0893	Cabasa 1 L b-Down	0970	Whistle 3	1047	Wood Block 1 a	1124	WD-Ethno SD 5
0894	Cabasa 1 L b-Up	0971	Whistle 4-Long	1048	Wood Block 1 b	1125	WD-Ethno SD 6
0895	Cabasa 1 S a-Down	0972	Whistle 4-Short	1049	Wood Block 2 a	1126	WD-Gothic 1
0896	Cabasa 1 S a-Up	0973	Whistle 5	1050	Wood Block 2 b	1127	WD-Gothic 2
0897	Cabasa 1 S b-Down	0974	Dumbek-a	1051	Wood Block 3 a	1128	WD-Gothic 3
0898	Cabasa 1 S b-up	0975	Dumbek-b	1052	Wood Block 3 b	1129	WD-Gothic 4
0899	Cabasa 2 L-Stack a	0976	Dumbek-c	1053	Wood Block 4 a	1130	WD-Gothic 5
0900	Cabasa 2 L-Stack b	0977	Dumbek-d	1054	Wood Block 4 b	1131	WD-Gothic 6
0901	Cabasa 2 L-Roll	0978	Dumbek-e	1055	Wood Block 5 a	1132	WD-Kangaroo 1
0902	Cabasa 2 S-Stack a	0979	Dumbek-f	1056	Wood Block 5 b	1133	WD-Kangaroo 2
0903	Cabasa 2 S-Stack b	0980	Dumbek-g	1057	Wood Block 6 a	1134	WD-Kangaroo 3
0904	Cabasa 2 S-Roll	0981	Dumbek-h	1058	Wood Block 6 b	1135	WD-Kangaroo 4
0905	Shaker 1-Push a	0982	Dumbek-i	1059	Castanet 1 a	1136	WD-Kangaroo 5
0906	Shaker 1-Push b	0983	Dumbek-j	1060	Castanet 1 b	1137	WD-Kangaroo 6
0907	Shaker 1-Pull a	0984	Dumbek-k	1061	Castanet 1 c	1138	WD-Kangaroo 7
0908	Shaker 1-Pull b	0985	Djembe L-Basstone a	1062	Castanet 2	1139	WD-Kangaroo 8
0909	Shaker 1-Accent a	0986	Djembe L-Basstone b	1063	Timpani mf	1140	WD-Snake Drum 1
0910	Shaker 1-Accent b	0987	Djembe L-Basstone c	1064	Timpani ff	1141	WD-Snake Drum 2
0911	Shaker 1-Slow a	0988	Djembe L-Open	1065	Timpani-Roll Lo mf	1142	Dance Perc 01
0912	Shaker 1-Slow b	0989	Djembe L-OpenSlap	1066	Timpani-Roll Lo ff	1143	Dance Perc 02
0913	Shaker 1-Slow c	0990	Djembe L-ClosedSlap	1067	Timpani-Roll Hi mf	1144	Perc-WS 01 (Vox Box)
0914	Shaker 1-Roll a	0991	Djembe S-Basstone a	1068	Timpani-Roll Hi ff	1145	Dance Claps Crunk
0915	Shaker 1-Roll b	0992	Djembe S-Basstone b	1069	Chinese Gong	1146	Dance Claps 01
0916	Shaker 1-Roll c	0993	Djembe S-Basstone c	1070	Finger Cymbal	1147	Dance Claps 02
0917	Shaker 2 a	0994	Djembe S-Open	1071	Rap Sleigh Bell	1148	Dance Claps 03
0918	Shaker 2 b-Push	0995	Djembe S-OpenSlap a	1072	Sleigh Bell	1149	Dance Claps 04
0919	Shaker 2 b-Pull	0996	Djembe S-ClosedSlap a	1073	Bell Tree-Slow	1150	Dance Claps 05
0920	Shaker 2 c-Push	0997	Djembe S-ClosedSlap b	1074	Bell Tree-Fast	1151	Dance Claps 06
0921	Shaker 2 d-Push	0998	Djembe S-ClosedSlap c	1075	Marc Tree	1152	Dance Claps 07
0922	Shaker 2 d-Pull	0999	Udu-HalfOpen a	1076	Rainstick 1 a	1153	Dance Claps 08
0923	Shaker 2 e-Push	1000	Udu-HalfOpen b	1077	Rainstick 1 b	1154	Dance Claps 09
0924	Shaker 2 e-Pull	1001	Udu-HalfOpen c	1078	Rainstick 2	1155	Dance Claps 10
0925	Shaker 2 f-Push	1002	Udu-Open a	1079	Rainstick-OneShot Down	1156	Dance Claps 11
0926	Shaker 2 f-Pull	1003	Udu-Open b	1080	Rainstick-OneShot Up	1157	Dance Conga 1 Lo-Open
0927	Shaker 2 f-Accent	1004	Udu-Open c	1081	Bull Roar	1158	Dance Conga 1 Hi-Open
0928	Shaker 3-Push	1005	Udu-Open d	1082	Flexatone	1159	Dance Conga 1 Hi-Muffled
0929	Shaker 3-Pull	1006	Udu-Bell a	1083	Jew's Harp 01	1160	Dance Caoga 2 Open a
0930	Toy Shaker-Push	1007	Udu-Bell b	1084	Jew's Harp 02	1161	Dance Conga 2 Open b
0931	Toy Shaker-Pull	1008	Udu-Slide a	1085	Jew's Harp 03	1162	Dance Conga 2 Slap a
0932	Agogo 1 Lo-Open	1009	Udu-Slide b	1086	Jew's Harp 04	1163	Dance Conga 2 Slap b
0933	Agogo 1 Hi-Open	1010	Caxixi 1 a	1087	Jew's Harp 05	1164	Dance Perc 03-Closed
0934	Agogo 2 Lo-Open	1011	Caxixi 1 b	1088	Jew's Harp 06	1165	Dance Perc 03-Open
0935	Agogo 2 Hi-Open	1012	Caxixi 1 c	1089	Jew's Harp 07	1166	Dance Perc 04-Closed
0936	Agogo-Belltone	1013	Caxixi 2 a	1090	Jew's Harp 08	1167	Dance Perc 04-Open
0937	Triangle 1 L-Open a	1014	Caxixi 2 b	1091	Jew's Harp 09	1168	Dance Perc 05
0938	Triangle 1 L-Open b	1015	Caxixi 3 a	1092	Jew's Harp 10	1169	Dance Perc 06 a
0939	Triangle 1 L-Mute a	1016	Caxixi 3 b	1093	Jew's Harp 11	1170	Dance Perc 06 b
0940	Triangle 1 L-Mute b	1017	Caxixi 3 c	1094	Jew's Harp 12	1171	Dance Perc 07 a
0941	Triangle 1 L-Mute c	1018	Tabla-Tin a	1095	Jew's Harp 13	1172	Dance Perc 07 b
0942	Triangle 1 S-Open a	1019	Tabla-Tin b	1096	Jew's Harp 14	1173	Dance Perc 08
0943	Triangle 1 S-Open b	1020	Tabla-Na a	1097	Jew's Harp 15	1174	Perc-WS 02 (Tick Hit)
0944	Triangle 1 S-Roll a	1021	Tabla-Na b	1098	Jew's Harp 16	1175	Dance Perc 09 a
0945	Triangle 1 S-Roll b	1022	Tabla-Na c	1099	Jew's Harp 17	1176	Dance Perc 09 b
0946	Triangle 1 S-Roll c	1023	Tabla-Tun a	1100	Jew's Harp 18	1177	Dance Perc 09 c
0947	Triangle 1 S-Mute a	1024	Tabla-Tun b	1101	Jew's Harp 19	1178	Dance Perc 10
0948	Triangle 1 S-Mute b	1025	Tabla-Tele a	1102	WD-Native Drum 1	1179	Dance Perc 11
0949	Triangle 2-Open	1026	Tabla-Tele b	1103	WD-Native Drum 2	1180	Dance Perc Tambourine
0950	Triangle 2-Closed a	1027	Tabla-Tele c	1104	WD-Native Drum 3	1181	Perc-WS 03 (SynTom)
0951	Triangle 2-Closed b	1028	Tabla-Ti a	1105	WD-Native Drum 4	1182	Dance SynTom
0952	Triangle 2-Closed c	1029	Tabla-Ti b	1106	WD-Big Hand 1	1183	Dance SynConga
0953	Triangle 2-Mute a	1030	Tabla-Ti c	1107	WD-Big Hand 2	1184	Perc-WS 04 (SynthCow)
0954	Triangle 2-Mute b	1031	Tabla-Tera	1108	WD-Big Hand 3	1185	Perc-Vocal Cowbell
0955	Triangle 3 Lp	1032	Baya-GheUp a	1109	WD-Big Hand 4	1186	Dance SynCowbell
0956	Triangle WS-Open	1033	Baya-GheUp b	1110	WD-Big Hand 5	1187	Dance SynMaraca
0957	Triangle WS-Closed	1034	Baya-KaPalm	1111	WD-Big Hand 6	1188	E.Tom 1
0958	Recoreco-Long	1035	Baya-KaToe a	1112	WD-Big Hand 7	1189	E.Tom 2
0959	Recoreco-Short a	1036	Baya-KaToe b	1113	WD-Bongo	1190	Zap 1
0960	Recoreco-Short b	1037	Baya-Nail a	1114	WD-Bongo Open	1191	Zap 2
0961	Recoreco-Short c	1038	Baya-Nail b	1115	WD-Bongo OpenSlap	1192	Orch Hit 1
0962	Cuica Lo a	1039	Baya-Nail c	1116	WD-Bongo Closed	1193	Orch Hit 2
0963	Cuica Lo b	1040	Baya-Ge	1117	WD-Bongo ClosedSlap	1194	Orch Hit 3
0964	Cuica Lo c	1041	Baya-Up	1118	WD-Brazilia 1	1195	Orch Hit 4
0965	Cuica Hi a	1042	Baya-UpDown a	1119	WD-Brazilia 2	1196	Orch Hit 5
0966	Cuica Hi b	1043	Baya-UpDown b	1120	WD-Ethno SD 1	1197	Orch Hit 6
0967	Cuica Hi c	1044	Taiko-Open	1121	WD-Ethno SD 2	1198	Orch Hit 7
0968	Whistle 1	1045	Taiko-Rim	1122	WD-Ethno SD 3	1199	Impact Hit

**Voice Name List**

#	Name
1200	Band Hit 1
1201	Band Hit 2
1202	Big Hit
1203	Jazz Hit 1
1204	Jazz Hit 2
1205	Jazz Hit 3
1206	Brass Fall 1
1207	Brass Fall 2
1208	Brass Fall 3
1209	Brass Fall 4
1210	Dance Hit
1211	VibeChord
1212	W.E.P.Chord
1213	Synth Hit Loop 1
1214	Synth Hit Loop 2
1215	Synth Hit Loop 3
1216	Synth Hit Loop 4
1217	Synth Hit Loop 5
1218	Synth Hit Loop 6
1219	Synth Hit Decay 1
1220	Synth Hit Decay 2
1221	Synth Hit Decay 3
1222	Synth Hit Decay 4
1223	Vinyl Hit 1
1224	Vinyl Hit 2
1225	DJ Vinyl Sliced 01
1226	DJ Vinyl Sliced 02
1227	DJ Vinyl Sliced 03
1228	DJ Vinyl Sliced 04
1229	DJ Vinyl Sliced 05
1230	DJ Vinyl Sliced 06
1231	DJ Vinyl Sliced 07
1232	DJ Vinyl Sliced 08
1233	DJ Vinyl Sliced 09
1234	DJ Vinyl Sliced 10
1235	DJ Vinyl Sliced 11
1236	DJ Vinyl Sliced 12
1237	DJ Vinyl Sliced 13
1238	DJ Vinyl Sliced 14
1239	DJ Vinyl Sliced 15
1240	DJ Vinyl Sliced 16
1241	DJ Vinyl Sliced 17
1242	DJ Vinyl Sliced 18
1243	DJ Vinyl Sliced 19
1244	DJ Vinyl Sliced 20
1245	DJ Vinyl Sliced 21
1246	DJ Vinyl Sliced 22
1247	DJ Vinyl Sliced 23
1248	DJ Vinyl Sliced 24
1249	DJ Vinyl Sliced 25
1250	DJ Vinyl Sliced 26
1251	DJ Vinyl Sliced 27
1252	DJ Vinyl Sliced 28
1253	DJ Vinyl Sliced 29
1254	DJ-Scratch 1
1255	DJ-Scratch 2
1256	DJ-BD Rub
1257	DJ-SD Rub
1258	DJ-Record Stop
1259	DJ-Reverse
1260	Industry Hit 01
1261	Industry Hit 02
1262	Industry Hit 03
1263	Industry Hit 04
1264	Pot Hit
1265	Industry Hit 05
1266	Industry Hit 06
1267	Industry Hit 07
1268	Industry Hit 08
1269	Thonk
1270	Industry Hit 09
1271	Noise Vibe
1272	Industry Hit 10
1273	Hammer
1274	Industry Hit 11
1275	Industry Hit 12
1276	Industry Hit 13

#	Name
1277	Industry Hit 14
1278	PianoHit
1279	Spike
1280	Industry Hit 15
1281	Industry Hit 16
1282	Industry Hit 17
1283	Industry Hit 18
1284	Industry Hit 19
1285	Industry Hit 20
1286	Industry Hit 21
1287	Industry Hit 22
1288	Industry Hit 23
1289	Industry Hit 24
1290	Industry Hit 25
1291	Industry Hit 26
1292	Industry Hit 27
1293	Industry Hit 28
1294	Industry Hit 29
1295	Industry Hit 30
1296	Industry Hit 31
1297	Industry Hit 32
1298	Industry Hit 33
1299	Industry Hit 34
1300	Industry Hit 35
1301	Industry Hit 36
1302	Industry Hit 37
1303	Industry Hit 38
1304	Industry Hit 39
1305	Industry Loop 1
1306	Industry Loop 2
1307	Industry Loop 3
1308	Industry Loop 4
1309	Voice 01
1310	Voice 02
1311	Voice 03
1312	Voice 04
1313	Voice 05
1314	Voice 06
1315	Voice 07
1316	Voice 08
1317	Voice 09
1318	Voice 10
1319	Voice 11
1320	Voice 12
1321	Voice 13
1322	Voice 14
1323	Voice 15
1324	Voice 16
1325	Voice 17
1326	Voice 18
1327	Voice 19
1328	Voice 20
1329	Voice 21
1330	Voice 22
1331	Voice 23
1332	Voice 24
1333	Voice 25
1334	Voice 26
1335	Voice 27
1336	Voice 28
1337	Voice 29
1338	Voice 30
1339	Voice 31
1340	Voice 32
1341	Voice 33
1342	Voice 34
1343	Voice 35
1344	Voice 36
1345	Voice 37
1346	Voice 38
1347	Voice 39
1348	Voice 40
1349	Voice 41
1350	Voice 42
1351	Voice 43
1352	Voice 44
1353	Voice 45

#	Name
1354	Voice 46
1355	Voice 47
1356	Voice 48
1357	Voice 49
1358	Voice 50
1359	Voice 51
1360	Voice 52
1361	Voice 53
1362	Voice 54
1363	Voice 55
1364	Voice 56
1365	Voice 57
1366	Voice 58
1367	Voice 59
1368	Voice 60
1369	Voice 61
1370	Voice 62
1371	Voice 63
1372	Voice 64
1373	Voice 65
1374	Voice 66
1375	Voice 67
1376	Voice 68
1377	Voice 69
1378	Voice 70
1379	Voice 71
1380	Voice 72
1381	Voice 73
1382	Voice 74
1383	Vocoder Voice 01
1384	Vocoder Voice 02
1385	Vocoder Voice 03
1386	Vocoder Voice 04
1387	Vocoder Voice 05
1388	Vocoder Voice 06
1389	Vocoder Voice 07
1390	Vocoder Voice 08
1391	Vocoder Voice 09
1392	Vocoder Voice 10
1393	Vocoder Voice 11
1394	Vocoder Voice 12
1395	Vocoder Voice 13
1396	Vocoder Voice 14
1397	Vocoder Voice 15
1398	Vocoder Voice 16
1399	Vocoder Voice 17
1400	Vocoder Voice 18
1401	Vocoder Voice 19
1402	Vocoder Voice 20
1403	Vocoder Voice 21
1404	Vocoder Voice 22
1405	Vocoder Voice 23
1406	CompuVoice-BEEP
1407	CompuVoice-Noise
1408	CompuVoice-Chi
1409	CompuVoice-Do it
1410	PC Voice 1-01
1411	PC Voice 1-02
1412	PC Voice 1-03
1413	PC Voice 1-04
1414	PC Voice 1-05
1415	PC Voice 1-06
1416	Machine Voice
1417	Psycho Voice
1418	Stadium
1419	Applause
1420	Scream
1421	Laughing
1422	Footstep 1
1423	Footstep 2
1424	Click 1
1425	Click 2
1426	Bird 1
1427	Bird 2
1428	Dog
1429	Gallop
1430	Crickets 1

#	Name
1431	Crickets 2
1432	Heart Beat
1433	Punch
1434	Tribe
1435	Sword 1
1436	Sword 2
1437	Glass Crash
1438	Glass Scratch
1439	Ice Drop
1440	Door Creak
1441	Door Slam 1
1442	Door Slam 2
1443	Car Engine
1444	Car Stop
1445	Car Pass
1446	Car Crash
1447	Car Horn
1448	Train
1449	Train Horn
1450	Railroad Crossing
1451	Railroad Crossing Lp
1452	Helicopter
1453	Fireworks
1454	Gun Shot
1455	Rifle Shot
1456	Machine Gun
1457	Laser Gun
1458	Cannon 1
1459	Cannon 2
1460	Cannon 3
1461	Explosion
1462	Thunder
1463	Wind
1464	Stream
1465	Bubble
1466	Jungle
1467	Forest
1468	ChurchBell
1469	Old Telephone-Ring
1470	Telephone-Call
1471	Telephone-Ring
1472	Telephone-Busy
1473	Telephone-Tone 1
1474	Telephone-Tone 2
1475	Telephone-Tone 3
1476	Telephone-Tone 4
1477	Telephone-Tone 5
1478	Swish Terra
1479	Noise
1480	Cricket Spectrum
1481	Noise-White
1482	Noise-VPM Mod
1483	Coin Thwack
1484	Meditation Tree
1485	G-BALL
1486	Gamelan
1487	Ac.Gtr Chord Hit 1
1488	Ac.Gtr Ghost Hit 2
1489	Ac.Gtr Ghost Hit-Slide
1490	El.Gtr Chord Hit
1491	El.Gtr-Glissando Down 1
1492	El.Gtr-Glissando Down 2
1493	El.Gtr-Glissando Down 3
1494	El.Gtr-Glissando Down 4
1495	El.Gtr-Glissando Up 1
1496	El.Gtr-Glissando Up 2
1497	El.Gtr-Glissando Up 3
1498	Vox-Wah Gtr 1
1499	Vox-Wah Gtr 2
1500	Vox-Wah Gtr 3
1501	Vox-Wah Gtr 4
1502	El.Gtr-ChordGhost Down 1
1503	El.Gtr-ChordGhost Down 2
1504	El.Gtr-ChordGhost Down 3
1505	El.Gtr-ChordGhost Down 4
1506	El.Gtr-ChordGhost Down 5
1507	El.Gtr-ChordGhost Down 6

#	Name
1508	El.Gtr-ChordGhost Up 1
1509	El.Gtr-ChordGhost Up 2
1510	El.Gtr-ChordGhost Up 3
1511	El.Gtr-ChordGhost Up 4
1512	El.Gtr-ChordGhost Up 5
1513	El.Gtr-ChordGhost Up 6
1514	El.Gtr-ChordGhost Up 7
1515	GtCutNois 1
1516	GtCutNois 2
1517	El.Gtr-Dead Note 1
1518	El.Gtr-Dead Note 2
1519	El.Gtr-Dead Note 3
1520	El.Guitar-Fret Noise 1
1521	El.Guitar-Fret Noise 2
1522	El.Guitar-Fret Noise 3
1523	El.Guitar-Fret Noise 4
1524	El.Guitar-Fret Noise 5
1525	El.Guitar PowerChord
1526	El.Gtr-DistSlideDown 1
1527	El.Gtr-DistSlideDown 2
1528	El.Gtr-DistScratchDown
1529	El.Gtr-DistMuted a
1530	El.Gtr-DistMuted b
1531	El.Gtr-DistMuted c
1532	El.Gtr-DistGhost1 a
1533	El.Gtr-DistGhost1 b
1534	El.Gtr-DistGhost2 a
1535	El.Gtr-DistGhost2 b
1536	El.Gtr-DistGhost 3 a
1537	El.Gtr-DistGhost 3 b
1538	El.Gtr-DistGhost 4 a
1539	El.Gtr-DistGhost 4 b
1540	El.Gtr-DistGhost 5 a
1541	El.Gtr-DistGhost 5 b
1542	El.Gtr-DistFretNoise 1 a
1543	El.Gtr-DistFretNoise 1 b
1544	El.Gtr-DistFretNoise 2 a
1545	El.Gtr-DistFretNoise 2 b
1546	El.Gtr-DistFretNoise 2 c
1547	El.Gtr-DistFretNoise 2 d
1548	El.Gtr-Amp.Noise
1549	Ac.Bs-Slide Up&Down 1
1550	Ac.Bs-Slide Up&Down 2
1551	Ac.Bs-Slide Up&Down 3
1552	Ac.Bs-Slide Down 1
1553	Ac.Bs-Slide Down 2
1554	Ac.Bs-Slide Down 3
1555	Ac.Bs-Slide Down 4
1556	Ac.Bs-Slide Up
1557	Ac.Bs-BumpThud 1
1558	Ac.Bs-BumpThud 2
1559	Ac.Bs-DeadNote 1
1560	Ac.Bs-DeadNote 2
1561	Ac.Bs-DeadPizz 1
1562	Ac.Bs-DeadPizz 2
1563	Ac.Bs-DeadPizz 3
1564	Ac.Bs-SlapTouch 1
1565	Ac.Bs-SlapTouch 2
1566	Ac.Bs-SlapTouch 3
1567	Ac.Bs-SlapTouch 4
1568	Ac.Bs-SlapTouch 5
1569	Ac.Bs-String Slap
1570	El.Bs-Slide Up&Down 1
1571	El.Bs-Slide Up&Down 2
1572	El.Bs-Slide Down 1
1573	El.Bs-Slide Down 2
1574	El.Bs-Slide Down 3
1575	El.Bs-Slide Down 4
1576	El.Bs-SlapGhostSlide 1
1577	El.Bs-SlapGhostSlide 2
1578	El.Bs-SlapGhostSlide 3
1579	El.Bs-Fret Noise 1
1580	El.Bs-Fret Noise 2
1581	El.Bs-Fret Noise 3
1582	El.Bs-Fret Noise 4
1583	El.Bs-SlapGhostNote 01
1584	El.Bs-SlapGhostNote 02

#	Name
1585	El.Bs-SlapGhostNote 03
1586	El.Bs-SlapGhostNote 04
1587	El.Bs-SlapGhostNote 05
1588	El.Bs-SlapGhostNote 06
1589	El.Bs-SlapGhostNote 07
1590	El.Bs-SlapGhostNote 08
1591	El.Bs-SlapGhostNote 09
1592	El.Bs-SlapGhostNote 10
1593	El.Bs-SlapGhostNote 11
1594	HarpGliss
1595	Berimbau-Wah-Lo
1596	Berimbau-Wah-Hi
1597	Berimbau-HO
1598	Berimbau-PO
1599	Berimbau-Phrase1 Loop
1600	Berimbau-Phrase1-1
1601	Berimbau-Phrase1-2
1602	Berimbau-Phrase1-3
1603	Berimbau-Phrase1-4
1604	Berimbau-Phrase2 Loop
1605	Berimbau-Phrase2-1
1606	Berimbau-Phrase2-2
1607	Berimbau-Phrase2-3
1608	Berimbau-Phrase2-4

## ROM stereo

#	Name
0000	BD-01-amb f
0001	BD-01-amb ff
0002	BD-02-amb mf
0003	BD-02-amb f
0004	BD-03-amb mf
0005	BD-03-amb f
0006	BD-04-amb mf
0007	BD-04-amb f
0008	BD-05-amb mf
0009	BD-05-amb f
0010	BD-06-dry mp
0011	BD-06-dry f
0012	BD-07-dry mf
0013	BD-07-dry f
0014	BD-08-dry mf
0015	BD-08-dry f
0016	BD-09-dry mp
0017	BD-09-dry mf
0018	SD-01-dry mp
0019	SD-01-dry f
0020	SD-02-dry mp
0021	SD-02-dry mf
0022	SD-03-dry mf
0023	SD-03-dry f
0024	SD-04-amb p
0025	SD-04-amb mp
0026	SD-04-amb mf
0027	SD-04-amb ff
0028	SD-05-dry f
0029	SD-05-dry ff
0030	SD-06-dry mf
0031	SD-06-dry f
0032	SD-08-dry f
0033	SD-08-dry ff
0034	SD-09-dry f
0035	SD-09-dry ff
0036	SD-10-dry f
0037	SD-10-dry ff
0038	SD-11-dry mf
0039	SD-11-dry ff
0040	SD-12-dry p
0041	SD-12-dry mp
0042	SD-12-dry mf
0043	SD-12-dry f
0044	SD-12-dry ff
0045	SD-12-dry fff
0046	SD-13-dry mf
0047	SD-13-dry ff
0048	SD-14-dry f
0049	SD-14-dry ff
0050	SD-15-dry mp
0051	SD-15-dry f
0052	SD-16-dry f
0053	SD-16-dry ff
0054	SD-21-dry mf
0055	SD-21-dry ff
0056	SD-24-dry f
0057	SD-24-dry ff
0058	SD-24-dry GhostRoll
0059	SD-25-dry Brush Tap mp
0060	SD-25-dry Brush Tap f
0061	SD-26-dry Brush Tap mp
0062	SD-26-dry Brush Tap mf
0063	SD-26-dry Brush Tap f
0064	SD-26-dry BrushTriplet
0065	SD-26-dry BrushSwirl a
0066	SD-26-dry BrushSwirl b
0067	SD-Roll-Open 1 a
0068	SD-Roll-Open 2
0069	SD-Roll-Closed 1 a
0070	SD-Roll-Closed 3 b
0071	SD-Sidestick 1 mf
0072	SD-Sidestick 3 mf
0073	SD-Sidestick 4 mf
0074	Tom Basic Lo mf

#	Name
0075	Tom Basic Lo f
0076	Tom Basic MidLo mf
0077	Tom Basic MidLo f
0078	Tom Basic MidHi mf
0079	Tom Basic MidHi f
0080	Tom Basic Hi mp
0081	Tom Basic Hi mf
0082	Tom Vintage Mid mf
0083	Tom Vintage Mid ff
0084	Tom Vintage Hi mf
0085	Tom Vintage Hi ff
0086	Tom Rock1-dry Lo f
0087	Tom Rock1-dry Lo ff
0088	Tom Rock1-dry Mid f
0089	Tom Rock1-dry Mid ff
0090	Tom Rock1-dry Hi f
0091	Tom Rock1-dry Hi ff
0092	Tom Rock2-dry Lo f
0093	Tom Rock2-dry Lo ff
0094	Tom Brush1 Low mf
0095	Tom Brush1 Low ff
0096	Tom Brush1 Mid mf
0097	Tom Brush1 Mid ff
0098	Tom Brush1 Hi mf
0099	Tom Brush1 Hi ff
0100	Crash Cymbal 2 f
0101	Crash Cymbal 6 mf
0102	Crash Cymbal 7 f
0103	Ride Cymbal 1 mf
0104	Ride Cymbal 1 f
0105	Ride Cymbal 3 mf
0106	Ride Cymbal 3 f
0107	Ride Cymbal 6 mf
0108	Ride Cymbal 6 f
0109	Ride Cymbal 7-Cup
0110	Ride Cymbal 8
0111	China Cymbal 1
0112	Splash Cymbal 1 ff
0113	Hand Claps 2-a
0114	Hand Claps 2-d
0115	Hand Claps 2-g

## Demo Song

### S000

#### Keep It Simple

Composed and performed by Tommy Coster

© 2008 Strawberry Blonde Music BMI all rights reserved.

For more information about Tommy Coster visit [www.myspace.com/faup](http://www.myspace.com/faup)

### S001

#### Electronista

Composed, arranged and performed by Toni Diaz

© 2008 Toni Diaz all rights reserved.

For more information about Toni Diaz visit [www.tonidiaz.co.uk](http://www.tonidiaz.co.uk)

### S002

#### Abstrakt Truth

Composed and performed by Peter Wolf

© 2008 Peter Wolf Music all rights reserved.

For more information about Peter Wolf visit [www.peterwolfmusic.com](http://www.peterwolfmusic.com)

### S003

#### The Path of Truth

Composed, arranged and performed by Jordan Rudess

Orchestra arranged by Jack Hotop

©2007 Jordan Rudess all rights reserved.

For more information about Jordan Rudess and to purchase his music visit [www.jordanrudess.com](http://www.jordanrudess.com)

### Cue List

C00: Demo Song Medley





