

Model: volca kick

MIDI Implementation Chart

Function		Transmitted	Recognized	Remarks
Basic Channel	Default	*****	1-16	Memorized
	Changed	*****	1-16	
Mode	Memorized	×	3	
	Messages	×	×	
	Altered	*****		
Note Number:	True Voice	*****	0-127	*1
		*****	0-127	*1
Velocity	Note On	×	× 9n, V=1-127	
	Note Off	×	×	
Aftertouch	Polyphonic (Key)	×	×	
	Monophonic (Channel)	×	×	
Pitch Bend		×	×	*1
Control Change	40	×	○	PULSE COLOUR *1
	41	×	○	PULSE LEVEL *1
	42	×	○	AMP ATTACK *1
	43	×	○	AMP DECAY *1
	44	×	○	DRIVE *1
	45	×	○	TONE *1
	46	×	○	RESONATOR PITCH *1
	47	×	○	RESONATOR BEND *1
	48	×	○	RESONATOR TIME *1
	49	×	○	ACCENT *1
Program Change	Variable Range	×	×	
		*****	*****	
System Exclusive		×	×	
System Common	Song Position	×	○	*2
	Song Select	×	×	
	Tune	×	×	
System Real Time	Clock Command	×	○	*2
		×	○	*2
Aux Messages	Local On/Off	×	×	*1
	All Notes Off	×	○ 123-127	
	Active Sense	×	○	
	Reset	×	×	
Notes *1: Received when global parameter MIDI RX ShortMessage is set to ON. *2: Not received when global parameter MIDI Clock src is set to Internal; received when set to Auto.				

Mode 1: OMNI ON, POLY

Mode 2: OMNI ON, MONO

○ : Yes

Mode 3: OMNI OFF, POLY

Mode 4: OMNI OFF, MONO

× : No

Consult your local Korg distributor for more information on MIDI IMPLEMENTATION.