

-- English --

Adapter for devices in the SOIC-16 package to be used with the GALEP programmer (40 pin DIL). It can also be used with most other programmers.

Please follow the pictures below to connect the adapter onto the GALEP in the right orientation, and to correctly place the programmable device into the adapter.



Devices with less than 16 pins can be placed into the adapter just as the DIL packages on the GALEP socket, but it's a little difficult to keep the exact position of the device.

-- Deutsch --

Adapter für Bauteile im SOIC-16-Gehäuse, benutzbar mit dem GALEP Programmiergerät (40 Pin DIL). Er ist auch mit den meisten anderen Programmiergeräten benutzbar.

Bitte beachten Sie die folgenden Abbildungen für den richtigen Einsatz im Galep und das richtige Einlegen des Bauteils in den Adapter.

Bauteile mit weniger als 16 Pins können eingelegt werden genau wie die DIL-Gehäuse auf dem GALEP-Sockel, aber es ist etwas schwierig, die exakte Position des Bauteils einzuhalten.



Connection-list	Pinzuordnung
-----------------	--------------

16 pin DIL **16 pin SOIC**
1-16 1-16