

-- English --

Adapter for specific MCU devices in the QFP-44 package to be used with the GALEP programmer (40 pin DIL). It can also be used with most other programmers.

For the different devices in the DIL-40 package an appropriate pin configuration at the GALEP socket will be selected. The same pin configuration is used for the QFP-44 devices. Because there are different pinouts for the QFP-44 devices, the **plug position** of the upper board at the lower board **must be correctly selected**:

Pos. 1: e.g. P87C591 (Philips)

Pos. 2: e.g. T89C51AC2, T89C51CC01 (Atmel)

-- Deutsch --

Adapter für bestimmte MCU-Bauteile im QFP-44-Gehäuse, benutzbar mit dem GALEP Programmiergerät (40 Pin DIL). Er ist auch mit den meisten anderen Programmiergeräten benutzbar.

Für die verschiedenen Bauteile im DIL-40-Gehäuse werden entsprechende Pin Konfigurationen am GALEP-Sockel ausgewählt. Dieselbe Pin-Konfiguration wird für die QFP-44-Bauteile benutzt. Da es unterschiedliche Pin-Belegungen an den QFP-44-Bauteilen gibt, **muß unbedingt die Steck-Position** der oberen Platine auf der unteren entsprechend **ausgewählt werden**:

Pos. 1: z.B. P87C591 (Philips)

Pos. 2: z.B. T89C51AC2, T89C51CC01 (Atmel)



