Instructions for BEHRINGER BCR2000 & PROPELLERHEAD® REASON Subtractor

BEHRINGER BCR2000 REASON Subtractor

This document will give you a quick overview about the BEHRINGER BCR2000 'REASON SUBTRACTOR' PRESET and how to install it.
Please consider this preset merely as a starting point and as inspiration for your own imagination.

Installation:

1. **Open and extract the ZIP file.**
   The following files are included:
   - This INSTRUCTION text document (.pdf)
   - SINGLE PRESET file (.syx)

2. **How to get the B-CONTROL PRESET from your computer into your hardware:**
   - **Connect the B-CONTROL to your computer** via USB or MIDI port (Computer MIDI OUT to B-Control MIDI IN)
   - **Select the correct USB or stand alone operating mode** on the hardware (please refer to the manual for details)
   - **Open the B-CONTROL preset file of your choice with a MIDI dump program** like "MIDI-OX" or "Send-SX" on your computer
     or use the B-CONTROL EDIT software editor, which is available free of charge at our homepage www.behringer.com
   - Don't forget to **select the correct MIDI ports** in the dump software!

Dumping a single preset

1. **Select the desired preset** (e.g. ‘bcr_Reason_Subtractor.syx’) on your MIDI dump program
2. **Send the preset** to the B-CONTROL and wait until completion
3. **Push** the **STORE** button on the hardware
4. **Select the desired destination** preset number
5. **Push** the **STORE** button again
6. **The preset is now saved** on your hardware
7. Now you can dump the next preset (repeat the steps 1 thru 5 again)

Hint: If you do not want to overwrite one of your presets in the B-CONTROL hardware, select a free destination number at step 4 (e.g. preset ‘P-32’).

#	Name	Type	Description/Application
04	'bcr_Reason_Subtractor'	Single Preset	Basic Setup for controlling Propellerhead®'s REASON 'Subtractor' * [polyphonic synthesizer]





E1 – Encoder Group 1 (Left Section, Level)

E2 – Encoder Group 2 (Wheels, Noise, Level)

E3 – Encoder Group 3 (LFO 1+2)

E4 – Encoder Group 4 (Filter 1+2, Level)

UB – Upper Button Line (Osc 1)

LB – Lower Button Line (Osc 2)

UE – Upper Encoder Line (Mod Env.)

ME – Middle Encoder Line (Filter + Amp Env.)

LE – Lower Encoder Line (Velocity)

* Software depicted is **not** included and all rights therein belong to its respective owners. Screenshots used with owner's kind permission. PROPELLERHEAD ® Reason and its respective logos are registered trademarks of their respective owners. Their use neither constitutes a claim of the trademarks by BEHRINGER® nor affiliation of the trademark owners with BEHRINGER®.
© 2004 BEHRINGER Spezielle Studiotechnik GmbH