RHYTHM PERFORMER

MIDI Implementation Chart

Date: Apr. 22, 2020

Model: TR-6S

Version 1.00

Function		Transmitted	Recognized	Remarks
Basic	Default	10	10	Memorized
Channel	Changed	1-16, OFF	1-16, OFF	
	Default	Mode 4	Mode 4	
Mode	Messages	x	x	
	Altered	**********	**********	
Note		*1	*1	
Number	: True Voice	**********		
Velocity	Note On	o 9nH v=80	o	
	Note Off	o 8nH v=00	o	
After	Key's	x	x	
Touch	Channel's	x	x	
Pitch Bend		x	x	
	2	o	x	BEAT
	9	o	o	SHUFFLE
	15	o	o	MASTER FX
	16	o	o	DELAY LEVEL
	17	o	o	DELAY TIME
	18	o	o	DELAY FEEDBACK
	19	o	o	MASTER FX CTRL
	20	o	o	BD TUNE
	23	o	o	BD DECAY
	24	o	o	BD LEVEL
	25	o	o	SD TUNE
	28	o	o	SD DECAY
	29	o	o	SD LEVEL
	46	o	o	LT TUNE
	47	o	o	LT DECAY
	48	o	o	LT LEVEL
	58	o	o	HC TUNE
	59	o	o	HC DECAY
Control	60	o	o	HC LEVEL
Change	61	o	o	CH TUNE
	62	o	o	CH DECAY
	63	o	o	CH LEVEL
	80	o	o	OH TUNE
	81	o	o	OH DECAY
	82	o	o	OH LEVEL
	70	o *2	x	FILL IN TRIG
	71	o	o	ACCENT
	91	o	o	REVERB LEVEL
	96	o	o	BD CTRL
	97	o	o	SD CTRL
	102	o	o	LT CTRL
	106	o	o	HC CTRL
	107	o	o	CH CTRL
	108	o	o	OH CTRL
Program		o	o	
Change	: True Number	0-127	0-127	
System Exclusive		x	x	
	: Song Position	x	x	
System Common	: Song Select	x	x	
	: Tune Request	x	x	
	: Clock	o	o	
System	: Start	o	o	
Real Time	: Continue	x	o	
	: Stop	o	o	
	: All Sound Off	x	x	
	: Reset All Controllers	x	x	
	: Local On/Off	x	x	
	: All Notes Off	x	x	
Aux	: Omni Mode Off	x	x	
Message	: Omni Mode On	x	x	
	: Mono Mode On	x	x	
	: Poly Mode On	x	x	
	: Active Sensing	o	o	
	: System Reset	x	x	

*1

INST	Note Number	Note Number (ALT)
BD	36	35
SD	38	40
LT	43	41
HC	39	54
CH	42	44
OH	46	58

*1 These note numbers are configurable on UTILITY:MIDI:Inst Note.

*2 Transmitted when the UTILITY:SOUND:LocalSw is SURFACE.

Mode 1: Omni On, Poly　　Mode 2: Omni On, Mono　　o: Yes

Mode 3: Omni Off, Poly　　Mode 4: Omni Off, Mono　　x: No